

Device serial number (SN) is usually consist of nine digits, or one letter + eight digits.

You can find device serial number according to below methods.


### Method 1: Find serial number on the package label or the device label.



### Method 2: Find serial number on device local menu.

#### For DVR/NVR GUI3.0:

Please enter device local Menu- Maintenance- System Info- Device Info to check device serial number.




#### For DVR/NVR GUI4.0:

Please enter device local Maintenance- System Info- Device Information to check device serial number.



### For IPC:

Please login device via web browser, enter Configuration- System- System Settings to check device serial number.




### Method 3: Find serial number with SADP tool.

1. Follow the link to download the latest version of SADP tool on your computer.

<https://www.hikvision.com/en/support/tools/hitools/TS20200826033/>

2. Use SADP software to automatically search active online devices in the same subnet with the PC running the software, and then select the required device to view its serial number.

### For IPC:



### For NVR/DVR:

iDS-9632NXI-I8/BA1620200321CCRF26311731WCVU