

# **DS-K3Y411X Series Flap Barrier**

**Quick Start Guide** 

# **Legal Information**

©2021 Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.

#### **About this Manual**

The Manual includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of this Manual at the Hikvision website ( <a href="https://www.hikvision.com/">https://www.hikvision.com/</a>).

Please use this Manual with the guidance and assistance of professionals trained in supporting the Product.

#### **Trademarks**

**HKVISION** and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions.

Other trademarks and logos mentioned are the properties of their respective owners.

#### Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS MANUAL AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.

YOU ACKNOWLEDGE THAT THE NATURE OF THE INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INFECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.

YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS. YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END-USES, INCLUDING THE

### DS-K3Y411X Series Flap Barrier Quick Start Guide

DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THIS MANUAL AND THE APPLICABLE LAW, THE LATTER PREVAILS.

#### **Data Protection**

During the use of device, personal data will be collected, stored and processed. To protect data, the development of Hikvision devices incorporates privacy by design principles. For example, for device with facial recognition features, biometrics data is stored in your device with encryption method; for fingerprint device, only fingerprint template will be saved, which is impossible to reconstruct a fingerprint image.

As data controller, you are advised to collect, store, process and transfer data in accordance with the applicable data protection laws and regulations, including without limitation, conducting security controls to safeguard personal data, such as, implementing reasonable administrative and physical security controls, conduct periodic reviews and assessments of the effectiveness of your security controls.

# **Regulatory Information**

#### **FCC Information**

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC compliance: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help FCC Conditions

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference.
- 2. This device must accept any interference received, including interference that may cause undesired operation.

### **EU Conformity Statement**



This product and - if applicable - the supplied accessories too are marked with "CE" and comply therefore with the applicable harmonized European standards listed

under the EMC Directive 2014/30/EU, RE Directive 2014/53/EU, the RoHS Directive 2011/65/EU



2012/19/EU (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: www.recyclethis.info



2006/66/EC (battery directive): This product contains a battery that cannot be disposed of as unsorted municipal waste in the European Union. See the product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point. For more information see:www.recyclethis.info

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radioexempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

#### **COMPLIANCE NOTICE**

The thermal series products might be subject to export controls in various countries or regions, including without limitation, the United States, European Union, United Kingdom and/or other member countries of the Wassenaar Arrangement. Please consult your professional legal or compliance expert or local government authorities for any necessary export license requirements if you intend to transfer, export, re-export the thermal series products between different countries.

# **Safety Instruction**

These instructions are intended to ensure that user can use the product correctly to avoid danger or property loss.

The precaution measure is divided into Dangers and Cautions:

**Dangers:** Neglecting any of the warnings may cause serious injury or death.

Cautions: Neglecting any of the cautions may cause injury or equipment damage.

$\triangle$	$\triangle$
	<b>Cautions:</b> Follow these precautions to prevent potential injury or material damage.

### ♠ Danger:

- In the use of the product, you must be in strict compliance with the electrical safety regulations of the nation and region.
- The equipment must be connected to an earthed mains socket-outlet.
- Shock hazard! Disconnect all power sources before maintenance.
- Do not touch the bare metal contacts of the inlets after the circuit breaker is turned off. Electricity still exists.
- 4 indicates hazardous live and the external wiring connected to the terminals requires installation by an instructed person.
- Keep body parts away from fan blades. Disconnect the power source during servicing.
- Keep body parts away from motors. Disconnect the power source during servicing.
- To prevent possible hearing damage, do not listen at high volume levels for long periods.
- All the electronic operation should be strictly compliance with the electrical safety regulations, fire prevention regulations and other related regulations in your local region.
- Do not connect several devices to one power adapter as adapter overload may cause over-heat or fire hazard.
- Please make sure that the power has been disconnected before you wire, install or dismantle the device.
  - If the top caps should be open and the device should be powered on for maintenance, make sure:
  - 1. Power off the fan to prevent the operator from getting injured accidentally.
  - 2. Do not touch bare high-voltage components.
  - 3. Make sure the switch's wiring sequence is correct after maintenance.
- Please make sure that the power has been disconnected before you wire, install or dismantle the
  device.
- When the product is installed on wall or ceiling, the device shall be firmly fixed.
- If smoke, odors or noise rise from the device, turn off the power at once and unplug the power cable, and then please contact the service center.

- Do not ingest battery, Chemical Burn Hazard.
  - This product contains a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
  - Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
- If the product does not work properly, please contact your dealer or the nearest service center. Never attempt to disassemble the device yourself. (We shall not assume any responsibility for problems caused by unauthorized repair or maintenance.)
- The device do not support the PoE network switch. Connecting with the PoE network switch may damage the control board.

### ♠ Cautions:

- The equipment shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the equipment.
- Ensure correct wiring of the terminals for connection to an AC mains supply.
- The equipment has been designed, when required, modified for connection to an IT power distribution system.
- + identifies the positive terminal(s) of equipment which is used with, or generates direct current.
  - + identifies the negative terminal(s) of equipment which is used with, or generates direct current.
- No naked flame sources, such as lighted candles, should be placed on the equipment.
- This equipment is suitable for mounting on concrete or other non-combustible surface only.
- Install the equipment according to the instructions in this manual.
- To prevent injury, this equipment must be securely attached to the floor/wall in accordance with the installation instructions.
- Stainless steel may be corroded in some circumstances. You need to clean and care the device by using the stainless steel cleaner. It is suggested to clean the device every month.
- Do not drop the device or subject it to physical shock, and do not expose it to high electromagnetism radiation. Avoid the equipment installation on vibrations surface or places subject to shock (ignorance can cause equipment damage).
- Do not place the device in extremely hot (refer to the specification of the device for the detailed operating temperature), cold, dusty or damp locations, and do not expose it to high electromagnetic radiation.
- The device cover for indoor use shall be kept from rain and moisture.
- Exposing the equipment to direct sun light, low ventilation or heat source such as heater or radiator is forbidden (ignorance can cause fire danger).
- Do not aim the device at the sun or extra bright places. A blooming or smear may occur otherwise (which is not a malfunction however), and affecting the endurance of sensor at the same time.
- Please use the provided glove when open up the device cover, avoid direct contact with the
  device cover, because the acidic sweat of the fingers may erode the surface coating of the device
  cover.


### DS-K3Y411X Series Flap Barrier Quick Start Guide

- Please use a soft and dry cloth when clean inside and outside surfaces of the device cover, do not use alkaline detergents.
- Please keep all wrappers after unpack them for future use. In case of any failure occurred, you
  need to return the device to the factory with the original wrapper. Transportation without the
  original wrapper may result in damage on the device and lead to additional costs.
- Improper use or replacement of the battery may result in hazard of explosion. Replace with the same or equivalent type only. Dispose of used batteries according to the instructions provided by the battery manufacturer.
- Biometric recognition products are not completely applicable to anti-spoofing environments. If you require a higher security level, use multiple authentication modes.
- Do not stay in the lane when the device is rebooting.
- RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.
- SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY.
- The instructions shall require connection of the equipment protective earthing conductor to the installation protective earthing conductor.

# **Available Models**

Product Name	Model	Description	Example
Flap Barrier	DS-K3Y411X-L1	Left Pedestal 1	DS-K3Y411X-L1/Dp60
			DS-K3Y411X-L1/Dp60- S12
	DS-K3Y411X-L2	Left Pedestal 2	DS-K3Y411X-L2/Dp60
			DS-K3Y411X-L2/Dp60- S12
	DS-K3Y411X-M1	Middle Pedestal 1	DS-K3Y411X-M1/M- Dp60
			DS-K3Y411X-M1/M- Dp60-S12
	DS-K3Y411X-M2	Middle Pedestal 2	DS-K3Y411X-M2/M- Dp60
			DS-K3Y411X-M2/M- Dp60-S12
	DS-K3Y411X-R	Right Pedestal	DS-K3Y411X-R/M-Dp60
			DS-K3Y411X-R/M-
			Dp60-S12

You can follow the picture below to select pedestals:



Scan the QR code to get User Manual of Flap Barrier. Note that mobile data charges may apply if Wi-Fi is unavailable.



# **Contents**


Chapter 1 Overview	1
1.1 Introduction	1
1.2 Main Features	1
Chapter 2 System Wiring	3
Chapter 3 Installation	6
3.1 Disassemble Pedestals	6
3.2 Install Pedestals	7
Chapter 4 General Wiring	. 10
4.1 Components Introduction	10
4.2 Wiring Electric Supply	. 12
4.3 Wire Interconnecting Cable	. 14
4.4 Face Recognition Terminal Power Supply Wiring (Optional)	16
4.5 Terminal Description	. 17
4.5.1 UART Related Terminal and Position	17
4.5.2 Main Control Board Terminal Description	20
4.5.3 Sub Control Board Terminal Description	. 21
4.5.4 BUS Terminal Description	22
4.5.5 Access Control Board Terminal Description	. 24
4.5.6 Access Control Board UART Description	. 30
4.5.7 RS-485 Wiring	. 36
4.5.8 RS-232 Wiring	. 37
4.5.9 Barrier Control Wiring	38
4.5.10 Alarm Output Wiring	39
4.5.11 Exit Button Wiring	. 39
Chapter 5 Device Settings	. 40
5.1 Pair Keyfob (Optional)	40

# DS-K3Y411X Series Flap Barrier Quick Start Guide

5.2 Initialize Device	. 41
5.3 Switch Relay Output Mode (NO/NC)	43
5.3.1 Barrier Control Relay Output Mode	. 43
5.3.2 Alarm Relay Output Mode (NO/NC)	44
Chapter 6 Activation	. 47
6.1 Activate via SADP	. 47
6.2 Activate Device via Client Software	48
Appendix A. DIP Switch Description	50
Appendix B. Event and Alarm Type	. 51
Appendix C. Table of Audio Index Related Content	. 52
Appendix D. Error Code Description	53
Appendix E. Communication Matrix and Device Command	55

# **Chapter 1 Overview**

#### 1.1 Introduction



The flap barrier with two barriers and 12 IR lights is designed to detect unauthorized entrance or exit. By adopting the flap barrier integratedly with the access control system, person should authenticate to pass through the lane via swiping IC or ID card, scanning QR code, etc. It is widely used in attractions, stadiums, construction sites, residences, etc.

#### 1.2 Main Features

- 32-bit high-speed processor
- TCP/IP network communication and network speed adaptive
   The communication data is specially encrypted to relieve the concern of privacy leak
- Permissions validation and anti-tailgating
- Remaining open/closed mode selectable
- Bidirectional (Entering/Exiting) lane
   The barrier opening and closing speed can be configured according to the visitor flow
- The barrier will be locked or stop working when people are nipped
- Anti-forced-accessing
   The barrier will be locked automatically without open-barrier signal.
- · Self-detection, Self-diagnostics, and automatic alarm
- Audible and visual alarm will be triggered when detecting intrusion, tailgating, reverse passing, and climbing over barrier
- · IP conflict detection

### DS-K3Y411X Series Flap Barrier Quick Start Guide

- · Remote control and management
- Online/offline operation
- LED indicates the entrance/exit and passing status
- Barrier is in open status when powered down; If the device is installed with supercapacitor, the barrier remains open when powered down
- Fire alarm passing
   When the fire alarm is triggered, the barrier will be open automatically for emergency
   evacuation
- Valid passing duration settings
   System will cancel the passing permission if a person does not pass through the lane within the valid passing duration
- Opens/Closes barrier according to the schedule template

# **Chapter 2 System Wiring**

The preparation before installation and general wiring.

#### **Steps**

- 1. Draw a central line on the installation surface of the left or right pedestal.
- 2. Draw other parallel lines for installing the other pedestals.



The distance between the nearest two line is L+200 mm. L represents the lane width.

3. Slot on the installation surface and dig installation holes according to the hole position diagram.





Figure 2-1 Hole Position Diagram

**4.** Bury cables. Each lane buries 1 network cable and 1 high voltage cable. For details, see the system wiring diagram below.




**Entrance** 

Figure 2-2 System Wiring Diagram (General Wiring)

# **i**Note

- The supplied interconnecting cable length is 3.75 m. If you need a longer one, you can buy a new accessory.
- The suggested inner diameter of the low voltage conduit is larger than 30 mm.
- If you want to bury both of the AC power cord and the low voltage cable at the entrance, the two cables should be in separated conduits to avoid interference.
- If more peripherals are required to connect, you should increase the conduit diameter or bury another conduit for the external cables.
- The external AC power cord should be double-insulated.
- The network cable must be CAT5e or the network cable has better performance. And the suggested network cable length should be less than 100 m.



**Entrance** 

Figure 2-3 Wire Face Recognition Terminal

# **i**Note

- The face recognition terminal installed on the left pedestal will gain power from the sub switch, which should connect to high voltage.
- The suggested inner diameter of the low voltage conduit is larger than 30 mm.
- The supplied interconnecting cable length is 3.75 m. If you need a longer one, you can extend the cable by yourself.
- If you want to bury both of the AC power cord and the low voltage cable at the entrance, the two cables should be in separated conduits to avoid interference.
- If more peripherals are required to connect, you should increase the conduit diameter or bury another conduit for the external cables.
- The external AC power cord should be double-insulated.
- The network cable must be CAT5e or the network cable has better performance. And the suggested network cable length should be less than 100 m.

# **Chapter 3 Installation**

### 3.1 Disassemble Pedestals

Before installation, you should use the key to open the pedestals.

View the pictures below to find the lock holes.




Figure 3-1 Lock Holes



Please check and avoid metal pieces dropped into the high and low voltage modules, which will cause short circuit.

### 3.2 Install Pedestals


#### **Before You Start**


Prepare for the installation tools, check the device and the accessories, and clear the installation base.

#### **Steps**




- The device should be installed on the concrete surface or other non-flammable surfaces.
- For opening the pedestal conveniently, make sure the distance between the pedestal and the wall should be more than 10 mm.





· The dimension is as follows.



- Figure 3-2 Dimension
- 1. Prepare for the installation tools, check the components, and prepare for the installation base.
- **2.** Drill holes on the ground according to the installation holes on the pedestals and insert the expansion sleeves.
- **3.** According to the entrance and exit marks on the pedestals, move the pedestals to the corresponded positions.


Note

Make sure the installation holes on the pedestals and the base are aligned with each other.

4. Secure the pedestals with expansion bolts.

**i** Note

- The suggested expansion bolt's size is M12\*150. You can change or transform the expansion bolt according to your actual needs. But make sure that do not drill through the floor. If the floor is too soft to install, it is suggested to apply the construction adhesive to strengthen.
- Do not immerse the pedestal in the water. In special circumstances, the immersed height should be no more than 150 mm.
- The installation footprint is as follows:



**Figure 3-3 Installation Footprint** 

**5.** After installation, assemble the components and screws back to the pedestal in reverse order (except for protective sheets).

# **Chapter 4 General Wiring**



- After maintenance, you should close the water-proof cover over the high/low voltage module.
- When you should maintain or disassemble the high voltage modules, you should remove the
  entire high voltage modules and maintain it outside the turnstile. You should unplug the cables
  that connected to the peripherals before maintenance to avoid destroy of the device.

### 4.1 Components Introduction

By default, basic components of the turnstile are connected well. The pedestals can communicate by wiring the interconnecting cables. And the turnstile supports wiring the AC electric supply for the whole system's power supply.

The voltage fluctuation of the electric supply is between 100 VAC and 240 VAC, 50 to 60 Hz.

The picture displayed below describes each component's position on the turnstile.

Note

The diagram is for reference only.






Figure 4-1 Components Diagram 1



The reinstalled supercapacitor needs to be powered on for at least 3 minutes before it can work normally.

The picture displayed below describes the IR adapter and the IR sending/receiving board and their corresponding number on the pedestal.





12 IR Sending/Receiving Modules

6 IR Sending/Receiving Module


Figure 4-2 Components 2



If the turnstile contains two lanes, standing at the entrance position, the IR boards on the left pedestal are the IR sending boards. The IR boards on the right pedestal are the IR receiving boards. The IR boards on the left side of the middle pedestal are the IR receiving boards, while the IR boards on the right side of the middle pedestal are the IR sending boards.

## 4.2 Wiring Electric Supply

Wire electric supply with the switch in the pedestal. Terminal L and terminal N are on the switch, while terminal PE should connect to a ground wire (yellow and green wire).



# Note

- The cable bare part should be no more than 8 mm. It is suggested that you can immerse the bare part into the liquid tin. If possible, wear an insulation cap at the end of the bare cable. Make sure there's no bare copper or cable after the wiring.
- The Terminal L and the Terminal N cannot be wired reversely. Do not wire the input and output terminal reversely.
- To avoid people injury and device damage, when testing, the ground resistance of the equipotential points should not be larger than 2  $\Omega_\circ$
- Use the device in conjunction with an UPS.

## 4.3 Wire Interconnecting Cable

You should use interconnecting cables to connect the main lane board and the sub lane board for components communication.



The right/middle pedestal contains an interconnecting cable, including one network cable (5.5 m) and one 2-core cable.

The picture displayed below describes the cable hole's position on the pedestals.




Figure 4-3 Cable Hole of Interconnecting Cable

If the slotting position is at the middle of the pedestal, you can wire the cable through the pedestal, and the side cable hole. For details about the wiring instructions, see the picture below:





Figure 4-4 Wiring Method of Slotting in Middle

Follow the instructions below to connect the interconnecting cable.



**Figure 4-5 Connect Interconnecting Cable** 

### 4.4 Face Recognition Terminal Power Supply Wiring (Optional)

If connect to face recognition terminals, the face recognition terminals of right pedestal and middle pedestal (entrance) will power supplied by 12 V terminal on left side of the pedestal.

The face recognition terminal of left pedestal and middle pedestal (exit) will power supplied by 12 V terminal of the power adaptor of the right pedestal. The sub lane control board will power supplied by the power adaptor.

For details about the wiring, see the picture below:




Figure 4-6 Face Recognition Terminal Power Supply Wiring

## 4.5 Terminal Description

The lane controller contains main lane controller and sub lane controller, which controls the IR beams, motor, and other components' work.

#### 4.5.1 UART Related Terminal and Position

View the UART position on the lane control board and the access control board. You can also view the UART related terminals and DIP switch information.

The reserved UART terminal positions in the turnstile and their corresponded UART No. are as follows:

Note

The diagram is for reference only.




Figure 4-7 Interface and Corresponded UART No.

The UART related terminals are on the access control board and BUS of the lane control board. You can switch between the RS-232 and the RS-485 communication modes via DIP switch.

The UART and the related DIP switch information is as follows:




Figure 4-8 UART No. Description

Table 4-1 UART Related Position/Terminals/DIP Switch Introduction


UART No.	Related Terminals	Terminal Position	DIP Switch No.	Function
UART1  i Note	485A/232A	BUS of Main Lane Control Board	1 to 3	ON: UART1 is RS- 232A Interface
External card reader is			4 to 6	ON: UART1 is RS- 485A Interface
recommended to			7	Reserved
access.			8	Reserved
UART3	485C+/232C+	Access Control Board	1 to 3	ON: UART3 is RS- 232C Interface

UART No.	Related Terminals	<b>Terminal Position</b>	DIP Switch No.	Function
Note			4 to 6	ON: UART3 is RS- 485C Interface
External card reader is	485C-/232C-		7	Reserved
recommended to access.			8	Reserved
UART5  Note	485E+/232E+	BUS of Sub Lane Control Board	1 to 3	ON: UART3 is RS- 232E Interface
External card reader is			4 to 6	ON: UART3 is RS- 485E Interface
recommended to	485E-/232E-		7	Reserved
access.			8	Reserved
UART6  Note	485F+/232F+	BUS of Sub Lane Control Board	1 to 3	ON: UART3 is RS- 232F Interface
Face recognition terminal is	erecognition		4 to 6	ON: UART3 is RS- 485F Interface
	485F-/232F-		7	Reserved
			8	Reserved
UART7	232G+/232G-	Access Control Board	/	/
UART8	232H+/232H-	Access Control Board	/	/

## 4.5.2 Main Control Board Terminal Description

The main lane control board contains power input, BUS interface, interconnecting interface, supercapacitor interface, barrier position control board interface and motor drive interface.

The picture displayed below is the main control board diagram.




**Figure 4-9 Main Control Board Terminal** 

### 4.5.3 Sub Control Board Terminal Description

The sub lane control board contains power input, BUS interface, interconnecting interface, supercapacitor interface, barrier position control board interface and motor drive interface.

The picture displayed below is the sub control board diagram.



**Figure 4-10 Sub Control Board Terminal** 

### 4.5.4 BUS Terminal Description

You can connect the lane controller light board, fan, TAMPER, lane control board, card reader, face recognition terminal, QR code scanner, etc. via the BUS terminal.



Part of the wiring has been completed at the factory, please connect according to actual needs.

**Table 4-2 BUS Terminal in Main Lane Controller** 

Terminal Name	Description
Lane Controller Light Board 1	Connects lane controller light board 1
Lane Controller Light Board 2	Connects lane controller light board 2
Fan	Connects fan
TAMPER1	Connects TAMPER1
TAMPER2	Connects TAMPER2
Lane Controller Board	Connects main lane controller board
5 V	Reserved
IR Adaptor	Connects IR adaptor

Terminal Name	Description
UART 1	Red 12 V: connects 12 VDC power supply terminal
External card reader or face recognition terminal is recommended to access. If both should be connected, you should configure the address code for both of the devices.	Yellow 485A/232A+: card reader RS-485A+/RS-232A+ access terminal
	Blue 485A/232A-: card reader RS-485A-/RS-232A- access terminal
	Black GND: grounding

**Table 4-3 BUS Terminal in Sub Lane Controller (Left Pedestal)** 


Terminal Name	Description
Lane Controller Light Board 1	Connects lane controller light board 1
Lane Controller Light Board 2	Connects lane controller light board 2
Fan	Connects fan
TAMPER1	Connects TAMPER1
TAMPER2	Connects TAMPER2
Lane Controller Board	Connect sub lane controller board
5 V	Reserved
IR Adaptor	Connects IR adaptor
UART 5	Red 12 V: connects 12 VDC power supply terminal
Note External card reader is recommended to access.	Yellow 485E/232E+: card reader RS-485E+/RS-232E+ access terminal
	Blue 485E/232E-: card reader RS-485E-/RS-232E- access terminal
	Black GND: grounding
UART 6	Red 12 V: connects 12 VDC power supply terminal
Note External face recognition terminal is recommended to access.	Yellow 485F/232F+: card reader RS-485F+/RS-232F+ access terminal
	Blue 485F/232F-: card reader RS-485F-/RS-232F- access terminal
	Black GND: grounding

**Table 4-4 BUS Terminal in Sub Lane Controller (Middle Pedestal)** 

Terminal Name	Description
Lane Controller Light Board 1	Connects lane controller light board 1
Lane Controller Light Board 2	Connects lane controller light board 2
Lane Controller Board	Connect sub lane controller board
5 V	Reserved
IR Adaptor	Connects IR adaptor
UART 5	Red 12 V: connects 12 VDC power supply terminal
Note External card reader is recommended to access.	Yellow 485E/232E+: card reader RS-485E+/RS-232E+ access terminal
	Blue 485E/232E-: card reader RS-485E-/RS-232E- access terminal
	Black GND: grounding
UART 6	Red 12 V: connects 12 VDC power supply terminal
Note External face recognition terminal is recommended to access.	Yellow 485F/232F+: card reader RS-485F+/RS-232F+ access terminal
	Blue 485F/232F-: card reader RS-485F-/RS-232F- access terminal
	Black GND: grounding

### 4.5.5 Access Control Board Terminal Description

Access control board is mainly used for authority identification in places with high security levels such as public security or judicial place, external device accessing, and communication with the upper platform and lane controller.



**Figure 4-11 Access Control Board Terminal** 

**Table 4-5 Access Control Board Terminal Description** 

Access Control Board Terminal Description				
Power Output 1	+12 V	12 VDC Power Output	/	
	G	Grounding		
RS-485 Interface	RS-485 C+	Connect to Card Reader RS485+	• RS-485 card	
	RS-485 C-	Connect to Card Reader RS485-	reader ID factory DIP is	
	GND	Grounding	1 and 3. 1 represents the passage entrance, and 3 represents	

Access Control Board Terminal Description			
	Access Cor	ntrol Board Terminal Description	the passage exit. UART 1 in the main control board corresponds to the entrance card reader, and UART 5 in the main control board corresponds to the exit card reader.  If the user has configured a guest card, the exit needs to be connected to two card readers, one with the DIP 4 and the other with the DIP 3. The card reader 3 and the card receiver are used together, the ordinary user swipes the card on the card reader 4, and the guest user swipes the card on the card on the

	Access Control Board Terminal Description				
			card reader 3. • This is the RS-485 interface, which cannot be switched by dialing.		
Power Output 2	5 V	5 VDC Power Output	/		
	G	Grounding			
RS-232 Interface	G	Grounding	• This is the		
	RS-232 G-	Connect to RS-232G-	RS-232 interface,		
	RS-232 G+	Connect to Card Reader RS-232G+	which cannot		
	G	Grounding	be switched by dialing.		
	RS-232 H-	Connect to RS-232H-	• The RS-232		
	RS-232 H+	Connect to Card Reader RS-232H+	interface's QR code transmission database should no more than 64 bit.  By default, there is no QR code scanner on the left pedestal of the device entrance. If you need to connect an additional QR code scanner, you need to connect it		

	Access Control Board Terminal Description			
			through the RS-232 interface here. After the cable is connected to the RS-232 interface, it passes through the embedded pipe and connects with the QR code on the left.	
Power Input	+24 V	24 VDC Power Input	/	
	GND	Grounding		
Event Input	C1	Event Alarm Input 1	The event	
	G	Grounding	alarm input hardware	
	C2	Event Alarm Input 2	interface is remaining open, and only supports access to remaining open signals, which can be linked to the host buzzer output, card reader buzzer output, alarm relay output, door open relay output, etc.	
Exit Button	B2	Door 2 Signal Input	/	
	G	Grounding		

Access Control Board Terminal Description				
	B1	Door 1 Signal Input		
Door Lock (Relay)	D1- D1+	Door 1 Relay Output (Dry Contact)	If necessary, the door lock relay can be used to control the third-party barrier switch. D1 controls the door opening for ordinary entrance, and D2 controls the door opening for ordinary exit.	
	D2- D2+	Door 2 Relay Output (Dry Contact)	If necessary, the door lock relay can be used to control the third-party barrier switch. D1 controls the door opening for ordinary entrance, and D2 controls the door opening for ordinary exit.	
Alarm Output	NO/NC1 COM1	Alarm Output Relay 1 (Dry Contact)	The alarm output supports switch output.	
	NO/NC2 COM2	Alarm Output Relay 2 (Dry Contact)	The alarm output supports switch output.	
Loudspeaker	/	Connect to loudspeaker	/	

## DS-K3Y411X Series Flap Barrier Quick Start Guide

Access Control Board Terminal Description					
Network Interface LAN Network Accessing /					
Fire Input	ire Input XF Fire input /				
	G	Grounding			



- You can swtich between RS-485 and RS-232 via the DIP switch on the access control board. For details about DIP switch and switching method, see *Access Control Board UART Description*.
- For details about DIP switch operation, see **DIP Switch Description** .

## 4.5.6 Access Control Board UART Description

You can set the device mode, switch the communication mode of the corresponding UART, and initialize the device through the DIP on the access control board.

The DIP switch of the access control board is shown in the figure below:

Note
The diagram is for reference only.




Figure 4-12 DIP Switch on Access Control Board

DIP A can set the device mode, DIP 2 to 5 can set the RS-485/RS-232 interface, and DIP B can also be used to initialize the device.

The UART corresponding to the DIP Switch is shown in the figure below:




Figure 4-13 UART No. Description

The corresponding functions of different DIP Switch are described as follows:

No.	Device Mode	UART No.	Function	Binary Value
DIP A	1 to 2: Work Mode	/	Normal Mode	ON 1 2 3 4 5 6 7 8
			Test Mode	ON

No.	Device Mode	UART No.	Function	Binary Value
	3: Memory Mode		Enable Memory Mode	ON
			Disable Memory Mode	ON
	4: Keyfob Paring Mode		Enable Keyfob Paring Mode	ON
			Disable Keyfob Paring Mode	ON
	5 to 8: Passing Mode		Controlled Bi- direction	ON
			Controlled Entrance and Prohibit Exit	ON
			Controlled Entrance and Free Exit	ON 1 2 3 4 5 6 7 8
			Free Bi-direction	ON
			Free Entrance and Controlled Exit	ON 1 2 3 4 5 6 7 8
			Free Entrance and Prohibit Exit	ON
			Prohibited Bi- direction	ON

No.	Device Mode	UART No.	Function	Binary Value
			Prohibit Entrance and Controlled Exit	ON
			Prohibit Entrance and Free Exit	ON
DIP B	1 to 3	UART 5	ON: UART 5 is RS- 232E Interface	/
	4 to 6		ON: UART 5 is RS- 485E Interface	/
	7	/	Reserved	/
	8	/	Default is OFF. You can dial to ON for initial operation	/
DIP C	1 to 3	UART 6	ON: UART 6 is RS- 232F Interface	/
	4 to 6		ON: UART 6 is RS- 485F Interface	/
	7	/	Reserved	/
	8	/	Reserved	/
DIP D	1 to 3	UART 1	ON: UART 1 is RS- 232A Interface	/
	4 to 6		ON: UART 1 is RS- 485A Interface	/
	7	/	Reserved	/
	8	/	Reserved	/
DIP E	1 to 3	UART 3	ON: UART 3 is RS- 232C Interface	/
	4 to 6		ON: UART 3 is RS- 485C Interface	/
	7	/	Reserved	/
	8	/	Reserved	/

# **i**Note

For proper communication between turnstile and peripherals, DIP Switch No. 1 to 3, 4 to 6, 7, and 8 of DIP B, DIP C, DIP D, and DIP E cannot be turned ON at the same time.

The reserved UART terminal positions in the turnstile and their corresponded UART No. are as follows:

 $\bigcap$ iNote

The diagram is for reference only.





Figure 4-14 Interface and Corresponded UART No.

## 4.5.7 RS-485 Wiring




# iNote

- The RS-485 interfaces are for connecting ID card reader, IC card reader, card reader, card recycler, text screen, and face recognition terminal. Take the wiring of RS-485 card reader as an example.
- For details about text screen, see *Configuring Screen Parameters* in *User Manual of iVMS-4200 AC Client Software*.

## 4.5.8 RS-232 Wiring



- Access control board of pedestal can connect QR code scanner, card recycler, text screen and face recognition terminal via RS-232 interface.
- For details about text screen, see *Configuring Screen Parameters* in *User Manual of iVMS-4200 AC Client Software*.
- Take the wiring of text screen as an example.




## 4.5.9 Barrier Control Wiring

By default, the barrier has connected with the access control board. The lane control board can control the barrier status. If possible, the device can connect with a third party lane control board to control the third party barriers. Interface D1 controls barrier opening for entrance, while interface D2 controls barrier opening for exit.




Use the jumper cap to switch the relay status. For details, see **Barrier Control Relay Output Mode** .


## **Entering Wiring**



## **Exiting Wiring**



# 4.5.10 Alarm Output Wiring



Note

For details about changing the relay output status via the jumper cap, see  $\underline{\textit{Alarm Relay Output}}$   $\underline{\textit{Mode (NO/NC)}}$ .

# 4.5.11 Exit Button Wiring

You can view the exit button wiring diagram.




Figure 4-15 Exit Button Wiring

# **Chapter 5 Device Settings**

After installation and wiring completed, the turnstile will learn the open and closed position automatically.

After the learning, the turnstile is in the normal mode. You can also set the turnstile to test mode, passing mode and memory mode, pair the keyfob, initialize the hardware, switching between RS-485 communication mode and RS-232 communication mode, and view relay output NO/NC diagram by setting the DIP switch on the access control board.

- · Normal Mode: The device will work properly.
- Test Mode: Test mode is the same as the normal mode except that the device cannot report the alarm, the event, or the people counting information to the center.
- Passing Mode: There are 9 passing modes, including controlled bi-direction, controlled entrance and prohibited exit, controlled entrance and free exit, free bi-direction, free entrance and controlled exit, free entrance and prohibited exit, prohibited bi-direction, prohibited entrance and free exit.
- Memory Mode: By default, the memory mode is enabled. When multiple cards are presented
  and authenticated, it allows multiple persons passing through the lane. When it counts the
  passing people number is equal to the card presented times, or no person passing through the
  lane after the last person passing, the barriers will be closed.



You can also set the DIP switch on the access control board to control the entrance and exit controlling type, keyfob pairing, etc. For details about the DIP switch value, see <u>Access Control</u> <u>Board UART Description</u>.

# 5.1 Pair Keyfob (Optional)

Pair the remote control to the device through DIP switch to open/close the barrier remotely.

#### **Before You Start**

Ask our technique supports or sales and purchase the keyfob.

#### **Steps**



- Up to 32 keyfobs can be added to the turnstile.
- You can set the keyfob to one-to-one mode or one-to-many mode via the DIP switch on the keyfob. Here takes one-to-one mode as an example to explain. For one-to-many mode, see the keyfob user manual.

#### **One-to-One Mode**

By default, the keyfob is in one-to-one mode. The keyfob's DIP switch is towards 1 (OFF). The keyfob can control only one turnstile.

#### **One-to-Many Mode**

The keyfob's DIP switch is ON. In this mode, the keyfob can control multiple turnstiles.

- 1. Power off the turnstile.
- 2. Set the No.4 switch of the DIP Switch on the access control board to the ON side.



- 3. Power on the turnstile and it will enter the keyfob pairing mode.
- **4.** Hold the **Close** button for more than 10 seconds. Or pair turnstile and keyfob in the client software, see *Manage Keyfob User* of the user manual for more details.

The keyfob's indicator of the will flash twice if the pairing is completed.

5. Set the No.4 switch to OFF, and reboot the turnstile to take effect.



- Only one turnstile can pair the keyfob. If multiple turnstiles are in the pairing mode, the keyfob will select only one of them to pair.
- For details about DIP switch value and meaning, see Access Control Board UART Description .
- 6. Optional: Go to System → User → Keyfob User on the remote control page of the client software to delete the keyfob.

#### 5.2 Initialize Device

#### **Steps**

1. Set the No.8 switch of the DIP 2 Switch on the access control board to the ON side.




Figure 5-1 Initialization Jumper Cap

- 2. Disconnect the power and reboot the device.
- **3.** When the beep stopped, set the No.8 switch to the OFF side, and reboot the turnstile to take effect.
- **4.** Disconnect the power and power on the device again.



The initialization of the device will restore all the parameters to the default setting and all the device events are deleted.



Make sure no persons are in the lane when powering on the device.

# 5.3 Switch Relay Output Mode (NO/NC)

## 5.3.1 Barrier Control Relay Output Mode

The jumper cap of the barrier control relay on the access control board is as below:




Figure 5-2 Jumper Cap Location (Barrier Control Relay Output Mode)

The jumper cap position of barrier opening (NO) is as below:





Figure 5-3 Barrier Opening (NO)

The jumper cap position of barrier closing (NC) is as below:





Figure 5-4 Barrier Closing (NC)



The default status is NC.

# 5.3.2 Alarm Relay Output Mode (NO/NC)

The jumper cap of the alarm relay on the access control board is as below:




Figure 5-5 Jumper Cap Location (Alarm Relay Output Mode)

The jumper cap position of alarm opening (NO) is as below:




Figure 5-6 Alarm Opening (NO)

The jumper cap position of alarm closing (NC) is as below:





Figure 5-7 Alarm Closing (NC)

Note

The default status is NO.

# **Chapter 6 Activation**

You should activate the device before the first login. After powering on the device, the system will switch to Device Activation page.

Activation via the device, SADP tool and the client software are supported.

The default values of the device are as follows:

• The default IP address: 192.0.0.64

The default port No.: 8000The default user name: admin

### 6.1 Activate via SADP

SADP is a tool to detect, activate and modify the IP address of the device over the LAN.

#### **Before You Start**

- Get the SADP software from the supplied disk or the official website <a href="http://www.hikvision.com/en/">http://www.hikvision.com/en/</a>, and install the SADP according to the prompts.
- The device and the PC that runs the SADP tool should be within the same subnet.

The following steps show how to activate a device and modify its IP address. For batch activation and IP addresses modification, refer to *User Manual of SADP* for details.

#### **Steps**

- 1. Run the SADP software and search the online devices.
- 2. Find and select your device in online device list.
- 3. Input new password (admin password) and confirm the password.




STRONG PASSWORD RECOMMENDED-We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.



Characters containing admin and nimda are not supported to be set as activation password.

4. Click Activate to start activation.



Status of the device becomes Active after successful activation.

- 5. Modify IP address of the device.
  - 1) Select the device.
  - 2) Change the device IP address to the same subnet as your computer by either modifying the IP address manually or checking **Enable DHCP**.
  - 3) Input the admin password and click **Modify** to activate your IP address modification.

### **6.2 Activate Device via Client Software**

For some devices, you are required to create the password to activate them before they can be added to the software and work properly.

#### **Steps**



This function should be supported by the device.

- 1. Enter the Device Management page.
- 2. Click on the right of **Device Management** and select **Device**.
- 3. Click Online Device to show the online device area.

The searched online devices are displayed in the list.

- 4. Check the device status (shown on **Security Level** column) and select an inactive device.
- 5. Click Activate to open the Activation dialog.
- **6.** Create a password in the password field, and confirm the password.

## DS-K3Y411X Series Flap Barrier Quick Start Guide

# **!** Caution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you change your password regularly, especially in the high security system, changing the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.



Characters containing admin and nimda are not supported to be set as activation password.

7. Click OK to activate the device.

# **Appendix A. DIP Switch Description**

The DIP switch is on the main lane control board. The left side to the right side is from the low bit to the high bit.



When the switch is towards ON, it means the switch is enabled, otherwise, the switch is off. If you set the DIP switch like the figure displayed below, its binary value is 00001100, and its decimal value is 12.



# **Appendix B. Event and Alarm Type**

Event	Alarm Type
Tailgating	Visual and Audible
Reverse Passing	Visual and Audible
Force Accessing	None
Climb over Barrier	Visual and Audible
Overstay	Visual and Audible
Passing Timeout	None
Intrusion	Visual and Audible
Free Passing Authentication Failed	Visual
Barrier Obstructed	None

# **Appendix C. Table of Audio Index Related Content**

Index	Content
1	Authenticated.
2	Card No. does not exist.
3	Card No. and fingerprint mismatch.
4	Climbing over the barrier.
5	Reverse passing.
6	Passing timeout.
7	Intrusion.
8	Force accessing.
9	Tailgating.
10	No permissions.
11	Authentication time out.
12	Authentication failed.
13	Expired card.
14	Stay out of time.

# **Appendix D. Error Code Description**

The swing barrier will display the error code on the seven-segment display if error occurred. Refer to the table below to find the description of each number.

Error Reason	Code	Error Reason	Code
Normal Working	00	Lower Fifth IR Beam Triggered	21
First IR Beam Triggered	01	Lower Sixth IR Beam Triggered	22
Second IR Beam Triggered	02	Lower Seventh IR Beam Triggered	23
Third IR Beam Triggered	03	Lower Eighth IR Beam Triggered	24
Fourth IR Beam Triggered	04	Lower Ninth IR Beam Triggered	25
Fifth IR Beam Triggered	05	Lower Tenth IR Beam Triggered	26
Sixth IR Beam Triggered	06	Lower Eleventh IR Beam Triggered	27
Seventh IR Beam Triggered	07	Lower Twelfth IR Beam Triggered	28
Eighth IR Beam Triggered	08	Lower Thirteenth IR Beam Triggered	29
Ninth IR Beam Triggered	09	Lower Fourteenth IR Beam Triggered	30
IR Beam Triggered	10	Lower Fifteenth IR Beam Triggered	31
Eleventh IR Beam Triggered	11	Lower Sixteenth IR Beam Triggered	32
Twelfth IR Beam Triggered	12	Light Board Offline (Entrance)	49
Thirteenth IR Beam Triggered	13	Light Board Offline (Exit)	50
Fourteenth IR Beam Triggered	14	IR Adapter Offline (Up)	51
Fifteenth IR Beam Triggered	15	IR Adapter Offline (Low)	52
Sixteenth IR Beam Triggered	16	CAN Bus Exception	53
Lower First IR Beam Triggered	17	Not Studying	54

# DS-K3Y411X Series Flap Barrier Quick Start Guide

Error Reason	Code	Error Reason	Code
Lower Second IR Beam Triggered	18	Obstruction	55
Lower Third IR Beam Triggered	19	Exceeding Studying Range	56
Lower Fourth IR Beam Triggered	20	Motor Exception	57

# Appendix E. Communication Matrix and Device Command

#### **Communication Matrix**

Scan the following QR code to get the device communication matrix. Note that the matrix contains all communication ports of Hikvision access control and video intercom devices.



Figure E-1 QR Code of Communication Matrix

#### **Device Command**

Scan the following QR code to get the device common serial port commands. Note that the command list contains all commonly used serial ports commands for all Hikvision access control and video intercom devices.



**Figure E-2 Device Command** 

