



Hik-ProConnect ARC Function Installation Guide-Sentinel

Content

1 SOFTWARE REQUIREMENT.....1-1

2 INSTALLATION2-1

■ HIK-PROCONNECT SETTING2-1

2.1.1 Enable ARC Service and Add device.....2-1

■ SENTINEL PLATFORM SETTING..... **ERROR! BOOKMARK NOT DEFINED.**

2.2.1 Create a site**Error! Bookmark not defined.**

2.2.2 Add transmitter to the Site**Error! Bookmark not defined.**

1 Software Requirement


1. Sentinel platform
2. Hik-ProConnect Account with ARC service subscribed.


2 Installation

Hik-ProConnect Setting

2.1.1 Enable ARC Service and Add device

1. Log on The Hik-ProConnect Portal-Site-ARC service and select your arc company as below.





Select ARC for Authorization

Search

Frequently Used Alarm Receiving Centers

Authorize Cancel

2. If you find your ARC company is not listed, please ask your ARC company to register in below link and submit, Hikvision will offer the “ARC ID and key” to your ARC company and then add it to the list (it may take 1-2 days).

<https://www.surveymonkey.co.uk/r/H72878M>

Or ARC company can send the enquiry to Hik-ProconnectUK@hikvision.com

And ARC company should talk to Sentinel regarding how to use the ID and Key in the Sentinel software

3. Select the device want to add to sentinel in the same page, and end user will receive an authorization notification in hik-connect app.

