Deleting a Hik-Connect Device
## via Internet Explorer Using a PC

GREAT PRODUCTS. GREATER PARTNERSHIPS.™

HIKVISION®

Access Your Account

- Type Hik-Connect.Com into browser location bar [1]

- On main page, enter your User Name or Email or Mobile Phone Number and Password [2]

- Click LOGIN[3]

Access the Device Management Tab

- In the Device Management Tab identify the device to be deleted [4]

- Click on the "Trash Can" (Delete) icon [5]

- In the pop-up click OK [6]

- Deletion will be confirmed [7]