

Title:	DS-PWA32 How to Reset AX Hub	Version:	v1.0	Date:	10/30/2018
Product:	AX Series Wireless Security Control Panel			Page:	1 of 2

Preparation

1. AX Series Wireless Security Control Panel——AX Hub

How to Reset AX Hub

1. Reset AX Hub

- 1) Power up the AX Hub, wait about 50 seconds.
- 2) After you hear the first system voice, hold down **Reset Button** of Hub.



- 3) Hold down about 10 seconds, then wait **System voice disappear**.
- 4) Wait hub starting, the device will be inactive status.



Title:	DS-PWA32 How to Reset AX Hub	Version:	v1.0	Date:	10/30/2018
Product:	AX Series Wireless Security Control Panel			Page:	2 of 2

First Choice for Security Professionals HIKVISION Technical Support