

Title:	How to Switch P/N format for Analog Cameras	Version:	v1.0	Date:	02/26/2020
Product:	Cameras, DVR	Page:	1 of 6		


Preparation

1. In this case, camera model is DS-2CE10DF0T-PF
2. DVR model is DS-7208HTHI-K2 4.21.000 build190722 ; DS-7108HGHI-F1 3.4.891 build190121

How to switch P/N Format for Analog Cameras

1. Operation on DVR web

- 1) Press 90 preset to change PAL(25fps) to NTSL(30fps)
After this operation, you will see 1080P30 on the screen.




- 2) Press 91 preset to change NTSL to PAL
After this operation, you will see 1080P25 on the screen.




Title:	How to Switch P/N format for Analog Cameras	Version:	v1.0	Date:	02/26/2020
Product:	Cameras, DVR			Page:	2 of 6

3) Operation on Camera OSD menu

You can call out camera OSD menu through pressing “Menu” or “Iris+”,



Secondly, press “Left” or “Right” to change from 2M30(NTSL) to 2M25(PAL), after that, “SAVE&EXIT” and press “Iris+” for confirm.




4) Besides TVI signal, you should switch the format through Camera OSD menu in AHD CVI and CVBS rather than call presets.


Title:	How to Switch P/N format for Analog Cameras	Version:	v1.0	Date:	02/26/2020
Product:	Cameras, DVR			Page:	3 of 6

2. Operation on DVR local GUI

1) Press 90 preset to change PAL to NTSL, and call 91 preset to change NTSL to PAL.




Title:	How to Switch P/N format for Analog Cameras	Version:	v1.0	Date:	02/26/2020
Product:	Cameras, DVR			Page:	4 of 6



2) Operation on Camera OSD menu


Just like operation on DVR web. You can call out camera OSD menu through pressing “Menu” or “Iris+”.

Secondly, press “Left” or “Right” to change from 2M30(NTSL) to 2M25(PAL), after that, “SAVE&EXIT” and press “Iris+” for confirm.



Title:	How to Switch P/N format for Analog Cameras	Version:	v1.0	Date:	02/26/2020
Product:	Cameras, DVR			Page:	5 of 6

- 3) In GUI3.0 menu, call out PTZ Control and select Configuration, as show bellow. Then call 90 preset to change PAL to NTSL, or call 91 preset to change NTSL to PAL.





Title:	How to Switch P/N format for Analog Cameras	Version:	v1.0	Date:	02/26/2020
Product:	Cameras, DVR			Page:	6 of 6

- 4) Besides TVI signal, you should switch the format through Camera OSD menu in AHD、CVI and CVBS rather than call presets.

First Choice for Security Professionals
HIKVISION Technical Support