

Title:	How to Enable ONVIF Protocol on IP Camera	Version:	v1.0	Date:	25/03/2022
Product:	IP Camera			Page:	1 of 4

Comment activer le protocole ONVIF sur une caméra IP ?

1. Allez dans [configuration]-[Réseau]-[Paramètres avancés]-[Protocole d'intégration], cochez la case de l'activation de ONVIF.

The screenshot shows the Hikvision web interface with the 'Configuration' tab selected. Under 'Integration Protocol', the 'Enable ONVIF' checkbox is checked and highlighted with a red box. The 'ONVIF Version' is set to 17.12. Below this, there is a 'User List' table with columns 'No.', 'User Name', and 'Level'. The table is currently empty. At the bottom, there is a 'Save' button.

No.	User Name	Level
-----	-----------	-------

Title:	How to Enable ONVIF Protocol on IP Camera	Version:	v1.0	Date:	25/03/2022
Product:	IP Camera			Page:	2 of 4

2. Cliquez sur Add pour créer un utilisateur ONVIF

The screenshot shows the Hikvision web interface with the 'Configuration' tab selected. The 'Integration Protocol' sub-tab is active, showing options for enabling ONVIF. The 'ONVIF Version' is set to 17.12. Below this, there is a 'User List' table with columns for 'No.', 'User Name', and 'Level'. The 'Add' button is highlighted with a red box. At the bottom, there is a 'Save' button.

Configuration

SNMP FTP Email Platform Access HTTPS QoS 802.1x **Integration Protocol** Network Service

☐ Enable Hikvision-CGI

Hikvision-CGI Authentica... digest

☒ Enable ONVIF

ONVIF Version 17.12

User List


No.	User Name	Level
-----	-----------	-------

Add Modify Delete

Save

Title:	How to Enable ONVIF Protocol on IP Camera	Version:	v1.0	Date:	25/03/2022
Product:	IP Camera			Page:	3 of 4

3. Créez un utilisateur ONVIF et utilisez ce nom d'utilisateur et ce mot de passe pour vous connecter à la caméra via le protocole ONVIF.



Note :

1. Seule la version du micrologiciel de la caméra IP est V5.5.0 ou supérieure.
2. Le protocole ONVIF de la version du firmware de la caméra IP inférieure à V5.5.0 est activé par défaut, le nom d'utilisateur et le mot de passe ONVIF sont les mêmes que le nom d'utilisateur et le mot de passe de la caméra.

Title:	How to Enable ONVIF Protocol on IP Camera	Version:	v1.0	Date:	25/03/2022
Product:	IP Camera			Page:	4 of 4

Premier choix des professionnels de la sécurité Support technique **HIKVISION**