

Quick Start Guide



Before you start:

Make sure the wall/ceiling is strong enough to withstand three times the weight of the camera, and the mount.



Note:

- The product images listed below are for reference only. For more information, visit our website (<http://www.hikvision.com/en/>).
- For wooden wall/ceiling, expansion bolts are not necessary.


Type I Dome Camera





Type II Dome Camera





Type III Dome Camera





Type I Turret Camera





Type II Turret Camera





Type III Turret Camera



Type IV Turret Camera



Type I Bullet Camera



Type II Bullet Camera

