How to Upgrade Software Version of 1600KI Keyboard to V2.0.0

1. Step 1

1) Put hikservice folder under the **root directory** of D Disk, double click UPDATE update.bat, input IP of keyboard (the keyboard and PC should be at the same network segment, e.g., **192.168.0**.5 & **192.168.0**.12), hit Enter.

   If prompt as below:

```
(1)Connect Keyboard
unable to connect to 10.5.3.102:5555
```

2) You'll have to open the Developer mode on the keyboard, General -> About -> Click "DS-1600K" character for 6-7 times



3) Click Others -> Developer options to open the developer mode, turn to Step 2

© Hangzhou Hikvision Digital Technology Co.,Ltd. All Rights Reserved.
No.555 Qianmo Road, Binjiang District, Hangzhou 310052, China • Tel: +86-571-8807-5998 • Fax: +1 909-595-0788
E-Mail: support@hikvision.com • www.hikvision.com



Note: V2.0.0 do not support hikservice of V1.0.0, thus keyboards with initial version of V1.0.0, must install new hikservice before upgrading to V2.0.0 (including V1.0.0 -> V2.0.0 or V1.0.0 -> V1.1.0 -> V2.0.0)

2. Step 2

1) If prompt as below:



2) It means hikservice has been installed successfullye

3. Step 3

Use USB Disk to upgrade the software to V2.0.0, click Browse to select the upgrade patch to update the system

© Hangzhou Hikvision Digital Technology Co.,Ltd. All Rights Reserved.



© Hangzhou Hikvision Digital Technology Co.,Ltd. All Rights Reserved.
No.555 Qianmo Road, Binjiang District, Hangzhou 310052, China • Tel: +86-571-8807-5998 • Fax: +1 909-595-0788
E-Mail: support@hikvision.com • www.hikvision.com

First Choice for Security Professionals

***HIKVISION* Technical Support**

© Hangzhou Hikvision Digital Technology Co.,Ltd. All Rights Reserved.
No.555 Qianmo Road, Binjiang District, Hangzhou 310052, China • Tel: +86-571-8807-5998 • Fax: +1 909-595-0788
E-Mail: support@hikvision.com • www.hikvision.com