

Hik-ProConnect

Convergent Security Service Solution

Hik-ProConnect is a convergent, cloud-based security solution that helps manage services for your customers and expand your business by subscription offers.

You can monitor the system health status of your customers' sites – even resolving problems – remotely, using a simple and reliable platform.

Hik-ProConnect solution enables you to customize security solutions for customers with fully-converged Hikvision device, covering video, intrusion, access, intercom, and more.

- Easy to access with Portal and Mobile Client
- Centralized device management
- 24/7 device status monitoring
- Multiple accounts with individual permissions
- Comprehensive device authority management mechanism
- Remote operation and maintenance capabilities for high quality and efficient services
- More efficient installation process
- Various cross-device linkage scenarios and timely pushing event and related videos to Hik-Connect Mobile Client
- Co-branding and brand promotion



Hik-ProConnect Portal

Comorol		
General		
Supported	English, Bulgarian, Croatian, Czech,	
Language	Danish, Dutch, Estonian, Finnish,	
	French, German, Greek, Hungarian,	
	Italian, Latvian, Lithuanian,	
	Norwegian, Polish, Portuguese,	
	Romanian, Russian, Serbian, Slovakian,	
	Slovenian, Spanish, Swedish, Turkish,	
	and Ukrainian.	
Wizard	Guide user through the process of	
	configurations and operations.	
Feedback	• Submit feedback information,	
	including Installation and	
	Deployment, Linkage Rule,	
	Maintenance, Company	
	Management, Permission,	
	Exception, and Other.	
	• The words, a picture, and email	
	address can be used for reply.	
Demo	Experience general features of Hik-	
	ProConnect without registering any	
	accounts to promote further	
	registration, use and purchase for Hik-	
	ProConnect.	
System Requirer	nents	
Operating System	Microsoft [®] Windows 7/8.1/10 (32-bit	
	and 64-bit).	
Web Browser	Internet Explorer 11 (32-bit and 64-bit)	
	and above, and version of Firefox (32-	
	bit and 64-bit) and Google Chrome	
	(32-bit and 64-bit) released in the last	
	half year.	
Account Manage	ement	
Account Manage		
-	ement	
Number of	ement Unlimited.	
Number of	ement Unlimited. * Currently, up to 100 employees are	
Number of Installers	ement Unlimited. * Currently, up to 100 employees are supported in trial period.	
Number of Installers	ement Unlimited. * Currently, up to 100 employees are supported in trial period. • Register Installer Admin account	
Number of Installers	ement Unlimited. * <i>Currently, up to 100 employees are</i> <i>supported in trial period.</i> • Register Installer Admin account using email. When registering	
Number of Installers	 ement Unlimited. <i>Currently, up to 100 employees are</i> supported in trial period. Register Installer Admin account using email. When registering account, select to subscribe to marketing communications about Hik-ProConnect. You can 	
Number of Installers	 ement Unlimited. * Currently, up to 100 employees are supported in trial period. Register Installer Admin account using email. When registering account, select to subscribe to marketing communications about 	
Number of Installers	 ement Unlimited. <i>Currently, up to 100 employees are</i> supported in trial period. Register Installer Admin account using email. When registering account, select to subscribe to marketing communications about Hik-ProConnect. You can 	
Number of Installers	 ement Unlimited. * Currently, up to 100 employees are supported in trial period. Register Installer Admin account using email. When registering account, select to subscribe to marketing communications about Hik-ProConnect. You can unsubscribe at any time. 	
Number of Installers	 ement Unlimited. * Currently, up to 100 employees are supported in trial period. Register Installer Admin account using email. When registering account, select to subscribe to marketing communications about Hik-ProConnect. You can unsubscribe at any time. Delete Installer Admin account. 	
Number of Installers	 Unlimited. <i>Currently, up to 100 employees are</i> supported in trial period. Register Installer Admin account using email. When registering account, select to subscribe to marketing communications about Hik-ProConnect. You can unsubscribe at any time. Delete Installer Admin account. Edit basic information or change 	
Number of Installers	 ement Unlimited. * Currently, up to 100 employees are supported in trial period. Register Installer Admin account using email. When registering account, select to subscribe to marketing communications about Hik-ProConnect. You can unsubscribe at any time. Delete Installer Admin account. Edit basic information or change password for current account. Invite employee to register an Installer account. 	
Number of Installers	 Unlimited. <i>Currently, up to 100 employees are</i> supported in trial period. Register Installer Admin account using email. When registering account, select to subscribe to marketing communications about Hik-ProConnect. You can unsubscribe at any time. Delete Installer Admin account. Edit basic information or change password for current account. Invite employee to register an Installer account. Manage roles and customize role. 	
Number of Installers Account	 ement Unlimited. * Currently, up to 100 employees are supported in trial period. Register Installer Admin account using email. When registering account, select to subscribe to marketing communications about Hik-ProConnect. You can unsubscribe at any time. Delete Installer Admin account. Edit basic information or change password for current account. Invite employee to register an Installer account. 	
Number of Installers Account	 Unlimited. <i>Currently, up to 100 employees are</i> supported in trial period. Register Installer Admin account using email. When registering account, select to subscribe to marketing communications about Hik-ProConnect. You can unsubscribe at any time. Delete Installer Admin account. Edit basic information or change password for current account. Invite employee to register an Installer account. Manage roles and customize role. 	
Number of Installers Account	 Unlimited. <i>Currently, up to 100 employees are</i> supported in trial period. Register Installer Admin account using email. When registering account, select to subscribe to marketing communications about Hik-ProConnect. You can unsubscribe at any time. Delete Installer Admin account. Edit basic information or change password for current account. Invite employee to register an Installer account. Manage roles and customize role. Assign roles with different 	
Number of Installers Account	 Unlimited. * Currently, up to 100 employees are supported in trial period. Register Installer Admin account using email. When registering account, select to subscribe to marketing communications about Hik-ProConnect. You can unsubscribe at any time. Delete Installer Admin account. Edit basic information or change password for current account. Invite employee to register an Installer account. Manage roles and customize role. Assign roles with different permissions, including managing 	
Number of Installers Account	 Unlimited. * Currently, up to 100 employees are supported in trial period. Register Installer Admin account using email. When registering account, select to subscribe to marketing communications about Hik-ProConnect. You can unsubscribe at any time. Delete Installer Admin account. Edit basic information or change password for current account. Invite employee to register an Installer account. Manage roles and customize role. Assign roles with different permissions, including managing assigned site, assigning site, 	
Number of Installers Account	 ement Unlimited. * Currently, up to 100 employees are supported in trial period. Register Installer Admin account using email. When registering account, select to subscribe to marketing communications about Hik-ProConnect. You can unsubscribe at any time. Delete Installer Admin account. Edit basic information or change password for current account. Invite employee to register an Installer account. Manage roles and customize role. Assign roles with different permissions, including managing assigned site, assigning site, managing account and role, and 	
Number of Installers Account Role	 Unlimited. * Currently, up to 100 employees are supported in trial period. Register Installer Admin account using email. When registering account, select to subscribe to marketing communications about Hik-ProConnect. You can unsubscribe at any time. Delete Installer Admin account. Edit basic information or change password for current account. Invite employee to register an Installer account. Manage roles and customize role. Assign roles with different permissions, including managing assigned site, assigning site, managing account and role, and managing company information. 	

	 license number, VAT number, etc. Display company logo on the Hik-Connect Mobile Client for brand promotion. View comparison about the supported functions and manageable devices between basic package and health monitoring package.
Home Page	01 0
Contents	Include the banner, site overview, device overview, exception overview, frequently used functions, recently visited sites, employees in total, help.
Quick Entries	Go to the module directly via quick entries.
Site Managemer	
Number of Sites	Unlimited.
Manage Site	Add new/existing site, edit, and delete site. More countries and regions are supported when adding new site, including time zone and phone area code.
Invite Site Owner	Invite end user as site owner by email or phone number. The end user can register Hik-Connect account and
	receive the invitation via Hik-Connect Mobile Client.
Apply for Site Authorization	When inviting site owner, apply for permissions of site information management, device configuration, and device live view. The end user can select whether to accept invitation and grant the authorization.
Cancel	The end user can cancel the site
Authorization	authorization.
Device Manager	
Number of Devices	Up to 2,000 devices for each installation company. * Currently, up to 1,024 devices are supported in trial period.
Supported Device Type	Network camera, NVR, DVR, access control device, security control panel, video intercom device, and doorbell.
Cloud P2P	Support accessing device via Cloud P2P, applicable for different network environments.
Adding Mode	 Add one or multiple devices detected by SADP. Add device manually by entering serial number and verification code.



	Device Upgrade	 Upgrade one or multiple devices remotely. Detect the compatibility of devices' firmware versions with Hik-ProConnect when adding devices. 		 Alarm, 24-Hour Auxiliary Zone Alarm, 24-Hour Shock Alarm Zone Alarm, Sensor Tampered, and Stay Arming. For zone linked to security control panel: Instant Zone
	Live View			Alarm, 24-Hour Annunciating
	Window Division	1/4/9/16-window division for live view.		Zone Alarm, Delayed Zone Alarm, Internal Delayed Zone Alarm, Fire
_	Display Time	Up to five minutes once for live view via Hik-Connect service.		Alarm Zone Alarm, Perimeter Zone Alarm, 24-Hour Silent Alarm
	Supported Operations	Capturing picture, recording, digital zoom, audio control, PTZ control (preset, zoom in/out, focus, iris, speed control, etc.), wiper, and switching image quality (high definition / standard definition / fluent) are supported during live view.		 Zone Alarm, 24-Hour Auxiliary Zone Alarm, 24-Hour Shock Alarm Zone Alarm, and Sensor Tampered. For doorbell: Calling. For camera linked to doorbell: PIR detection.
	Linkage		Linkage Action	Up to 10 linked devices and 128
	Device Type	Configure linkage rule for the devices (including network camera, NVR/DVR, security control panel, access control device, video intercom device, and doorbell) in a site.		 linkage actions (including up to 4 linkage actions of capturing and recording) are supported. For camera: Capture, Recording, Call Preset, Call Patrol, Call
	Template	Six pre-defined templates designed for typical applications and used for flexible linkage rule configuration, including Intrusion, Forced Entry Alarm, Back to Home/Office, Away, Visitor Calling, and Perimeter Zone Alarm.		 Pattern, Arm, Disarm, Enable Privacy Mask, and Disable Privacy Mask. For alarm output: Alarm Output. For door linked to access control device: Open Door, Remain Open, and Remain Closed. For area of security control
	Linkage Mode	 The linkage of the device (if supported) will be triggered via LAN in priority. The linkage via Hik-ProConnect Cloud is active in different networks. 		 For area of security control panel: Stay Arm, Away Arm, and Disarm. For door station: Open Door. For alarm input: Arm Alarm Input and Disarm Alarm Input.
-	Linkage Schedule	Customize linkage schedule for activating the linkage in specified time and dates in each week.	Enable/Disable Linkage Rule	Enable or disable linkage rule to allow the linkage rule to be active or inactive (if abnormal).
-	Triggering Event	For camera: Motion Detection,	Health Status	
		 For current, Motion Detection, Face Detection, Intrusion, and Line Crossing Detection. For access control device: Network Disconnected, 	Locate Device	 According to device types, locate the abnormal device(s) quickly. Search device by entering keywords.
		 Tampering Alarm. For door linked to access control device: Door Opened Abnormally. 	Status Display	Show device list of each site and status information. Refresh status for the first time login and entering Health Status page.
		 For door station: Calling. 	Automatically	Inspect the working status of the
	 For door station: Calling. For area of security control panel: Away Arming, Disarmed, 	Inspect	devices automatically and display the last inspected time.	
		Instant Zone Alarm, 24-Hour Annunciating Zone Alarm,	Manually Inspect	Inspect the status information of the devices manually.
		Delayed Zone Alarm, Internal	Remote	Remotely configure device
		Delayed Zone Alarm, Fire Alarm	Configuration	parameters.
		Zone Alarm, Perimeter Zone	Status of Encoding	Show status information, including
		Alarm, 24-Hour Silent Alarm Zone	Device	network status, storage status of HDD



2		or SD card, IP channel status of NVR, S.M.A.R.T. information of HDD, overwritten recording status, HDD usage, etc.
	Status of Security Control Panel	Show status information, including network status, low battery, mobile network/wireless network/wired network/disconnected, and remaining battery power.
-	Status of Access Control Device	Show network status.
	Status of Video Intercom Device	Show network status.
	Status of Doorbell	Show network status and SD Card status.
	Exception Rule	
	Exception Type	 Device Exception: Offline (duration configurable), SD Card Full, SD Card Error, HDD Full, HDD Error, No HDD, Invalid Property of HDD, Abnormal HDD Temperature, HDD Self-Test Exception, HDD All-Test Exception, Weak Wi-Fi Signal, No Network Connection, Low Battery, Network Exception, and Zone Tampered. Channel Exception: Offline (duration configurable), Low Battery, Network Exception, Weak Signal for Connecting, Zone Tampered, and Video Loss.
_	Received by	Portal, Mobile, and Email.
_	Recipient	Site Manager (by default), or Installer Admin.
_	Time	Receive the exception always or in specified time and dates in each week.
	Batch	Enable or set exception rules in a
-	Configuration	batch.
	Copy Rule	Copy rule settings to other devices or channels.

Exception Conta	~
Exception Center	
Notification	Up to 7 days.
Retention Days	
Real-Time Display	Display the exceptions of devices in all
	sites or assigned site(s) in real time,
	including time, site name, source,
	exception type, site owner, etc.
Filter Exception	Filter the exceptions by exception
	type, time period, and source.
Open in New	Open a new window of the browser to
Window	view the Exception Center.
Export Records	Export exception records in CSV, Excel,
	or PDF format.
Logs	
Log Retention	Up to 90 days.
Days	
Log Search	Search operation logs by operator and
	time.
Log Information	Including operator, operating time,
	client, site, target, result, etc.
Security	
Jecuncy	
Channel	HTTPS and TLS/SSL are used to ensure
	HTTPS and TLS/SSL are used to ensure the security of the transmission
Channel	-
Channel	the security of the transmission
Channel Encryption	the security of the transmission process.
Channel Encryption	the security of the transmission process. AES 128 and RSA are used to ensure
Channel Encryption Signal Encryption	the security of the transmission process. AES 128 and RSA are used to ensure the security of data content.
Channel Encryption Signal Encryption Protection Against	the security of the transmission process. AES 128 and RSA are used to ensure the security of data content. Once the platform discovers account-
Channel Encryption Signal Encryption Protection Against Account Attacks	the security of the transmission process. AES 128 and RSA are used to ensure the security of data content. Once the platform discovers account- hacking attacks, it will ban IPs.
Channel Encryption Signal Encryption Protection Against Account Attacks Verification Code	the security of the transmission process. AES 128 and RSA are used to ensure the security of data content. Once the platform discovers account- hacking attacks, it will ban IPs. Ensure the security of streaming
Channel Encryption Signal Encryption Protection Against Account Attacks Verification Code Encryption	the security of the transmission process. AES 128 and RSA are used to ensure the security of data content. Once the platform discovers account- hacking attacks, it will ban IPs. Ensure the security of streaming during remote preview and download.
Channel Encryption Signal Encryption Protection Against Account Attacks Verification Code Encryption	the security of the transmission process. AES 128 and RSA are used to ensure the security of data content. Once the platform discovers account- hacking attacks, it will ban IPs. Ensure the security of streaming during remote preview and download. Establish secure link without port
Channel Encryption Signal Encryption Protection Against Account Attacks Verification Code Encryption P2P	the security of the transmission process. AES 128 and RSA are used to ensure the security of data content. Once the platform discovers account- hacking attacks, it will ban IPs. Ensure the security of streaming during remote preview and download. Establish secure link without port mapping and avoid exposing ports to the public network.
Channel Encryption Signal Encryption Protection Against Account Attacks Verification Code Encryption	the security of the transmission process. AES 128 and RSA are used to ensure the security of data content. Once the platform discovers account- hacking attacks, it will ban IPs. Ensure the security of streaming during remote preview and download. Establish secure link without port mapping and avoid exposing ports to the public network. The unique serial number can only be
Channel Encryption Signal Encryption Protection Against Account Attacks Verification Code Encryption P2P Unique Serial	the security of the transmission process. AES 128 and RSA are used to ensure the security of data content. Once the platform discovers account- hacking attacks, it will ban IPs. Ensure the security of streaming during remote preview and download. Establish secure link without port mapping and avoid exposing ports to the public network. The unique serial number can only be bound by one account to prevent the
Channel Encryption Signal Encryption Protection Against Account Attacks Verification Code Encryption P2P Unique Serial	the security of the transmission process. AES 128 and RSA are used to ensure the security of data content. Once the platform discovers account- hacking attacks, it will ban IPs. Ensure the security of streaming during remote preview and download. Establish secure link without port mapping and avoid exposing ports to the public network. The unique serial number can only be



Hik-ProConnect Mobile Client

General			Mobile Client.
Supported Language	English, Bulgarian, Croatian, Czech, Danish, Dutch, Estonian, Finnish, French, German, Greek, Hungarian, Italian, Latvian, Lithuanian, Norwegian, Polish, Portuguese, Romanian, Russian, Serbian, Slovakian, Slovenian, Spanish, Swedish, Turkish, and Ukrainian.	Apply for Site Authorization	When inviting site owner, apply for permissions of site information management, device configuration, and device live view. The end user can select whether to accept invitation and grant the authorization.
Feedback	• Submit feedback information, including Installation and	Cancel Authorization	The end user can cancel the site authorization.
	Deployment, Linkage Rule,	Device Manag	ement
	 Maintenance, Company Management, Permission, Exception and Other. The words, a picture, and email 	Number of Devices	Up to 2,000 devices for each installation company. * Currently, up to 1,024 devices are supported in trial period.
	address can be used for reply.	Supported	Network camera, NVR, DVR, access
System Requi	iOS 10 or later versions (since iPhone 6	Device Type	control device, security control panel, video intercom device, and doorbell.
Android	or iPad Air). Android 5.0 or later versions. * The latest version of Hik-ProConnect	Cloud P2P	Support accessing device via Cloud P2P, applicable for different network environments.
	Mobile Client can be detected and you can select whether to upgrade it when a prompt pops up.	Adding Mode	 Add device by scanning QR code. Add device manually by serial number and verification code.
Account Mana	agement		Connect wired offline device to
Account	 Register Installer Admin account using email. When registering account, select to subscribe to marketing communications about Hik-ProConnect. You can 	Device Upgrade	 network by setting AP. Upgrade device remotely. Detect the compatibility of devices' firmware versions with Hik- ProConnect when adding devices.
	unsubscribe at any time via Hik-	Live View	
	ProConnect Portal.Change password for current	Window Division	1-window division for live view.
Company	account. Bind company information, including	Display Time	Up to five minutes once for live view via Hik-Connect service.
Information	company logo, business license number, VAT number, etc.	Supported Operations	PTZ control (preset, zoom in/out, focus, iris, speed control, etc.), wiper, and
Home Page			switching image quality ((high definition
Contents	Include the shortcut, banner, site overview, exception overview, and		<pre>/ standard definition / fluent)) are supported during live view.</pre>
	recently visited sites.	Linkage	
Quick Entries	Go to the module directly via quick entries.	Device Type	Configure linkage rule for the devices (including network camera, NVR, DVR,
Site Managen			access control device, security control
Number of Sites Manage Site	Unlimited. Add new/existing site, edit, and delete	<u> </u>	panel, video intercom device, and doorbell) in a site.
Invite Site Owner	site. More countries and regions are supported when adding new site, including time zone and phone area code. Invite end user as site owner by email or phone number. The end user can	Template	Six pre-defined templates designed for typical applications and used for flexible linkage rule configuration, including Intrusion, Forced Entry Alarm, Back to Home/Office, Away, Visitor Calling, and Perimeter Zone Alarm.
Owner	register Hik-Connect account and receive the invitation via Hik-Connect	Linkage Mode	 The linkage of the device (if supported) will be triggered via



the linkage rule to be active or inactive

Device Exception: Offline (duration

(if abnormal).

•

_		LAN in priority.
		 The linkage via Hik-ProConnect
		Cloud is active in different
		networks.
1	Linkage	Customize linkage schedule for
	Schedule	activating the linkage in specified time
		and dates in each week.
-	Triggering Event	• For camera: Motion Detection,
		Face Detection, Intrusion, and Line
		Crossing Detection.
		• For access control device:
		Tampering Alarm.
		 For door linked to access control
		device: Opening Door Abnormally.
		 For door station: Calling.
		 For area of security control panel:
		Away Arming, Disarmed, Instant
		Zone Alarm, 24-Hour Annunciating
		Zone Alarm, Delayed Zone Alarm,
		Internal Delayed Zone Alarm, Fire
		Alarm Zone Alarm, Perimeter Zone
		Alarm, 24-Hour Silent Alarm Zone
		Alarm, 24-Hour Auxiliary Zone
		Alarm, 24-Hour Shock Alarm Zone
		Alarm, Sensor Tampered, and Stay
		 Arming. For zone linked to security control
		panel: Instant Zone Alarm, 24-Hour
		Annunciating Zone Alarm, Delayed
		Zone Alarm, Internal Delayed Zone
		Alarm, Fire Alarm Zone Alarm,
		Perimeter Zone Alarm, 24-Hour
		Silent Alarm Zone Alarm, 24-Hour
		Auxiliary Zone Alarm, 24-Hour
		Shock Alarm Zone Alarm, and
		Sensor Tampered.
		• For doorbell: Tampering Alarm.
		• For camera linked to doorbell: PIR
_		detection.
-	Linkage Action	Up to 10 linked devices and 128 linkage
		actions (including up to 4 linkage actions
		of capturing and recording) are
		supported.
		• For camera: Capture, Recording,
		Preset, Patrol, Pattern, Arm,
		Disarm, Enable Privacy Mask,
		Disable Privacy Mask.
		For alarm output: Alarm Output.
		• For door linked to access control
		device: Open Door, Remain Open,
		and Remain Closed.
		For area of security control panel: Stay Arming Away Arming and
		Stay Arming, Away Arming, and
		Disarm.
		 For door station: Open Door. For alarm input: Arm Alarm Input
		For alarm input: Arm Alarm Input and Dicarm Alarm Input
-		and Disarm Alarm Input.

Exception Type	 Device Exception: Offline (duration configurable), SD Card Full, SD Card Full, SD Card Error, HDD Full, HDD Error, No HDD, Invalid Property of HDD, Abnormal HDD Temperature, HDD Self-Test Exception, HDD All-Test Exception, Weak Wi-Fi Signal, No Network Connection, Low Battery, Network Exception, and Zone Tampered. Channel Exception: Offline (duration configurable), Low Battery, Network Exception, Weak Signal for Connecting, Zone Tampered, and Video Loss.
Received by	Portal, Mobile, and Email.
Recipient	Site Manager (by default), or Installer Admin.
Time	Receive the exception notifications always or in specified time and dates in each week
Batch	Enable or set exception rules in a batch.
Configuration	
Copy Rule	Copy rule settings to other devices or channels.
Exception Cent	er
Notification	Up to 7 days.
Retention Days	
Real-Time	Display the exceptions of the devices in
Display	all sites or assigned site(s) in real time,
	including time, site name, source,
Filter Exception	exception type, site owner, etc. Filter the exceptions by exception type,
	time period and source.
Open in New	open a new window of the browser to
Window	view the Exception Center.
Security	· · · · · · · · · · · · · · · · · · ·
Channel	HTTPS and TLS/SSL are used to ensure
Encryption	the security of the transmission process.
Signal	AES 128 and RSA are used to ensure the
Encryption	security of data content.
Protection	Once the platform discovers account-
Against Account	hacking attacks, it will ban IPs.
Attacks	
Verification	Ensure the security of streaming during
Code Encryption	remote preview and download.
P2P	Establish secure link without port mapping and avoid exposing ports to the public network.
Unique Serial	The unique serial number can only be
Number	bound by one account to prevent the
	device from being added by an attacker.
	· · · ·

Linkage Rule

Exception Exception Type



Distributed by

Γ



Hikvision Europe

Dirk, Storklaan 3, 2132 PX Hoofddorp, The Netherlands T +31-23-5542770 sales.eu@hikvision.com

Headquarters T +86-571-8807-5998 overseasbusiness@hikvision.com

Hikvision Australia T +61-2-8599-4233 salesau@hikvision.com

Hikvision India T +91-22-28469900 sales@pramahikvision.com

Hikvision Canada T +1-866-200-6690 sales.canada@hikvision.com

Hikvision Thailand T +662-275-9949 sales.thailand@hikvision.com Hikvision USA T +1-909-895-0400 sales.usa@hikvision.com

Hikvision Italy T +39-0438-6902

info.it@hikvision.com Hikvision Brazil T +55 11 3318-0050 Latam.support@hikvision.com

Hikvision Turkey T +90 (216)521 7070- 7074 sales.tr@hikvision.com

Hikvision Malaysia T +601-7652-2413 sales.my@hikvision.com Hikvision UK & Ireland T +01628-902140 sales.uk@hikvision.com

Hikvision South Africa Tel: +27 (10) 0351172 sale.africa@hikvision.com

Hikvision France T +33(0)1-85-330-450 info.fr@hikvision.com

Hikvision Kazakhstan T +7-727-9730667 nikia.panfilov@hikvision.ru

Hikvision Vietnam T +84-974270888 sales.vt@hikvision.com Hikvision UAE T +971-4-4432090 salesme@hikvision.com

Hikvision Singapore T +65-6684-4718

sg@hikvision.com Hikvision Spain

T +34-91-737-16-55 info.es@hikvision.com

Hikvision Tashkent T +99-87-1238-9438 uzb@hikvision.ru

Hikvision Hong Kong T +852-2151-1761 info.hk@hikvision.com Hikvision Russia T +7-495-669-67-99 saleru@hikvision.com

Hikvision Korea T +82-(0)31-731-8817 sales.korea@hikvision.com

Hikvision Poland T +48-22-460-01-50 info.pl@hikvision.com

Hikvision Indonesia T +62-21-2933759 Sales.Indonesia@hikvision.com

Hikvision Colombia sales.colombia@hikvision.com

© 2020 Hikvision Europe B.V. All rights reserved.