

HikCentral Professional Web Client

User Manual

Legal Information

User Manual

©2019 Hangzhou Hikvision Digital Technology Co., Ltd.

About this Manual

This Manual is subject to domestic and international copyright protection. Hangzhou Hikvision Digital Technology Co., Ltd. ("Hikvision") reserves all rights to this manual. This manual cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of Hikvision.

Please use this user manual under the guidance of professionals.

Trademarks

HIKVISION and other Hikvision marks are the property of Hikvision and are registered trademarks or the subject of applications for the same by Hikvision and/or its affiliates. Other trademarks mentioned in this manual are the properties of their respective owners. No right of license is given to use such trademarks without express permission.

Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, REGARDING THIS MANUAL. HIKVISION DOES NOT WARRANT, GUARANTEE, OR MAKE ANY REPRESENTATIONS REGARDING THE USE OF THE MANUAL, OR THE CORRECTNESS, ACCURACY, OR RELIABILITY OF INFORMATION CONTAINED HEREIN. YOUR USE OF THIS MANUAL AND ANY RELIANCE ON THIS MANUAL SHALL BE WHOLLY AT YOUR OWN RISK AND RESPONSIBILITY.

REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.

SURVEILLANCE LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS THE APPLICABLE LAW. HIKVISION SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THIS MANUAL AND THE APPLICABLE LAW, THE LATER PREVAILS.

Symbol Conventions

The symbols that may be found in this document are defined as follows.

Symbol	Description
Danger	Indicates a hazardous situation which, if not avoided, will or could result in death or serious injury.
A Caution	Indicates a potentially hazardous situation which, if not avoided, could result in equipment damage, data loss, performance degradation, or unexpected results.
i Note	Provides additional information to emphasize or supplement important points of the main text.

Contents

Chapter 1 About This Document 1
Chapter 2 Introduction 2
Chapter 3 Getting Started
Chapter 4 Login
4.1 Recommended Running Environment
4.2 First Time Login
4.2.1 Login for First Time for admin User
4.2.2 First Time Login for Normal User 6
4.3 Login via Web Client
4.4 Change Password for Reset User
4.5 Forgot Password 10
Chapter 5 Download Mobile Client 11
Chapter 6 Web Control 12
Chapter 7 Wizard 13
Chapter 7 Wizard
-
Chapter 8 Manage License 14
Chapter 8 Manage License 14 8.1 Activate License - Online 14
Chapter 8 Manage License 14 8.1 Activate License - Online 14 8.2 Activate License - Offline 16
Chapter 8 Manage License 14 8.1 Activate License - Online 14 8.2 Activate License - Offline 16 8.3 Update License - Online 17
Chapter 8 Manage License - Online148.1 Activate License - Online148.2 Activate License - Offline168.3 Update License - Online178.4 Update License - Offline18
Chapter 8 Manage License - Online148.1 Activate License - Online148.2 Activate License - Offline168.3 Update License - Online178.4 Update License - Offline188.5 Deactivate License - Online19
Chapter 8 Manage License148.1 Activate License - Online148.2 Activate License - Offline168.3 Update License - Online178.4 Update License - Offline188.5 Deactivate License - Online198.6 Deactivate License - Offline19
Chapter 8 Manage License148.1 Activate License - Online148.2 Activate License - Offline168.3 Update License - Online178.4 Update License - Offline188.5 Deactivate License - Online198.6 Deactivate License - Offline198.6 Deactivate License - Offline198.7 Deactivate License - Offline198.8 Deactivate License - Offline <td< th=""></td<>
Chapter 8 Manage License148.1 Activate License - Online148.2 Activate License - Offline168.3 Update License - Online178.4 Update License - Offline188.5 Deactivate License - Online198.6 Deactivate License - Offline198.6 Deactivate License - Offline199.1 Create Password for Inactive Device(s)21

	9.3.2 Add Encoding Device by IP Address or Domain Name	29
	9.3.3 Add Encoding Devices by IP Segment	33
	9.3.4 Add Encoding Devices by Port Segment	35
	9.3.5 Add Encoding Device by Hik-Connect	38
	9.3.6 Add Encoding Device by Device ID	42
	9.3.7 Add Encoding Devices by Device ID Segment	44
	9.3.8 Add Encoding Devices in a Batch	46
	9.3.9 Limit Bandwidth for Video Downloading	47
	9.3.10 Set N+1 Hot Spare for NVR	48
9.4	Manage Access Control Device	49
	9.4.1 Add Online Device	49
	9.4.2 Add Access Control Device by IP Address	54
	9.4.3 Add Access Control Devices by IP Segment	56
	9.4.4 Add Access Control Devices by Port Segment	58
	9.4.5 Add Access Control Devices by Device ID	60
	9.4.6 Add Access Control Devices by Device ID Segment	62
	9.4.7 Add Access Control Devices in a Batch	63
9.5	Manage Security Control Device	64
	9.5.1 Add Online Device	65
	9.5.2 Add Security Control Device by IP Address	68
	9.5.3 Add Security Control Device by Hik-Connect	70
	9.5.4 Add Security Control Devices by IP Segment	71
	9.5.5 Add Security Control Devices by Port Segment	73
	9.5.6 Add Security Control Devices in a Batch	74
9.6	Manage Dock Station	75
	9.6.1 Add Dock Station by IP/Domain	76
	9.6.2 Add Dock Stations by IP Segment	77
	9.6.3 Add Dock Stations by Port Segment	78

9.6.4 Add Dock Stations in Batch	79
9.7 Upgrade Device Firmware	80
9.7.1 Upgrade Device Firmware via Current Web Client	80
9.7.2 Upgrade Device Firmware via EZVIZ Cloud Service	80
9.8 Restore/Reset Device Password	81
9.8.1 Reset Device Password	81
9.8.2 Restore Device's Default Password	83
9.9 Manage Remote Site	84
9.9.1 Add Remote Site by IP Address or Domain Name	84
9.9.2 Add Remote Site Registered to Central System	87
9.9.3 Add Remote Sites in a Batch	89
9.9.4 Back Up Remote Site's Database to Central System	91
9.9.5 Edit Remote Site	
9.9.6 View Remote Site's Changes	
0	
9.10 Manage Application Data Server	95
9.10 Manage Application Data Server	
9.10 Manage Application Data Server 9.11 Manage Recording Server	
 9.10 Manage Application Data Server 9.11 Manage Recording Server 9.11.1 Manage Cloud Storage Server 	
 9.10 Manage Application Data Server 9.11 Manage Recording Server 9.11.1 Manage Cloud Storage Server 9.11.2 Add Hybrid Storage Area Network 	98 98
 9.10 Manage Application Data Server 9.11 Manage Recording Server 9.11.1 Manage Cloud Storage Server 9.11.2 Add Hybrid Storage Area Network	98 98 000 000 000 000 000 000 000 000 00
 9.10 Manage Application Data Server 9.11 Manage Recording Server	
 9.10 Manage Application Data Server 9.11 Manage Recording Server	
 9.10 Manage Application Data Server	
 9.10 Manage Application Data Server	
 9.10 Manage Application Data Server 9.11 Manage Recording Server 9.11.1 Manage Cloud Storage Server 9.11.2 Add Hybrid Storage Area Network 9.11.3 Add pStor 9.11.4 Add Network Video Recorder 9.11.5 Set N+1 Hot Spare for Hybrid SAN 9.12 Manage Streaming Server 9.12.1 Import Service Component Certificate to Streaming Server 9.12.2 Add Streaming Server 	
 9.10 Manage Application Data Server	

HikCentral Professional Web Client User Manual

9.14.3 Add Smart Wall 119
9.14.4 Link Decoding Output with Window 119
Chapter 10 Manage Area 121
10.1 Add Area 121
10.1.1 Add Area for Current Site 121
10.1.2 Add Area for Remote Site 123
10.2 Add Element to Area 124
10.2.1 Add Camera to Area for Current Site 124
10.2.2 Add Camera to Area for Remote Site 126
10.2.3 Add Access Point to Area for Current Site 127
10.2.4 Add Alarm Input to Area 128
10.2.5 Add Alarm Output to Area 129
10.2.6 Add UVSS to Area for Current Site 130
10.3 Edit Element in Area 130
10.3.1 Edit Camera for Current Site 130
10.3.2 Edit Access Point for Current Site 133
10.3.3 Edit Alarm Input for Current Site 137
10.3.4 Edit Alarm Output for Current Site 137
10.3.5 Edit Under Vehicle Surveillance System for Current Site 138
10.3.6 Edit Element for Remote Site 138
10.4 Remove Element from Area 139
10.4.1 Remove Element from Area for Current Site 139
10.4.2 Remove Element from Area for Remote Site 140
Chapter 11 Configure Recording 141
11.1 Configure Recording for Cameras on Current Site 141
11.2 Configure Recording for Cameras on Remote Site145
11.3 Configure Storage for Imported Pictures 148
11.4 Configure Storage for Uploaded Pictures 148

11.5 Configure Recording Schedule Template	149
Chapter 12 Configure Event and Alarm	152
12.1 Configure System-Monitored Event	153
12.1.1 Add Event for Camera	154
12.1.2 Add Event for Access Point	158
12.1.3 Add Event for Alarm Input	162
12.1.4 Add Event for ANPR Camera	165
12.1.5 Add Event for Person	170
12.1.6 Add Event for UVSS	174
12.1.7 Add Event for Remote Site	178
12.1.8 Add Event for Encoding Device	181
12.1.9 Add Event for Access Control Device	185
12.1.10 Add Event for Security Control Device	189
12.1.11 Add Event for Dock Station	192
12.1.12 Add Event for Streaming Server or Recording Server	196
12.1.13 Add Event for Facial Recognition Server	200
12.1.14 Add Event for HikCentral Professional Server	203
12.1.15 Add Event for User	207
12.1.16 Add Event for User-Defined Event	210
12.1.17 Add Event for Generic Event	214
12.1.18 Edit System-Monitored Event	217
12.2 Configure Generic Event	218
12.3 Configure User-Defined Event	221
12.4 Configure Alarm	222
12.4.1 Alarm Settings	223
12.4.2 Add Alarm for Camera on Current Site	225
12.4.3 Add Alarm for Camera on Remote Site	230
12.4.4 Add Alarm for Access Point	233

12.4.5 Add Alarm for Alarm Input 2	237
12.4.6 Add Alarm for ANPR Camera 2	242
12.4.7 Add Alarm for Person 2	246
12.4.8 Add Alarm for UVSS 2	251
12.4.9 Add Alarm for Encoding Device 2	255
12.4.10 Add Alarm for Access Control Device 2	259
12.4.11 Add Alarm for Security Control Device 2	263
12.4.12 Add Alarm for Dock Station 2	267
12.4.13 Add Alarm for Streaming Server and Recording Server 2	271
12.4.14 Add Alarm for Facial Recognition Server 2	275
12.4.15 Add Alarm for HikCentral Professional Server 2	279
12.4.16 Add Alarm for User 2	283
12.4.17 Add Alarm for User-Defined Event 2	287
12.4.18 Add Alarm for Generic Event 2	291
12.4.19 Add Alarm for Remote Site 2	296
12.5 Configure Arming Schedule Template 3	300
Chapter 13 Manage Map 3	302
13.1 Set GIS Map and Icons 3	302
13.2 Link E-Map to Area	303
13.3 Search Locations	
13.5 Scarch Eocations	305
13.4 Locate Sites on Map	
	305
13.4 Locate Sites on Map 3	305 306
13.4 Locate Sites on Map 3 13.5 Add Hot Spot	305 306 308
13.4 Locate Sites on Map 3 13.5 Add Hot Spot 3 13.6 Add Hot Region 3	305 306 308 308
13.4 Locate Sites on Map 3 13.5 Add Hot Spot 3 13.6 Add Hot Region 3 13.7 Add Label 3	305 306 308 308 308 310
13.4 Locate Sites on Map 3 13.5 Add Hot Spot 3 13.6 Add Hot Region 3 13.7 Add Label 3 Chapter 14 Manage Vehicle	305 306 308 308 308 310 310

	14.2.2 Manually Add Vehicle Information	312
Cha	pter 15 Manage Person List	315
	15.1 Add a Person	315
	15.2 Batch Add Persons by Importing Person Information File	320
	15.3 Import Domain Persons	321
	15.4 Batch Add Profiles	323
	15.5 Import Persons from Device	324
	15.6 Batch Issue Cards to Persons	325
	15.7 Set Card Issuing Parameters	326
	15.8 Report Card Loss	328
	15.8.1 Report Loss for One Card	328
	15.8.2 Issue a Temporary Card to Person	328
	15.8.3 Cancel Card Loss	329
	15.9 Custom Additional Information	330
Cha	pter 16 Manage Access Control	331
Cha	apter 16 Manage Access Control 16.1 Add Access Group	
Cha		331
Cha	16.1 Add Access Group	331 333
Cha	16.1 Add Access Group 16.2 Manage Access Level	331 333 333
Cha	16.1 Add Access Group 16.2 Manage Access Level 16.2.1 Add Access Level	331 333 333 335
Cha	 16.1 Add Access Group 16.2 Manage Access Level 16.2.1 Add Access Level 16.2.2 Assign Access Level to Access Group 	331333333335336
Cha	 16.1 Add Access Group 16.2 Manage Access Level 16.2.1 Add Access Level 16.2.2 Assign Access Level to Access Group 16.3 Apply Persons' Access Levels to Device 	 331 333 333 335 336 336
Cha	 16.1 Add Access Group 16.2 Manage Access Level	 331 333 335 336 336 337
Cha	 16.1 Add Access Group 16.2 Manage Access Level	 331 333 335 336 336 337 338
Cha	 16.1 Add Access Group	 331 333 335 336 336 337 338 339
Cha	 16.1 Add Access Group 16.2 Manage Access Level 16.2.1 Add Access Level 16.2.2 Assign Access Level to Access Group 16.3 Apply Persons' Access Levels to Device 16.3.1 Manually Apply Persons' Access Levels to Device 16.3.2 Regularly Apply Person's Access Levels to Devices 16.4 Set Access Schedule Template 16.5 Configure Anti-Passback Rules 	 331 333 335 336 336 337 338 339 340
	 16.1 Add Access Group 16.2 Manage Access Level 16.2.1 Add Access Level 16.2.2 Assign Access Level to Access Group 16.3 Apply Persons' Access Levels to Device 16.3.1 Manually Apply Persons' Access Levels to Device 16.3.2 Regularly Apply Person's Access Levels to Devices 16.4 Set Access Schedule Template 16.5 Configure Anti-Passback Rules 16.6 Configure Multi-Door Interlocking 	 331 333 335 336 336 337 338 339 340 340

17	2.2 Add Shift Schedule	344
17	.3 Assign Shift Schedule to Attendance Group	347
17	.4 Add Attendance Check Point	347
17	.5 Manage Attendance Record	348
	17.5.1 Search Attendance Record	348
	17.5.2 Correct Attendance Record for Single Person	349
	17.5.3 Correct Attendance Records for Multiple Persons	351
Chapt	er 18 Manage Face Comparison Group	352
18	.1 Add Face Comparison Group	352
18	2.2 Apply Face Comparison Group to Device	354
Chapt	er 19 Add Dock Station Group	356
Chapt	er 20 Manage Security Control	358
20	.1 Link Alarm Inputs to Security Control Partition	358
20	.2 Configure Defense Schedule Template	359
Chapt	er 21 Manage Role and User	361
-	er 21 Manage Role and User	
21		361
21 21	.1 Add Role	361 364
21 21 21	.1 Add Role .2 Add Normal User	361 364 367
21 21 21 21 21	.1 Add Role .2 Add Normal User .3 Import Domain Users	361 364 367 369
21 21 21 21 21 21	.1 Add Role .2 Add Normal User .3 Import Domain Users .4 Change Password of Current User	361 364 367 369 370
21 21 21 21 21 21 21 21	.1 Add Role .2 Add Normal User .3 Import Domain Users .4 Change Password of Current User .5 Reset Password for Admin User	361 364 367 369 370 373
21 21 21 21 21 21 21 21 21	.1 Add Role	361 364 367 369 370 373 373
21 21 21 21 21 21 21 21 Chapt	.1 Add Role	361 364 367 369 370 373 373 373 375
21 21 21 21 21 21 21 21 Chapt 22	.1 Add Role	361 364 367 369 370 373 373 373 375
21 21 21 21 21 21 21 21 Chapt 22 22	.1 Add Role	361 364 367 369 370 373 373 373 375 375
21 21 21 21 21 21 21 21 Chapt 22 22 22	1 Add Role	361 364 367 369 370 373 373 373 375 375 376 378

Ch	apter 24 System Configuration	381
	24.1 Set Site Name	381
	24.2 Set First Day of the Week	381
	24.3 Set Temperature Unit	381
	24.4 Set Warning Threshold for Server Usage	382
	24.5 Set NTP	382
	24.6 Set Active Directory	382
	24.7 Enable Receiving Generic Event	385
	24.8 Allow for Remote Site Registration	385
	24.9 Register to Central System	386
	24.10 Set WAN Access	386
	24.11 Set Network Timeout	387
	24.12 Set Device Access Mode	387
	24.13 Set Server NIC	388
	24.14 Set Data Retention Period	388
	24.15 Set Holiday	389
	24.16 Set Email Template	390
	24.16.1 Configure Email Account	390
	24.16.2 Add Email Template	392
	24.17 Send Report Regularly	393
	24.17.1 Send Event Report Regularly	393
	24.17.2 Send Alarm Report Regularly	394
	24.17.3 Send Passing Vehicle Report Regularly	396
	24.17.4 Send People Counting Report Regularly	397
	24.17.5 Send Queue Analysis Report Regularly	399
	24.17.6 Send Heat Map Report Regularly	401
	24.17.7 Send Pathway Report Regularly	402
	24.17.8 Send Temperature Report Regularly	404

	24.17.9 Send Attendance Report Regularly	406
	24.18 Enable Evidence Collection	407
	24.19 Set Transfer Protocol	408
	24.20 Set Camera ID	409
	24.21 Set Working Mode	409
	24.22 Export Service Component Certificate	410
	24.23 Set Health Check Frequency	410
	24.24 Configure System Hot Spare	411
	24.25 Reset Device Network Information	411
Cha	pter 25 Applications	412
	pter 25 Applications	
		412
	25.1 Live View	412 412
:	25.1 Live View 25.1.1 Start Live View	412 412 413
:	25.1 Live View	412 412 413 419
:	25.1 Live View	412 412 413 419 419
	 25.1 Live View 25.1.1 Start Live View 25.1.2 PTZ Control 25.2 Playback 25.2.1 Search Video File 	412 412 413 419 419 420

Chapter 1 About This Document

This user manual is intended for the administrator of the system.

The manual guides you to establish and configure the surveillance system. Follow this manual to perform system activation, access of the system, and configuration of the surveillance task via the provided Web Client, etc. To ensure the properness of usage and stability of the system, refer to the contents below and read the manual carefully before installation and operation.

Chapter 2 Introduction

The system is developed for central management of surveillance system and features flexibility, scalability high reliability, and powerful functions.

The system provides the central management, information sharing, convenient connection, and multi-service cooperation. It is capable of adding devices for management, live view, storage and playback of video files, alarm linkage, access control, time and attendance, face comparison, and so on.

iNote

The displayed modules on the home page vary with the License you purchased. For detailed information, contact our technical support.

The complete system contains the following modules. You can install the modules according to actual needs.

Module	Introduction
System Management Service (SYS)	 Provides the unified authentication service for connecting with the clients and servers. Provides the centralized management for the users, roles, permissions, devices, and services. Provides the configuration interface for surveillance and management module.
Application Data Service (ADS)	Provides data storage and processing.
Streaming Service (Optional)	Provides forwarding and distributing the audio and video data of live view.

The following table shows the provided clients for accessing or managing system.

Client	Introduction
Control Client	Control Client is a C/S software which provides multiple operating functionalities, including real-time live view, PTZ control, video playback and downloading, alarm receiving, log query, and so on.
Web Client	Web Client is a B/S client for managing system. It provides multiple functionalities, including device management, area management, recording schedule settings, event configuration, user management, and so on.
Mobile Client	Mobile Client is the software designed for getting access to the system via Wi-Fi, 3G, and 4G networks with mobile device. It fulfills the functions of the devices

Client	Introduction		
	connected to the system, such as live view, remote playback, PTZ control, and so on.		

Chapter 3 Getting Started

The following content describes the tasks typically involved in setting a working system.

Verify Initial Configuration of Devices and other Servers

Before doing anything on system, make sure the devices (camera, DVR, recording server, and so on) you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to connect the devices to the system via network.

Open Web Client and Login

Refer to Login for First Time for admin User .

Activate License

Refer to Manage License .

Add Devices to System and Configure Area

The system can quickly scan your network for relevant devices (camera, DVR, and so on), and add them to your system. Or you can add the devices by inputting the required information manually. The devices added should be organized into areas for convenient management. Refer to *Manage Resource* and *Manage Area*.

Configure Recording Settings

You can record the video files of the cameras on the storage device according to the configured recording schedule. The schedule can be set as continuous, alarm triggered, or command triggered as desired. Refer to *Configure Recording*.

Configure Event and Alarm

The camera exception, device exception, server exception, and alarm input can trigger linkage actions in the system. Refer to *Configure Event and Alarm*.

Configure Users

Specify who should be able to access your system, and how. You can set the different permissions for the users to limit the operation of the system. Refer to *Manage Role and User*.

Chapter 4 Login

You can access and configure the system via web browser directly, without installing any client software on the your computer.

4.1 Recommended Running Environment

The following is recommended system requirement for running Web Client.

CPU

Intel Pentium IV 3.0 GHz and above

Memory

1 GB and above

Video Card RADEON X700 Series

Web Browser

Internet Explorer 10/11 and above (32-bit), Firefox 32 and above (32-bit), Google Chrome 35 and above (32-bit), Safari 11 and above

i Note

You should run the web browser as administrator.

4.2 First Time Login

If this is the first time for you to login, you can choose to login as admin or normal user according to your user role.

4.2.1 Login for First Time for admin User

By default, the system predefined the administrator user named admin. When you login via the Web Client for the first time, you are required to create a password for the admin user before you can properly configure and operate the system.

Steps

1. In the address bar of the web browser, enter the address of the PC running SYS service and press Enter key.

Example

If the IP address of PC running SYS is 172.6.21.96, and you should enter http://172.6.21.96 or https://172.6.21.96 in the address bar.

iNote

- You should set the transfer protocol before accessing the SYS. For details, refer to **Set Transfer Protocol**.
- You should set the SYS's IP address before accessing the SYS via WAN. For details, refer to Set WAN Access.
- **2.** Enter the password and confirm password for the admin user in the pop-up Create Password window.

iNote

The password strength can be checked by the system and should meet the system requirements. The default minimum password strength should be **Medium**. For setting minimum password strength, refer to **Manage System Security**.

Caution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

3. Click OK.

Web Client home page displays after you successfully creating the admin password.

Result

After you logging in, the Site Name window opens and you can set the site name for the current system as you want.

iNote

You can also set it in **System → Site Name** . See **Set Site Name** for details.

4.2.2 First Time Login for Normal User

When you log in to the system as normal user via Web Client for the first time, you should change the initial password and set a new password for login.

Steps

1. In the address bar of the web browser, input the address of the PC running SYS service and press the Enter key.

Example

If the IP address of PC running SYS is 172.6.21.96, and you should enter http://172.6.21.96 or https://172.6.21.96 in the address bar.

i Note

You should configure the SYS's IP address in WAN Access of System Configuration before accessing the SYS via WAN. For details, refer to **Set WAN Access**.

2. Enter the user name and password.

iNote

Contact the administrator for the user name and initial password.

- 3. Click Login and the Change Password window opens.
- 4. Set a new password and confirm the password.

iNote

The password strength can be checked by the system and should meet the system requirements. If password strength is lower than the required minimum strength, you will be asked to change your password. For setting minimum password strength, refer to **Manage System Security**.

The password strength of the device can be checked by the system. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

5. Click OK to change the password.

Result

Web Client home page displays after you successfully logging in.

4.3 Login via Web Client

You can access the system via web browser and configure the system.

Steps

1. In the address bar of the web browser, input the address of the PC running SYS service and press Enter key.

Example

If the IP address of PC running SYS is 172.6.21.96, and you should enter http://172.6.21.96 or https://172.6.21.96 in the address bar.

iNote

You should configure the SYS's IP address in WAN Access of System Configuration before accessing the SYS via WAN. For details, refer to **Set WAN Access**.

- **2.** Enter the user name and password.
- 3. Click Login to log in to the system.

iNote

- If failed password attempt of current user is detected, you are required to input the verification code. The failed password attempts from current client, other client, and other address will all require the verification code.
- The failed password attempt and verification code attempt from current client, other client (e.g., Control Client), and other address will all be accumulated. Your IP address will be locked for a specified period of time after specific number of failed password or verification code attempts detected. For setting failed login attempts and locking duration, refer to *Manage System Security*.
- The account will be frozen for 30 minutes after 5 failed password attempts. The failed password attempts from current client, other clients (e.g., Control Client), and other addresses will all be accumulated.
- The password strength can be checked by the system and should meet the system requirements. If password strength is lower than the required minimum strength, you will be asked to change your password. For setting minimum password strength, refer to *Manage System Security*.
- If your password is expired, you will be asked to change your password when login. For setting maximum password age, refer to *Manage System Security*.

Result

Web Client home page displays after you successfully logging in to the system.

4.4 Change Password for Reset User

When the normal user's password is reset by admin user, he/she should change the initial password and set a new password when logging into HikCentral Professional via the Web Client.

Steps

1. In the address bar of the web browser, enter the address of the PC running SYS service and press Enter key.

Example

If the IP address of PC running SYS is 172.6.21.96, and you should enter http://172.6.21.96 or https://172.6.21.96 in the address bar.

iNote

You should configure the SYS's IP address in WAN Access of System Configuration before accessing the SYS via WAN. For details, refer to **Set WAN Access**.

- 2. Enter the user name and initial password set by the administrator.
- 3. Click Login and a Change Password window opens.
- **4.** Set a new password and confirm the password.

iNote

The password strength can be checked by the system and should meet the system requirements. If password strength is lower than the required minimum strength, you will be asked to change your password. For setting minimum password strength, refer to **Manage System Security**.

Caution

The password strength of the device can be checked by the system. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

5. Click OK.

Result

Web Client home page displays after you successfully changing the password.

4.5 Forgot Password

If you forgot the your account's password, you can reset the password and set a new password.

Perform this task when you forgot the user's password.

Steps

- **1.** Open the login page.
- 2. Enter a user name in the User Name field.
- 3. Click Forgot Password.
- 4. Set the new password for the user.
 - For admin user, enter the activation code, new password, and confirm password in the Reset Password window.
 - For normal user, if the email address is set when adding the user and email server is tested successfully, click **Get Code**, and then you will receive an email with the verification code in your email address. Within 10 minutes, enter the received verification code, new password, and confirm password to set the new password for the normal user.

i Note

If the email address is not set for the normal user, contact the admin user to reset the password for you and change the password when login. See **Reset Password for Normal User** for details.

- For domain user, contact the admin user to reset the password.

iNote

The password strength can be checked by the system and should meet the system requirements. If password strength is lower than the required minimum strength, you will be asked to change your password. For setting minimum password strength, refer to *Manage System Security*.

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

5. Click OK.

Chapter 5 Download Mobile Client

On the login page of Web Client, you can scan the QR code to download the Mobile Client that is used for accessing the system via mobile terminal (e.g., mobile phone).

Perform this task when you need to download the Mobile Client.

iNote

You can also search and download the Mobile Client in the App Store or Google Play.

Steps

1. In the address bar of the web browser, enter the address of the PC running SYS service and press **Enter** key.

Example

If the IP address of PC running SYS is 172.6.21.96, and you should enter http://172.6.21.96 in the address bar.

iNote

You should configure the SYS's IP address in WAN Access of System Configuration before accessing the SYS via WAN. For details, refer to **Set WAN Access**.

2. Scan the corresponding QR code with your mobile terminal to download the Mobile Client.

Chapter 6 Web Control

For accessing the Web Client via web browser, you must install a web control on the PC on which you access the Web Client when performing some functions, e.g., live view, playback, and searching online devices. Web Client automatically asks you to install the web control when you want to access the corresponding functions, and you can follow the prompts to install it on the PC.

Chapter 7 Wizard

The wizard can guide you to go through the basic operations of the system, including adding the encoding devices, adding access control devices, configuring event parameters, and managing the users.

Click 🕤 on Home page to enter the Start Wizard page.

Video

You can add the active online encoding devices in the same local subnet with the Web Client, add the devices by IP address, IP segment, or port segment, and import cameras in batch, etc. See *Manage Encoding Device* for detailed configuration.

Access Control

You can add the access control devices to the system for further operations, and set the access permission for persons to access the door, etc. See *Manage Access Control Device* for detailed configuration.

Event

You can configure the detected events with linkage actions for notification. For example, when motion is detected, it will trigger a user-defined event. See *Configure Event and Alarm* for detailed configuration.

User

You can add multiple user accounts to the system for accessing through Web Client, Control Client, or Mobile Client, and you are allowed to assign different roles for different users. The roles can be specified with different permissions. Refer to *Manage Role and User* for detailed configuration.

Chapter 8 Manage License

After installing HikCentral Professional, you have a temporary License for a specified number of cameras and limited functions. To ensure the proper use of HikCentral Professional, you can activate the SYS to access more functions and manage more devices. If you do not want to activate the SYS now, you can skip this chapter and activate the system later.

Two types of License are available for HikCentral Professional:

- Base: You need to purchase at least one basic License to activate the HikCentral Professional.
- **Expansion:** If you want to increase the capability of your system (e.g., connect more cameras), you can purchase an expanded License to get additional features.

iNote

- Only the admin user can perform the activation, update, and deactivation operation.
- If you encounter any problems during activation, update, and deactivation, please send the server logs to our technical support engineers.

8.1 Activate License - Online

If the SYS server to be activated can properly connect to the Internet, you can activate the SYS server in online mode.

Steps

iNote

If you activate the system by the License with server distributed deployment function, you cannot switch the system to server central deployment.

1. Log in to HikCentral Professional via the Web Client. Refer to Login via Web Client .

2. Click Online Activation in the License area to open the License configuration window.

Online Activation			×
*Activation Code		+	-
Hot Spare	OFF		
		ок	Cancel

Figure 8-1 License Configuration Window

3. Enter the activation code received when you purchased your License.

iNote

If you have purchased more than one Licenses, you can click + and enter other activation codes.

4. Optional: Set the **Hot Spare** switch to **ON** and input the required parameters if you want to build a hot spare system.

i Note

- You must select Hot Spare mode when you install the system.
- For how to build the hot spare system, please contact our technical support engineers.
- 5. Click OK and the License Agreement dialog opens.
- 6. Read the License Agreement.
 - If you accept the terms of the License Agreement, check I accept the terms of the agreement and click OK to continue.
 - If you do not accept the agreement, click **Cancel** to cancel the activation.

Result

The prompt **Operation completed** will appear when the License is activated.

8.2 Activate License - Offline

If the SYS server to be activated cannot connect to the Internet, you can activate the License in offline mode.

Steps

∎Note

If you activate the system by the License with server distributed deployment function, you cannot switch the system to server central deployment.

- 1. Log in to HikCentral Professional via the Web Client. Refer to Login via Web Client .
- 2. Click Export the license request file in the License area to open the License configuration window.

Export File		×
*Activation Code		+
Hot Spare	OFF	
	Export	Cancel

Figure 8-2 License Configuration Window

3. Enter the activation code received when you purchased your License.

iNote

If you have purchased more than one License, you can click + and enter other activation codes.

4. Optional: Set the **Hot Spare** switch to **ON** and input the required parameters if you want to build a hot spare system.

iNote

- You must select Hot Spare mode when you install the system.
- For how to build the hot spare system, please contact Hikvision's technical support engineers.
- 5. Click Export and save the request file to the proper directory or the removable storage medium (e.g., USB flash disk).
- 6. Copy the request file to the PC that can connect to the Internet.

iNote

If the PC accessing HikCentral Professional via the Web Client can connect to the Internet, you can skip this step.

- Enter HIKVISION's website (<u>http://www.hikvision.com/en</u>) and go to VMS → VMS Support → License Management page.
- 8. Log into to your account.
- **9.** Select **How to Activate Your Account** and click **Browse** at the bottom of the page to select the license request file exported in step 5.
- **10.** In the pop-up dialog, click **Download** to download the generated activation file and set the name and saving path.
- **11.** Save the activation file to the proper directory of the PC that accesses HikCentral Professional via the Web Client.
- **12.** In the License configuration window, click **Import the activation file** to import the activation file and the License Agreement dialog opens.
- 13. Read the License Agreement.
 - If you accept the terms of the license agreement, check the I accept the terms of the agreement and click OK to continue.
 - If you do not accept the agreement, click **Cancel** to cancel the activation.

Result

The prompt **Operation completed** will appear when the SYS server is successfully activated.

8.3 Update License - Online

As your project grows, you may need to increase the connectable number of resources (e.g., cameras) for your HikCentral Professional. If the SYS to be updated can properly connect to the Internet, you can update the License in online mode.

Before You Start

Contact your dealer or our sales team to purchase a License for additional features

Steps

- 1. Log in to HikCentral Professional via the Web Client. Refer to Login via Web Client for details.
- 2. Click Update License at the License area to open the update panel.
- **3.** Enter the activation code received when you purchase your License.

iNote

If you have purchased more than one Licenses, you can click + and enter other activation codes.

- 4. Click Update and the License Agreement dialog opens.
- **5.** Read the License Agreement.
 - If you accept the terms of the license agreement, check I accept the terms of the agreement and click **OK** to continue.
 - If you do not accept the agreement, click **Cancel** to cancel the update.

Result

The prompt **Operation completed** will appear when the SYS is successfully updated.

8.4 Update License - Offline

As your project grows, you may need to increase the connectable number of cameras for your HikCentral Professional. If the SYS to be updated cannot connect to the Internet, you can update the system in offline mode.

Before You Start

Contact your dealer or our sales team to purchase a License for additional features.

Steps

- 1. Log in to HikCentral Professional via the Web Client. Refer to Login via Web Client for details.
- 2. Click Update License in the License area to open the update panel.
- **3.** Click **Export the license request file** in the License area to open the License configuration window.
- **4.** Input the activation code of your additional License.

iNote

If you have purchased more than one License, you can click + and enter other activation codes.

- 5. Click **Export** and save the request file to the proper directory or the removable storage medium (e.g., USB flash disk).
- 6. Copy the request file to the PC that can connect to the Internet.

iNote

If the PC accessing HikCentral Professional via the Web Client can connect to the Internet, you can skip this step.

- Enter HIKVISION's website (<u>http://www.hikvision.com/en</u>) and go to VMS → VMS Support → License Management page.
- 8. Login to your account.

- **9.** Select **How to Update Your Account** and click **Browse** at the bottom of the page to select the license request file exported in step 5.
- **10.** Click **Submit** to generate the update file.
- **11.** In the pop-up dialog, click **Download** to download the generated update file and set the name and saving path.
- **12.** Save the update file to the proper directory of the PC that accesses HikCentral Professional via the Web Client.
- **13.** In the License configuration window, click **Import the update file** to import the update file and the License Agreement dialog opens.
- **14.** Read the License Agreement.
 - If you accept the terms of the license agreement, check I accept the terms of the agreement and click **OK** to continue.
 - If you do not accept the agreement, click **Cancel** to cancel the update.

Result

The prompt **Operation completed** will appear when the SYS is successfully updated.

8.5 Deactivate License - Online

If you want to run the SYS on another PC or server, you should deactivate the SYS first and then activate the other SYS again. If the SYS to be deactivated can properly connect to the Internet, you can deactivate the License in online mode.

Steps

- 1. Log in to HikCentral Professional via the Web Client. Refer to Login via Web Client .
- 2. Click Deactivate License in the License area to open the deactivation panel.
- 3. Click Online Deactivation and check the activation code(s) to be deactivated.
- 4. Click OK to deactivate the license.

Result

The prompt **Operation completed** will appear when the SYS is successfully deactivated. You can activate another SYS with the License.

8.6 Deactivate License - Offline

If you want to run the SYS on another PC or server, you should deactivate the SYS first and then activate the SYS again. If the SYS to be deactivated cannot connect to the Internet, you can deactivate the License in offline mode.

Steps

- 1. Log in to the HikCentral Professional via Web Client. Refer to Login via Web Client for details.
- 2. Click Deactivate License at the License area to unfold the deactivation panel.
- 3. Click Export the license request file and select the activation code(s) to be deactivated.

- **4.** Click **Export** and save the request file to the proper directory or the removable storage medium (e.g., USB flash disk).
- 5. Copy the request file to the PC that can connect to the Internet.

iNote

If the PC accessing the HikCentral Professional via Web Client can connect to the Internet, you can skip this step.

- Enter HIKVISION's website (<u>http://www.hikvision.com/en</u>) and go to VMS → Support → License Management page.
- **7.** Login with your account.
- **8.** Select **How to Deactivate Your Account** and click **Browse** at the bottom of the page to select the license request file exported in step 4.
- **9.** In the pop-up dialog, click **Download** to download the generated deactivation file and set the name and saving path.
- **10.** Save the deactivation file to the proper directory of the PC that accesses the HikCentral Professional via Web Client.
- **11.** In the License configuration window, click **Import the deactivation file** to import the deactivation file.
- **12.** Deactivate again to complete the deactivation operation.

1) A new request file will be generated automatically and ask you to export it again, or you can click **Export the license request file** to export request file manually.

2)Save the request file to the proper directory or the removable storage medium and perform step 4-9 again to complete the deactivation operation.

Result

The prompt **Operation completed** will pop up when the SYS is successfully deactivated. You can activate other SYS with the License.

Chapter 9 Manage Resource

HikCentral Professional supports multiple resource types, such as encoding device, access control device, Remote Site, decoding device and Smart Wall. After adding them to the system, you can manage them, configure required settings and perform further operations. For example, you can add encoding devices for live view, playback, recording settings, event configuration, etc., add access control devices for access control, time and attendance management, etc., add Remote Site for central management of multiple systems, add Recording Server for storing the videos, add Streaming Server for getting the video data stream from the server, and add Smart Wall for displaying decoded video on smart wall.

9.1 Create Password for Inactive Device(s)

Because of simple default password, the devices may be accessed by the unauthorized user easily. For more security purpose, the default password is not provided for some devices. You are required to create the password to activate them before adding them and performing some operations on them via the system . Besides activating the device one by one, you can also deal with multiple ones at the same time. The devices which are activated in a batch will have the same password

Before You Start

- Make sure the devices (cameras, DVR, etc.) you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.
- This function should be supported by the device. Make sure the devices you want to activate support this function.

Perform this task when you need to activate the detected online devices. Here we take creating password for the encoding device as an example.

Steps

1. Click Physical View → Encoding Device to enter the Encoding Device Management page.

iNote

- For access control devices, click Physical View → Access Control Device to enter the access control device management page.
- For security control devices, click Physical View → Security Control Device to enter the security control device management page.
- For decoding devices, click Physical View → Smart Wall. On the Decoding Device area, click Add and check Online Devices as Adding Mode.

The detected online devices list in the online device area.

2. View the device status (shown on Security column) and select one or multiple inactive devices.

- **3.** Click \bigcirc to open the Device Activation window.
- 4. Create a password in the password field, and confirm the password.

ACaution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

5. Click Save to create the password for the device.

An **Operation completed.** message is displayed when the password is set successfully.

6. Click ⊘ in the Operation column of the device and change its IP address, subnet mask, and gateway to the same subnet with your computer if you need to add the device to the system. Refer to *Edit Online Device's Network Information*.

9.2 Edit Online Device's Network Information

The online devices, which have IP addresses in the same local subnet with SYS server or Web Client, can be detected by HikCentral Professional. For the detected online devices, you can edit their network information as desired via HikCentral Professional remotely and conveniently. For example, change the device IP address due to the changes of the network.

Before You Start

For some devices, you must activate it before editing its network information. Refer to **Create Password for Inactive Device(s)** for details.

Perform this task when you need to edit the network information for the detected online devices. Here we take editing encoding device as an example.

Steps

1. Click Physical View → Encoding Device to enter the Encoding Device Management page.

iNote

- For access control devices, click Physical View → Access Control Device to enter the access control device management page.
- For security control devices, click Physical View → Security Control Device to enter the security control device management page.
- For decoding devices, click **Physical View** → **Smart Wall** . On the Decoding Device area, click **Add** and check **Online Devices** as Adding Mode.
- 2. In the Online Device area, select a network type.

Server Network

The detected online devices in the same local subnet with the SYS server will list in the Online Device area.

Local Network

The detected online devices in the same local subnet with the Web Client will list in the Online Device area.

- **3.** View the device status (shown on Security column) and click Z in the Operation column of an active device.
- **4.** Change the required parameters, such as IP address, device port, HTTP port, subnet mask, and gateway.

iNote

The parameters may vary for different device types.

- 5. Click ⊘ .
- 6. Enter device's password.
- 7. Click Save.

9.3 Manage Encoding Device

The encoding devices (e.g., camera, NVR, DVR) can be added to the system for management, including editing and deleting the devices, remote configuration, changing online devices' password, etc. You can also perform further operations based on the added devices, such as live view, video recording, and event settings,

9.3.1 Add Online Device

The system can perform an automated detection for available encoding devices in the network where the Web Client or server is located, which makes the devices' information about themselves (e.g., IP address) recognized by the system. Based on the information, you can add the devices quickly.

You can add one online devices at a time, or add multiple online devices in a batch.

iNote

You should install the web control according to the instructions and then the online device detection function is available.
Add an Online Encoding Device

When you want to add one of the detected online devices at present or add a few of these devices with different user names and passwords, you need to select only one device every time to add it to HikCentral Professional. The IP address, port number and user name will be recognized automatically, which may reduce some manual operations in a way.

Before You Start

- Make sure the devices (cameras, DVR, etc.) you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.
- The devices to be added should be activated. Refer to *Create Password for Inactive Device(s)* for details about activating devices.

Steps

- 1. Click Physical View → Encoding Device to enter the Encoding Device Management page.
- 2. In the Online Device area, select a network type.

Server Network

As the default selection, the detected online devices in the same local subnet with the SYS server will be listed in the Online Device area.

Local Network

The detected online devices in the same local subnet with the Web Client will be listed in the Online Device area.

- 3. In the Online Device area, select the active device to be added.
- 4. Click Add to Device List to open the Add Online Device window.
- **5.** Set the required information.

Device Address

The IP address of the device, which is shown automatically.

Device Port

The port number of the device, which is shown automatically. The default port number is 8000.

Verify Stream Encryption Key

Switch Verify Stream Encryption Key to on, and enter stream encryption key in Stream Encryption Key on Device field. Then when starting live view or remote playback of the device, the client will verify the key stored in SYS server for security purpose.

iNote

This function should be supported by the devices. Refer to the user manual of the device for getting key.

Alias

Create a descriptive name for the device. For example, you can use an alias that can show the location or feature of the device.

User Name

The user name for administrator account created when activating the device or the added non-admin account such as operator. When adding the device to HikCentral Professional using the non-admin account, your permissions may restrict your access to certain features.

Password

The password required to access the account.

Caution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product. Proper configuration of all passwords and other security settings is the responsibility of the

installer and/or end-user.

- **6.** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zones of the device and the SYS server are not consistent.
- 7. Optional: Switch Add Channel to Area to on to import the channels of the added devices to an area.

iNote

- You can import all the channels including cameras, alarm inputs and alarm outputs, or the specified camera(s) to the corresponding area.
- You can create a new area by the device name or select an existing area.
- If you do not import channels to area, you cannot perform operations such as live view, playback, event settings, etc., for the cameras.
- **8. Optional:** If you choose to add channels to area, select a Streaming Server to get the video stream of the channels via the server.

iNote

You can check **Wall Display via Streaming Server** to get stream via the selected Streaming Server when displaying live view on the smart wall.

9. Optional: If you choose to add channels to area, enable the **Video Storage** function and select the storage location for recording.

Encoding Device

The video files will be stored in the device according to the configured recording schedule.

Hybrid Storage Area Network

The video files will be stored in the Hybrid Storage Area Network according to the configured recording schedule.

Cloud Storage Server

The video files will be stored in the Cloud Storage Server according to the configured recording schedule.

pStor

According to the configured recording schedule, the video files will be stored in the pStor, which is the storage access service for managing local HDDs and logical disks.

iNote

- For adding the encoding device by domain name, the video files can only be stored in the local storage of the device.
- Configure the Hybrid Storage Area Network, Cloud Storage Server or pStor in advance, or its storage location cannot display in the drop-down list. You can click **Add New** to add a new Hybrid Storage Area Network, Cloud Storage Server or pStor.
- **10.** Set the quick recording schedule for added channels.
 - Check **Get Device's Recording Settings** to get the recording schedule from the device and the channels of the device will start recording according to the schedule.
 - Uncheck Get Device's Recording Settings and set the required information, such as recording schedule template, stream type, etc. Refer to Configure Recording for Cameras on Current Site for details.
- 11. Click Add.
- **12. Optional:** Perform the following operations after adding the online device.

Remote	Click 🛞 to set the remote configurations of the corresponding device.	
Configurations	i Note	
	For detailed operation steps about remote configuration, see the user manual of the device.	
Change Password	Select the added device(s) and click 🔑 to change the password for the device(s).	
	i Note	
	 You can only change the password for online HIKVISION devices currently. 	
	 If the devices have the same password, you can select multiple devices to change the password for them at the same time. 	

What to do next

For facial recognition camera/ANPR camera/thermal camera (report supported), turn to Home page, click **License Details** \rightarrow **Configuration** \rightarrow **Add**, and then select the added cameras as these three types of cameras respectively. Otherwise, these cameras' functions (facial recognition, plate recognition, and temperature report) cannot be performed normally in the system.

Add Online Encoding Devices in a Batch

For the detected online encoding devices, if they have the same user name and password, you can add multiple devices to HikCentral Professional at a time. The devices added by this method will be set as the same channel information, which you can edit later if required.

Before You Start

- Make sure the devices (cameras, DVR, etc.) you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.
- The devices to be added should be activated. Refer to *Create Password for Inactive Device(s)* for details about activating devices.

Perform this task when you need to add the detected online devices in a batch.

Steps

- 1. Click Physical View → Encoding Device to enter the Encoding Device Management page.
- 2. In the Online Device area, select a network type.

Server Network

As the default selection, the detected online devices in the same local subnet with the SYS server will list in the Online Device area.

Local Network

The detected online devices in the same local subnet with the Web Client will list in the Online Device area.

- **3.** In the Online Device area, check the active devices to be added.
- 4. Click Add to Device List to open the Add Online Device dialog.
- 5. Optional: Switch Verify Stream Encryption Key to on, and enter stream encryption key in Stream Encryption Key on Device field.

Then when starting live view or remote playback of the camera, the client will verify the key stored in SYS server for security purpose.

i Note

This function should be supported by the devices. Refer to the user manual of the device for getting key.

6. Enter the same user name and password.

User Name

The user name for administrator account created when activating the device or the added non-admin account such as operator. When adding the device to HikCentral Professional using the non-admin account, your permissions may restrict your access to certain features.

Password

The password required to access the account.

Caution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

- **7.** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zones of the device and the SYS server are not consistent.
- 8. Optional: Switch Add Channel to Area to on to import the channels of the added devices to an area.

iNote

- You can import all the channels including cameras, alarm inputs and alarm outputs, or the specified camera(s) to the corresponding area.
- You can create a new area by the device name or select an existing area.
- If you do not import channels to area, you cannot perform operations such as live view, playback, event settings, etc., for the cameras.
- 9. Optional: Select a Streaming Server to get the video stream of the channels via the server.

i Note

You can check **Wall Display via Streaming Server** to get stream via the selected streaming server when starting live view on the smart wall.

10. Click Add.

11. Optional: Perform the following operations after adding the online devices in a batch.

Remote
Configurati

Click to set the remote configurations of the corresponding device.

Configurations

i Note

For details about remote configuration, see the user manual of the device.

Change Password	Select the added device(s) and click 🔑 to change the password for the device(s).
	i Note
	 You can only change the password for online HIKVISION devices currently. If the devices have the same password, you can select multiple

devices to change the password for them at the same time.

What to do next

For facial recognition camera/ANPR camera/thermal camera (report supported), turn to Home page, click **License Details** \rightarrow **Configuration** \rightarrow **Add**, and then select the added cameras as these three types of cameras respectively. Otherwise, these cameras' functions (facial recognition, plate recognition, and temperature report) cannot be performed normally in the system.

9.3.2 Add Encoding Device by IP Address or Domain Name

When you know the IP address or domain name of a device, you can add it to the system by specifying the IP address (or domain name), user name, password, etc.

Before You Start

Make sure the devices (cameras, DVR, etc.) you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Perform this task when you need to add a device by IP address or domain name.

Steps

- 1. Click Physical View → Encoding Device to enter the Encoding Device Management page.
- 2. Click Add to enter the Add Encoding Device page.

G Add Encoding Dev Basic Information	ice	
* Access Protocol	Hikvision Private Protocol 🔹	
* Adding Mode		
	 IP Segment Port Segment 	
	Batch Import	
* Device Address		
* Device Port	8000	
 Verify Stream Encryption Key 	0	
* Alias		
* User Name	admin	
* Password	······	•
	Stron	9
Time Zone		
Time Zone of Device	(UTC+08:00) Beijing, Chongqing 🔻	View
	(i) When the time zone of the device an device.	nd the system are not consistent, the system
Channel Information		
(i) Add Channel to Area		
	Add Add and C	ontinue Cancel

Figure 9-1 Add Encoding Device Page

- **3.** Select **Hikvision Private Protocol/Hikvision EHome Protocol** to add a Hikvision device and select **ONVIF Protocol** to add a third-party device.
- 4. Select IP/Domain as the adding mode.
- **5.** Enter the required information.

Device Address

The IP address or domain name of the device.

Device Port

By default, the device port No. is 8000.

Verify Stream Encryption Key

This button is for **Hikvision Private Protocol** only. Switch **Verify Stream Encryption Key** to on, and enter the stream encryption key in the following **Stream Encryption Key on Device** field.

Then when starting live view or remote playback of the device, the client will verify the key stored in SYS server for security purpose.

iNote

This function should be supported by the devices. For details about getting the key, refer to the user manual of the device.

Alias

Create a descriptive name for the device. For example, you can use an alias that can show the location or feature of the device.

ACaution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

- **6. Optional:** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zones of the device and the SYS server are not consistent.
- 7. Optional: Switch Add Channel to Area to on to import the channels of the added devices to an area.

iNote

- You can import all the channels including cameras, alarm inputs and alarm outputs, or the specified camera(s) to the corresponding area.
- You can create a new area by the device name or select an existing area.
- If you do not import channels to area, you cannot perform operations such as live view, playback, event settings, etc., for the cameras.
- **8. Optional:** If you choose to add channels to area, select a Streaming Server to get the video stream of the channels via the server.

iNote

You can check **Wall Display via Streaming Server** to get stream via the selected Streaming Server when displaying live view on the smart wall.

9. Optional: If you choose to add channels to area, enable the **Video Storage** function and select the storage location for recording.

Encoding Device

The video files will be stored in the device according to the configured recording schedule.

Hybrid Storage Area Network

The video files will be stored in the Hybrid Storage Area Network according to the configured recording schedule.

Cloud Storage Server

The video files will be stored in the Cloud Storage Server according to the configured recording schedule.

pStor

According to the configured recording schedule, the video files will be stored in the pStor, which is the storage access service for managing local HDDs and logical disks.

iNote

- For adding the encoding device by domain name, the video files can only be stored in the local storage of the device.
- Configure the Hybrid Storage Area Network, Cloud Storage Server or pStor in advance, or its storage location cannot display in the drop-down list. You can click **Add New** to add a new Hybrid Storage Area Network, Cloud Storage Server or pStor.
- **10.** Set the quick recording schedule for added channels.
 - Check **Get Device's Recording Settings** to get the recording schedule from the device and the channels of the device will start recording according to the schedule.
 - Uncheck Get Device's Recording Settings and set the required information, such as recording schedule template, stream type, etc. Refer to Configure Recording for Cameras on Current Site for details.
- **11.** Finish adding the device.
 - Click Add to add the encoding device and back to the encoding device list page.
 - Click Add and Continue to save the settings and continue to add other encoding devices.
- **12. Optional:** Perform the following operation(s) after adding the devices.

Remote	Click 🐵 to set the remote configurations of the corresponding device.	
Configurations	i Note	
	For detailed operation steps for the remote configuration, see the user manual of the device.	
Change Password	Select the added device(s) and click $ ot\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!$	
	i Note	
	 You can only change the password for online HIKVISION devices currently. 	
	 If the devices have the same password, you can select multiple devices to change the password for them at the same time. 	

What to do next

For facial recognition camera/ANPR camera/thermal camera (report supported), turn to Home page, click **License Details** \rightarrow **Configuration** \rightarrow **Add**, and then select the added cameras as these three types of cameras respectively. Otherwise, these cameras' functions (facial recognition, plate recognition, and temperature report) cannot be performed normally in the system.

9.3.3 Add Encoding Devices by IP Segment

When multiple encoding devices to add have the same port number, user name and password, but have different IP addresses within a range, you can select this adding mode, and specify the IP range where your devices are located, and other related parameters. The system will scan from the start IP address to the end IP address for the devices in order to add them quickly.

Before You Start

Make sure the devices (cameras, DVR, etc.) you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Steps

- 1. Click Physical View → Encoding Device to enter the Encoding Device Management page.
- 2. Click Add to enter the Add Encoding Device page.
- 3. Select Hikvision Private Protocol/ONVIF Protocol as the Access Protocol.

iNote

Select **Hikvision Private Protocol** to add a Hikvision device, while select **ONVIF Protocol** to add a third-party device.

- 4. Select IP Segment as the adding mode.
- **5.** Enter the required information.

Device Address

Enter the start IP address and the end IP address where the devices are located.

Device Port

By default, the device port No. is 8000.

Verify Stream Encryption Key

This button is for **Hikvision Private Protocol** only. You can switch **Verify Stream Encryption Key** to on, and enter the stream encryption key in the following **Stream Encryption Key on Device** field. Then when starting live view or remote playback of the device, the client will verify the key stored inSYS server for security purpose.

iNote

This function should be supported by the devices. Refer to the User Manual of the device for getting key.

User Name

The user name for administrator created when activating the device or the added non-admin users. When adding the device to HikCentral Professional using the non-admin user, your permissions may restrict your access to certain features.

Password

The password required to access the device.

Caution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

- **6. Optional:** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zones of the device and the SYS server are not consistent.
- 7. Optional: Switch Add Channel to Area to on to import the channels of the added devices to an area.

iNote

- You can import all the channels including cameras, alarm inputs and alarm outputs, or the specified camera(s) to the corresponding area.
- You can create a new area by the device name or select an existing area.
- If you do not import channels to area, you cannot perform the live view, playback, event settings, etc., for the channels.
- **8. Optional:** If you choose to add channels to area, select a Streaming Server to get the video stream of the channels via the server.

iNote

You can check **Wall Display via Streaming Server** to get stream via the selected Streaming Server when displaying live view on the smart wall.

- 9. Set the quick recording schedule for added channels.
 - Check **Get Device's Recording Settings** to get the recording schedule from the device and the channels of the device will start recording according to the schedule.
 - Uncheck Get Device's Recording Settings and set the required information, such as recording schedule template, stream type, etc. Refer to Configure Recording for Cameras on Current Site for details.
- **10.** Finish adding the device.

- Click **Add** to add the devices of which the IP addresses are between the start IP address and end IP address and back to the device list page.
- Click Add and Continue to save the settings and continue to add other encoding devices.
- **11. Optional:** Perform the following operations after adding the devices.

Remote	Click 🐵 to set the remote configurations of the corresponding device.	
Configurations	i Note	
	For details about remote configuration, see the user manual of the device.	
Change Password	Select the added device(s) and click 🔑 to change the password for the device(s).	
	i Note	
	 You can only change the password for online HIKVISION devices currently. 	
	 If the devices have the same password, you can select multiple devices to change the password for them at the same time. 	

What to do next

For facial recognition camera/ANPR camera/thermal camera (report supported), turn to Home page, click License Details \rightarrow Configuration \rightarrow Add , and then select the added cameras as these three types of cameras respectively. Otherwise, these cameras' functions (facial recognition, plate recognition, and temperature report) cannot be performed normally in the system.

9.3.4 Add Encoding Devices by Port Segment

When multiple encoding devices to add have the same IP address, user name and password, but have different port numbers within a range, you can select this adding mode and specify the port range, IP address, user name, password, and other related parameters to add them.

Before You Start

Make sure the devices (cameras, DVR, etc.) you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Perform this task when you want to add devices by port segment.

Steps

- **1.** Click **Physical View** → **Encoding Device** to enter the Encoding Device Management page.
- 2. Click Add to enter the Add Encoding Device page.
- 3. Select Hikvision Private Protocol/ONVIF Protocol as the access protocol.

iNote

Select **Hikvision Private Protocol** to add Hikvision devices and select **ONVIF Protocol** to add third-party devices.

- 4. Select Port Segment as the adding mode.
- **5.** Enter the required information.

Device Address

Enter the IP address to add the devices which have the same IP address.

Device Port

Enter the start port No. and the end port No.

Verify Stream Encryption Key

This button is for **Hikvision Private Protocol** only. You can switch **Verify Stream Encryption Key** to on, and enter the stream encryption key in the following **Stream Encryption Key on Device** field. Then when starting live view or remote playback of the device, the client will verify the key stored in SYS server for security purpose.

iNote

This function should be supported by the devices. Refer to the user manual of the device for getting key.

User Name

The user name for administrator account created when activating the device or the added non-admin account such as operator. When adding the device to HikCentral Professional using the non-admin account, your permissions may restrict your access to certain features.

Password

The password required to access the account.

ACaution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

- **6. Optional:** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zones of the device and the SYS server are not consistent.
- 7. Optional: Switch Add Channel to Area to on to import the channels of the added devices to an area.

iNote

- You can import all the channels including cameras, alarm inputs and alarm outputs, or the specified camera(s) to the corresponding area.
- You can create a new area by the device name or select an existing area.
- If you do not import channels to area, you cannot perform the live view, playback, event settings, etc., for the channels.
- **8. Optional:** If you choose to add channels to area, select a Streaming Server to get the video stream of the channels via the server.

iNote

You can check **Wall Display via Streaming Server** to get stream via the selected streaming server when displaying live view on the smart wall.

- 9. Set the quick recording schedule for added channels.
 - Check **Get Device's Recording Settings** to get the recording schedule from the device and the channels of the device will start recording according to the schedule.
 - Uncheck Get Device's Recording Settings and set the required information, such as recording schedule template, stream type, etc. Refer to *Configure Recording for Cameras on Current Site* for details.
- **10.** Finish adding the device.
 - Click **Add** to add the devices of which the port No. is between the start port No. and end port No. and back to the device list page.
 - Click Add and Continue to save the settings and continue to add other devices.
- **11. Optional:** Perform the following operations after adding the devices.

Remote Configurations	Click 🐵 to set the remote configurations of the corresponding device.		
	i Note		
	For details about remote configuration, see the user manual of the device.		
Change Password	Select the added device(s) and click 🔑 to change the password for the device(s).		
	iNote		
	• You can only change the password for online HIKVISION devices currently.		

• If the devices have the same password, you can select multiple devices to change the password for them at the same time.

What to do next

For facial recognition camera/ANPR camera/thermal camera (report supported), turn to Home page, click **License Details** \rightarrow **Configuration** \rightarrow **Add**, and then select the added cameras as these three types of cameras respectively. Otherwise, these cameras' functions (facial recognition, plate recognition, and temperature report) cannot be performed normally in the system.

9.3.5 Add Encoding Device by Hik-Connect

With this adding mode, you can add encoding devices which have been added to Hik-Connect accout even if the devices do not have fixed IP addresses.

Before You Start

Make sure the devices (cameras, DVR, etc.) you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Perform this task when you need to add device by Hik-Connect.

Steps

- 1. Click Physical View → Encoding Device to enter the Encoding Device Management page.
- 2. Click Add to enter the Add Encoding Device page.

C Add Encoding Dev Basic Information	ice	
* Access Protocol	Hikvision Private Protocol 🔹	
* Adding Mode	O IP/Domain	
	Hik-Connect	
	IP Segment	
	 Port Segment Batch Import 	
	Batchimport	
* Device Source	New Device	
	Hik-Connect Device List	
* Hik-Connect Server Address	https://open.ezvizlife.com	
* Serial No.		
* Verification Code	Ø	
Verify Stream Encryption Key		
Stream Encryption Key on Device	Ø	
* Alias		
Allas		
* User Name	admin	
* Password	Ø	
	Risky	
Time Zone		
	Add Add and C	Continue
	Add and C	Cancer .

Figure 9-2 Add Encoding Device Page

- **3.** Select **Hikvision Private Protocol** as the Access Protocol.
- **4.** Select **Hik-Connect** as the adding mode.
- 5. Select a device source.

New Device

Add a new device to both Hik-Connect and HikCentral Professional.

Hik-Connect Device List

Add devices managed by Hik-Connect to HikCentral Professional in a batch by getting the device list.

6. Enter the required information.

Hik-Connect Server Address

Enter the address of the Hik-Connect service. By default, it's *https://open.ezvizlife.com*. Serial No.

Enter the serial No. of the device.

Verification Code

Enter the verification code of the device.

Stream Encryption Key on Device

After switching **Verify Stream Encryption Key** to on, you should enter stream encryption key in **Stream Encryption Key on Device** field. Then when starting live view or remote playback of the camera, the client will verify the key stored in the SYS server for security purpose.

iNote

This function should be supported by the devices. Refer to user manual of the device.

Alias

Create a descriptive name for the device. For example, you can use an alias that can show the location or feature of the device.

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

- **7. Optional:** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zones of the device and the SYS server are not consistent.
- 8. Switch Add Channel to Area to on to import the channels of the added devices to an area.

iNote

- You can import all the channels including cameras, alarm inputs and alarm outputs, or the specified camera(s) to the corresponding area.
- You can create a new area by the device name or select an existing area.
- If you do not import channels to area, you cannot perform the live view, playback, event settings, etc., for the channels.
- **9. Optional:** If you choose to add channels to area, select a Streaming Server to get the video stream of the channels via the server.

iNote

You can check **Wall Display via Streaming Server** to get stream via the selected Streaming Server when displaying live view on smart wall.

10. Optional: If you choose to add channels to area, enable the **Video Storage** function and select the storage location for recording.

Encoding Device

The video files will be stored in the device according to the configured recording schedule.

Hybrid Storage Area Network

The video files will be stored in the Hybrid Storage Area Network according to the configured recording schedule.

Cloud Storage Server

The video files will be stored in the Cloud Storage Server according to the configured recording schedule.

pStor

According to the configured recording schedule, the video files will be stored in the pStor, which is the storage access service for managing local HDDs and logical disks.

iNote

- For adding the encoding device by domain name, the video files can only be stored in the local storage of the device.
- Configure the Hybrid Storage Area Network, Cloud Storage Server or pStor in advance, or its storage location cannot display in the drop-down list. You can click **Add New** to add a new Hybrid Storage Area Network, Cloud Storage Server or pStor.

11. Set the quick recording schedule for added channels.

- Check **Get Device's Recording Settings** to get the recording schedule from the device and the channels of the device will start recording according to the schedule.
- Uncheck Get Device's Recording Settings and set the required information, such as recording schedule template, stream type, etc. Refer to Configure Recording for Cameras on Current Site for details.
- **12.** Finish adding the device.
 - Click Add to add the encoding device and back to the encoding device list page.
 - Click Add and Continue to save the settings and continue to add other encoding devices.
- 13. Optional: Perform the following operation(s) after adding the devices.

Remote Configurations	Click to set the remote configurations of the corresponding device.
	Note For details about remote configuration, see the user manual of the
	device.
Change Password	Select the added device(s) and click 🔑 to change the password for the device(s).

iNote

- You can only change the password for online HIKVISION devices currently.
- If the devices have the same password, you can select multiple devices to change the password for them at the same time.

What to do next

For facial recognition camera/ANPR camera/thermal camera (report supported), turn to Home page, click **License Details** \rightarrow **Configuration** \rightarrow **Add**, and then select the added cameras as these three types of cameras respectively. Otherwise, these cameras' functions (facial recognition, plate recognition, and temperature report) cannot be performed normally in the system.

9.3.6 Add Encoding Device by Device ID

For the encoding devices supporting EHome V5.0, you can add them by specifying a predefined device ID, key, etc. This is an economic choice when you need to manage an encoding device without fixed IP address by HikCentral Professional.

Before You Start

Make sure the encoding devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Steps

- 1. Click Physical View → Encoding Device to enter the Encoding Device Management page.
- 2. Click Add to enter the Add Encoding Device page.
- 3. Select Hikvision EHome Protocol as the Access Protocol.
- 4. Select **Device ID** as the adding mode.
- **5.** Enter the required the information.
- **6.** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zone of device and the SYS server are not consistent.
- 7. Optional: Switch Add Channel to Area to ON to import the channels of the added devices to an area.

i Note

- You can import all the channels including cameras, alarm inputs and alarm outputs, or the specified camera(s) to the corresponding area.
- For video access control terminal of a device, the camera on the terminal will also be imported to the corresponding area.
- You can create a new area by the device name or select an existing area.
- If you do not import channels to area, you cannot perform operations such as live view, playback, event settings, etc., for the cameras.

8. Optional: If you choose to add channels to area, select a Streaming Server to get the video stream of the channels via the server.

iNote

You can check **Wall Display via Streaming Server** to get stream via the selected Streaming Server when displaying live view on the smart wall.

9. Optional: If you choose to add channels to area, enable the **Video Storage** function and select the storage location for recording.

Encoding Device

The video files will be stored in the device according to the configured recording schedule.

Hybrid Storage Area Network

The video files will be stored in the Hybrid Storage Area Network according to the configured recording schedule.

Cloud Storage Server

The video files will be stored in the Cloud Storage Server according to the configured recording schedule.

pStor

According to the configured recording schedule, the video files will be stored in the pStor, which is the storage access service for managing local HDDs and logical disks.

iNote

- For adding the encoding device by domain name, the video files can only be stored in the local storage of the device.
- Configure the Hybrid Storage Area Network, Cloud Storage Server or pStor in advance, or its storage location cannot display in the drop-down list. You can click **Add New** to add a new Hybrid Storage Area Network, Cloud Storage Server or pStor.
- **10.** Set the quick recording schedule for added channels.
 - Check **Get Device's Recording Settings** to get the recording schedule from the device and the channels of the device will start recording according to the schedule.
 - Uncheck Get Device's Recording Settings and set the required information, such as recording schedule template, stream type, etc. Refer to *Configure Recording for Cameras on Current Site* for details.

11. Finish adding the device.

- Click Add to add the encoding device and back to the encoding device list page.
- Click Add and Continue to save the settings and continue to add other encoding devices.
- **12. Optional:** Perform the following operation(s) after adding the devices.

RemoteClick (a) to set the remote configurations of the corresponding device.Configurations

	i Note
	For detailed operation steps for the remote configuration, see the user manual of the device.
Change Password	Select the added device(s) and click 🔑 to change the password for the device(s).
	i Note
	 You can only change the password for online HIKVISION devices currently.
	 If the devices have the same password, you can select multiple devices to change the password for them at the same time.

9.3.7 Add Encoding Devices by Device ID Segment

If you need to add multiple encoding devices which have no fixed IP address and support EHome V5.0 to HikCentral Professional, you can add them to HikCentral Professional at a time after configuring a device ID segment for the devices.

Before You Start

Make sure the encoding devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Steps

- 1. Click Physical View → Encoding Device to enter the Encoding Device Management page.
- 2. Click Add to enter the Add Encoding Device page.
- 3. Select Hikvision EHome Protocol as the Access Protocol.
- 4. Select Device ID Segment as the adding mode.
- **5.** Enter the required parameters
- **6.** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zone of device and the SYS server are not consistent.
- 7. Optional: Switch Add Channel to Area to on to import the channels of the added devices to an area.

iNote

- You can import all the channels including cameras, alarm inputs and alarm outputs, or the specified camera(s) to the corresponding area.
- For video access control terminal of a device, the camera on the terminal will also be imported to the corresponding area.

- You can create a new area by the device name or select an existing area.
- If you do not import channels to area, you cannot perform operations such as live view, playback, event settings, etc., for the cameras.
- **8. Optional:** If you choose to add channels to area, select a Streaming Server to get the video stream of the channels via the server.

iNote

You can check **Wall Display via Streaming Server** to get stream via the selected Streaming Server when displaying live view on the smart wall.

9. Optional: If you choose to add channels to area, enable the **Video Storage** function and select the storage location for recording.

Encoding Device

The video files will be stored in the device according to the configured recording schedule.

Hybrid Storage Area Network

The video files will be stored in the Hybrid Storage Area Network according to the configured recording schedule.

Cloud Storage Server

The video files will be stored in the Cloud Storage Server according to the configured recording schedule.

pStor

According to the configured recording schedule, the video files will be stored in the pStor, which is the storage access service for managing local HDDs and logical disks.

iNote

- For adding the encoding device by domain name, the video files can only be stored in the local storage of the device.
- Configure the Hybrid Storage Area Network, Cloud Storage Server or pStor in advance, or its storage location cannot display in the drop-down list. You can click **Add New** to add a new Hybrid Storage Area Network, Cloud Storage Server or pStor.

10. Set the quick recording schedule for added channels.

- Check **Get Device's Recording Settings** to get the recording schedule from the device and the channels of the device will start recording according to the schedule.
- Uncheck Get Device's Recording Settings and set the required information, such as recording schedule template, stream type, etc. Refer to Configure Recording for Cameras on Current Site for details.
- **11.** Finish adding the device.
 - Click Add to add the encoding device and back to the encoding device list page.
 - Click Add and Continue to save the settings and continue to add other encoding devices.

9.3.8 Add Encoding Devices in a Batch

When there are a batch of devices to add to HikCentral Professional , you can edit the predefined template containing the required device information, and import it to add multiple devices at a time. This is also a highly effective methods if you set up several similar systems.

Before You Start

Make sure the devices (cameras, DVR, etc.) you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Perform this task when you need to add devices by importing the template which contains information of multiple devices.

Steps

- 1. Click Physical View → Encoding Device to enter the Encoding Device Management page.
- 2. Click Add to enter the Add Encoding Device page.

⊖ Add Encoding Dev	ice	
Basic Information		
* Access Protocol	Hikvision Private Protocol	
* Adding Mode	O IP/Domain	
	O IP Segment	
	 Port Segment 	
	Batch Import	
* Select File		
	Download Template	
Time Zone		
Time Zone of Device	(UTC+08:00) Beijing, Chongqing 🔻 View	
	(j) When the time zone of the device and the system a	re not consistent, the s
	device.	
	Add Add and Continue	Cancel

Figure 9-3 Add Encoding Device Page

3. Select Hikvision Private Protocol/Hikvision EHome Protocol/ as the access protocol.

iNote

Select **Hikvision Private Protocol/Hikvision EHome Protocol** to add a Hikvision device and select **ONVIF Protocol** to add a third-party device.

4. Select Batch Import as the adding mode.

- 5. Click Download Template and save the predefined template (CSV file) on your PC.
- **6.** Open the exported template file and enter the required information of the devices to be added on the corresponding column.
- 7. Click ... and select the edited file.
- **8. Optional:** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zones of the device and the SYS server are not consistent.
- 9. Finish adding devices.
 - Click **Add** to add the devices and go back to the device list page.
 - Click Add and Continue to save the settings and continue to add next batch of devices.
- **10. Optional:** Perform the following operation(s) after adding devices in a batch.

Remote	Click 💮 to set the remote configurations of the corresponding device.	
Configurations	i Note	
	For details about remote configuration, see the user manual of the device.	
Change Password	Select the added device(s) and click 🔑 to change the password for the device(s).	
	i Note	
	 You can only change the password for online HIKVISION devices currently. 	
	 If the devices have the same password, you can select multiple devices to change the password for them at the same time. 	

What to do next

For facial recognition camera/ANPR camera/thermal camera (report supported), turn to Home page, click **License Details** \rightarrow **Configuration** \rightarrow **Add**, and then select the added cameras as these three types of cameras respectively. Otherwise, these cameras' functions (facial recognition, plate recognition, and temperature report) cannot be performed normally in the system.

9.3.9 Limit Bandwidth for Video Downloading

You can limit bandwidth for video downloading of specific NVRs to save on the total bandwidth, thus ensuring the fluency of main features such as live view.

iNote

The NVR should be of V4.1.50 or later versions.

Click **Physical View** \rightarrow **Encoding Device** to enter the Encoding Device page and then select encoding device(s) and click **Edit Bandwidth for Video Downloading** to set the bandwidth upperlimit for video downloading of the selected device(s).

9.3.10 Set N+1 Hot Spare for NVR

You can form an N+1 hot spare system with several NVRs (Network Video Recorder). The system consists of several host servers and a spare server. When the host server fails, the spare server switches into operation, thus increasing the video storage reliability of HikCentral Professional.

Before You Start

- At least two online NVRs should be added to form an N+1 hot spare system. For details about adding NVR, see *Manage Encoding Device*.
- Make sure the NVRs you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

If the N+1 hot spare settings have already been configured on the NVR, click **Physical View** \rightarrow **Encoding Device** \rightarrow **N+1 Hot Spare** \rightarrow **Get Hot Spare Settings from Device** to upload the hot spare settings from the device to HikCentral Professional. If the N+1 hot spare settings haven't been configured on the device, perform the following task to set N+1 hot spare for the NVR.

Steps

iNote

- The N+1 hot spare function is only supported by NVRs and Hybrid Storage Area Networks. For details about configuring N+1 hot spare system with Hybrid Storage Area Networks, see *Set N+1 Hot Spare for Hybrid SAN*.
- The spare server cannot be selected for storing videos until it switches to host server.
- The host server cannot be set as a spare server and the spare server cannot be set as a host server.
- **1.** Click Physical View \rightarrow Encoding Device \rightarrow N+1 Hot Spare to enter the N+1 Configuration page.

⊗ N+1 Configuration

+ Add	↑↓ Get Hot Spare Settings from Device	🖹 Apply Hot Spare Settings to Device	
Spare	Host	Hot Spare Status	Operation
172.7.20.89	172.7.20.8	8 Idle	Ľ×

Figure 9-4 N+1 Configuration Page

- 2. Click Add to set N+1 hot spare.
- 3. Select a NVR in the Spare drop-down list to set it as the spare server.
- **4.** Select the NVR(s) in the **Host** field to set them as the host server.
- 5. Click Add.

iNote

The recording schedules configured on the NVR will be deleted after setting it as the spare Recording Server.

- 6. Click Apply Hot Spare Settings to Device to apply the Hot Spare settings to the devices to take effect.
- 7. Optional: Perform the following operations after setting the hot spare.

Edit Hot Spare	Click 📝 on the Operation column, and you can edit the spare and host settings.
Delete Hot	Click $ imes$ on the Operation column to cancel the N+1 hot spare settings.
Spare	i Note
	Canceling the N+1 hot spare will cancel all the host-spare associations and clear the recording schedule on the spare server.

9.4 Manage Access Control Device

You can add the access control devices to the system for access permission configuration, time and attendance management, etc.

9.4.1 Add Online Device

The active online access control devices in the same local subnet with the current Web Client or SYS server will be displayed on a list. You can add one online device one by one, or add multiple online devices in a batch.

iNote

You should install the web control according to the instructions and then the online device detection function is available.

Add an Online Access Control Device

You can add the detected online access control devices, and here we introduce the process for adding one device.

Before You Start

- Make sure the access control devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.
- The devices to be added should be activated. Refer to *Create Password for Inactive Device(s)* for detailed operation about activating devices.

Steps

 Click Physical View → Access Control Device to enter the Access Control Device Management page. 2. In the Online Device area, select a network type.

Server Network

As the default selection, the detected online devices in the same local subnet with the SYS server will be listed in the Online Device area.

Local Network

The detected online devices in the same local subnet with the current Web Client will be listed in the Online Device area.

iNote

For the DS-K5600 face recognition series, the displayed online devices are different according to the working mode setting. Refer to **Set Working Mode** for details.

- **3.** In the Online Device area, select the active device to be added.
- 4. Click Add to Device List to open the Add Online Device window.
- **5.** Enter the required information.

iNote

The device's IP address can be automatically shown in **Device Address** field.

Caution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

- **6.** Select a time zone for the device(s) in drop-down list of **Time Zone of Device** when the time zone of device and the SYS server are not consistent.
- 7. Optional: Switch Add Channel to Area to on to import the access points of the added device to an area.

iNote

- You can import all the access points or the specified access point(s) of the device to the corresponding area.
- For video access control terminal of a device, the camera on the terminal will also be imported to the corresponding area.
- You can create a new area by the device name or select an existing area.
- If you do not import any access point to an area, you cannot perform further configurations for the access point.

8. Click Add.

9. Optional: Perform the following operations after adding the online device.

Remote Configurations	Click 🚳 to edit the time parameters, reboot the device, restore the device, or set other configurations of the corresponding device.
	iNote
	 For some access control devices, you can customize Wiegand communication rules for connecting the customized Wiegand card reader.
	 After restoring the device, you need to apply the parameters in the system to the device (click Apply Application Settings on Access Control Device Management page).
	 For details about remote configuration, see the user manual of the device.
Change Password	Select the added device(s) and click 🔑 to change the password for the device(s).
	iNote
	 You can only change the password for online HIKVISION devices currently.
	 If the devices have the same password, you can select multiple devices to change the password for them at the same time.
Apply Application Settings	After restoring the database or device's default configurations, if the parameters (such as anti-passback and opening door with first card) in the system are inconsistent with the parameters on the access control device(s), a red icon () will be displayed on the right side of the Apply Application Settings . Click Apply Application Settings to clear the original data on the device and apply the current settings in system to the device(s).

Add Online Access Control Devices in a Batch

For the detected online access control devices, if they have the same password for the same user name, you can add multiple devices at a time.

Before You Start

- Make sure the access control devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.
- The devices to be added should be activated. Refer to *Create Password for Inactive Device(s)* for detailed operation about activating devices.

Steps

- Click Physical View → Access Control Device to enter the Access Control Device Management page.
- 2. In the Online Device area, select a network type.

Server Network

The detected online devices in the same local subnet with the SYS server will list in the Online Device area.

Local Network

The detected online devices in the same local subnet with the Web Client will list in the Online Device area.

iNote

For the DS-K5600 face recognition series, the displayed online devices are different according to the working mode setting. Refer to *Set Working Mode* for details.

- **3.** In the Online Device area, select the active devices to be added.
- 4. Click Add to Device List to open the Add Online Device window.
- 5. Switch Verify Stream Encryption Key to on, and enter the stream encryption key in the following Stream Encryption Key on Device field. Then when starting live view or remote playback of the device, the client will verify the key stored in SYS server for security purpose.
- 6. Enter the required information.

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

- **7.** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zones of the device and the SYS server are not consistent.
- 8. Optional: Switch the Add Channel to Area to on to import the access points of the added devices to an area.

iNote

- You can create a new area by the device name or select an existing area.
- For video access control terminal of a device, the camera on the terminal will also be imported to the corresponding area.
- If you do not import access points to area, you cannot perform the further operations for the access points.

9. Optional: Select a Streaming Server to get the video stream of the channels via the server.

iNote

You can check **Wall Display via Streaming Server** to get stream via the selected streaming server when starting live view on the smart wall.

10. Optional: If you choose to add channels to area, enable the **Video Storage** function and select the storage location for recording.

Encoding Device

The video files will be stored in the device according to the configured recording schedule.

Hybrid Storage Area Network

The video files will be stored in the Hybrid Storage Area Network according to the configured recording schedule.

Cloud Storage Server

The video files will be stored in the Cloud Storage Server according to the configured recording schedule.

pStor

According to the configured recording schedule, the video files will be stored in the pStor, which is the storage access service for managing local HDDs and logical disks.

iNote

- For adding the encoding device by domain name, the video files can only be stored in the local storage of the device.
- Configure the Hybrid Storage Area Network, Cloud Storage Server or pStor in advance, or its storage location cannot display in the drop-down list. You can click **Add New** to add a new Hybrid Storage Area Network, Cloud Storage Server or pStor.
- **11.** Set the quick recording schedule for added channels.
 - Check **Get Device's Recording Settings** to get the recording schedule from the device and the channels of the device will start recording according to the schedule.
 - Uncheck Get Device's Recording Settings and set the required information, such as recording schedule template, stream type, etc. Refer to Configure Recording for Cameras on Current Site for details.

12. Click Add.

13. Perform the following operation(s) after adding the devices.

Remote Configurations	Click 🚳 to edit the time parameters, reboot the device, restore the device, or set other configurations of the corresponding device.
	i Note
	 For some access control devices, you can customize Wiegand communication rules for connecting the customized Wiegand card reader.
	 After restoring the device, you need to apply the parameters in the system to the device (click Apply Application Settings on Access Control Device Management page).
	 For details about remote configuration, see the user manual of the device.
Change Password	Select the added device(s) and click 🔑 to change the password for the device(s).
	iNote
	 You can only change the password for online HIKVISION devices currently.
	 If the devices have the same password, you can select multiple devices to change the password for them at the same time.
Apply Application Settings	After restoring the database or device's default configurations, if the parameters (such as anti-passback and opening door with first card) in the system are inconsistent with the parameters on the access control device(s), a red icon ① will be displayed on the right side of the Apply Application Settings . Click Apply Application Settings to clear the original data on the device and apply the current settings in system to the device(s).

9.4.2 Add Access Control Device by IP Address

When you know the IP address of an access control device to add, you can add the device to the system by specifying its IP address, user name, password, etc.

Before You Start

Make sure the access control devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Steps

 Click Physical View → Access Control Device to enter the Access Control Device Management page.

- 2. Click Add to enter the Add Access Control Device page.
- 3. Select Hikvision Private Protocol as the access protocol.
- 4. Select IP Address as the adding mode.
- **5.** Enter the required parameters.

i Note

By default, the device port number is 8000.

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

- **6. Optional:** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zones of the device and the SYS server are not consistent.
- 7. Optional: Switch Add Channel to Area to on to import the access points of the added devices to an area.

iNote

- You can import all the access points or the specified access point(s) of the device to the corresponding area.
- For video access control terminal of a device, the camera on the terminal will also be imported to the corresponding area.
- You can create a new area by the device name or select an existing area.
- If you do not import any access point to an area, you cannot perform further operations for the access point.
- 8. Finish adding the device.
 - Click Add to add the access control device and back to the access control device list page.
 - Click Add and Continue to save the settings and continue to add next access control device.
- 9. Perform the following operation(s) after adding the devices.

RemoteClick (a) to edit the time parameters, reboot the device, restore the
device, or set other configurations of the corresponding device.

	i Note
	 For some access control devices, you can customize Wiegand communication rules for connecting the customized Wiegand card reader.
	 After restoring the device, you need to apply the parameters in the system to the device (click Apply Application Settings on Access Control Device Management page).
	 For details about remote configuration, see the user manual of the device.
Change Password	Select the added device(s) and click 🔑 to change the password for the device(s).
	i Note
	 You can only change the password for online HIKVISION devices currently.
	• If the devices have the same password, you can select multiple devices to change the password for them at the same time.
Apply Application Settings	After restoring the database or device's default configurations, if the parameters (such as anti-passback and opening door with first card) in the system are inconsistent with the parameters on the access control device(s), a red icon () will be displayed on the right side of the Apply Application Settings . Click Apply Application Settings to clear the original data on the device and apply the current settings in system to the device(s).

9.4.3 Add Access Control Devices by IP Segment

If the access control devices share a user name and password, and their IP addresses are in an IP segment, you can add them to the system by specifying the start IP address and the end IP address, user name, password, etc.

Before You Start

Make sure the access control devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Steps

- Click Physical View → Access Control Device to enter the Access Control Device Management page.
- 2. Click Add to enter the Add Access Control Device page.

- 3. Select Hikvision Private Protocol as the access protocol.
- 4. Select IP Segment as the adding mode.
- 5. Enter the required the information.

iNote

By default, the device port number is 8000.

ACaution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

- **6. Optional:** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zone of device and the SYS server are not consistent.
- 7. Optional: Switch Add Channel to Area to on to import the access points of the added devices to an area.

iNote

- You can create a new area by the device name or select an existing area.
- For video access control terminal of a device, the camera on the terminal will also be imported to the corresponding area.
- If you do not import any access point to an area, you cannot perform further operations for the access point.
- 8. Finish adding the device.
 - Click **Add** to add the access control device and back to the access control device list page.
 - Click Add and Continue to save the settings and continue to add next access control device.
- 9. Perform the following operation(s) after adding the devices.

RemoteClick (a) to edit the time parameters, reboot the device, restore the
device, or set other configurations of the corresponding device.

	iNote
	 For some access control devices, you can customize Wiegand communication rules for connecting the customized Wiegand card reader.
	 After restoring the device, you need to apply the parameters in the system to the device (click Apply Application Settings on Access Control Device Management page).
	 For details about remote configuration, see the user manual of the device.
Change Password	Select the added device(s) and click \wp to change the password for the device(s).
	i Note
	 You can only change the password for online HIKVISION devices currently.
	 If the devices have the same password, you can select multiple devices to change the password for them at the same time.
Apply Application Settings	After restoring the database or device's default configurations, if the parameters (such as anti-passback and opening door with first card) in the system are inconsistent with the parameters on the access control device(s), a red icon (1) will be displayed on the right side of the Apply Application Settings . Click Apply Application Settings to clear the original data on the device and apply the current settings in system to the device(s).

9.4.4 Add Access Control Devices by Port Segment

If the access control devices share an IP address, a user name and password, and their port numbers are between the port segment, you can add them to the system by specifying the start port number and the end port number, IP address, user name, password, etc.

Before You Start

Make sure the access control devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Steps

- Click Physical View → Access Control Device to enter the Access Control Device Management page.
- 2. Click Add to enter the Add Access Control Device page.

- **3.** Select **Hikvision Private Protocol** as the Access Protocol.
- 4. Select Port Segment as the adding mode.
- 5. Enter the required the information.

ACaution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

- **6. Optional:** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zone of device and the SYS server are not consistent.
- 7. Optional: Switch Add Channel to Area to on to import the access points of the added devices to an area.

iNote

- For video access control terminal of a device, the camera on the terminal will also be imported to the corresponding area.
- You can create a new area by the device name or select an existing area.
- If you do not import any access point to an area, you cannot perform further operations for the access point.
- 8. Finish adding the device.
 - Click Add to add the access control device and back to the access control device list page.
 - Click Add and Continue to save the settings and continue to add next access control device.
- 9. Perform the following operation(s) after adding the devices.

Remote	Click 🐵 to edit the time parameters, reboot the device, restore the
Configurations	device, or set other configurations of the corresponding device.

i Note

- For some access control devices, you can customize Wiegand communication rules for connecting the customized Wiegand card reader.
- After restoring the device, you need to apply the parameters in the system to the device (click **Apply Application Settings** on Access Control Device Management page).
- For details about remote configuration, see the user manual of the device.
| Change
Password | Select the added device(s) and click 🔑 to change the password for the device(s). |
|----------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | i Note |
| | You can only change the password for online HIKVISION devices
currently. |
| | If the devices have the same password, you can select multiple devices
to change the password for them at the same time. |
| Apply
Application
Settings | After restoring the database or device's default configurations, if the parameters (such as anti-passback and opening door with first card) in the system are inconsistent with the parameters on the access control device(s), a red icon () will be displayed on the right side of the Apply Application Settings . Click Apply Application Settings to clear the original data on the device and apply the current settings in system to the device(s). |

9.4.5 Add Access Control Devices by Device ID

For the access control devices supporting EHome V5.0, you can add them by specifying a predefined device ID, key, etc. This is an economic choice when you need to manage an access control device without fixed IP address by HikCentral Professional.

Before You Start

Make sure the access control devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Steps

- Click Physical View → Access Control Device to enter the Access Control Device Management page.
- 2. Click Add to enter the Add Access Control Device page.
- 3. Select Hikvision EHome Protocol as the Access Protocol.
- 4. Select Device ID as the adding mode.
- 5. Enter the required the information.
- **6.** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zone of device and the SYS server are not consistent.
- 7. Optional: Switch Add Channel to Area to on to import the channels of the added devices to an area.

iNote

- You can import all the channels including cameras, alarm inputs and alarm outputs, or the specified camera(s) to the corresponding area.
- For video access control terminal of a device, the camera on the terminal will also be imported to the corresponding area.
- You can create a new area by the device name or select an existing area.
- If you do not import channels to area, you cannot perform operations such as live view, playback, event settings, etc., for the cameras.
- **8. Optional:** If you choose to add channels to area, select a Streaming Server to get the video stream of the channels via the server.

iNote

You can check **Wall Display via Streaming Server** to get stream via the selected Streaming Server when displaying live view on the smart wall.

9. Optional: If you choose to add channels to area, enable the **Video Storage** function and select the storage location for recording.

Encoding Device

The video files will be stored in the device according to the configured recording schedule.

Hybrid Storage Area Network

The video files will be stored in the Hybrid Storage Area Network according to the configured recording schedule.

Cloud Storage Server

The video files will be stored in the Cloud Storage Server according to the configured recording schedule.

pStor

According to the configured recording schedule, the video files will be stored in the pStor, which is the storage access service for managing local HDDs and logical disks.

iNote

- For adding the encoding device by domain name, the video files can only be stored in the local storage of the device.
- Configure the Hybrid Storage Area Network, Cloud Storage Server or pStor in advance, or its storage location cannot display in the drop-down list. You can click **Add New** to add a new Hybrid Storage Area Network, Cloud Storage Server or pStor.

10. Set the quick recording schedule for added channels.

- Check **Get Device's Recording Settings** to get the recording schedule from the device and the channels of the device will start recording according to the schedule.

- Uncheck Get Device's Recording Settings and set the required information, such as recording schedule template, stream type, etc. Refer to Configure Recording for Cameras on Current Site for details.
- **11.** Finish adding the device.
 - Click Add to add the encoding device and back to the access control device list page.
 - Click Add and Continue to save the settings and continue to add other access control devices.
- **12. Optional:** Perform the following operation(s) after adding the devices.

Remote Configurations	Click to set the remote configurations of the corresponding device.		
	i Note		
	For detailed operation steps for the remote configuration, see the user manual of the device.		
Change Password	Select the added device(s) and click 🔑 to change the password for the device(s).		
	i Note		
	 You can only change the password for online HIKVISION devices currently. 		
	 If the devices have the same password, you can select multiple devices to change the password for them at the same time. 		

9.4.6 Add Access Control Devices by Device ID Segment

If you need to add multiple access control devices which have no fixed IP address and support EHome V5.0 to HikCentral Professional, you can add them to HikCentral Professional at a time after configuring a device ID segment for the devices.

Before You Start

Make sure the access control devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Steps

- Click Physical View → Access Control Device to enter the Access Control Device Management page.
- 2. Click Add to enter the Add Access Control Device page.
- 3. Select Hikvision EHome Protocol as the Access Protocol.
- 4. Select Device ID Segment as the adding mode.
- 5. Enter the required parameters
- **6.** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zone of device and the SYS server are not consistent.

7. Optional: Switch Add Channel to Area to on to import the channels of the added devices to an area.

iNote

- You can import all the channels including cameras, alarm inputs and alarm outputs, or the specified camera(s) to the corresponding area.
- For video access control terminal of a device, the camera on the terminal will also be imported to the corresponding area.
- You can create a new area by the device name or select an existing area.
- If you do not import channels to area, you cannot perform operations such as live view, playback, event settings, etc., for the cameras.
- 8. Finish adding the device.
 - Click **Add** to add the access control device and back to the encoding device list page.
 - Click Add and Continue to save the settings and continue to add other access control devices.

9.4.7 Add Access Control Devices in a Batch

You can enter the access control device information to the predefined template to add multiple devices at a time.

Before You Start

Make sure the access control devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Steps

- Click Physical View → Access Control Device to enter the Access Control Device Management page.
- 2. Click Add to enter the Add Access Control Device page.
- 3. Select Hikvision Private Protocol or Hikvision eHome Protocol as the Access Protocol.
- 4. Select Batch Import as the adding mode.
- 5. Click Download Template and save the predefined template (CSV file) in your PC.
- **6.** Open the downloaded template file and enter the required information of the devices to be added on corresponding columns.
- 7. Click ••• and select the edited file.
- **8. Optional:** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zone of device and the SYS server are not consistent.
- 9. Finish adding devices.
 - Click Add to add the devices and go back to the device list page.
 - Click Add and Continue to save the settings and continue to add other devices.
- **10.** Perform the following operation(s) after adding devices in a batch.

Remote Configurations	Click 🛞 to edit the time parameters, reboot the device, restore the device, or set other configurations of the corresponding device.	
	i Note	
	 For some access control devices, you can customize Wiegand communication rules for connecting the customized Wiegand card reader. 	
	 After restoring the device, you need to apply the parameters in the system to the device (click Apply Application Settings on Access Control Device Management page). 	
	 For details about remote configuration, see the user manual of the device. 	
Change Password	Select the added device(s) and click \wp to change the password for the device(s).	
	i Note	
	 You can only change the password for online HIKVISION devices currently. 	
	 If the devices have the same password, you can select multiple devices to change the password for them at the same time. 	
Apply Application Settings	After restoring the database or device's default configurations, if the parameters (such as anti-passback and opening door with first card) in the system are inconsistent with the parameters on the access control device(s), a red icon () will be displayed on the right side of the Apply Application Settings . Click Apply Application Settings to clear the original data on the device and apply the current settings in system to the device(s).	

9.5 Manage Security Control Device

You can add the security control devices to the system for managing partition, zone, arming/ disarming, handling alarms, etc.

The security control device includes the security control panel, panic alarm station, Axiom wireless security control panel, etc., which are widely applied to many scenarios.

A security control panel is used for monitoring arming zones, handling alarm signal from the triggers, and uploading alarm reports to the central alarm monitoring station. The security control panel is very important for preventing robbery, theft or other accidents.

A panic alarm station is mainly installed in the areas with the crowd or high incidence of cases, such as school, square, tourist attraction, hospital, supermarket gate, market, station, parking lot,

etc. When the emergency happens or someone asks for help, the person can press panic button to send alarm to the monitoring center, and the operator in the center will take the appropriate actions. The panic alarm station helps to realize alarm aid in emergency.

9.5.1 Add Online Device

The active online security control devices in the same local subnet with the current Web Client or SYS server will be displayed on a list. You can add one online device one by one, or add multiple online devices in a batch.

iNote

You should install the web control according to the instructions and then the online device detection function is available.

Add an Online Security Control Device

You can add the detected online security control devices, and here we introduce the process for adding single one device.

Before You Start

- Make sure the security control devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the system via network.
- The devices to be added should be activated. Refer to *Create Password for Inactive Device(s)* for detailed operation about activating devices.

Steps

- Click Physical View → Security Control Device to enter the Security Control Device Management page.
- 2. In the Online Device area, select a network type.

Server Network

As the default selection, the detected online devices in the same local subnet with the SYS server will list in the Online Device area.

Local Network

The detected online devices in the same local subnet with the current Web Client will list in the Online Device area.

- 3. In the Online Device area, select the active device to be added .
- 4. Click 📑 to open the Add Online Device window.
- **5.** Enter the required information.

iNote

The device's IP address and port number can be automatically shown in **Device Address** field and **Device Port** field.

Caution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

- **6. Optional:** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zones of the device and the SYS server are not consistent.
- **7. Optional:** Set the **Add Channel to Area** switch to ON to import the channels (including cameras, alarm inputs, and alarm outputs) of the added security control device to an area.

i Note

- You can select **Specified Alarm Input** and select alarm inputs to import to the area.
- System will generate security control partitions in the area, based on the settings on the device.
- You can create a new area by the device name or select an existing area.
- If you do not import channels to area, you cannot perform the further configurations for the channels.
- 8. Click Add.
- 9. Optional: Perform the following operations after adding the online device.

Remote	Click to set the remote configurations of the corresponding device.
Configurations	i Note
	For details about remote configuration, see the user manual of the device.
Change Password	Select the added device(s) and click \swarrow to change the password for the device(s).

iNote

- You can only change the password for online HIKVISION devices currently.
- If the devices have the same password, you can select multiple devices to change the password for them at the same time.

Add Online Security Control Devices in a Batch

For the detected online security control devices, if they have the same password for the same user name, you can add multiple devices at a time.

Before You Start

- Make sure the security control devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the system via network.
- The devices to be added should be activated. Refer to *Create Password for Inactive Device(s)* for detailed operation about activating devices.

Steps

- Click Physical View → Security Control Device to enter the Security Control Device Management page.
- 2. In the Online Device area, select a network type.

Server Network

The detected online devices in the same local subnet with the SYS server will list in the Online Device area.

Local Network

The detected online devices in the same local subnet with the Web Client will list in the Online Device area.

- **3.** In the Online Device area, select the active devices to be added.
- 4. Click 📑 to open the Add Online Device window.
- **5.** Enter the required information.

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

- **6. Optional:** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zones of the device and the SYS server are not consistent.
- **7. Optional:** Set the **Add Channel to Area** switch to on to import the channels (including cameras, alarm inputs, and alarm outputs) of the added security control device to an area.

iNote

- System will generate security control partitions in the area, based on the settings on the device.
- You can create a new area by the device name or select an existing area.
- If you do not import channels to area, you cannot perform the further configurations for the channels.
- 8. Click Add.
- 9. Optional: Perform the following operations after adding the online devices in batch.

Remote	Click 🐵 to set the remote configurations of the corresponding device.		
Configurations	i Note		
	For details about remote configuration, see the user manual of the device.		
Change Password	Select the added device(s) and click 🔑 to change the password for the device(s).		
	i Note		
	 You can only change the password for online HIKVISION devices currently. 		
	 If the devices have the same password, you can select multiple devices to change the password for them at the same time. 		

9.5.2 Add Security Control Device by IP Address

When you know the IP address of the security control device to add, you can add the devices to your system by specifying the IP address, user name, password, and other related parameters.

Before You Start

Make sure the security control devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the system via network.

Steps

- Click Physical View → Security Control Device to enter the Security Control Device Management page.
- 2. Click Add to enter the Add Security Control Device page.
- 3. Select IP Address as the adding mode.
- **4.** Enter the required the information.

iNote

- By default, the device port is 8000.
- For wireless security control panel, the default port is 80.

Caution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

- **5. Optional:** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zones of the device and the SYS server are not consistent.
- **6. Optional:** Set the **Add Channel to Area** switch to on to import the channels (including cameras, alarm inputs, and alarm outputs) of the added security control device to an area.

iNote

- You can select **Specified Alarm Input** and select alarm inputs to import to the area.
- System will generate security control partitions in the area, based on the settings on the device.
- You can create a new area by the device name or select an existing area.
- Up to 64 alarm inputs can be imported in one area. If you don't import channels to area, you cannot perform further operations for the channels.
- 7. Finish adding the device.
 - Click Add to add the security control device and back to the security control device list.
 - Click Add and Continue to save the settings and continue to add next security control device.
- 8. Perform the following operations after adding the devices.

RemoteClick (a) to set the remote configurations of the corresponding device.Configurations

	i Note
	For details about remote configuration, see the user manual of the device.
Change Password	Select the added device(s) and click 🔑 to change the password for the device(s).
	i Note
	 You can only change the password for online HIKVISION devices currently.
	 If the devices have the same password, you can select multiple devices to change the password for them at the same time.

9.5.3 Add Security Control Device by Hik-Connect

You can add the security control devices which have been added to the Hik-Connect account to the system.

Before You Start

Make sure the security control devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the system via network.

Steps

- Click Physical View → Security Control Device to enter the Security Control Device Management page.
- 2. Click Add to enter the Add Security Control Device page.
- **3.** Select Hik-Connect as the adding mode.
- 4. Select a device source.

New Device

Add a new device to both Hik-Connect and the system.

Hik-Connect Device List

Add devices managed by Hik-Connect to the system in a batch by getting the device list.

5. Set required parameters.

Hik-Connect Server Address

Enter the address of the Hik-Connect service. By default, it's *https://open.ezvizlife.com*.

iNote

If you select Hik-Connect Device List as source type, you can click **Get Device List** to get the device list in the account.

Serial No.

For adding new device, enter the serial No. of the device.

Verification Code

For adding new device, enter the verification code of the device.

- **6. Optional:** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zones of the device and the SYS server are not consistent.
- **7. Optional:** Set the **Add Channel to Area** switch to on to import the channels (including cameras, alarm inputs, and alarm outputs) of the added security control device to an area.

iNote

- System will generate security control partitions in the area, based on the settings on the device.
- You can create a new area by the device name or select an existing area.
- If you do not import channels to area, you cannot perform the further configurations for the channels.
- **8.** Finish adding the device.
 - Click **Add** to add the security control device and back to the security control device list page.
 - Click Add and Continue to save the settings and continue to add next security control device.
- 9. Optional: Perform the following operations after adding the devices.

Remote Configurations	Click 🐵 to set the remote configurations of the corresponding device.		
	i Note		
	For details about remote configuration, see the user manual of the device.		
Change Password	Select the added device(s) and click 🔑 to change the password for the device(s).		
	i Note		
	 You can only change the password for online HIKVISION devices currently. 		
	 If the devices have the same password, you can select multiple devices to change the password for them at the same time. 		

9.5.4 Add Security Control Devices by IP Segment

If the security control devices having the same port No., user name and password, and their IP addresses are between the IP segment, you can specify the start IP address and the end IP address, port No., user name, password, and other related parameters to add them.

Before You Start

Make sure the security control devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the system via network.

Steps

- Click Physical View → Security Control Device to enter the Security Control Device Management page.
- 2. Click Add to enter the Add Security Control Device page.
- **3.** Select **IP Segment** as the adding mode.
- **4.** Enter the required the information.

iNote

By default, the device port No. is 8000.

ACaution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

- **5. Optional:** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zones of the device and the SYS server are not consistent.
- **6. Optional:** Set the **Add Channel to Area** switch to on to import the channels (including cameras, alarm inputs, and alarm outputs) of the added security control device to an area.

iNote

- System will generate security control partitions in the area, based on the settings on the device.
- You can create a new area by the device name or select an existing area.
- If you do not import channels to area, you cannot perform the further configurations for the channels.

7. Finish adding the device.

- Click Add to add the security control device and back to the security control device list page.
- Click **Add and Continue** to save the settings and continue to add next security control device.
- 8. Perform the following operations after adding the devices.

RemoteClick (a) to set the remote configurations of the corresponding device.Configurations

	i Note
	For details about remote configuration, see the user manual of the device.
Change Password	Select the added device(s) and click 🔑 to change the password for the device(s).
	i Note
	 You can only change the password for online HIKVISION devices currently.
	 If the devices have the same password, you can select multiple devices to change the password for them at the same time.

9.5.5 Add Security Control Devices by Port Segment

If the security control devices having the same user name and password, and their port No. are between the port segment, you can specify the start port No. and the end port No., user name, password, and other related parameters to add them.

Before You Start

Make sure the security control devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Steps

- Click Physical View → Security Control Device to enter the Security Control Device Management page.
- 2. Click Add to enter the Add Security Control Device page.
- 3. Select Port Segment as the adding mode.
- **4.** Enter the required the information.

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

- **5. Optional:** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zones of the device and the SYS server are not consistent.
- **6. Optional:** Set the **Add Channel to Area** switch to on to import the channels (including cameras, alarm inputs, and alarm outputs) of the added security control device to an area.

i Note

- System will generate security control partitions in the area, based on the settings on the device.
- You can create a new area by the device name or select an existing area.
- If you do not import channels to area, you cannot perform the further configurations for the channels.
- **7.** Finish adding the device.
 - Click **Add** to add the security control device and back to the security control device list page.
- Click Add and Continue to save the settings and continue to add next security control device.
 8. Perform the following operations after adding the devices.

Remote	Click 🐵 to set the remote configurations of the corresponding device.		
Configurations	i Note		
	For details about remote configuration, see the user manual of the device.		
Change Password	Select the added device(s) and click 🔑 to change the password for the device(s).		
	iNote		
	 You can only change the password for online HIKVISION devices currently. 		
	 If the devices have the same password, you can select multiple devices to change the password for them at the same time. 		

9.5.6 Add Security Control Devices in a Batch

You can edit the predefined template with the security control device information to add multiple devices at a time.

Before You Start

Make sure the security control devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the system via network.

Steps

- Click Physical View → Security Control Device to enter the Security Control Device Management page.
- 2. Click Add to enter the Add Security Control Device page.
- 3. Select Batch Import as the adding mode.
- 4. Click Download Template and save the predefined template (CSV file) in your PC.
- **5.** Open the exported template file and edit the required information of the devices to be added on the corresponding column.
- 6. Click ... and select the template file.
- **7. Optional:** Select a time zone for the device in drop-down list of **Time Zone of Device** when the time zones of the device and the SYS server are not consistent.
- 8. Finish adding devices.
 - Click Add to add the devices and go back to the device list page.
 - Click Add and Continue to save the settings and continue to add other devices.
- **9.** Perform the following operations after adding devices in a batch.

Remote Configurations	Click 🐵 to set the remote configurations of the corresponding device.		
	i Note		
	For details about remote configuration, see the user manual of the device.		
Change Password	Select the added device(s) and click $price P$ to change the password for the device(s).		
	i Note		
	 You can only change the password for online HIKVISION devices currently. 		
	 If the devices have the same password, you can select multiple devices to change the password for them at the same time. 		

9.6 Manage Dock Station

The dock station is a data collector which can automatically detect and back up law-enforcement data and evidence data from body camera(s) connected to it. The dock station can also be used to charge the body cameras.

You can add a dock station to the system by IP/domain. You can also add multiple dock stations to the HikCentral Professional by IP segment, port segment, or importing a pre-defined template which contains the required dock stations' information.

After adding dock stations to the system, you can search the data (video footage, pictures, and audio files) backed up on the dock stations and download the data via the Control Client for

convenient management. You can also monitor the online status of the dock stations, and perform other operations such as playing video footage backed up on the dock stations.

iNote

- For more details about dock station, see the user manual of the device.
- For details about searching video footage of the dock stations, see the User Manual of HikCentral Professional Control Client.

9.6.1 Add Dock Station by IP/Domain

When you know the IP address or domain name of the to-be-added dock station, you can add the device to the system by specifying the IP address, user name, password, and other related parameters.

Before You Start

Make sure the access control devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Steps

- **1.** Click **Physical View** \rightarrow **Dock Station** to enter the dock station management page.
- 2. Select IP/Domain as the adding mode.
- **3.** Enter the required information.

Device Address

IP address or domain name of the dock station.

User Name

User name of the dock station.

Password

Password of the dock station.

4. Optional: Set time zone for the dock station.

- 1) Select a time zone in drop-down list of **Time Zone of Device**.
- 2) Set time zone of the dock station via the dock station's web page, and make sure the device's time zone is the same with the time zone selected in the previous sub-step.
- 5. Configure the dock station group.

iNote

Dock station group is a group of persons (usually policemen or policewomen). Only when the persons are added to the dock station, can the data in their body cameras be backed up to the dock station.

- Click Add New in the Dock Station Group drop-down list to add a new dock station group.

∎Note

For details about adding dock station group, see Add Dock Station Group.

- Select a dock station group from the **Dock Station Group** drop-down list.
- 6. Finish adding the dock station.
 - Click Add to add the dock stations and back to the dock station list page.
 - Click Add and Continue to save the settings and add more dock stations by port segment.
- 7. Optional: Perform the following operations after adding the dock station.

Edit Dock Station Click the dock station alias on the device list to edit the dock station.

Delete Dock Station Select dock station(s) and then click **Delete** to delete them.

9.6.2 Add Dock Stations by IP Segment

When multiple dock stations have the same port number, user name and password, but have different IP addresses, which are within a range, you can select this adding mode and specify the range of IP address, port number, user name, password, and other related parameters to add them.

Before You Start

Make sure the dock stations you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Steps

- 1. Click Physical View → Dock Station to enter the dock station management page.
- 2. Click Add to enter the Add Dock Station page.
- 3. Select IP Segment as the adding mode.
- 4. Enter the required information.

Device Address

Enter the start IP address and the end IP address. For example, if five dock stations need to be added, and their IP address are "10.41.7.231", "10.41.7.232", "10.41.7.233", "10.41.7.234", and "10.41.7.235" respectively, you should enter **10.41.7.231** and **10.41.7.235**.

- 5. Optional: Set time zone for the dock station.
 - 1) Select a time zone in drop-down list of **Time Zone of Device**.
 - 2) Set time zone of the dock station via the dock station's web page, and make sure the device's time zone is the same with the time zone selected in the previous sub-step.
- 6. Finish adding the dock stations.
 - Click Add to add the dock stations and back to the dock station list page.
 - Click Add and Continue to save the settings and continue to add more dock stations.
- 7. Optional: Perform the following operations after adding the dock stations.

Edit Dock Station Click the dock station alias on the device list to edit the dock station.

Delete Dock Station Select dock station(s) and then click **Delete** to delete them.

9.6.3 Add Dock Stations by Port Segment

When multiple to-be-added dock stations have the same IP address, user name and password, but have different port numbers, which are within a range, you can select this adding mode and specify the port range, IP address, user name, password, and other related parameters to add them at a time.

Before You Start

Make sure the devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Steps

- **1.** Click **Physical View** \rightarrow **Dock Station** to enter the dock station management page.
- 2. Click Add to enter the Add Dock Station page.
- 3. Select Port Segment as the adding mode.
- **4.** Enter the required information.

Device Address

The same IP address where the devices are located.

Device Port

Enter the start port number and the end port number. For example, if there are five dock stations need to be added, and their port number are 80, 81, 82, 83, and 84 respectively, you should enter **80** and **84**.

User Name

The same user name of the dock stations.

Password

The same password of the dock stations.

- **5. Optional:** Set time zone for the dock station.
 - 1) Select a time zone in drop-down list of **Time Zone of Device**.
 - 2) Set time zone of the dock station via the dock station's web page, and make sure the device's time zone is the same with the time zone selected in the previous sub-step.

6. Finish adding the device.

- Click Add to add the dock stations and back to the dock station list page.
- Click Add and Continue to save the settings and add more dock stations by port segment.
- 7. Optional: Perform the following operations after adding the dock stations.

Edit Dock Station Click the dock station alias on the device list to edit the dock station.

Delete Dock Station Select dock station(s) and then click **Delete** to delete them.

9.6.4 Add Dock Stations in Batch

When there are multiple dock stations need to be added to HikCentral Professional, you can download a predefined template and fill in the required information about the dock stations, and then import the template to the system to add multiple dock stations at a time.

Before You Start

Make sure the dock stations you are going to use are correctly installed and connected to the network as specified by the manufacturer. Such initial configuration is required in order to be able to connect the device to the HikCentral Professional via network.

Steps

- **1.** Click **Physical View** \rightarrow **Dock Station** to enter the dock station management page.
- 2. Click Add to open the Add Dock Station page.

⊖ Add Dock Station			
Adding Mode			
	IP/Domain		
	 IP Segment 		
	 Port Segment 		
	 Batch Import 		
Basic Information			
* Device Address			
* Device Port	5651		
* Alias			
* User Name	admin		
* Password		Ø	
	Add	Add and Continue	Cancel

Figure 9-5 Add Dock Station Page

- 3. Select Batch Import as the adding mode.
- 4. Click Download Template and save the predefined template (CSV file) on your PC.
- **5.** Open the template file and enter the required information of the devices to be added on the corresponding column.
- **6.** Click ... and select the template file.
- 7. Optional: Set time zone for the dock station.
 - 1) Select a time zone in drop-down list of Time Zone of Device.
 - 2) Set time zone of the dock station via the dock station's web page, and make sure the device's time zone is the same with the time zone selected in the previous sub-step.
- **8.** Finish adding the dock stations.
 - Click Add to add the dock stations and back to the dock station list page.

- Click Add and Continue to save the settings and continue to add more dock stations.
- **9. Optional:** Perform the following operation(s) after adding the dock stations.

Edit Dock Station Click the dock station alias on the device list to edit the dock station.

Delete Dock Station Select dock station(s) and then click **Delete** to delete them.

9.7 Upgrade Device Firmware

You can upgrade the firmwares of the devices added to the system via the current Web Client or EZVIZ Cloud service.

iNote

The card reader of the access control device can also be upgraded.

9.7.1 Upgrade Device Firmware via Current Web Client

You can upgrade device firmware via the current Web Client.

Steps

- 1. Click Upgrade Device Firmware on the Home page to open the Upgrade Device Firmware window.
- 2. Click Via Current Web Client tab.
- **3.** Set the required information.

Simultaneous Upgrade

Set the maximum number of devices for simultaneous upgrade. For example, if you set the value to 5, up to 5 devices can be selected for batch upgrade.

4. Select a upgrade package from the local PC and then click Next.

The upgradable devices will be displayed.

- 5. Optional: Filter devices by device type, device firmware version, or device model.
- 6. Select device(s) and then click Next.
- 7. Select a upgrade schedule to upgrade the selected device(s).
 - Select Upgrade Now from the Upgrade Schedule drop-down list to start upgrade.
 - Select **Custom** from the **Upgrade Schedule** drop-down list and then customize a time period to upgrade the selected device(s).

9.7.2 Upgrade Device Firmware via EZVIZ Cloud Service

You can upgrade device firmware via EZVIZ Cloud Service, which is a cloud service provided by EZVIZ.

Steps

- 1. Click Upgrade Device Firmware on the Home page to open the Upgrade Device Firmware window.
- 2. Click Via EZVIZ Cloud tab.
- **3.** Set the required information.

Simultaneous Upgrade

Set the maximum number of devices for simultaneous upgrade. For example, if you set the value to 5, up to 5 devices can be selected for batch upgrade.

- 4. Click Next.
- **5.** Install the required web plug-in.

iNote

If you select local PC as the upgrade method, you should install the required web plug-in if the prompt pops up.

The upgradable devices will be displayed.

- 6. Select device(s) and click **Next** to enter the upgrade schedule page.
- 7. Select a upgrade schedule to upgrade the selected device(s).
 - Select Upgrade Now from the Upgrade Schedule drop-down list to start upgrade.
 - Select **Custom** from the **Upgrade Schedule** drop-down list and then customize a time period to upgrade the selected device(s).

9.8 Restore/Reset Device Password

If you forgot the password of the detected online devices, you can restore the device's default password or reset the device's password through the system. Then you can access the device or add it to the system using the password.

For detailed operations of restoring device's default password, refer to **Restore Device's Default Password**.

For detailed operations of resetting device's password, refer to Reset Device Password .

9.8.1 Reset Device Password

If you have forgotten your password you use to access online device, you can request to have a key file from your technical support and reset the device's password through the system.

Before You Start

• Make sure the devices (cameras, DVR, access control device, etc.) you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial

configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

• The devices should be activated. Refer to *Create Password for Inactive Device(s)* for details about activating devices.

Perform this task when you need to reset the device's password. Here we take the encoding device as an example.

Steps

1. Click Physical View → Encoding Device to enter the Encoding Device Management page.

```
iNote
```

- For access control devices, click Physical View → Access Control Device to enter the access control device management page.
- For decoding devices, click Physical View → Smart Wall. On the Decoding Device area, click Add and check Online Devices as Adding Mode.

The detected online devices list in the Online Device area.

2. In the Online Device area, view the device status (shown on Security column) and click icon 5 in the Operation column of an active device.

A dialog with import file and export file, password and confirm password fields opens.

- 3. Click Export to save the device file on your PC.
- 4. Send the file to our technical engineers.

iNote

For the following operations about resetting the password, contact the technical support engineer.

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

9.8.2 Restore Device's Default Password

For some encoding devices with old firmware version, if you forgot the password you use to access the online device, you can restore the device's default password through the system and then you must change the default password to a stronger one for better security.

Before You Start

- Make sure the devices (cameras, DVR, etc.) you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.
- The devices should be activated. Refer to *Create Password for Inactive Device(s)* for detailed operations about activating devices.

Perform this task when you need to restore the device's default password.

Steps

- Click Physical View → Encoding Device to enter the Encoding Device Management page. The detected online devices list in the Online Device area.
- 2. In the Online Device area, view the device status (shown on Security column) and click 🕤 in the Operation column of an active device.

A dialog with security code pops up.

3. Enter the security code and restore the default password of the selected device.

iNote

Contact our technical support to obtain a security code.

What to do next

You must change this default password to better protect against security risks, such as the unauthorized access by others to the product that may prevent the product from functioning properly and/or lead to other undesirable consequences.

Caution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

9.9 Manage Remote Site

You can add other HikCentral Professional without RSM (Remote Site Management) module to the HikCentral Professional with RSM module as the Remote Site for central management.

After adding the Remote Site to the Central System, you can manage the Remote Site's cameras (such as live view and playback), add the Remote Site's configured alarms so that you can manage the alarms via the Central System, and set the recording schedule for the Remote Site's cameras and store the recorded video files in the Recording Server added to the Central System. You can also view the Remote Site's GIS location, hot spot, and hot region settings in Map module.

Remote Site

If the HikCentral Professional doesn't have RSM module (based on the License you purchased), you can add it to the Central System as Remote Site.

Central System

If the HikCentral Professional has RSM module (based on the License you purchased), you can add other Remote Sites to this system. This system and the added Remote Sites are called Central System.

iNote

- The system with RSM module cannot be added to other Central System as Remote Site.
- If one Remote Site has been added to one Central System, it cannot be added to other Central System.

9.9.1 Add Remote Site by IP Address or Domain Name

When you know the IP address or domain name of the Remote Site to add, you can add the site to the Central System by specifying the IP address (or domain name), user name, password, and other related parameters.

Perform this task when you need to add Remote Site by IP address or domain name.

Steps

iNote

When adding Remote Site, the site's cameras and logical area information are imported to the Central System by default.

1. Click Remote Site Management on home page to open the Remote Site management page.

- 2. Enter the Add Remote Site page.
 - If no Remote Site added, click Add Site to enter the Add Remote Site page.
 - If you have already added Remote Site, click + on the left to enter the Add Remote Site page.

😔 Add Remote S	Site	
Adding Mode		
	IP/Domain	
	○ Site Registered to Central System	
	O Batch Import	
Basic Information		
*Site Address]
*Site Port	443]
Alias		Synchronize Name
*User Name	admin]
*Password]
Description	Briefly describe the site information, e.g., site location and deployment.	
Channel Information		
	Add Add and	Continue Cancel

Figure 9-6 Add Remote Site Page

- **3.** Select **IP/Domain** as the adding mode.
- **4.** Enter the required information.

Site Address

The IP address or domain name of the Remote Site.

Site Port

Enter the port No. of the Remote Site. By default, it's 80.

Alias

Edit a name for the Remote Site as desired. You can check **Synchronize Name** to synchronize the Remote Site's name automatically.

User Name

The user name for the Remote Site, such as admin user and normal user.

Password

The password required to access the Remote Site.

Description

Optionally, you can enter the descriptive information for the Remote Site, such as location and deployment.

Caution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

- 5. Optional: Enable receiving the alarms configured on the Remote Site.
 - 1) Set the **Select Alarm** switch to **ON** to display all the configured alarms on a Remote Site.

Receive Alarm from Site							
Select Alarm		ON					
		er receiving the alarm from remo [.] it alarms in Alarm module. Defaul			ed as alarm in c	entral system automatically. Y	ou can view
	Source	 Triggering Event < Alarm 	n Priority∨			Alarm Name	Q
		Alarm Name	Source	Area	Trigge		
		IPdome-Motion Detection	IPdome	250	Motion		
	Total	1 Record(s) 20 -			I< <	> > 1 / 1 Pa	age(s) Go

Figure 9-7 Receive Alarm from Site Page

- 2) **Optional:** Filter the configured alarms by the alarm source, triggering event, and alarm priority.
- 3) Select the configured alarm(s).

iNote

- After receiving the alarm from Remote Site, the alarm will be configured as alarm in Central System automatically. You can click **Default Configuration Rule** to view the imported alarms' default settings including alarm name, alarm priority, actions, etc.
- You can view and edit alarms in Alarm module. For details about setting the alarm, refer to *Configure Alarm*.
- **6.** Back up the Remote Sites' database in the Central System and you can set the maximum number of backups and view the database saving path in the Central System.

Max. Number of Backups

Define the maximum number of backup files available on the system.

- 7. Optional: Enable backing up the Remote Site's database in schedule.
 - 1) Set the Scheduled Database Backup switch to ON.
 - 2) Select how often to back up the database.

iNote

If you select **Weekly** or **Monthly** for running the backup task, select which day to run.

- 3) Select what time of a day to start backup.
- 8. Finish adding the Remote Site.
 - Click Add to add the Remote Site and back to the Remote Site list page.
 - Click Add and Continue to save the settings and continue to add other Remote Sites.

9.9.2 Add Remote Site Registered to Central System

If the Remote Sites have been registered the Central System and the Central System also enabled the receiving site registration function, the registered Remote Sites will display in the site list. You can add them to the Central System by entering user names and passwords.

Before You Start

- The Remote Site must be registered to the Central System by itentering the Central System's network parameters (see *Register to Central System* for details).
- The Central System should enable the receiving site registration function (see *Allow for Remote Site Registration* for details).

Perform this task when you need to add the site which has registered to the Central System.

Steps

iNote

When adding Remote Site, the site's cameras and logical area information are imported to the Central System by default.

- 1. Click Remote Site Management on home page to enter the Remote Site management page.
- 2. Enter the adding Remote Site page.
 - If no Remote Site added, click **Add Site** to enter the Add Remote Site page.
 - If you have already added Remote Site, click + on the left to enter the Add Remote Site page.

⊖ Add Remote	Site
Adding Mode	
	 IP/Domain Site Registered to Central System Batch Import
Basic Information	
*Select Si	e Search Q Show Added Site
	□ Name IP Address Port No. ID Add to System
	Add Add and Continue Cancel

Figure 9-8 Add Remote Site Page

3. Select Site Registered to Central System as the adding mode.

The sites which have already registered to the Central System will display in the list.

4. Select the Remote Site(s) and enter the user name and password of the Remote Site(s).

Caution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

 Back up the Remote Sites' database in the Central System and you can set the maximum number of backups and view the database saving path in the Central System.
 Max. Number of Backups

Define the maximum number of backup files available on the system.

iNote

The value of maximum number of backups ranges from 1 to 5.

- 6. Optional: Back up the Remote Site's database in schedule.
 - 1) Set the Scheduled Database Backup switch to ON to enable the scheduled backup.
 - 2) Select how often to back up the database.

iNote

If you select **Weekly** or **Monthly** for running the backup task, select which day to run.

- 3) Select what time of the day to start backup.
- 7. Finish adding Remote Site.
 - Click Add to add the Remote Site and back to the Remote Site list page.
 - Click Add and Continue to save the settings and continue to add other Remote Sites.

9.9.3 Add Remote Sites in a Batch

When you want to add multiple Remotes Sites at a time for convenience, you can edit the predefined template by entering the sites' parameters and import the template to the Central System to add them.

Perform this task when you need to add Remote Sites in a batch.

Steps

iNote

When adding Remote Site, the site's cameras and logical area information are imported to the Central System by default.

1. Click Remote Site Management on home page to enter the Remote Site management page.

- 2. Enter the adding Remote Site page.
 - If no Remote Site added, click Add Site to enter the Add Remote Site page.
 - If you have already added Remote Site, click + on the left to enter the Add Remote Site page.

⊘ Add Remote Site					
Adding Mode					
	O IP/Domain				
 Site Registered to Central System 					
	e Batch Import				
Basic Information					
*Select File					
	Download Template				
Channel Information					
	O When adding remote site, the site's cameras and logical area information imported to the central system by default.				
Back up Remote Site Database	e in Central System				
Scheduled Database Backup	OFF				
Save to	C:\Program Files (x86)\I	HikCentral\VSI			
* Max. Number of Backups	5				
	Add	Add and Co	ontinue	Cancel	

Figure 9-9 Add Remote Site

- 3. Select Batch Import as the adding mode.
- 4. Click Download Template and save the predefined template (CSV file) on your PC.
- **5.** Open the exported template file and input the required information of the Remote Sites to be added on the corresponding column.
- **6.** Click ... and select the template file.
- **7.** Back up the Remote Sites' database in the Central System and you can set the maximum number of backups and view the database saving path in the Central System.

Max. Number of Backups

Define the maximum number of backup files available on the system.

- **8. Optional:** Back up the Remote Site's database in schedule.
 - 1) Set the Scheduled Database Backup switch to ON to enable the scheduled backup.
 - 2) Select how often to back up the database.

iNote

If you select **Weekly** or **Monthly** for running the backup task, select which day to run.

3) Select what time of the day to start backup.

- 9. Finish adding Remote Site.
 - Click Add to add the Remote Site and back to the Remote Site list page.

- Click Add and Continue to save the settings and continue to add other Remote Sites.

9.9.4 Back Up Remote Site's Database to Central System

After adding the Remote Site, you can back up the database of the Remote Site to the Central System. The database backup can be performed according to the configured schedule or immediately. In case of the data deletion or corruption following a natural or human-induced disaster, you can recover the data to ensure the business continuity.

Perform this task when you need to back up the database of Remote Site in the Central System.

Steps

Click Remote Site Management on home page to open the Remote Site management page.
 In the site list on the left, click the Remote Site name to view its details.

Back up Remote Site Database in Central System					
	දිල්† Set Database Backup (Back Up No	w		
	File Name	T	Backup Time		
	20170726153317_Backup	o.zip	2017-07-26 15:33:17		

Figure 9-10 Back up Remote Site Database in Central System

- 3. Click Back Up Now to back up the Remote Site's database manually.
- **4. Optional:** Set the backup parameters and enable scheduled database backup if needed to back up the Remote Site's database regularly.
 - 1) Click Set Database Backup to open the Set Database Backup dialog.

Set Database Backup		×
Scheduled Database Backup	ON	
How Often	Weekly -	
Which Day	Monday -	
When	0:00 ~	
Save to	G:\HikCentral\VSM Servers\VSM\E	
* Max. Number of Backups	5	
	Save	Cancel

Figure 9-11 Set Database Backup

- 2) Set the Scheduled Database Backup switch as ON to enable the scheduled backup.
- 3) Select how often to back up the database.

iNote

If you select Weekly or Monthly for running the backup task, select which day to run.

- 4) Select what time of the day to start backup.
- 5) Set the **Maximum Number of Backups** to define the maximum number of backup files available on the system.

ĨiNote

The maximum number of the backups should be between 1 to 5.

6) Click Save.

Result

The backup file (including manual backup and scheduled backup) will display in the list, showing the file name and backup time.

9.9.5 Edit Remote Site

After adding the Remote Site, you can view and edit the added Remote Site's information and set its GPS location.

Perform this task when you need to edit the added Remote Site's details.

Steps

- 1. Click Remote Site Management on home page to open the Remote Site management page.
- 2. In the site list on the left, click the Remote Site name to view its details.

3. View and edit the basic information of the Remote Site, including IP address, port, alias, etc.

iNote

You cannot edit the address and port of the site registered to the Central System.

4. In the original information field, view the Remote Site's site name, system ID, system version, and GPS location.

iNote

If the GPS location is not configured, click **Configuration** to set its location in Map module. See *Manage Map* for details.

5. Optional: Click **Configuration on Site** to open the Web Client of the Remote Site and log in for further configuration.



The site must be online if you need to enter its Web Client.

6. Click Save.

9.9.6 View Remote Site's Changes

When there are changed resources on the Remote Site, such as newly added cameras, deleted cameras, and name changed cameras, you can view the changed resources and synchronize the resources in Central System with the Remote Site.

Perform this task when you need to view the Remote Site's changes.

Steps

iNote

The site should be online if you need to view the changed resources.

- 1. Click Remote Site Management on home page to open the Remote Site management page.
- 2. Click \bigcirc in the site list on the left to get the latest status of the Remote Sites.

If the resources on the Remote Site are changed, a red dot will appear on the icon of Remote Site as 🎇 .

- **3.** Click the site name whose resources are changed to enter its details page.
- 4. Click Changes of Remote Site to view the changes.

Last Checked Time : 2017/07/12 16:23:27			
	Change of Remote Site	Number	
>	Newly Added Camera	1	
>	Deleted Camera	1	

Figure 9-12 Remote Site Management

- 5. When there are newly added cameras on the site, you can view the added cameras and add them to the area in Central System.
 - 1) If there are some newly added cameras on Remote Site, click **Newly Added Camera** to expand the newly added camera list.

Change of Remote Site	Number
✓ Newly Added Camera	1
+ Add to Central Area	
□ Name	Area
Camera1	aisxsalsja

Figure 9-13 Changes of Remote Site

You can view the camera name and area name on the Remote Site.

- 2) Select the camera(s) and click **Add to Central Area** to synchronize the newly added cameras to the Central System.
- 3) Select the area in the Central System.
- 4) Click Save.
- **6.** When there are some cameras deleted from the site, you can view the deleted cameras and remove them from Central System.
 - 1) If there are some cameras deleted from Remote Site, click **Deleted Camera** to expand the deleted camera list.

	Change of Remote Site	Number
\sim	Deleted Camera	1
\times	Delete All Cameras Below in Central	
	Name	Area (Central)
IPd	ome	250

Figure 9-14 Change of Remote Site

You can view the camera name and its area in Central System.

- 2) Click Delete All Cameras Below in Central to delete the deleted cameras in Central System.
- **7.** When there are some cameras whose names are changed on the site, you can view the name changed cameras and synchronize them to Central System.

1) If the name of camera of Remote Site is changed, click **Name Changed Camera** to expand the name changed camera list.

Change of Remote Site	Number
✓ Name Changed Camera	1
°↓ Synchronize Camera Name	
Camera Name (Remote)	Camera Name (Central)
Camera123	Camera1

Figure 9-15 Name Changed Camera

You can view the camera names in Remote Site and Central System.

2) Select the cameras and click **Synchronize Camera Name** to synchronize the camera name in Central System.

9.10 Manage Application Data Server

HikCentral Professional provides distributed deployment for the two core services: System Management Service and Application Data Service. Distributed deployment can improve the system performance and the number of connectable cameras can be increased to 10,000.

Enter **Physical View** → **Application Data Server** to enter the application data server management page.

What is Application Data Server?

Application Data Server is the PC running the Application Data Service, which is mainly used for processing and storing the application data of the system. If the system License supports distributed deployment, you need to deploy an Application Data Server independently and add it to the system before any other operations.

What should I do before adding the Application Data Server to the system?

- Make sure the License of your system supports server distributed deployment.
- Download the installation package of Application Data Service and install it on a computer (except the computer running the System Management Service). After installation, run the Application Data Service and then the computer is an Application Data Server.
- You can add another Application Data Server as standby server for data backup redundancy if needed, which can improve the reliability and availability of the system. When the Application Data Server fails, the Application Data Standby Server will take over automatically.
- The Application Data Server, Application Data Standby Server, and the System Management Server should be in the same LAN which is secure and in the same time zone, or the system cannot run properly.
- Make sure the Application Data Server and Application Data Standby Server are online and running properly.
How to add an Application Data Server?

iNote

Only the admin user has the permission to add Application Data Server and Application Data Standby Server.

In the Application Data Server page, click **Add** and enter the server's IP address and port to add the server.

* Server Address	
* Server Port(TLS)	8208
* Alias	
	Add

Figure 9-16 Add Application Data Server

After adding the Application Data Server, in Application Data Server page, click **Add Standby Server** to add an Application Data Standby Server if necessary.

۞ Server Settings 🕗 Downlo	ad Installation Package	⊖ Refresh		
10.66.75.59	2 1		172.7.20.11	Ľ i
		Switch	(Standby Server)	
Running	_		(standady server)	

Figure 9-17 Application Data Server Management

INote

Click **Refresh** to get the latest status of the Application Data Server and Application Data Standby Server.

Encrypted Transmission

For data security, the system provides encrypted transmission for the Application Data Server, which encrypts the data transmitted between the Application Data Server and other services or clients.

Only admin user can edit this function and the admin user can only edit it via the Web Client running on the SYS server.

In Application Data Server page, click **Server Settings** and check **Encrypted Transmission** to enable this function.

Set Threshold of Failure Status

If the system disconnects with the Application Data Server or Application Data Standby Server and the disconnection lasts for specified time, the system will regard the server as failure and notify the administrator to maintain it.

In Application Data Server page, click **Server Settings** and you can set the threshold in **Change Status to Failure after Disconnection of** field.

For example, if you set the threshold as 10 seconds, and the server disconnects with the system for 10 or more seconds, the server status will turn to failure.

Automatically Switch to Application Data Standby Server

If the Application Data Server fails, the Application Data Standby Server will take over automatically. After that, the original Application Data Standby Server will turn to Application Data Server, and the original Application Data Server will turn to standby server.

You can click **Refresh** to get the latest status of the Application Data Server and Application Data Standby Server.

Maintain Server Fault

iNote

Only the admin user has the permission to perform the maintenance.

After refreshing manually, if the Application Data Server or Application Data Standby Server fails, the server's status will change to failure and system will display the fault details to help you diagnose the reason. After maintenance, if the system detects the server is running properly, click **I've maintained it.** and then the servers will turn to normal status.

Manually Switch to Application Data Standby Server

iNote

Only the admin user has the permission to switch to Application Data Standby Server.

If the Application Data Server fails but the system cannot detect its fault, or you need to change the server to a better one, you can manually switch the Application Data Server currently in working status to the Application Data Standby Server which is in ready status. In Application Data Server page, click **Switch** to switch to the Application Data Standby Server and then the standby server will take over.

During switching, the Application Data Server will be stopped for a while and it will resume after switching.

9.11 Manage Recording Server

You can add the Recording Server to the system for storing the videos and pictures. Currently, the Recording Server supports Hybrid Storage Area Network, Cloud Storage Server, pStor, and NVR (Network Video Recorder). You can also form an N+1 hot spare system with several Hybrid Storage Area Networks to increase the video storage reliability of system.

∎Note

NVR can only be used to store pictures.

9.11.1 Manage Cloud Storage Server

You can add a Cloud Storage Server as a Recording Server to the HikCentral Professional for storing the video files.

Import Service Component Certificate to Cloud Storage Server

For data security purpose, the Cloud Storage Server's certificate should be same with the SYS server's. Before adding the Cloud Storage Server to the system, you should import the certificate stored in the SYS server to the Cloud Storage Server first.

Before You Start

Make sure the Cloud Storage Server you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Steps

iNote

If the service component certificate is updated, you should export the new certificate and import it to the Cloud Storage Server again to update.

- 1. Click System → Service Component Certificate .
- 2. Click Export to export the certificate stored in the SYS server.
- **3.** Log in the configuration page of the Cloud Storage Server via web browser.
- 4. Click System \rightarrow Configuration \rightarrow Cloud Configuration .
- **5.** Input the root keys salt and keys component according to the parameters in the certificate you export in Step 3.

Encryption & Decryption:	● Open ○ Close	Digest Algorithm:	sha256	•
Root Keys Salt:	F140BA81E408461A	Keys Component:	F140BA81E408461A	
Keys Security Level:	⊖ High ⊖ Medium			

6. Click Set.

What to do next

After importing the certificate to the Clout Storage Server, you can add the server to the system for management. See *Add Cloud Storage Server* for details.

Add Cloud Storage Server

You can add Cloud Storage Server as Recording Server to the HikCentral Professional for storing the video files and pictures.

Before You Start

- Make sure the Cloud Storage Servers you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.
- You should import the service component certificate to the Cloud Storage Server first before adding it to the system. See *Import Service Component Certificate to Cloud Storage Server* for details.

Steps

- 1. Click Physical View → Recording Server to enter the recording server page.
- 2. Click Add to enter the adding server page.
- 3. Select Cloud Storage Server.
- **4.** Enter the network parameters.

Address

The server's IP address in LAN that can communicate with SYS server.

Control Port

The control port No. of the server. If it is not changed, use the default value.

Network Port

The network port No. of the server. If it is not changed, use the default value.

Signaling Gateway Port

The signaling gateway port No. of the server. If it is not changed, use the default value.

5. Enter the user's access key and secret key of the Cloud Storage Server for searching the video files stored in this Cloud Storage Server via the HikCentral Professional Mobile Client or downloading pictures via Control Client.

- You can download these two keys on the Cloud Storage Server's configuration page (click Virtualizing → User Management).
- 6. Optional: Set the Enable Picture Storage switch to ON for storing pictures in this Cloud Storage Server.

iNote

If this function is enabled, you need to set picture downloading port No., which is used to download pictures via Control Client.

- **7. Optional:** If you need to access the server via WAN, set the **Enable WAN Access** switch to ON and set the corresponding parameters which are available when you access the server via WAN.
- 8. Enter the alias, user name, and password of the server.

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

9. Finish adding the server.

- Click Add to add the server and back to the server list page.
- Click Add and Continue to save the settings and continue to add other servers.
- **10. Optional:** Perform the following operations after adding the server:

Edit Server	Click Alias field of the server and you can edit the information of the server and view its storage and camera information.
Delete Server	Select the server(s) from the list, and click Delete to remove the selected server(s).
Configure Server	Click 😳 , and the login interface of the Cloud Storage Server displays. You can log in and configure the Cloud Storage Server.

9.11.2 Add Hybrid Storage Area Network

You can add the Hybrid Storage Area Network (hereafter simplyfied as Hybrid SAN) as Recording Server to the HikCentral Professional for storing the video files and pictures.

Before You Start

Make sure the Hybrid Storage Area Networks you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Steps

- 1. Click Physical View → Recording Server to enter the recording server page.
- 2. Click Add to enter the Add Recording Server page.
- 3. Select Hybrid Storage Area Network.
- 4. Enter the network parameters.

Address

The server's IP address in LAN that can communicate with SYS.

Control Port

The control port No. of the server. If it is not changed, use the default value.

Network Port

The network port No. of the server. If it is not changed, use the default value.

- **5. Optional:** Enable picture storage function for storing pictures in this Hybrid Storage Area Network.
 - 1) Set the Enable Picture Storage switch to ON.
 - 2) Set picture downloading port No. for downloading pictures via Control Client. If the picture downloading port No. is not changed, use the default ones.
 - 3) Set signaling gateway port No.. If the picture downloading port No. is not changed, use the default ones.
 - 4) Enter the access key and secret key.

iNote

The access key and secret key are used to download pictures via the Control Client. If required, you can contact our technical support to get them.

6. Optional: If you need to access the server via WAN, set the **Enable WAN Access** switch to ON and set the corresponding parameters which are available when you access the server via WAN.

7. Enter the alias, user name, and password of the server.

ACaution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

8. Optional: Set the storage Information.

Custom Video Copy-back

After enabled, the video footage (if exists) recorded within the defined **Start Time** and **End Time** on cameras or NVRs managed by the Hybrid SAN will be automatically copied back to the Hybrid SAN.

iNote

- The time for starting copy-back could be any time when there exists video footage meets the above mentioned condition.
- The time period within the start time and end time should be longer than 24 hours, and the end time should NOT be later than 2 hours before.

For example, if the current time is "10:00:00, Oct. 31st", and you have enabled custom video copy-back (in which you set "2 days before copy-back" as the start time, "2 hours before copy-back" as the end time), the video footage recorded from "10:00:00, Oct. 29th" to "8:00:00, Oct. 31st" on cameras or NVRs managed by the Hybrid SAN will be backed up to the Hybrid SAN.

Video Expiration

Set the expiration time to retain the video footage stored on the Hybrid SAN.

For example, if you set 30 days as the expiration time, the video footage stored on the Hybrid SAN for longer than 30 days will be automatically deleted.

9. Finish adding the server.

- Click Add to add the server and back to the server list page.
- Click Add and Continue to save the settings and continue to add other servers.
- **10. Optional:** Perform the following operations after adding the server:

Edit Server	Click Alias field of the server and you can edit the information of the server and view its storage and camera information.
Delete Server	Select the server(s) from the list, and click Delete to remove the selected server(s).
Configure Server	Click 😳 , and the login interface of the Hybrid Storage Area Network displays. You can log in and configure the Hybrid SAN.
One-Touch Configuration	If the Hybrid Storage Area Network has not been configured with storage settings, click 🔅 to perform one-touch configuration before you can store the video files of the camera on the Hybrid Storage Area Network.

9.11.3 Add pStor

You can add pStor as Recording Server to the HikCentral Professional for storing the video files and pictures.

Before You Start

Make sure the pStors you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Steps

- 1. Click Physical View → Recording Server to enter the recording server page.
- 2. Click Add to enter the adding server page.
- 3. Select pStor.
- 4. Enter the network parameters.

Address

The server's IP address in LAN that can communicate with SYS.

Control Port

The control port No. of the pStor. If it is not changed, use the default value.

Network Port

The network port No. of the pStor. If it is not changed, use the default value.

Signaling Gateway Port

The signaling gateway port No. of the pStor. If it is not changed, use the default value.

5. Enter the user's access key and secret key of the pStor for downloading pictures via Control Client.

iNote

You can download these two keys on the pStor's Web Client page.

6. Optional: Set the Enable Picture Storage switch to ON for storing pictures in this pStor.

i Note

If this function is enabled, you need to set picture downloading port No., which is used to download pictures via Control Client.

- **7. Optional:** If you need to access the server via WAN, set the **Enable WAN Access** switch to ON and set the corresponding parameters which are available when you access the server via WAN.
- 8. Enter the alias, user name, and password of the pStor.

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

9. Finish adding the server.

- Click Add to add the server and back to the server list page.
- Click Add and Continue to save the settings and continue to add other servers.
- **10. Optional:** Perform the following operations after adding the server:

Edit Server	Click Alias field of the server and you can edit the information of the server and view its storage and camera information.
Delete Server	Select the server(s) from the list, and click Delete to remove the selected server(s).
Configure Server	Click 😳 , and the login interface of the pStor displays. You can log in and configure the pStor.

9.11.4 Add Network Video Recorder

You can add NVR (Network Video Recorder) as a Recording Server to HikCentral Professional for storing video files and pictures.

Before You Start

Make sure the NVR you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the system via network.

Steps

- **1.** Click **Physical View** → **Recording Server** to enter the recording server page.
- 2. Click Add to enter the adding server page.
- 3. Select Network Recording Server as the server type.
- **4.** Set the required information.

Address

The server's IP address in LAN that can communicate with SYS.

Control Port

The control port No. of the NVR. If it is not changed, use the default value.

Network Port

The network port No. of the NVR. If it is not changed, use the default value.

Picture Download Port

The picture downloading port of the NVR. If it not changed, use the default value.

Signaling Gateway Port

The signaling gateway port No. of the NVR. If it is not changed, use the default value.

5. Enter the user's access key and secret key of the NVR for downloading pictures via Control Client.

iNote

You can download these two keys on the NVR's Web Client page.

- 6. Optional: If you need to access the server via WAN, set the Enable WAN Access switch to ON and set the corresponding parameters which are available when you access the server via WAN.
 7. Enter the alias, user name, and password of the NVP.
- **7.** Enter the alias, user name, and password of the NVR.

Caution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

8. Finish adding the NVR.

- Click Add to add the NVR and back to the server list page.
- Click Add and Continue to save the settings and continue to add other NVRs.
- **9. Optional:** Perform the following operations after adding the NVR:

Edit NVR	Click Alias field of the NVR and you can edit the information of the NVR and view its storage and camera information.
Delete NVR	Select the NVR(s) from the list, and click Delete to remove the selected server(s).
Configure NVR	Click 😳 , and the login interface of the NVR will be displayed. You can log in and configure the NVR.

9.11.5 Set N+1 Hot Spare for Hybrid SAN

You can form an N+1 hot spare system with several Recording Servers. The system consists of several host servers and a spare server. When the host server fails, the spare server switches into operation, thus increasing the video storage reliability of HikCentral Professional.

Before You Start

- Make sure the Hybrid Storage Area Networks you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.
- At least two online Hybrid Storage Area Networks should be added to form an N+1 hot spare system.

Steps

i Note

- The N+1 hot spare function is only supported by Hybrid Storage Area Networks and NVRs. For details about configuring N+1 hot spare system with NVRs, see **Set N+1 Hot Spare for NVR**.
- The spare server cannot be selected for storing videos until it switches to host server.
- The host server cannot be set as a spare server and the spare server cannot be set as a host server.
- 1. Click Physical View → Recording Server → N+1 Hot Spare to enter the N+1 Configuration page.

	nfiguration			
Spare	Host	Туре	Sending Status	Operation
_CVR	_CVR	Central Video Recorder	⊘ Successful	

Figure 9-18 N+1 Configuration Page

- 2. Click Add to set the N+1 hot spare.
- 3. Select a Hybrid Storage Area Network in the Spare drop-down list to set it as the spare server.
- **4.** Select the Hybrid Storage Area Network(s) in the Host field as the host server(s).
- 5. Click Add.

iNote

The recording schedules configured on the Hybrid Storage Area Network will be deleted after setting it as the spare Recording Server.

6. Optional: After setting the hot spare, you can do one or more of the following:

Edit Click Z on the Operation column, and you can edit the spare and host settings.

 $\textbf{Delete} \quad \mathsf{Click} \times \mathsf{on} \ \mathsf{the} \ \mathsf{Operation} \ \mathsf{column} \ \mathsf{to} \ \mathsf{cancel} \ \mathsf{the} \ \mathsf{N+1} \ \mathsf{hot} \ \mathsf{spare} \ \mathsf{settings}.$

iNote

Canceling the N+1 hot spare will cancel all the host-spare associations and clear the recording schedule on the spare server.

9.12 Manage Streaming Server

You can add the Streaming Server to the HikCentral Professional to get the video data stream from the Streaming Server, thus to lower the load of the device.

For system which supports Remote Site Management, the cameras imported from Remote Site adopt the Streaming Server configured on the Remote Site by default. You are not required to add the Streaming Server to Central System and configure again.

9.12.1 Import Service Component Certificate to Streaming Server

For data security purpose, the Streaming Server's certificate should be same with the SYS server's. Before adding the Streaming Server to the system, you should import the certificate stored in the SYS server to the Streaming Server first.

Perform this task when you need to import the service component certificate to the Streaming Server.

Steps

iNote

If the service component certificate is updated, you should import the new certificate to the Streaming Server again to update.

1. Log into the Web Client on the SYS server locally.

You will enter the home page of the Web Client.

- 2. Enter System → Service Component Certificate .
- 3. Click Export to export the certificate stored in the SYS server.
- 4. Copy the certificate to the computer which has installed with Streaming Service.
- 5. Open the Service Manager, select the Streaming Service and click 🗈 to import the certificate you exported in Step 3.

9.12.2 Add Streaming Server

You can add a Streaming Server to the system to forward the video stream.

Steps

- **1.** Click **Physical View** → **Streaming Server** to enter the Streaming Server management page.
- 2. Click Add to enter the Add Streaming Server page.
- **3.** Enter the required information.

Network Location

Select LAN IP Address if the Streaming Server and the SYS server are in the same LAN. Otherwise, select WAN IP Address.

4. Optional: If you need to access the server via WAN, set the **Enable WAN Access** switch as **ON** and set the corresponding parameters which are available when you access the server via WAN.

The Enable WAN Access switch is available when you set Network Location as LAN IP Address.

- 5. Finish adding the Streaming Server.
 - Click Add to add the server and back to the server list page.
 - Click Add and Continue to save the server and continue to add other servers.

The servers will be displayed on the server list for management after added successfully. You can check the related information of the added servers on the list.

9.13 Add Facial Recognition Server

You can add facial recognition server to the HikCentral Professional for face recognition.

Before You Start

Make sure the facial recognition server you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Steps

- 1. Click Physical View → Facial Recognition Server to enter the Facial Recognition Server page.
- 2. Click Add to enter the Add Facial Recognition Server page.

⊖ Add Facial Recognition Server		
Basic Information		
* Device Address		
* Port	443	
Enable WAN Access	0	
* Alias		
* User Name	admin	
* Password	Ø	
	Risky	
Facial Recognition Settings		
G Configuration	+ Add	
	Add Add and C	ontinue Cancel

Figure 9-19 Add Facial Recognition Server Page

3. Set the required basic information such as device address, device port number, and WAN access.

Device Address

IP address of the facial recognition server.

Enable WAN Access

Enable the facial recognition server to access WAN (Wide Area Network).

- 4. Configure facial recognition settings.
 - 1) Click Add.
 - 2) Select camera(s) from the area list or enter keywords to search camera(s).

i Note

After adding one normal camera, the amount of cameras that can be added to the facial recognition server will decrease by 5. While after adding one facial recognition camera, the amount will decease by 1.

- 3) Select face comparison group(s) for the server.
- **5.** Finish adding the facial recognition server.
 - Click Add to finish adding the server.
 - Click Add and Continue to add the server and continue to add more.

9.14 Manage Smart Wall

Smart wall can provide security personnel with a rich visual overview of the areas you want to keep an eye on. Before displaying the video on smart wall, you need to set up smart wall firstly, and you can also edit, delete smart wall or manage decoding devices here.

This mainly includes the following:

- Decoding devices that can be added to the system and used for decoding the video stream from the encoding devices.
- Virtual smart wall that defines the layout and the name of the smart wall.
- Link between the decoding outputs of the decoding device and the windows of the smart wall.

9.14.1 Add Decoding Device

The decoding devices can be added to the system for linking with the smart wall. You can add online decoding devices with the IP addresses within SYS server's or Web Client's subnet, and can also add decoding devices by IP address, IP segment, or by port segment.

Add Online Decoding Device

The system can perform an automated detection for available decoding devices on the network where the Web Client or SYS server is located, which makes the devices' information about themselves (e.g., IP address) recognized by the system. Based on the information, you can add the devices quickly.

Before You Start

Make sure the devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Steps

iNote

- For Google Chrome, you should install the SADP service according to the instructions and then the online device detection function is available.
- For Firefox, you should install the SADP service and import the certificate according to the instructions and then the online device detection function is available.
- 1. Click Physical View → Smart Wall to enter the smart wall management page.
- 2. Click Add on Decoding Device panel to enter the Add Decoding Device page.
- 3. Select Online Devices as Adding Mode.
- 4. In the Online Device area, select a network type.

Server Network

The detected online devices in the same local subnet with the SYS server will list in the Online Device area.

Local Network

The detected online devices in the same local subnet with the Web Client will list in the Online Device area.

5. Check the checkbox of the device(s) to be added.

i Note

- For the inactive device, you need to create the password for it before you can add it properly. For detailed steps, see .
- If the detected devices have the same password and user name, you can add multiple devices at a time. Otherwise, you can add them one by one.

6. Enter the required information.

User Name

The user name for administrator account created when activating the device or the added non-admin account such as operator. When adding the device to HikCentral Professional using the non-admin account, your permissions may restrict your access to certain features.

Password

The password required to access the account.

ACaution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

7. Finish adding the decoding device.

- Click **Add** to add the decoding device and back to the decoding device list page.
- Click Add and Continue to save the settings and continue to add other decoding devices.
- 8. Optional: Perform the following operations after adding the decoding device.

View Decoding Output	Click > to show the decoding outputs. You can view the output resolution and linking status after linking the output to smart wall. For details about linking decoding output with smart wall, see <i>Add Smart Wall</i> .
Edit	Click 🗹 to edit the decoding device. You can modify the network location as LAN IP address or WAN IP address.
Remote	Click 😳 to set the remote configurations of the device.
Configurations	i Note
	For detailed operations, see the user manual of the device.
Delete	Click $ imes$ to delete the device.

Add Decoding Device by IP Address

When you know the IP address of the decoding device to add, you can add the device to your system by specifying IP address, user name, password and other related parameters. This adding mode requires you to add the devices one by one, so it is a good choice if you only want to add a few devices and know all the details mentioned above.

Before You Start

Make sure the devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Steps

- 1. Click Physical View → Smart Wall to enter the smart wall management page.
- 2. Click Add to enter the Add Decoding Device page.

⊖ Add Decoding Dev	vice
Adding Mode	
	Online Devices
	IP Address
	O IP Segment
	O Port Segment
Basic Information	
* Access Protocol	Hikvision Protocol
* Device Address	
* Device Port	8000
* Alias	
* User Name	admin
* Password	
	Risky
	Add and Continue Cancel

Figure 9-20 Add Decoding Device Page

- 3. Select IP Address as Adding Mode.
- **4.** Enter the required information.

Access Protocol

Select **Hikvision Protocol** to add the devices and select **ONVIF Protocol** to add the thirdparty devices.

Device Address

The IP address of the device.

Device Port

The port number on which to scan. The default is 8000.

If the device is located behind a NAT (Network Address Translation)-enabled router or a firewall, you may need to specify a different port number. In such cases, remember to configure the router/firewall so it maps the port and IP address used by the device.

Alias

Create a descriptive name for the device. For example, you can use an alias that can show the location or feature of the device.

User Name

The user name for administrator account created when activating the device or the added non-admin account such as operator. When adding the device to HikCentral Professional using the non-admin account, your permissions may restrict your access to certain features.

Password

The password required to access the account.

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

5. Finish adding the device.

- Click Add to add the decoding device and back to the decoding device list page.
- Click Add and Continue to save the settings and continue to add other decoding devices.
- 6. Optional: Perform the following operations after adding the decoding device.

View Decoding Output	Click > to show the decoding outputs. You can view the output resolution and linking status after linking the output to smart wall. For details about linking decoding output with smart wall, see <i>Add Smart Wall</i> .
Edit	Click 🗹 to edit the decoding device. You can modify the network location as LAN IP address or WAN IP address.
Remote	Click 🐵 to set the remote configurations of the device.
Configurations	i Note
	For detailed operations, see the user manual of the device.
Delete	Click $ imes$ to delete the device.

Add Decoding Devices by IP Segment

If multiple decoding devices to add have the same port number, user name and password, but have different IP addresses, which are within a range, you can select this adding mode, and specify the IP range where your devices are located, and other related parameters. The system will scan from the start IP address to the end IP address for the devices in order to add them quickly.

Before You Start

Make sure the devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Steps

- 1. Click Physical View → Smart Wall to enter the smart wall management page.
- **2.** Click **Add** to enter the Add Decoding Device page.

⊖ Add Decoding Device		
Adding Mode		
	 Online Devices 	
	O IP Address	
	 IP Segment 	
	 Port Segment 	
Basic Information		
* Access Protocol	Hikvision Protocol]
* Device Address	Start	— End
* Device Port	8000]
* User Name	admin	
* Password]
	Risky	1
	Add Add and 0	Continue Cancel

Figure 9-21 Add Decoding Device Page

- 3. Select IP Segment as Adding Mode.
- **4.** Enter the required information.

Access Protocol

Select **Hikvision Protocol** to add the devices and select **ONVIF Protocol** to add the thirdparty devices.

Device Address

Enter the start IP address and end IP address where the devices are located.

Device Port

The same port number of the devices. By default, the device port No. is 8000.

User Name

The user name for administrator account created when activating the device or the added non-admin account such as operator. When adding the device to HikCentral Professional using the non-admin account, your permissions may restrict your access to certain features.

Password

The password required to access the account.

ACaution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

- 5. Finish adding the device.
 - Click **Add** to add the decoding device and back to the decoding device list page.
 - Click Add and Continue to save the settings and continue to add other decoding devices.
- 6. Optional: Perform the following operations after adding the decoding device.

View Decoding Output	Click > to show the decoding outputs. You can view the output resolution and linking status after linking the output to smart wall. For details about linking decoding output with smart wall, see <i>Add Smart Wall</i> .
Edit	Click 🗹 to edit the decoding device. You can modify the network location as LAN IP address or WAN IP address.
Remote Configurations	Click 🛞 to set the remote configurations of the device. Note For detailed operations, see the user manual of the device.

Delete

 $\mbox{Click} \times \mbox{to}$ delete the device.

Add Decoding Devices by Port Segment

When multiple decoding devices to add have the same IP address, user name and password, but have different port numbers, which are within a range, you can select this adding mode and specify the port range, IP address, user name, password, and other related parameters to add them.

Before You Start

Make sure the devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.

Steps

1. Click Physical View → Smart Wall to enter the smart wall management page.

2. Click Add to enter the Add Decoding Device page.

Add Decoding Device		
Adding Mode		
	Online Devices	
	O IP Address	
	O IP Segment	
	Port Segment	
Basic Information		
* Access Protocol	Hikvision Protocol	
* Device Address		
* Device Port	Start — End	
* User Name	admin	
* Password		
	Risky	
	Add and Continue Cancel	

Figure 9-22 Add Decoding Device Page

- 3. Select Port Segment as Adding Mode.
- **4.** Enter the required information.

Access Protocol

Select **Hikvision Protocol** to add the devices and select **ONVIF Protocol** to add the thirdparty devices.

Device Address

The same IP address where the devices are located.

Device Port

Enter the start port number and the end port number on which to scan.

User Name

The user name for administrator account created when activating the device or the added non-admin account such as operator. When adding the device to HikCentral Professional using the non-admin account, your permissions may restrict your access to certain features.

Password

The password required to access the account.

Caution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

- **5.** Finish adding the device
 - Click **Add** to add the decoding device and back to the decoding device list page.
 - Click Add and Continue to save the settings and continue to add other decoding devices.
- After adding the decoding device, the device will display in the list on Decoding Device panel.
- 6. Optional: Perform the following operations after adding the decoding device.

View Decoding Output	Click > to show the decoding outputs. You can view the output resolution and linking status after linking the output to smart wall. For details about linking decoding output with smart wall, see <i>Add Smart Wall</i> .
Edit	Click 🗹 to edit the decoding device. You can modify the network location as LAN IP address or WAN IP address.
Remote	Click 🐵 to set the remote configurations of the device.
Configurations	i Note
	For detailed operations, see the user manual of the device.
Delete	Click $ imes$ to delete the device.

9.14.2 Configure Cascade

In some actual scenarios for large screen display, the screen number of the smart wall will exceed the decoding output number of one decoder, or the cross-decoder functions such as roaming and spanning are required. You can cascade two decoders with video wall controller to meet various display demands.

Before You Start

- Make sure the devices you are going to use are correctly installed and connected to the network as specified by the manufacturers. Such initial configuration is required in order to be able to connect the devices to the HikCentral Professional via network.
- The decoders' interfaces have be connected with the video wall controller's using the matched wires.
- The decoders and video wall controller are added to the HikCentral Professional. Refer to *Add Decoding Device* for details.

Perform this task when you need to configure cascade for the decoding devices as follows.



Figure 9-23 Cascade

Steps

1. Click Physical View → Smart Wall to enter the smart wall management page.

The added decoding device(s) and the added smart wall will display.

2. Click $\square_{\square}^{\square}$ behind the added video wall controller to enter the Cascading page.

iNote

Only video wall controller DS-CS10S and DS-C10S-T can support this function.

- 3. Select the signal channel of the video wall controller and click \Box_2 .
- **4.** Select the decoding output of the decoders to set it as the signal input of the video wall controller.

iNote

If the decoders are cascaded with video wall controller, the spared decoding outputs of the decoders cannot be used to display on smart wall any more.

5. Click Save to save the cascade.

Result

After configuring cascade, you need to add a smart wall and link the decoding outputs of the video wall controller to display the signal outputs of the two decoders on the smart wall.

9.14.3 Add Smart Wall

You can add the smart wall to the system and configure its row and column.

Perform this task when you need to add a smart wall to the system.

Steps

- 1. Click Physical View → Smart Wall to enter the smart wall management page.
- 2. Click Add on Smart Wall panel to open the Add Smart Wall dialog.

*Name	Smart Wall 2		
*Row x Column	4	x	4
			Save

Figure 9-24 Add Smart Wall Dialog

- 3. Set the name for the smart wall.
- 4. Set the row number and the column number.
- 5. Click Save.
- 6. Optional: Perform the following operations after adding the decoding device.

Link Decoding Output with Window	For details about the operations, see <i>Link Decoding</i> <i>Output with Window</i> .
Edit Smart Wall	Edit the name of the smart wall.
Delete Smart Wall	Delete the smart wall.

9.14.4 Link Decoding Output with Window

After adding the decoding device and smart wall, you should link the decoding device's decoding output to the window of the smart wall.

Perform this task when you need to link the decoding output to the smart wall.

Steps

1. Click Physical View → Smart Wall to enter the smart wall management page.

The added decoding device(s) and the added smart wall will display.

- **2.** Click \rightarrow in front of the decoding device to show the decoding outputs.
- **3.** Click > in front of the smart wall to show the windows.
- **4.** Drag the decoding output from the Decoding Device panel to the display window of the smart wall, to configure the one-to-one correspondence.

Decoding Device				Smart Wall			
+ Add				+ Add			
✓ 10.18.139.120	2	6	\times \land	✓ Smart Wall			>
Decoding	Output Re	Linking	Status				
BNC_1							
BNC_2							
BNC_3							
BNC_4					HDMI_3	HDMI_4	
HDMI_1							
HDMI_2							
HDMI_3	720P •	\odot			HDMI_5	HDMI_6	
HDMI_4	XGA 👻	\oplus					
HDMI_5	1080 •	\odot					
HDMI_6	1080 •	\odot					
HDMI_7							
HDMI_8							
> 1.1.1.1(1) ()	Z	1 🔅	\times ,				
~		o					



5. Optional: Click \mathbf{x} to release the linkage.

Chapter 10 Manage Area

HikCentral Professional provides areas to manage the added resources in different groups. You can group the resources into different areas according to the resources' locations. For example, on the 1st floor, there mounted 64 cameras, 16 access points, 64 alarm inputs, and 16 alarm outputs. You can organize these resources into one area (named 1st Floor) for convenient management. You can get the live view, play back the video files, and do some other operations of the devices after managing the resources by areas.

iNote

If the current system is a Central System with a Remote Site Management module, you can also manage the areas on a Remote Site and add cameras on Remote Site into areas.

10.1 Add Area

You should add an area before managing the elements by areas.

10.1.1 Add Area for Current Site

You can add an area for current site to manage the devices.

Steps

- 1. Click Logical View on the Home page to enter the Logical View page.
- 2. Optional: Select the parent area in the area list panel to add a sub area.

iNote

- For a Central System with a Remote Site Management module, you can select the current site from the drop-down site list to show its areas.
- The icon (a) indicates that the site is a current site.
- **3.** Click + on the area list panel to open the Add Area window.

Add Area	
Basic Information	
1 *Parent Are	ea 🔟 0314_01 👻
*Area Nam	Area_20180316161219
🕕 Streaming Serve	er <none></none>
Мар	
Related Ma	рО
	Save Cancel

Figure 10-1 Add Area for Current Site

- 4. Select the parent area to add a sub area.
- 5. Create a name for the area.
- **6. Optional:** Select a Streaming Server for the area to get the video stream of the cameras belonging to this area via the server.
- **7. Optional:** If you select a Streaming Server for the area, check **Wall Display via Streaming Server** to display the area's resources on the smart wall via this Streaming Server.
- 8. Optional: Set the Related Map switch to ON and link e-map(s) to area. See *Link E-Map to Area* for details.
- 9. Click Save.
- **10. Optional:** After adding the area, you can do one or more of the following:

Edit Area	Click 🗹 to edit the area.
Delete Area	Click in to delete a selected area, or press Ctrl on your keyboard and select multiple areas and then click in to delete areas in a batch.

iNote

After deleting the area, the resources in the area (cameras, alarm inputs, alarm outputs, access points, and UVSSs) will be removed from the area, as well as the corresponding recording settings, event settings, and map settings.

Search Enter a keyword in the search field to search the area.

Area

10.1.2 Add Area for Remote Site

You can add an area for Remote Site to manage the devices in the Central System.

Steps

- 1. Click Logical View on the Home page to enter the Logical View page.
- **2.** In the area list panel, select the added Remote Site from the drop-down site list to show its areas.

iNote

The icon 🚱 indicates that the site is Remote Site.

3. Click + on the area list panel to open the Add Area window.

Add Area	
Basic Information	
() *Parent Area	None •
*Mode	Import Area with New Cameras
	 Add New Area
*Area	⊖ Refresh
	Search
	 No data.
() Streaming Server	<none> •</none>
	Save



4. Select the parent area to add a sub area.

5. Set the adding mode for adding the area.

Import Area with New Cameras

If there are some cameras newly added to the areas on a Remote Site, you can import the areas as well as those newly added cameras. The areas with newly added cameras will display and you can select the areas to add.

Add New Area

Add a new area to the parent area.

- **6. Optional:** Select a Streaming Server for the area to get the video stream of the cameras belonging to this area via the server.
- **7. Optional:** If you select a Streaming Server for the area, check **Wall Display via Streaming Server** if you want to display the area's resources on the smart wall via this Streaming Server.
- 8. Click Save.
- **9.** After adding the area, you can do one or more of the following:

 Edit Area
 Click ☑ to edit the area.

 Delete Area
 Click imes to delete the selected area, or press Ctrl on your keyboard and select multiple areas and then click imes to delete areas in a batch.

 Image: The selected area, the cameras will be removed from the area, as well as

Search Area Enter a keyword in the search field to search the area.

10.2 Add Element to Area

You can add elements including cameras, alarm inputs, alarm outputs, access points, and under vehicle surveillance systems into areas for management.

the corresponding recording settings and event settings.

10.2.1 Add Camera to Area for Current Site

You can add cameras to areas for the current site. After managing cameras into areas, you can get the live view, play the video files, and so on.

Before You Start

The devices need to be added to the HikCentral Professional for area management. Refer to *Manage Resource* for detailed configuration about adding devices.

Steps

iNote

One cameras can only belong to one area. You cannot add a camera to multiple areas.

- **1.** Click **Logical View** on the Home page to enter the Area Management page.
- 2. Select an area for adding cameras to.

- For a Central System with a Remote Site Management module, you can select the current site from the drop-down site list to show its areas.
- The icon 🛞 indicates that the site is current site.
- 3. Select the Cameras tab.
- 4. Click Add to enter the Add Camera page.
- **5.** Select the device type.

iNote

Some security control devices, such as the panic alarm stations, also contain the cameras.

- 6. Select the cameras to add.
- **7. Optional:** Check **Get Device's Recording Settings** to obtain the recording schedule configured on the local device and the device can start recording according to the schedule.

iNote

If the recording schedule configured on device is not continuous recording, it will be changed to event recording on the local device.

- 8. Optional: Check Add to Map to add the camera to the map.
- 9. Click Add.
- 10. Optional: After adding the cameras, you can do one or more of the followings

Get Camera Name	Select the cameras and click 1, Get Camera Name to get the cameras' names from the device in a batch.	
	i Note	
	You can only synchronize the camera name of online HIKVISION device.	
Apply Camera Name	Select the cameras and click $\buildrel black$ to apply the cameras' names to the device in a batch.	
Get Recording Schedule	Select the cameras and click 🔚 to get the recording schedules from the devices in a batch.	
Move to Other Area	Select the cameras and click 🔄 Move to Other Area . Then select the target area to move the selected cameras to and click Move .	
Display Cameras of Child Areas	Check Include Sub-area to display the cameras of child areas.	

10.2.2 Add Camera to Area for Remote Site

If the current system is a Central System with a Remote Site Management module, you can also add cameras from Remote Sites to areas in Central System for management.

Before You Start

Encoding devices need to be added to the HikCentral Professional for area management. Refer to *Manage Encoding Device* for detailed configuration about adding devices.

Perform this task when you need to add Remote Site's camera to central area.

Steps

i Note

Cameras can only belong to one area. You cannot add a camera to multiple areas.

- 1. Click Logical View on the Home page to enter the Area Management page.
- **2.** In the area list panel, select the added Remote Site from the drop-down site list to show its areas.

iNote

The icon 🖓 indicates that the site is Remote Site.

- 3. Select an area for adding elements to.
- 4. Click Add to enter the Add Camera page.

Add Camera	
*Camera	$\mathcal C$ Refresh
	Search
	✓ ■ ■ VSM1_147.250
	✓ ✓ I VSM1_RSM-SMS_RSM-CVR
	🗹 🔘 Camera1_onvif10.18.147.92
	> 🗌 📠 VSM1_VSM-SMS_VSM-Local
	Add Cancel

Figure 10-3 Add Camera Page

5. Select the cameras to add.

Up to 64 cameras can be added to one area.

- 6. Click Add.
- 7. Optional: After adding the cameras, you can do one or more of the following:

Synchronize Camera Name	Select the cameras and click \uparrow_{\downarrow} to get the cameras' names from the device in a batch.
Move to Other Area	Select the cameras and click 🖃 . Then select the target area to move the selected cameras to and click Move .
Display Cameras of Child Areas	Select Include Sub-area to display the cameras of child areas.

10.2.3 Add Access Point to Area for Current Site

You can add access points to areas for the current site for management.

Before You Start

Access control devices need to be added to the HikCentral Professional for area management. Refer to *Manage Resource* for detailed configuration about adding devices.

Steps

iNote

One access point can only belong to one area. You cannot add a access point to multiple areas.

- 1. Click Logical View on the Home page to enter the Area Management page.
- 2. Select an area for adding access points to.

iNote

- For a Central System with a Remote Site Management module, you can select the current site from the drop-down site list to show its areas.
- The icon () indicates that the site is current site.
- 3. Select the Access Points tab.
- 4. Click Add to enter the Add Access Point page.
- **5.** Select the access point(s) to add.
- 6. Optional: Check Add to Map to add the access point to the map.
- 7. Click Add.
- 8. Optional: After adding the access points, you can do one or more of the followings.

Get Access	Select the access points and click 1, Get Access Point Name to get the
Point Name	access points' names from the device in a batch.

You can only synchronize the access point name of online HIKVISION device.

Apply AccessSelect the access points and click is to apply the access points' names to
the device in a batch.

10.2.4 Add Alarm Input to Area

You can add alarm inputs to areas for the current site for management.

Before You Start

Devices need to be added to the HikCentral Professional for area management. Refer to *Manage Resource* for detailed configuration about adding devices.

Perform this task when you need to add current site's alarm inputs to areas.

Steps

iNote

Alarm input can only belong to one area. You cannot add an alarm input to multiple areas.

- **1.** Click **Logical View** on the Home page to enter the Area Management page.
- 2. Select an area for adding alarm inputs to.

iNote

- For a Central System with a Remote Site Management module, you can select the current site from the drop-down site list to show its areas.
- The icon 🛞 indicates that the site is current site.
- 3. Select the Alarm Inputs tab.
- 4. Click Add to enter the Add Alarm Inputs page.
- **5.** Select the device type.
- **6.** Select the alarm inputs to add.

iNote

For the security control device, you need to select its zones as alarm inputs to add to the area.

- 7. Optional: Check Add to Map to add the alarm input to the map.
- 8. Click Add.
- 9. Optional: After adding the alarm inputs, you can do one or more of the followings.
 - Move to Other AreaSelect the alarm inputs and click Move to Other Area. Then select
the target area to move the selected alarm inputs to and click
Move.

Display Alarm Inputs Check **Include Sub-area** to display the alarm inputs of child areas. **of Child Areas**

10.2.5 Add Alarm Output to Area

You can add alarm outputs to areas for the current site for management. When the alarm or event linked with the alarm output is detected, the alarm devices (e.g., the siren, alarm lamp, etc.) connected with alarm output will make actions. For example, when receiving the alarm out signal from the system, the alarm lamp will flash.

Before You Start

Devices need to be added to the HikCentral Professional for area management. Refer to *Manage Resource* for detailed configuration about adding devices.

Perform this task when you need to add current site's alarm outputs to areas.

Steps

iNote

One alarm output can only belong to one area. You cannot add an alarm output to multiple areas.

1. Click **Logical View** on the Home page to enter the Area Management page.

2. Select an area for adding alarm outputs to.

iNote

- For a Central System with a Remote Site Management module, you can select the current site from the drop-down site list to show its areas.
- The icon 🛞 indicates that the site is current site.
- 3. Select the Alarm Outputs tab.
- 4. Click Add to enter the Add Alarm Outputs page.
- **5.** Select the device type.
- **6.** Select the alarm outputs to add.
- 7. Optional: Check Add to Map to add the alarm output to the map.
- 8. Click Add.
- 9. Optional: After adding the alarm outputs, you can do one or more of the followings.

Move to Other Area	Select the alarm outputs and click Move to Other Area . Then select the target area to move the selected alarm outputs to and click Move .
Display Alarm Outputs of Child Areas	Check Include Sub-area to display the alarm outputs of child areas.

10.2.6 Add UVSS to Area for Current Site

You can add Under Vehicle Surveillance Systems (UVSSs) to areas for the current site for management.

Perform this task when you need to add Current Site's UVSSs to areas.

Steps

iNote

UVSSs can only belong to one area. You cannot add a UVSS to multiple areas.

- 1. Click Logical View on the Home page to enter the Area Management page.
- **2.** Select an area for adding UVSSs to.

iNote

- For a Central System with a Remote Site Management module, you can select the current site from the drop-down site list to show its areas.
- The icon 🛞 indicates that the site is current site.
- 3. Select the Under Vehicle Surveillance Systems tab.

iNote

If the map function is enabled, you can click \gg and click UVSSs.

- 4. Click Add to enter the Add UVSS page.
- **5.** Input the required information of UVSS.
- **6.** Link cameras to the UVSS.
 - 1) Set **Relate Camera** switch to ON.
 - 2) Select the cameras.
- 7. Check Add to Map to add the UVSS on the map.
- 8. Click Add.

10.3 Edit Element in Area

You can edit the area's added elements, such as recording settings, event settings, and map settings for cameras, application settings, hardware settings, and attendance settings for doors, and so on.

10.3.1 Edit Camera for Current Site

You can edit basic information, recording settings, picture storage settings, event settings, and map settings of the camera for current site. You can also edit the face comparison group settings of the cameras which support face picture comparison.

Steps

- 1. Click Logical View on the Home page to enter the Area Management page.
- 2. In the area list panel, select the added current site from the drop-down site list to show its areas.

iNote

The icon 🛞 indicates that the site is current site.

- 3. Select an area.
- 4. Select the Cameras tab to show the added cameras.
- 5. Click Name column to enter the Edit Camera page.
- 6. Edit the camera's basic information, including camera name and protocol type.

iNote

If you changes the camera's name, you can click **Apply Camera Name** in the added cameras list page to apply the new name to the device.

7. Optional: Click ▶ to view the live view of the camera and hover over the window and click ▶ in the lower-right corner to switch to playback.

iNote

The live view and playback functions in the camera details page are only supported by Internet Explorer.

8. Edit the recording settings of the camera. See *Configure Recording* for details.

iNote

- If no recording settings have been configured for the camera, you can click **Configuration** to set the parameters.
- You can also select multiple cameras and click **Get Recording Schedule** in the added cameras list page to get recording schedules of the devices in a batch.
- **9. Optional:** Set the **Picture Storage** switch to on and select the storage location from the dropdown list for storing the pictures uploaded from the camera to the specified location.

iNote

Refer to *Configure Storage for Uploaded Pictures* for details.

10. Optional: Set pathway for people counting.

iNote

- This function is only supported by the second generation of fisheye cameras. You should have configured intersection analysis rule for the fisheye camera. If not, click **Configuration** to set that on the remote configuration page of the device.
- Make sure the camera has been added on an e-map.
- 1)Click the camera icon on the e-map, and click **Add Pathway** to select a direction as exit for the pathway.
- 2)Click a exist direction of one fisheye camera as starting point to draw the line, and click again to end drawing the line.
- 3)Enter the pathway name and select the direction as exit.

If there are two fisheye cameras in the pathway, you need to select the directions for each camera.

4) Click Save to save the pathway.

The configured pathway and exit of the current camera and related camera will display in the area.

- 5)**Optional:** Click the camera icon and select **Edit Direction Area** to set radius, view angle and direction.
- 11. Edit the event settings of the camera. See *Configure Event and Alarm* for details.

iNote

If no event settings have been configured for the camera, you can click **Configuration** to set the parameters.

12. Optional: Set the face comparison.

iNote

If this is supported by the license you purchased, you need to enter License Details page and click **Configuration** on Facial Recognition Camera line to add the camera as the facial recognition camera firstly.

1) Optional: Set Link to Facial Recognition Server switch to on and select the server.

iNote

After linking to facial recognition server, the facial recognition camera no longer supports the face comparison groups on itself. For the normal camera, you must link it with a server.

2)Select the person group(s) for face comparison.

iNote

You can click **Add New** to add new face comparison group and set the face comparison similarity threshold which affects the frequency and accuracy of face picture comparison alarm.

13. Add the camera to the map.

1)Set the **Add to Map** switch to ON.

2)Select the icon style and name color for displaying the camera on the map.

14. Optional: Click **Configuration on Device** to set the remote configurations of the corresponding device if needed.

For details about the remote configuration, refer to the user manual of the device.

- 15. Click Save.
- **16. Optional:** Enter Edit Camera page again and click **Copy to** to select configuration item and copy the settings of this camera to other cameras.

10.3.2 Edit Access Point for Current Site

You can edit basic information, related cameras, application settings, hardware settings, access level, attendance settings, event settings, and map settings of the access point for current site.

Steps

- 1. Click Logical View on the Home page to enter the Area Management page.
- 2. In the area list panel, select the added current site from the drop-down site list to show its areas.

iNote

The icon 🛞 indicates that the site is current site.

- 3. Select an area.
- 4. Select the Access Points tab to show the added access points.
- 5. Click Name column to enter the Edit Access Point page.
- 6. Edit the access point's basic information.

Name

Edit the name for the access point.

iNote

If you changes the name, you can click **Apply Access Point Name** in the added access points list page to apply the new name to the device.

Door Contact

The door contact's connection mode.

Exit Button Type

The exit button connection mode.

Open Duration(s)

The time interval between the access point is unlocked and locked again.

Extended Open Duration(s)

The time interval between the access point is unlocked and locked again when the person's extended access function enabled.

Door Open Timeout Alarm

After enabled, if the access point has configured with event or alarm, when the door contact open duration has reached the limit, the event or alarm will be uploaded to the system.

Duress Code

If you enter this code on the card reader keypad, the Control Client will receive an duress event. It should be different with the super password and dismiss code.

Super Password

If you enter this password on the card reader keypad, you are exempted from all the remaining locked (Credential Failed), anti-passback, and first card authorization restrictions. It should be different with the duress code and dismiss code.

Dismiss Code

If you enter this code on the card reader keypad, the buzzer's beeping will be stopped. It should be different with the duress code and super password.

Door Status Settings

You can enable this function to set free access schedule and access forbidden schedule.

Free Access Schedule

During this schedule, the access point remains open. User can enter or exit via the access point without any credentials. For turnstile, you can set schedules for entrance and exist respectively.

Access Forbidden Schedule

During this schedule, the access point remains closed. No user (except for super user) can enter or exit via the access point with credentials.

7. Link the cameras to the access point, and you can view its live view, recorded video, captured pictures via the Control Client.

iNote

Up to two cameras can be related to one access point.

8. Edit the application settings.

Entry & Exit Counting

You can enable this function to count the persons entering and exiting the access points in the group. For setting entry & exit counting rule, refer to *Configure Entry and Exit Counting Rules*.

Multi-Door Interlocking

You can enable the multi-door interlocking function between multiple doors of the same access control device. To open one of the doors, other doors must keep closed. For setting multi-door interlocking rule, refer to *Configure Multi-Door Interlocking*.

Anti-passback

The person should exit via the access point in the anti-passback if he/she enters via the access point in the anti-passback. It minimizes the misuse or fraudulent use of access credentials such as passing back card to an unauthorized person, or tailed access. For setting the anti-passback rule, refer to **Configure Anti-Passback Rules**.

Open Door with First Card

After swiping the first card, the access point will remain unlocked or be authorized. The status depends on the card swiping times (odd or even). For odd, the access point will remain unlocked or be authorized. For even, it will exit the unlocked or authorized mode.

- **9.** Edit the hardware settings.
 - 1) Set the Card Reader switch to on and set the card reader related parameters.

OK LED Polarity

Only supported when the device is connected via Wiegand interface. The polarity for OK core wire connection on the card reader mainboard.

Error LED Polarity

Only supported when the device is connected via Wiegand interface. The polarity for ERR core wire connection on the card reader mainboard.

Buzzer Polarity

Only supported when the device is connected via Wiegand interface. The polarity for buzzer connection on the card reader mainboard.

2) Set the card reader's access mode in normal time periods.

i Note

The card reader's access modes should be supported by the device.

Example

If you select **Card**, you should open the access point by swiping the card all the time.

3) **Optional:** When you want to open the access point via another access mode in some special time periods, set the card reader's access mode and select the custom time period.

Example

If you select **Fingerprint** and **Weekend Schedule**, you should open the access point via fingerprint at weekends.

i Note

You can add a custom schedule template and up to 3 time periods can be set for each day. See *Set Access Schedule Template* for details.

4) Set the Min. Card Swipe Interval switch to on and set the interval.

Min. Card Swipe Interval

After enabled, you cannot swipe the same card again within the minimum card swiping interval.

- 5) Set the maximum time interval of pressing two keys on the keypad. If timed out, the first entry will be reset.
- 6) Set the Failed Card Attempts Alarm switch to ON and set the maximum failed attempts.

Failed Card Attempts Alarm

After enabled, if the access point has configured with event or alarm, when the number of excessive failed card swiping attempts has reached the limit, the event or alarm will be uploaded to the system.

Tampering Detection

After enabled, if the access point has configured with device tampered event or alarm, when the device body or panel is taken apart, the alarm will be triggered and sent to the system.

- **10. Optional:** For the access point of the turnstile, set **Face Recognition Terminal** switch to ON and add the face recognition terminals to link the selected access point.
 - 1)Set the Face Recognition Terminal switch to ON to add the face recognition terminals.

2)Click Add to enter Add Face Recognition Terminal page.

3)Select **IP** or **Online Devices** as the adding mode, and set the required parameters, which may vary according to different terminals.

4)Click Add to link the terminal to access point.

iNote

After adding to the terminal list, you can edit, delete the devices, or do other further operations.

- **11.** Add the access point to one access level.
- **12.** Set the access point as attendance check point.
- 13. Edit the event settings of the access point. See *Configure Event and Alarm* for details.

iNote

If no event settings have been configured for the access point, you can click **Configuration** to set the parameters.

14. Add the access point to the map.

1)Set the **Add to Map** switch to ON.

2)Select the icon style and name color for displaying the access point on the map.

iNote

Up to 128 access points can be added to one map.

15. Click Save.

16. Optional: If required, enter the Edit Access Point page again and click **Copy to** to apply the current settings of the access point to other access point(s).

10.3.3 Edit Alarm Input for Current Site

You can edit basic information, event settings, and map settings of the alarm input for current site.

Perform this task when you need to edit alarm input for current site.

Steps

- 1. Click Logical View on the Home Page to enter the Area Management page.
- **2.** In the area list panel, select the added current site from the drop-down site list to show its areas.

iNote

The icon 🛞 indicates that the site is current site.

- 3. Select the Alarm Inputs tab to show the added alarm inputs.
- **4.** Click Name column to enter the Edit Alarm Input page.
- 5. Edit the alarm input name.
- 6. Optional: For the alarm input of the security control device, select **Detector Type** and **Zone Type** according to the actual deployment.
- 7. Edit the event settings of the alarm input. See Configure Event and Alarm for details.

iNote

If no event settings have been configured for the alarm input, you can click **Configuration** to set the parameters.

- **8.** Add the alarm input to the map.
 - 1) Set the Add to Map switch to ON.
 - 2) Select the icon style and name color for displaying the alarm input on the map.
- 9. Click Save.

10.3.4 Edit Alarm Output for Current Site

You can edit basic information and map settings of the alarm output for current site.

Perform this task when you need to edit alarm output for current site.

Steps

- 1. Click Logical View on the Home Page to enter the Area Management page.
- **2.** In the area list panel, select the added current site from the drop-down site list to show its areas.

iNote

The icon 🛞 indicates that the site is current site.

- 3. Select the Alarm Outputs tab to show the added alarm outputs.
- 4. Click Name column to enter the Edit Alarm Output page.

- 5. Edit the alarm output name.
- **6.** Add the alarm output to the map.
 - 1) Set the Add to Map switch to ON.
 - 2) Select the icon style and name color for displaying the alarm output on the map.
- 7. Click Save.

10.3.5 Edit Under Vehicle Surveillance System for Current Site

You can edit basic information, related cameras, and map settings of the Under Vehicle Surveillance System (UVSS) for current site.

Perform this task when you need to edit UVSS for current site.

Steps

- 1. Click Logical View on the Home page to enter the Area Management page.
- **2.** In the area list panel, select the added current site from the drop-down site list to show its areas.

iNote

The icon 🛞 indicates that the site is current site.

- 3. Select an area.
- 4. Select the Under Vehicle Surveillance Systems tab to show the added UVSSs.

iNote

If the map function is enabled, you should click » and click UVSSs.

- 5. Click Name column to enter the Edit UVSS page.
- 6. Edit the UVSS's basic information, such as IP address, port No., and so on.
- 7. Link cameras to the UVSS.
 - 1) Set the Relate Camera switch to ON.
- Select the camera(s).
- **8.** Add the UVSS to the map.
 - 1) Set the Add to Map switch to ON.
 - 2) Select the icon style and name color for displaying the UVSS on the map.
- 9. Click Save.

10.3.6 Edit Element for Remote Site

If the current system is a Central System with Remote Site Management module, you can edit the cameras added from the Remote Site.

Steps

1. Click Logical View on the Home page to enter the Area Management page.

2. In the area list panel, select the added Remote Site from the drop-down site list to show its areas.

iNote

The icon 🚱 indicates that the site is a Remote Site.

- 3. Select an area to show its added cameras.
- **4.** Click the Name field to edit the parameters of the cameras including basic information and recording settings.

iNote

For recording settings, if no recording settings have been configured for the camera, click **Configuration** to set the parameters (for details, refer to **Configure Recording for Cameras on Remote Site**).

5. Optional: Click to view the live view of the camera and hover over the window and click in the lower-right corner to switch to playback.

iNote

The live view and playback functions in the camera details page are only supported by Internet Explorer.

- **6. Optional:** Click **Copy to** to copy the current camera's specified configuration parameters to other cameras of the Remote Site.
- 7. Click Save.
- **8. Optional:** Perform one of the following operations.

Get Camera Name	Select one or multiple cameras and click Get Camera Name to get the cameras' names from the devices.
Edit Camera on Site	Click <a>o in the added camera list to open the remote site configuration page of the camera to edit it.

10.4 Remove Element from Area

You can remove the added cameras, alarm inputs, alarm outputs, doors, and Under Vehicle Surveillance Systems (UVSSs) from the area.

10.4.1 Remove Element from Area for Current Site

You can remove the added cameras, alarm inputs, alarm outputs, doors, and UVSSs from the area for current site.

Perform this task when you need to remove the element from the area for the current site.

Steps

- **1.** Click **Logical View** on the Home page to enter the Area Management page.
- 2. Select an area in the area list panel to show its added elements.

iNote

- For a Central System with a Remote Site Management module, you can select the current site from the drop-down site list to show its areas.
- The icon 🛞 indicates that the site is the current site.
- **3.** Select the Cameras, Alarm Inputs, Alarm Outputs, Doors, or UVSSs tab to show the added elements.
- 4. Select the elements.
- 5. Click Delete.

10.4.2 Remove Element from Area for Remote Site

If the current system is a Central System with a Remote Site Management module, you can remove the added cameras from its area.

Perform this task when you need to remove the element from the area for the Remote Site.

Steps

- 1. Click Logical View on the Home page to enter the Area Management page.
- **2.** In the area list panel, select the added Remote Site from the drop-down site list to show its areas.

iNote

The icon 🚱 indicates that the site is a Remote Site.

- **3.** Select an area to show its added cameras.
- 4. Select the cameras.
- 5. Click Delete.
- 6. Optional: If ⊗ appears near the camera name, it means the camera has been deleted from the Remote Site. Hover the cursor over the ⊗ and click **Delete** to delete the camera from the area.

Chapter 11 Configure Recording

Recording settings are for defining when and how the recording starts with the pre-defined parameters. You can also configure the storage settings for storing imported pictures and uploaded pictures.

HikCentral Professional provides four storage locations (storing on encoding devices, Hybrid Storage Area Network, Cloud Storage Server, or pStor) for storing the recorded video files of the cameras.

Encoding Device

The encoding devices, including the DVRs, NVRs, and network cameras, should provide storage devices such as the HDDs, Net HDDs, and SD/SDHC cards for video files. The newly installed storage devices need to be formatted. Go to the remote configuration page of the device (**Physical View** \rightarrow **Configuration**), click **Storage** \rightarrow **General**, select the HDD, Net HDD or SD/SDHC card, and click **Format** to initialize the selected storage device.

Hybrid Storage Area Network

Store the video files in the added Hybrid Storage Area Network. For details about adding Hybrid Storage Area Network, refer to **Add Hybrid Storage Area Network**.

Cloud Storage Server

Store the video files in the added Cloud Storage Server. For details about adding Cloud Storage Server, refer to *Add Cloud Storage Server*.

pStor

Store the video files in the added pStor, which is the storage access service used for managing local HDDs and logical disks. For details about adding pStor, refer to **Add pStor**.

11.1 Configure Recording for Cameras on Current Site

For the cameras on the current site, HikCentral Professional provides four storage methods (storing on encoding devices, Hybrid Storage Area Network, Cloud Storage Server, or pStor) for storing the video files of the cameras according to the configured recording schedule. You can get device's recording settings when adding camera to an area.

Before You Start

Encoding devices need to be added to the HikCentral Professional for area management. Refer to *Manage Resource* for detailed configuration about adding devices.

Perform this task when you need to record videos for the cameras on the current site.

Steps

- **1.** Enter the recording setting page.
 - 1) Click Logical View \rightarrow Cameras to enter the area management page.

2) Select an area to show its cameras.

iNote

For Central System with Remote Site Management module, you can select the current site (marked with () icon) from the drop-down site list to show its cameras.

3) Select a camera and click the Name field to enter the Edit Camera page.

\bigcirc	Camera 01 @ Config	uration on Device 🛛 📋 Copy to
	Basic Information	
	*Name	Camera 01
	*Protocol Type	ТСР 👻
		(\triangleright)
		\smile
	Recording Settings	
	Main Storage	Get Device's Recording Settings
	*Storage Location	Encoding Device -
	1 *Recording Schedule Template	All-day Event-based Template View
	*Stream Type	Main Stream 🔻
	() Pre-record	
	i *Post-record	10s •
	Video Expiration	0
		Save Cancel

Figure 11-1 Edit Camera Page

- 2. Set the Main Storage switch to ON.
- 3. Select the storage location for storing the recorded video file.

If you select **Hybrid Storage Area Network**, **Cloud Storage Server** or **pStor**, specify a server and (optional) select a Streaming Server to get the video stream of the camera via it.

- 4. Select the storage type and configure the required parameters.
 - Select **Real-Time Storage** as the storage type to store the recorded video files in the specified storage location at the real time.

i Note

If you choose **Encoding Device** as the storage location, you needn't select the storage type, but configure the following parameters as real-time storage settings by default.

Recording Schedule Template

Set the template which defines when to record the camera's video.

All-Day Time-Based Template

Record the video for all-day continuously.

All-Day Event-Based Template

Record the video when alarm occurs.

Add New

Set the customized template. For details about setting customized template, refer to *Configure Recording Schedule Template*.

View

View the template details.

iNote

The event-based recording schedule can not be configured for the **Cloud Storage Server**, and the command-based recording schedule can not be configured for the **Cloud Storage Server** and **pStor**.

Stream Type

Select the stream type as main stream, sub-stream or dual-stream.

iNote

For storing on Hybrid Storage Area Network, Cloud Storage Server or pStor, dual-stream is not supported.

Pre-Record

Record video from periods preceding detected events. For example, when someone opens a door, you can see what happens right before the door opened.

This field displays when the storage location is set as Encoding Device or pStor, and it is available for the camera that is configured with event-based recording.

Post-Record

Record video from periods following detected events.

This field displays when the storage location is set as Encoding Device or Hybrid Storage Area Network. It is available for the camera that is configured with event-based recording.

Video Expiration

If you select **Encoding Device** as the storage location , set Video Expiration switch to ON and enter expiration day(s).

Automatically delete the oldest videos after the specified retention period. This method allows you to define the longest time period to keep the videos as desired and the actual retention period for the videos depends on the allocated quota.

Enable ANR

If you select the **Encoding Device** or **Hybrid Storage Area Network** as the storage location, check **Enable ANR** to turn the automatic network replenishment on to temporarily store the video in the camera when network fails and transport the video to storage device when network recovers.

- Select **Scheduled Uploading** as the storage type to upload the recorded video files from the encoding device or pStor to the specified storage location according to scheduled period

iNote

- Make sure you have configured recording schedule stored in the device local storage or pStor for auxiliary storage first. Otherwise, the schedule uploading is not configurable.
- The recordings can be uploaded only from the encoding device to Hybrid Storage Area Network, Cloud Storage Server or pStor, or from pStor to another pStor.

Upload between

Specify the time period to upload the recorded video files to the specified storage location during the period.

Recording for Uploading

Select the recorded video file type to backup.

5. Optional: Set the **Auxiliary Storage** switch to ON and configure another storage location for the video files.

i Note

- If Cloud Storage Server, Hybrid Storage Area Network, or pStor is set as the auxiliary storage location, you can select **Real-Time Storage** to store recorded vide files or select **Scheduled Uploading** to upload recordings from the encoding device or pStor (main storage) to specified auxiliary storage location according to the scheduled period.
- Before setting **Scheduled Uploading**, make sure you have configured real-time recording schedule stored in device local storage or pStor for the main storage.
- The recordings can be uploaded only from the encoding device to Hybrid Storage Area Network, Cloud Storage Server or pStor, or from pStor to another pStor.

6. Click Save.

11.2 Configure Recording for Cameras on Remote Site

You can set recording schedule to record the video of cameras on Remote Sites and stores in the Central System's Recording Servers (Hybrid Storage Area Network, Cloud Storage Server, or pStor).

Perform this task when you need to record videos for the cameras on the Remote Site.

Steps

- **1.** Enter the recording setting page.
 - 1) Click Logical View \rightarrow Cameras to enter the area management page.
 - 2) Select the added Remote Site form the drop-down list.

iNote

The icon 🚱 indicates that the site is Remote Site.

- 3) Select an area to show its cameras.
- 4) Select a camera and click the **Name** field to enter the Edit Camera page.
- 5) In the Recording Settings area, set **Storage in Central System** switch to ON to show the recording setting area.

Camera 06 Config	uration on Site 📄 Copy to	
Basic Information		
*Name	Camera 06	
*Protocol Type	TCP •	
	C D The camera element does not exist.{Er	
Recording Settings		
Storage in Central System		
*Storage Location	Hybrid Storage Area Network 🔹	CVR_10.41.7.232
	RV_1 250.8GB Free of 802.3GB	
*Storage Type	Real-Time Storage	
	 Scheduled Uploading () 	
() *Recording Schedule Template	All-day Time-based Template 🔹	View
*Stream Type	Main Stream 🔻	
() *Post-record	10s •	
1 Streaming Server	10.18.64.32 •	
🚯 Enable ANR	Save Cancel	

Figure 11-2 Add Recording Settings Page

2. Select the storage location for storing the recorded video file.

iNote

You can select **Hybrid Storage Area Network**, **Cloud Storage Server** or **pStor**, specify a server and (optional) select a Streaming Server to get the video stream of the camera via it.

- 3. Select the storage type and configure the required parameters.
 - Select **Real-Time Storage** as the storage type to store the recorded video files in the specified storage location at the real time.

iNote

If you choose **Encoding Device** as the storage location, you needn't select the storage type, but configure the following parameters as real-time storage settings by default.

Recording Schedule Template

Set the template which defines when to record the camera's video.

All-Day Time-Based Template

Record the video for all-day continuously.

All-Day Event-Based Template

Record the video when alarm occurs.

Add New

Set the customized template. For details about setting customized template, refer to *Configure Recording Schedule Template*.

View

View the template details.

Stream Type

Select the stream type as main stream, sub-stream or dual-stream.

iNote

For storing on Hybrid Storage Area Network, Cloud Storage Server or pStor, dual-stream is not supported.

Pre-Record

Record video from periods preceding detected events. For example, when someone opens a door, you can see what happens right before the door opened.

This field displays when the storage location is set as Cloud Storage Server, and it is available for the camera that is configured with event-based recording.

Post-Record

Start recording the video from periods following detected events.

This field displays when the storage location is set as Hybrid Storage Area Network, and it is available for the camera that is configured with event-based recording.

Streaming Server

Optionally, select a **Streaming Server** to get the video stream of the camera via it.

Enable ANR

If you select the Storage Location as Hybrid Storage Area Network, check **Enable ANR** to turn the automatic network replenishment on to temporarily store the video in the camera when network disconnects and transport the video to Hybrid Storage Area Network when network recovers.

- Select **Scheduled Uploading** as the storage type and specify period, main/auxiliary storage, recording type and uploading speed to upload the recorded video files from the device local storage or pStor on the Remote Site to the specified storage location according to scheduled period.

Make sure you have configured recording schedule stored on encoding device or pStor for the camera on the remote site.

4. Click Save.

11.3 Configure Storage for Imported Pictures

The pictures imported by the users, such as the original undercarriage pictures imported on Vehicle page, static e-map pictures, the face pictures in the person list, can be stored on the HDD of SYS server.

Before You Start

Make sure that you have at least 1GB free space for picture storage.

Steps

iNote

You can configure the storage only when the current Web Client is running on SYS server.

1. Click **System** \rightarrow **Storage** \rightarrow **Storage on SYS Server** to enter the storage on SYS server page.

The disks of the SYS server are displayed with the free space and total capacity.

- 2. Select the disk to store the imported pictures.
- **3. Optional:** Set the **Restrict Quota for Pictures** switch to on to allocate the quota for storing the pictures.
- 4. Click Save.

11.4 Configure Storage for Uploaded Pictures

The pictures uploaded from the devices, such as alarm triggered pictures, captured face pictures, and captured plate license pictures, can be stored on the HDD of SYS server, Hybrid Storage Area Network, Cloud Storage Server, pStor, or NVR (Network Video Recorder).

Steps

- 1. Enter the picture storage setting page.
 - 1) Click Logical View \rightarrow Cameras to enter the area management page.
 - 2) Select an area to show its cameras.

iNote

For Central System with Remote Site Management module, you can select the current site (marked with () icon) from the drop-down site list to show its cameras.

- 3) Select a camera and click the Name field to enter the Edit Camera page.
- 2. Set the Picture Storage switch to on to enable the picture storage for the camera.
- 3. Select the storage location from the drop-down list.

- If you select System Management Server, the pictures will be stored on the SYS server. Click Configuration to view the disk on SYS server and storage quota, which can be edited via the Web Client running on the SYS server. Refer to Configure Storage for Imported Pictures for details.
- You cannot configure the storage location for the captured undercarriage pictures, which are stored on the UVSS device.
- 4. Click Save to save the uploaded pictures to the specified location.

11.5 Configure Recording Schedule Template

Recording schedule is time arrangement for video recording. You can configure the recording schedules to record video in a certain period. Two default recording schedules are available: All-day Time-based Template and All-day Event-based Template. All-day Time-based Template can be used for recording videos for all day continuously, and All-day Event-based Template is for recording videos when alarm is triggered. You can also customize the recording schedule.

Perform this task when you need to customize the schedule to record the video files.

Steps

- **1.** Click **System** on the home page and enter **Schedule** → **Recording Schedule Template** page.
- 2. Click Add to enter the adding recording schedule page.

iNote

Up to 32 templates can be added.

Add Rec	ordin	ig S	Sche	dule	e Te	mpla	ate							
Basic Information														
	*Name													
	Copy from					•								
Weekly Schedule														
	🔏 Time	-base	d 🔌	Event-	based	K Co	ommand	-based					🛷 Er	ase
		00	02	04	06	08	10	12	14	16	18	20	22	24
	Sun.													
	Mon.													
	Tue.													
	Wed.													
	Thu.													
	Fri.													
	Sat.													
		00	02	04	06	08	10	12	14	16	18	20	22	24
			Ad	d	<i>,</i>	Add and	Continue	e	C	ancel				



3. Set the required information.

Name

Set a name for the template.

Copy from

Optionally, you can select to copy the settings from other defined templates.

4. Select a recording type and drag on the time bar to draw a time period.

iNote

By default, the Time-based is selected.

Time-based

Continuous recording according to the time you arranged. The schedule time bar is marked with blue.

Event-based

The recording triggered by the alarm (e.g., alarm input alarm or motion detection alarm). The schedule time bar is marked with orange.

Command-based

The recording triggered by the ATM command. The schedule time bar is marked with green.

iNote

Up to 8 time periods can be set for each day in the recording schedule.

- 5. Optional: Click Erase and click on the time bar to clear the drawn time period.
- 6. Finish adding the template.
 - Click Add to add the template and back to the recording schedule template list page.
 - Click Add and Continue to save the settings and continue to add other template.
- 7. Optional: Perform the following operations on the recording schedule template list page.

View Template Details	Click the template to check the detailed settings.
Edit Template	Click \square in the Operation column to edit template details (except the template(s) in use).
Delete Template	Click $ imes$ in the Operation column to delete the template.
Delete All Templates	Click Delete All to delete all the schedule templates (except the default templates and the template(s) in use).

Chapter 12 Configure Event and Alarm

You can set the linkage actions for the detected events and alarms. The detailed information of the events and alarms can be received and checked via the Control Client and the Mobile Client.

Event

Events can be divided into: System-Monitored Event

The signal that resource (e.g., camera, device, server) sends when something occurs. System can trigger linkage actions (such as recording, capturing, sending email, etc.) to record the received event for checking.

Generic Event

The signal that resource (e.g., other software, device) sends when something occurs, and can be received in the form of TCP or UDP data packages, which the system can analyze, and generate events if they match configured expression.

User-Defined Event

The user-defined event can be used to:

- The user can trigger a user-defined event manually in Monitoring and Alarm Center module on the Control Client when viewing the video or checking the alarm information.
- A user-defined event can trigger an alarm if configured.
- An alarm will be armed or disarmed when the user-defined event is triggered.
- An alarm can trigger a user-defined event as alarm actions.

Alarm

Alarm is used to notify security personnel of the particular situation which helps handle the situation promptly. An alarm can trigger a series of linkage actions (e.g., popping up window) for notification and alarm handling.

Linkage Actions

You can set linkage actions for both events and alarms.

- An event's linkage actions are used to record the event details (such as recording and capturing) and trigger basic actions (such as linking access point to lock or unlock, triggering alarm output, sending email, etc.).
- An alarm's linkage actions are used to record the alarm details and provide the recipients multiple ways to view alarm information for alarm acknowledgment and handling, such as popping up alarm window, displaying on smart wall, audible warning, etc.

12.1 Configure System-Monitored Event

System-monitored event is the signal that resource (e.g., device, camera, server) sends when something occurs. System can receive and record event for checking, and can also trigger a series of linkage actions for notification. The event can also trigger an alarm for further notification and linkage actions (such as alarm recipients, pop-up window on the Control Client, displaying on the Smart Wall, etc.). You can check the event related video and captured pictures via the Control Client if you set the recording and capturing as event linkage.

It supports the following types of event:

Camera Event

The video exception or the events detected in the monitoring area of the camera, such as motion detection, video loss, line crossing, and so on.

Access Point Event

The access control event triggered at the access point, such as access event, door status event, etc.

Alarm Input Event

The event triggered by the alarm input.

ANPR Event

The license plate matched event and mismatched event detected by the ANPR camera or UVSS.

Person Event

The face matched event and mismatched event detected by the facial recognition camera.

UVSS Event

The event triggered by the UVSS, including getting online or offline.

Remote Site Event

The event triggered by the added Remote Site, including site getting offline.

Device Event

The event triggered by encoding device's, access control device's, security control panel's and dock station's exception.

Server Event

The events triggered by Recording Server, Streaming Server, or HikCentral Professional Server.

User Event

The event triggered by system users, including user login and logout.

Generic Event

The event triggered by the generic event added in the system.

User-Defined Event

The event triggered by the user-defined event added in the system.

12.1.1 Add Event for Camera

You can add an event for the cameras on the current site. When the event is triggered on the camera, system can receive and record event for checking and trigger a series of linkage actions (e.g., sending email) for notification.

Steps

1. Click Event & Alarm → System-Monitored Event → Add to enter the event adding page.

	System can receive and record e recording, sending email) for no	verst for checking, and can also trigger a series of tification.	linkage actions (e.g., camera	
Basic Information				
* Triggered by	Source Type	Triggering Event	Source	
	Camera	▲ Search	Camera/Area	C
	Access Point	Abnormal Face	√ ≥ ₫10.12.97.30	
	Alarm Input	Audio Exception Detection	😸 🔞 Pidome	
		Blackfut Alarm	10.18.64.223	
	ANPR		10.18.65.17	
	Person	Camera Communication Exception	10.1865.149	
	UVSS	Camera Communication Recovered	10.18.65.168	
	Remote Site	Camera Offline	1018.65.170	
	Hemote site	Camera Online	10.18.65.222	
	Encoding Device		10.18.65.223	
	Access Control Device	Camera Recording Exception	10.18.65.224	
		Camera Recording Recovered	10.18.65.225	
	Security Control Device	Channel Armed	10.18.65.226	
			E manua	
Active Control	0			

Figure 12-1 Add a System-Monitored Event

2. Configure the event's basic information, including source type, triggering event, and event source.

Source Type

Select the source type as Camera.

Triggering Event

The event detected on the camera will trigger a system-monitored event in the system.

Source

The specific camera(s) which can trigger this event.

3. Optional: Set the Active Control switch to on, and then set the Threshold for Reactivation.

- Active Control is used to avoid the same event occurs frequently in a short time, which may
 aggravate the burden of HikCentral Professional event center. You need to set the Threshold
 for Reactivation. For example, you have set the Threshold for Reactivation as **30 s**, the same
 events from the same camera within 30 s will be regarded as one event on the HikCentral
 Professional.
- The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.
- 4. Optional: Set the Action switch to on to set the linkage actions for the event.

Arming Schedule Template

The camera is armed during the arming schedule and the triggering event occurred on the camera during the arming schedule will trigger the configured linkage actions.

iNote

For setting customized template, refer to Configure Arming Schedule Template .

Trigger Recording

Select the camera to record video when the event occurs. You can play back the recorded video files when checking events in the Alarm & Event Search of the Control Client.

- To trigger the source camera itself for recording, select **Source Camera** and select the storage location for storing the video files.
- To trigger other cameras, select **Specified Camera** and click **Add** to add other cameras. Select the storage location for storing the video files. For example, when the camera outside the door detects suspicious person entering, you can configure to trigger the cameras inside the room to record video.

View Pre-Event Video: If the camera has recorded video files before the event, you can view the video recorded from periods preceding the event. Specify the number of seconds which you want to view the recorded video for before the event starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.

Post-record: Record video from periods following detected event. Specify the number of seconds which you want to record video for after the event stops.

Lock Video Files for: Set the days for protecting the video file from being overwritten.

Create Tag

Select the camera(s) to record video when the event occurs and add tag to the event triggered video. The tagged video can be searched and checked via the Control Client.

- To trigger the source camera itself for tagged recording, select **Source Camera** and select the storage location for storing the video files.
- To trigger other cameras for tagged recording, select **Specified Camera** and click **Add** to add other cameras. Select the storage location for storing the video files.

You can enter the tag name as desired. You can also click the button below to add the related information to the name.

Set the time range to define the tagged video length. For example, you can set to record the tagged video started from 5 seconds before the event and lasted until and 10 seconds after the event. The tagged video can be searched and checked via the Control Client.

Add the description to the tagged video as needed.

Capture Picture

Select one camera to capture pictures during the event, and you can view the captured pictures when checking event in the Alarm & Event Search of the Control Client.

- To trigger the source camera itself for capturing pictures, select Source Camera.
- To trigger other camera for capturing pictures, select **Specified Camera** and select one camera for capturing pictures.

iNote

Only one camera can be set for capturing pictures.

Capture Picture When: Specify the number of seconds to define when the camera will capture pictures for the event. After you set the number of seconds for pre/post-event, the camera will capture one picture at three time points respectively: at the configured seconds before the event starts, at the configured seconds after the event ends, and at the middle of the event (as shown in the picture below).



Figure 12-2 Capture Pictures

i Note

The pre-event picture is captured from the camera's recorded video files. This pre-event capture function is only supported by the camera which is set to store the video files in the Recording Server (Cloud Storage Server, Hybrid SAN, or pStor).

Link Access Point

You can enable this function to trigger the access point(s) to be locked or unlocked when the event occurs. For example, you can set to trigger all the access points closed when the system detects suspicious person entering.

- All Access Points: When the event occurs, all the access points in the system will be unlocked, locked, remain unlocked, or remain locked.
- **Specified Access Point:** Click **Add** to select the access point(s) as the linkage target(s). You can set the access point action so that the access point will be unlocked, locked, remained unlocked, or remained locked when the event occurs.

Up to 16 access points can be selected as event linkage.

Link Alarm Output

Select the alarm output (if available) and the external device connected can be activated when the event occurs.

iNote

Up to 64 alarm outputs can be selected as event linkage.

Close Alarm Output: The added alarm output(s) can be closed manually, or you can set the number of seconds in which the alarm output(s) will be closed automatically.

Trigger PTZ

Call the preset, patrol or pattern of the selected camera(s) when the event occurs.



Up to 64 PTZ linkages can be selected as event linkage.

Send Email

Select an email template to send the event information according to the defined email settings. You can select **Add New** to create a new email template. For details, refer to **Set Email Template**.

Trigger User-Defined Event

Trigger user-defined event(s) when the system-monitored event is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click **Add New** below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as event linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .

5. Finish adding the event.

- Click Add to add the event and back to the event list page.
- Click Add and Trigger Alarm to trigger this event as an alarm for further notification. For details, refer to *Configure Alarm*.

After adding the event, it displays on the event list, and you can view the event name, event source, and triggering event.

6. Optional: Perform the following operation(s) after adding the event.

Trigger EventClick in the Operation column of system-monitored event settings pageas Alarmto set the alarm properties, recipients, actions, and other parameters.

	i Note For details, refer to Configure Alarm .
Test Event	Click login the Operation column of system-monitored event settings page to trigger the event manually, and you can check whether the linkage actions take effect.
Delete Event	Select the event(s) and click Delete to delete the selected event(s).
Manage Invalid Event	If (\otimes) appears near the event name, it means the event is not supported by the device and it is invalid. You should hover the cursor over the (\otimes) and click Delete on the tooltip to delete the event.
Delete All Invalid Events	Click Delete All Invalid Items to delete all the invalid events in a batch.
Filter Event	Click γ to expand the filter conditions. Set the conditions and click Filter to filter the events according to the conditions.

12.1.2 Add Event for Access Point

You can add an event for the access points in the system. When the event is triggered at the access point, system can receive and record event for checking and trigger a series of linkage actions (e.g., sending email) for notification.

Steps

- 1. Click Event & Alarm → System-Monitored Event → Add to enter the event adding page.
- **2.** Configure the event's basic information, including source type, triggering event, and event source.

Source Type

Select the source type as Access Point.

Triggering Event

The event detected at the access point will trigger the system-monitored event in the system.

Source

The specific access point(s) which can trigger this event.

3. Optional: Set the Active Control switch to on, and then set the Threshold for Reactivation.

iNote

• Active Control is used to avoid the same event occurs frequently in a short time, which may aggravate the burden of HikCentral Professional event center. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30 s**, the same

events from the same camera within 30 s will be regarded as one event on the HikCentral Professional.

- The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.
- 4. Optional: Set the Action switch to on to set the linkage actions for the event.

Arming Schedule Template

The access point is armed during the arming schedule and the triggering event occurred on the event source during the arming schedule will trigger the configured linkage actions.

iNote

For setting customized template, refer to Configure Arming Schedule Template .

Trigger Recording

Select the camera to record video when the event occurs. You can play back the recorded video files when checking events in the Alarm & Event Search of the Control Client.

- To trigger the access point's related camera(s) for recording, you can select **Source Related Camera** and select the storage location for storing the video files.
- To trigger other cameras, select **Specified Camera** and click **Add** to add other cameras. Select the storage location for storing the video files.

View Pre-Event Video: If the camera has recorded video files before the event, you can view the video recorded from periods preceding the event. Specify the number of seconds which you want to view the recorded video for before the event starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.

Post-record: Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.

Lock Video Files for: Set the days for protecting the video file from being overwritten.

Create Tag

Select the camera to record video when the event occurs and add tag to the event triggered video. The tagged video can be searched and checked via the Control Client.

- To trigger the access point's related camera(s) for tagged recording, you can select **Source Related Camera** and select the storage location for storing the video files.
- To trigger other cameras for tagged recording, select **Specified Camera** and click **Add** to add other cameras. Select the storage location for storing the video files.

You can enter the tag name as desired. You can also click the button below to add the related information to the name.

Set the time range to define the tagged video length. For example, you can set to record the tagged video started from 5 seconds before the event and lasted until and 10 seconds after the event. The tagged video can be searched and checked via the Control Client.

Add the description to the tagged video as needed.

Capture Picture

Select one camera to capture pictures during the event, and you can view the captured pictures when checking event in the Alarm & Event Search of the Control Client.

iNote

Only one camera can be set for capturing pictures.

Capture Picture When: Specify the number of seconds at which the camera will capture before/after the event starts/ends. After you set the number of seconds for pre/post-event, the camera will capture one picture at three time points respectively: at the configured seconds before the event starts, at the configured seconds after the event ends, and at the middle of the event (as shown in the picture below).



Figure 12-3 Capture Pictures

iNote

The pre-event picture is captured from the camera's recorded video files. This pre-event capture function is only supported by the camera which is set to store the video files in the Recording Server (Cloud Storage Server, Hybrid SAN, or pStor).

Link Access Point

You can enable this function to trigger the access point(s) to be locked or unlocked when the event occurs. For example, you can set to trigger all the access points closed when the system detects suspicious person entering.

- All Access Points: When the event occurs, all the access points in the system will be unlocked, locked, remain unlocked, or remain locked.
- **Specified Access Point:** Click **Add** to select the access point(s) as the linkage target(s). You can set the access point action so that the access point will be unlocked, locked, remained unlocked, or remained locked when the event occurs.

iNote

Up to 16 access points can be selected as event linkage.

Link Alarm Output

Select the alarm output (if available) and the external device connected can be activated when the event occurs.

i Note

Up to 64 alarm outputs can be selected as event linkage.

Close Alarm Output: The added alarm output(s) can be closed manually, or you can set the number of seconds in which the alarm output(s) will be closed automatically.

Trigger PTZ

Call the preset, patrol or pattern of the selected camera(s) when the event occurs.

iNote

Up to 64 PTZ linkages can be selected as event linkage.

Send Email

Select an email template to send the event information according to the defined email settings. You can select **Add New** to create a new email template. For details, refer to **Set Email Template**.

Trigger User-Defined Event

Trigger user-defined event(s) when the system-monitored event is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as event linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .

5. Finish adding the event.

- Click Add to add the event and back to the event list page.
- Click Add and Trigger Alarm to trigger this event as an alarm for further notification. For details, refer to *Configure Alarm*.

After adding the event, it displays on the event list, and you can view the event name, event source, and triggering event.

6. Optional: Perform the following operation(s) after adding the event.

Trigger Event as Alarm	Click 😥 in the Operation column of system-monitored event settings page to set the alarm properties, recipients, actions, and other parameters.			
	i Note			
	For details, refer to Configure Alarm .			
Test Event	Click ③ in the Operation column of system-monitored event settings page to trigger the event manually, and you can check whether the linkage actions take effect.			
Delete Event	Select the event(s) and click Delete to delete the selected event(s).			
Manage Invalid Event	If \bigotimes appears near the event name, it means the event is not supported by the device and it is invalid. You should hover the cursor over the \bigotimes and click Delete on the tooltip to delete the event.			

Delete All Invalid Events	Click Delete All Invalid Items to delete all the invalid events in a batch.
Filter Event	Click γ to expand the filter conditions. Set the conditions and click Filter to filter the events according to the conditions.

12.1.3 Add Event for Alarm Input

You can add an event for the alarm inputs in the system. When the alarm input is triggered, system can receive and record event for checking and trigger a series of linkage actions (e.g., sending email) for notification.

Steps

- **1.** Click **Event & Alarm → System-Monitored Event → Add** to enter the event adding page.
- **2.** Configure the event's basic information, including source type, triggering event, and event source.

Source Type

Select the source type as Alarm Input.

Triggering Event

The event detected on the alarm input will trigger the system-monitored event in the system.

Source

The specific alarm input(s) which can trigger this event.

3. Optional: Set the Active Control switch to on, and then set the Threshold for Reactivation.

iNote

- Active Control is used to avoid the same event occurs frequently in a short time, which may
 aggravate the burden of HikCentral Professional event center. You need to set the Threshold
 for Reactivation. For example, you have set the Threshold for Reactivation as **30 s**, the same
 events from the same camera within 30 s will be regarded as one event on the HikCentral
 Professional.
- The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.
- 4. Optional: Set the Action switch to on to set the linkage actions for the event.

Arming Schedule Template

The alarm input is armed during the arming schedule and the triggering event occurred on the event source during the arming schedule will trigger the configured linkage actions.

i Note

For setting customized template, refer to Configure Arming Schedule Template .

Trigger Recording

Click **Add** to select the camera(s) to record video when the event occurs. Select the storage location for storing the video files. You can play back the recorded video files when checking events in the Alarm & Event Search of the Control Client.

View Pre-Event Video: If the camera has recorded video files before the event, you can view the video recorded from periods preceding the event. Specify the number of seconds which you want to view the recorded video for before the event starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.

Post-record: Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.

Lock Video Files for: Set the days for protecting the video file from being overwritten.

Create Tag

Click **Add** to select the camera(s) to record video when the event occurs and add tag to the event triggered video. Select the storage location for storing the video files. The tagged video can be searched and checked via the Control Client.

You can enter the tag name as desired. You can also click the button below to add the related information to the name.

Set the time range to define the tagged video length. For example, you can set to record the tagged video started from 5 seconds before the event and lasted until and 10 seconds after the event. The tagged video can be searched and checked via the Control Client.

Add the description to the tagged video as needed.

Capture Picture

Select one camera to capture pictures during the event, and you can view the captured pictures when checking event in the Alarm & Event Search of the Control Client.

iNote

Only one camera can be set for capturing pictures.

Capture Picture When: Specify the number of seconds at which the camera will capture before/after the event starts/ends. After you set the number of seconds for pre/post-event, the camera will capture one picture at three time points respectively: at the configured seconds before the event starts, at the configured seconds after the event ends, and at the middle of the event (as shown in the picture below).



Figure 12-4 Capture Pictures

The pre-event picture is captured from the camera's recorded video files. This pre-event capture function is only supported by the camera which is set to store the video files in the Recording Server (Cloud Storage Server, Hybrid SAN, or pStor).

Link Access Point

You can enable this function to trigger the access point(s) to be locked or unlocked when the event occurs. For example, you can set to trigger all the access points closed when the system detects suspicious person entering.

- All Access Points: When the event occurs, all the access points in the system will be unlocked, locked, remain unlocked, or remain locked.
- **Specified Access Point:** Click **Add** to select the access point(s) as the linkage target(s). You can set the access point action so that the access point will be unlocked, locked, remained unlocked, or remained locked when the event occurs.

iNote

Up to 16 access points can be selected as event linkage.

Link Alarm Output

Select the alarm output (if available) and the external device connected can be activated when the event occurs.

iNote

Up to 64 alarm outputs can be selected as event linkage.

Close Alarm Output: The added alarm output(s) can be closed manually, or you can set the number of seconds in which the alarm output(s) will be closed automatically.

Trigger PTZ

Call the preset, patrol or pattern of the selected camera(s) when the event occurs.

iNote

Up to 64 PTZ linkages can be selected as event linkage.

Send Email

Select an email template to send the event information according to the defined email settings. You can select **Add New** to create a new email template. For details, refer to **Set Email Template**.

Trigger User-Defined Event

Trigger user-defined event(s) when the system-monitored event is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

- Up to 16 user-defined events can be selected as event linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .
- **5.** Finish adding the event.
 - Click Add to add the event and back to the event list page.
 - Click Add and Trigger Alarm to trigger this event as an alarm for further notification. For details, refer to *Configure Alarm*.

After adding the event, it displays on the event list, and you can view the event name, event source, and triggering event.

6. Optional: Perform the following operation(s) after adding the event.

Trigger Event as Alarm	Click 😥 in the Operation column of system-monitored event settings page to set the alarm properties, recipients, actions, and other parameters.
	i Note
	For details, refer to Configure Alarm .
Test Event	Click ③ in the Operation column of system-monitored event settings page to trigger the event manually, and you can check whether the linkage actions take effect.
Delete Event	Select the event(s) and click Delete to delete the selected event(s).
Manage Invalid Event	If \bigotimes appears near the event name, it means the event is not supported by the device and it is invalid. You should hover the cursor over the \bigotimes and click Delete on the tooltip to delete the event.
Delete All Invalid Events	Click Delete All Invalid Items to delete all the invalid events in a batch.
Filter Event	Click \bigtriangledown to expand the filter conditions. Set the conditions and click Filter to filter the events according to the conditions.

12.1.4 Add Event for ANPR Camera

You can add an event for the cameras which have ANPR (Automatic Number-Plate Recognition) function (such as ANPR cameras and UVSS) in the system. When the recognized license plate numbers matched or mismatched with the license plate numbers in the vehicle list, system can receive and record event for checking and trigger a series of linkage actions (e.g., sending email) for notification.

Steps

1. Click Event & Alarm → System-Monitored Event → Add to enter the event adding page.

2. Configure the event's basic information, including source type, triggering event, and event source.

Source Type

Select the source type as **ANPR**.

Triggering Event

Select the vehicle list that will trigger the corresponding license plate matched/mismatched event.

∎Note

You need to configure vehicle list first. For details, refer to Add Vehicle List .

Source

The specific ANPR camera(s) which can trigger this event.

i Note

If there are no ANPR cameras in the source list, click **Configuration** to specify the ANPR camera(s) for HikCentral Professional.

Up to 20 cameras can be specified as ANPR cameras for HikCentral Professional. Only the cameras with ANPR function can be specified as ANPR camera for HikCentral Professional.

3. Optional: Set the Active Control switch to on, and then set the Threshold for Reactivation.

iNote

- Active Control is used to avoid the same event occurs frequently in a short time, which may aggravate the burden of HikCentral Professional event center. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30 s**, the same events from the same camera within 30 s will be regarded as one event on the HikCentral Professional.
- The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.
- 4. Optional: Set the Action switch to on to set the linkage actions for the event.

Arming Schedule Template

The ANPR camera is armed during the arming schedule and the matched or mismatched license plate recognized during the arming schedule will trigger the configured linkage actions.

iNote

For setting customized template, refer to Configure Arming Schedule Template .

Trigger Recording

Select the camera to record video when the event occurs. You can play back the recorded video files when checking events in the Alarm & Event Search of the Control Client.

- To trigger the source camera (when the source is ANPR camera) or trigger the source's related camera (when the source is UVSS) for recording, select **Source or Related Camera** and select the storage location for storing the video files.
- To trigger other cameras, select **Specified Camera** and click **Add** to add other cameras. Select the storage location for storing the video files.

View Pre-Event Video: If the camera has recorded video files before the event, you can view the video recorded from periods preceding the event. Specify the number of seconds which you want to view the recorded video for before the event starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.

Post-record: Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.

Lock Video Files for: Set the days for protecting the video file from being overwritten.

Create Tag

Select the camera(s) to record video when the event occurs and add tag to the event triggered video. The tagged video can be searched and checked via the Control Client.

- To trigger the source camera (when the source is ANPR camera) or trigger the source's related camera (when the source is UVSS) for tagged recording, select **Source or Related Camera** and select the storage location for storing the video files.
- To trigger other cameras for tagged recording, select **Specified Camera** and click **Add** to add other cameras. Select the storage location for storing the video files.

You can enter the name as desired. You can also click the button below to add the related information to the name.

Set the time range to define the tagged video length. For example, you can set to record the tagged video started from 5 seconds before the event and lasted until and 10 seconds after the event. The tagged video can be searched and checked via the Control Client.

Add the description to the tagged video as needed.

Capture Picture

Select one camera to capture pictures during the event, and you can view the captured pictures when checking event in the Alarm & Event Search of the Control Client.

- To trigger the source camera (when the source is ANPR camera) or trigger the source's related camera (when the source is UVSS) for capturing pictures, select **Source or Related Camera**.
- To trigger other camera for capturing pictures, select **Specified Camera** (optional) and select one camera for capturing pictures.
iNote

Only one camera can be set for capturing pictures.

Capture Picture When: Specify the number of seconds at which the camera will capture before/after the event starts/ends. After you set the number of seconds for pre/post-event, the camera will capture one picture at three time points respectively: at the configured seconds before the event starts, at the configured seconds after the event ends, and at the middle of the event (as shown in the picture below).



Figure 12-5 Capture Pictures

iNote

The pre-event picture is captured from the camera's recorded video files. This pre-event capture function is only supported by the camera which is set to store the video files in the Recording Server (Cloud Storage Server, Hybrid SAN, or pStor).

Link Access Point

You can enable this function to trigger the access point(s) to be locked or unlocked when the event occurs. For example, you can set to trigger all the access points closed when the system detects suspicious person entering.

- All Access Points: When the event occurs, all the access points in the system will be unlocked, locked, remain unlocked, or remain locked.
- **Specified Access Point:** Click **Add** to select the access point(s) as the linkage target(s). You can set the access point action so that the access point will be unlocked, locked, remained unlocked, or remained locked when the event occurs.

iNote

Up to 16 access points can be selected as event linkage.

Link Alarm Output

Select the alarm output (if available) and the external device connected can be activated when the event occurs.

iNote

Up to 64 alarm outputs can be selected as event linkage.

Close Alarm Output: The added alarm output(s) can be closed manually, or you can set the number of seconds in which the alarm output(s) will be closed automatically.

Trigger PTZ

Call the preset, patrol or pattern of the selected camera(s) when the event occurs.

iNote

Up to 64 PTZ linkages can be selected as event linkage.

Send Email

Select an email template to send the event information according to the defined email settings. You can select **Add New** to create a new email template. For details, refer to **Set Email Template**.

Trigger User-Defined Event

Trigger user-defined event(s) when the system-monitored event is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).



- Up to 16 user-defined events can be selected as event linkage.
- For setting the user-defined event, refer to *Configure User-Defined Event* .

5. Finish adding the event.

- Click Add to add the event and back to the event list page.
- Click Add and Trigger Alarm to trigger this event as an alarm for further notification. For details, refer to *Configure Alarm*.

After adding the event, it displays on the event list, and you can view the event name, event source, and triggering event.

6. Optional: Perform the following operation(s) after adding the event.

Trigger Event as Alarm	Click 😥 in the Operation column of system-monitored event settings page to set the alarm properties, recipients, actions, and other parameters.
	i Note
	For details, refer to Configure Alarm .
Test Event	Click ③ in the Operation column of system-monitored event settings page to trigger the event manually, and you can check whether the linkage actions take effect.
Delete Event	Select the event(s) and click Delete to delete the selected event(s).
Manage Invalid Event	If \bigotimes appears near the event name, it means the event is not supported by the device and it is invalid. You should hover the cursor over the \bigotimes and click Delete on the tooltip to delete the event.
Delete All Invalid Events	Click Delete All Invalid Items to delete all the invalid events in a batch.

Filter EventClick \bigtriangledown to expand the filter conditions. Set the conditions and click Filter
to filter the events according to the conditions.

12.1.5 Add Event for Person

You can add a matched and mismatched event for the added face recognition camera in the system. When the camera recognizes a matched or mismatched person face, system can receive and record event for checking and trigger a series of linkage actions (e.g., sending email) for notification.

Steps

- 1. Click Event & Alarm → System-Monitored Event → Add to enter the event adding page.
- **2.** Configure the event's basic information, including source type, triggering event, and event source.

Source Type

Select the source type as **Person**.

Triggering Event

Select the face comparison group that will trigger the corresponding face matched/ mismatched event.

iNote

You need to configure face comparison group first. For details, refer to **Add Face Comparison Group**.

Source

The specific camera(s) which can trigger this event.

iNote

If there are no face recognition cameras in the source list, click **Configuration** to specify the face recognition camera(s) for HikCentral Professional.

Up to 10 cameras can be specified as face recognition cameras for HikCentral Professional. Only the cameras with face recognition function can be specified as face recognition camera for HikCentral Professional.

3. Optional: Set the Active Control switch to on, and then set the Threshold for Reactivation.

iNote

• Active Control is used to avoid the same event occurs frequently in a short time, which may aggravate the burden of HikCentral Professional event center. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30 s**, the same

events from the same camera within 30 s will be regarded as one event on the HikCentral Professional.

• The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.

4. Optional: Set the Action switch to on to set the linkage actions for the event.

Arming Schedule Template

The face recognition camera is armed during the arming schedule and the matched or mismatched person recognized during the arming schedule will trigger the configured linkage actions.

iNote

For setting customized template, refer to Configure Arming Schedule Template .

Trigger Recording

Select the camera to record video when the event occurs. You can play back the recorded video files when checking events in the Alarm & Event Search of the Control Client.

- To trigger the face recognition camera itself for recording, select **Source Camera** and select the storage location for storing the video files.
- To trigger other cameras, select **Specified Camera** and click **Add** to add other cameras. Select the storage location for storing the video files.

View Pre-Event Video: If the camera has recorded video files before the event, you can view the video recorded from periods preceding the event. Specify the number of seconds which you want to view the recorded video for before the event starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.

Post-record: Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.

Lock Video Files for: Set the days for protecting the video file from being overwritten.

Create Tag

Select the camera to record video when the event occurs and add tag to the event triggered video. The tagged video can be searched and checked via the Control Client.

- To trigger the face recognition camera itself for tagged recording, select **Source Camera** and select the storage location for storing the video files.
- To trigger other cameras for tagged recording, select **Specified Camera** and click **Add** to add other cameras. Select the storage location for storing the video files.

You can enter the tag name as desired. You can also click the button below to add the related information to the name.

Set the time range to define the tagged video length. For example, you can set to record the tagged video started from 5 seconds before the event and lasted until and 10 seconds after the event. The tagged video can be searched and checked via the Control Client.

Add the description to the tagged video as needed.

Capture Picture

Select one camera to capture pictures during the event, and you can view the captured pictures when checking event in the Alarm & Event Search of the Control Client.

- To trigger the face recognition camera itself for capturing pictures, select Source Camera.
- To trigger other camera for capturing pictures, select **Specified Camera** and select one camera for capturing pictures.

i Note

Only one camera can be set for capturing pictures.

Capture Picture When: Specify the number of seconds at which the camera will capture before/after the event starts/ends. After you set the number of seconds for pre/post-event, the camera will capture one picture at three time points respectively: at the configured seconds before the event starts, at the configured seconds after the event ends, and at the middle of the event (as shown in the picture below).



Figure 12-6 Capture Pictures

iNote

The pre-event picture is captured from the camera's recorded video files. This pre-event capture function is only supported by the camera which is set to store the video files in the Recording Server (Cloud Storage Server, Hybrid SAN, or pStor).

Link Access Point

You can enable this function to trigger the access point(s) to be locked or unlocked when the event occurs. For example, you can set to trigger all the access points closed when the system detects suspicious person entering.

- All Access Points: When the event occurs, all the access points in the system will be unlocked, locked, remain unlocked, or remain locked.
- **Specified Access Point:** Click **Add** to select the access point(s) as the linkage target(s). You can set the access point action so that the access point will be unlocked, locked, remained unlocked, or remained locked when the event occurs.

iNote

Up to 16 access points can be selected as event linkage.

Link Alarm Output

Select the alarm output (if available) and the external device connected can be activated when the event occurs.

iNote

Up to 64 alarm outputs can be selected as event linkage.

Close Alarm Output: The added alarm output(s) can be closed manually, or you can set the number of seconds in which the alarm output(s) will be closed automatically.

Trigger PTZ

Call the preset, patrol or pattern of the selected camera(s) when the event occurs.

iNote

Up to 64 PTZ linkages can be selected as event linkage.

Send Email

Select an email template to send the event information according to the defined email settings. You can select **Add New** to create a new email template. For details, refer to **Set Email Template**.

Trigger User-Defined Event

Trigger user-defined event(s) when the system-monitored event is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click **Add New** below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as event linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .

5. Finish adding the event.

- Click Add to add the event and back to the event list page.
- Click Add and Trigger Alarm to trigger this event as an alarm for further notification. For details, refer to *Configure Alarm*.

After adding the event, it displays on the event list, and you can view the event name, event source, and triggering event.

6. Optional: Perform the following operation(s) after adding the event.

Trigger Event as Alarm	Click ы in the Operation column of system-monitored event settings page to set the alarm properties, recipients, actions, and other parameters.
	I Note
	For details, refer to Configure Alarm .
Test Event	Click in the Operation column of system-monitored event settings page to trigger the event manually, and you can check whether the linkage actions take effect.
Delete Event	Select the event(s) and click Delete to delete the selected event(s).

Manage Invalid Event	If \bigotimes appears near the event name, it means the event is not supported by the device and it is invalid. You should hover the cursor over the \bigotimes and click Delete on the tooltip to delete the event.
Delete All Invalid Events	Click Delete All Invalid Items to delete all the invalid events in a batch.
Filter Event	Click ∇ to expand the filter conditions. Set the conditions and click Filter to filter the events according to the conditions.

12.1.6 Add Event for UVSS

You can add an event for the UVSS in the system. When the event is triggered on the UVSS, system can receive and record event for checking and trigger a series of linkage actions (e.g., sending email) for notification.

Steps

- 1. Click Event & Alarm → System-Monitored Event → Add to enter the event adding page.
- **2.** Configure the event's basic information, including source type, triggering event, and event source.

Source Type

Select the source type as UVSS.

Triggering Event

The event detected on the UVSS and it will trigger the system-monitored event in the system.

Source

The specific UVSS(s) which can trigger this event.

3. Optional: Set the Active Control switch to on, and then set the Threshold for Reactivation.

iNote

- Active Control is used to avoid the same event occurs frequently in a short time, which may aggravate the burden of HikCentral Professional event center. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30 s**, the same events from the same camera within 30 s will be regarded as one event on the HikCentral Professional.
- The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.

4. Optional: Set the **Action** switch to on to set the linkage actions for the event.

Arming Schedule Template

The UVSS is armed during the arming schedule and the triggering event occurred on the event source during the arming schedule will trigger the configured linkage actions.

iNote

For setting customized template, refer to Configure Arming Schedule Template .

Trigger Recording

Select the camera to record video when the event occurs. Select the storage location for storing the video files. You can play back the recorded video files when checking events in the Alarm & Event Search of the Control Client.

- To trigger the UVSS's related camera(s) for recording, you can select **Source Related Camera** and select the storage location for storing the video files.
- To trigger other cameras, select **Specified Camera** and click **Add** to add other cameras. Select the storage location for storing the video files.

View Pre-Event Video: If the camera has recorded video files before the event, you can view the video recorded from periods preceding the event. Specify the number of seconds which you want to view the recorded video for before the event starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.

Post-record: Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.

Lock Video Files for: Set the days for protecting the video file from being overwritten.

Create Tag

Select the camera(s) to record video when the event occurs and add tag to the event triggered video. Select the storage location for storing the video files. The tagged video can be searched and checked via the Control Client.

- To trigger the UVSS's related camera(s) for tagged recording, you can select **Source Related Camera** and select the storage location for storing the video files.
- To trigger other cameras for tagged recording, select **Specified Camera** and click **Add** to add other cameras. Select the storage location for storing the video files.

You can enter the name as desired. You can also click the button below to add the related information to the name.

Set the time range to define the tagged video length. For example, you can set to record the tagged video started from 5 seconds before the event and lasted until and 10 seconds after the event. The tagged video can be searched and checked via the Control Client.

Add the description to the tagged video as needed.

Capture Picture

Select one camera to capture pictures during the event, and you can view the captured pictures when checking event in the Alarm & Event Search of the Control Client.

- To trigger the UVSS's related camera for capturing pictures, select **Source Related Camera**.
- To trigger other camera for capturing pictures, select **Specified Camera** (optional) and select one camera for capturing pictures.

iNote

Only one camera can be set for capturing pictures.

Capture Picture When: Specify the number of seconds at which the camera will capture before/after the event starts/ends. After you set the number of seconds for pre/post-event, the camera will capture one picture at three time points respectively: at the configured seconds before the event starts, at the configured seconds after the event ends, and at the middle of the event (as shown in the picture below).



Figure 12-7 Capture Pictures

iNote

The pre-event picture is captured from the camera's recorded video files. This pre-event capture function is only supported by the camera which is set to store the video files in the Recording Server (Cloud Storage Server, Hybrid SAN, or pStor).

Link Access Point

You can enable this function to trigger the access point(s) to be locked or unlocked when the event occurs. For example, you can set to trigger all the access points closed when the system detects suspicious person entering.

- All Access Points: When the event occurs, all the access points in the system will be unlocked, locked, remain unlocked, or remain locked.
- **Specified Access Point:** Click **Add** to select the access point(s) as the linkage target(s). You can set the access point action so that the access point will be unlocked, locked, remained unlocked, or remained locked when the event occurs.

iNote

Up to 16 access points can be selected as event linkage.

Link Alarm Output

Select the alarm output (if available) and the external device connected can be activated when the event occurs.

iNote

Up to 64 alarm outputs can be selected as event linkage.

Close Alarm Output: The added alarm output(s) can be closed manually, or you can set the number of seconds in which the alarm output(s) will be closed automatically.

Trigger PTZ

Call the preset, patrol or pattern of the selected camera(s) when the event occurs.

iNote

Up to 64 PTZ linkages can be selected as event linkage.

Send Email

Select an email template to send the event information according to the defined email settings. You can select **Add New** to create a new email template. For details, refer to **Set Email Template**.

Trigger User-Defined Event

Trigger user-defined event(s) when the system-monitored event is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).



- Up to 16 user-defined events can be selected as event linkage.
- For setting the user-defined event, refer to *Configure User-Defined Event* .

5. Finish adding the event.

- Click Add to add the event and back to the event list page.
- Click Add and Trigger Alarm to trigger this event as an alarm for further notification. For details, refer to *Configure Alarm*.

After adding the event, it displays on the event list, and you can view the event name, event source, and triggering event.

6. Optional: Perform the following operation(s) after adding the event.

Trigger Event as Alarm	Click 😥 in the Operation column of system-monitored event settings page to set the alarm properties, recipients, actions, and other parameters.
	i Note
	For details, refer to Configure Alarm .
Test Event	Click in the Operation column of system-monitored event settings page to trigger the event manually, and you can check whether the linkage actions take effect.
Delete Event	Select the event(s) and click Delete to delete the selected event(s).
Manage Invalid Event	If (2) appears near the event name, it means the event is not supported by the device and it is invalid. You should hover the cursor over the (2) and click Delete on the tooltip to delete the event.
Delete All Invalid Events	Click Delete All Invalid Items to delete all the invalid events in a batch.

Filter EventClick \bigtriangledown to expand the filter conditions. Set the conditions and click Filter
to filter the events according to the conditions.

12.1.7 Add Event for Remote Site

You can add an event for the managed Remote Sites in the system. When the Remote Site gets offline, Central System can receive and record event for checking and trigger a series of linkage actions (e.g., sending email) for notification.

Steps

- 1. Click Event & Alarm → System-Monitored Event → Add to enter the event adding page.
- **2.** Configure the event's basic information, including source type, triggering event, and event source.

Source Type

Select the source type as **Remote Site**.

Triggering Event

If the Remote Site gets offline, it will trigger a system-monitored event in the Central System.

Source

The specific resource(s) which can trigger this event.

iNote

For source type of generic event and user-defined event, you should select the configured generic event or user-defined event as the event source.

3. Optional: Set the Active Control switch to on, and then set the Threshold for Reactivation.

iNote

- Active Control is used to avoid the same event occurs frequently in a short time, which may aggravate the burden of HikCentral Professional event center. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30 s**, the same events from the same camera within 30 s will be regarded as one event on the HikCentral Professional.
- The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.
- 4. Optional: Set the Action switch to on to set the linkage actions for the event.

Arming Schedule Template

The Remote Site is armed during the arming schedule and the triggering event occurred on the event source during the arming schedule will trigger the configured linkage actions.

iNote

For setting customized template, refer to Configure Arming Schedule Template .

Trigger Recording

Click **Add** to select the camera to record video when the event occurs. Select the storage location for storing the video files. You can play back the recorded video files when checking events in the Alarm & Event Search of the Control Client.

View Pre-Event Video: If the camera has recorded video files before the event, you can view the video recorded from periods preceding the event. Specify the number of seconds which you want to view the recorded video for before the event starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.

Post-record: Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.

Lock Video Files for: Set the days for protecting the video file from being overwritten.

Create Tag

Click **Add** to select the camera to record video when the event occurs and add tag to the event triggered video. Select the storage location for storing the video files. The tagged video can be searched and checked via the Control Client.

You can enter the tag name as desired. You can also click the button below to add the related information to the name.

Set the time range to define the tagged video length. For example, you can set to record the tagged video started from 5 seconds before the event and lasted until and 10 seconds after the event. The tagged video can be searched and checked via the Control Client.

Add the description to the tagged video as needed.

Capture Picture

Select one camera to capture pictures during the event, and you can view the captured pictures when checking event in the Alarm & Event Search of the Control Client.

iNote

Only one camera can be set for capturing pictures.

Capture Picture When: Specify the number of seconds at which the camera will capture before/after the event starts/ends. After you set the number of seconds for pre/post-event, the camera will capture one picture at three time points respectively: at the configured seconds before the event starts, at the configured seconds after the event ends, and at the middle of the event (as shown in the picture below).



Figure 12-8 Capture Pictures

i Note

The pre-event picture is captured from the camera's recorded video files. This pre-event capture function is only supported by the camera which is set to store the video files in the Recording Server (Cloud Storage Server, Hybrid SAN, or pStor).

Link Access Point

You can enable this function to trigger the access point(s) to be locked or unlocked when the event occurs. For example, you can set to trigger all the access points closed when the system detects suspicious person entering.

- All Access Points: When the event occurs, all the access points in the system will be unlocked, locked, remain unlocked, or remain locked.
- **Specified Access Point:** Click **Add** to select the access point(s) as the linkage target(s). You can set the access point action so that the access point will be unlocked, locked, remained unlocked, or remained locked when the event occurs.

iNote

Up to 16 access points can be selected as event linkage.

Link Alarm Output

Select the alarm output (if available) and the external device connected can be activated when the event occurs.

iNote

Up to 64 alarm outputs can be selected as event linkage.

Close Alarm Output: The added alarm output(s) can be closed manually, or you can set the number of seconds in which the alarm output(s) will be closed automatically.

Trigger PTZ

Call the preset, patrol or pattern of the selected camera(s) when the event occurs.

iNote

Up to 64 PTZ linkages can be selected as event linkage.

Send Email

Select an email template to send the event information according to the defined email settings. You can select **Add New** to create a new email template. For details, refer to **Set Email Template**.

Trigger User-Defined Event

Trigger user-defined event(s) when the system-monitored event is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as event linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .
- **5.** Finish adding the event.
 - Click Add to add the event and back to the event list page.
 - Click Add and Trigger Alarm to trigger this event as an alarm for further notification. For details, refer to *Configure Alarm*.

After adding the event, it displays on the event list, and you can view the event name, event source, and triggering event.

6. Optional: Perform the following operation(s) after adding the event.

Trigger Event as Alarm	Click 😥 in the Operation column of system-monitored event settings page to set the alarm properties, recipients, actions, and other parameters.
	i Note
	For details, refer to Configure Alarm .
Test Event	Click <a>o in the Operation column of system-monitored event settings page to trigger the event manually, and you can check whether the linkage actions take effect.
Delete Event	Select the event(s) and click Delete to delete the selected event(s).
Manage Invalid Event	If (\otimes) appears near the event name, it means the event is not supported by the device and it is invalid. You should hover the cursor over the (\otimes) and click Delete on the tooltip to delete the event.
Delete All Invalid Events	Click Delete All Invalid Items to delete all the invalid events in a batch.
Filter Event	Click \bigtriangledown to expand the filter conditions. Set the conditions and click Filter to filter the events according to the conditions.

12.1.8 Add Event for Encoding Device

You can add an event for the encoding devices in the system. When the event is triggered on the device, system can receive and record event for checking and trigger a series of linkage actions (e.g., sending email) for notification.

Steps

- 1. Click Event & Alarm → System-Monitored Event → Add to enter the event adding page.
- **2.** Configure the event's basic information, including source type, triggering event, and event source.

Source Type

Select the source type as **Encoding Device**.

Triggering Event

The event detected on the encoding devices will trigger the system-monitored event in the system.

Source

The specific encoding devices(s) which can trigger this event.

3. Optional: Set the Active Control switch to on, and then set the Threshold for Reactivation.

iNote

- Active Control is used to avoid the same event occurs frequently in a short time, which may aggravate the burden of event center. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30** s, the same events from the same camera within 30 s will be regarded as one event on the system.
- The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.
- **4. Optional:** Set the **Action** switch to on to set the linkage actions for the event.

Arming Schedule Template

The event source is armed during the arming schedule and the triggering event occurred on the event source during the arming schedule will trigger the configured linkage actions.

iNote

For setting customized template, refer to Configure Arming Schedule Template .

Trigger Recording

Click **Add** to select the camera(s) to record video when the event occurs. You can play back the recorded video files when checking events in the Alarm & Event Search of the Control Client.

View Pre-Event Video: If the camera has recorded video files before the event, you can view the video recorded from periods preceding the event. Specify the number of seconds which you want to view the recorded video for before the event starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.

Post-record: Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.

Lock Video Files for: Set the days for protecting the video file from being overwritten.

Create Tag

Click **Add** to select the camera to record video when the event occurs and add tag to the event triggered video. Select the storage location for storing the video files. The tagged video can be searched and checked via the Control Client.

You can enter the name as desired. You can also click the button below to add the related information to the name.

Set the time range to define the tagged video length. For example, you can set to record the tagged video started from 5 seconds before the event and lasted until and 10 seconds after the event. The tagged video can be searched and checked via the Control Client.

Add the description to the tagged video as needed.

Capture Picture

Select one camera to capture pictures during the event, and you can view the captured pictures when checking event in the Alarm & Event Search of the Control Client.

i Note

Only one camera can be set for capturing pictures.

Capture Picture When: Specify the number of seconds at which the camera will capture before/after the event starts/ends. After you set the number of seconds for pre/post-event, the camera will capture one picture at three time points respectively: at the configured seconds before the event starts, at the configured seconds after the event ends, and at the middle of the event (as shown in the picture below).



Figure 12-9 Capture Pictures

iNote

The pre-event picture is captured from the camera's recorded video files. This pre-event capture function is only supported by the camera which is set to store the video files in the Recording Server (Cloud Storage Server, Hybrid SAN, or pStor).

Link Access Point

You can enable this function to trigger the access point(s) to be locked or unlocked when the event occurs. For example, you can set to trigger all the access points closed when the system detects suspicious person entering.

- All Access Points: When the event occurs, all the access points in the system will be unlocked, locked, remain unlocked, or remain locked.
- **Specified Access Point:** Click **Add** to select the access point(s) as the linkage target(s). You can set the access point action so that the access point will be unlocked, locked, remained unlocked, or remained locked when the event occurs.

iNote

Up to 16 access points can be selected as event linkage.

Link Alarm Output

Select the alarm output (if available) and the external device connected can be activated when the event occurs.

i Note

Up to 64 alarm outputs can be selected as event linkage.

Close Alarm Output: The added alarm output(s) can be closed manually, or you can set the number of seconds in which the alarm output(s) will be closed automatically.

Trigger PTZ

Call the preset, patrol or pattern of the selected camera(s) when the event occurs.

iNote

Up to 64 PTZ linkages can be selected as event linkage.

Send Email

Select an email template to send the event information according to the defined email settings. You can select **Add New** to create a new email template. For details, refer to **Set Email Template**.

Trigger User-Defined Event

Trigger user-defined event(s) when the system-monitored event is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as event linkage.
- For setting the user-defined event, refer to *Configure User-Defined Event* .

5. Finish adding the event.

- Click Add to add the event and back to the event list page.
- Click Add and Trigger Alarm to trigger this event as an alarm for further notification. For details, refer to *Configure Alarm*.

After adding the event, it displays on the event list, and you can view the event name, event source, and triggering event.

6. Optional: Perform the following operation(s) after adding the event.

Trigger EventClick in the Operation column of system-monitored event settings pageas Alarmto set the alarm properties, recipients, actions, and other parameters.



For details, refer to Configure Alarm .

Test Event	Click in the Operation column of system-monitored event settings page to trigger the event manually, and you can check whether the linkage actions take effect.
Delete Event	Select the event(s) and click Delete to delete the selected event(s).
Manage Invalid Event	If \bigotimes appears near the event name, it means the event is not supported by the device and it is invalid. You should hover the cursor over the \bigotimes and click Delete on the tooltip to delete the event.
Delete All Invalid Events	Click Delete All Invalid Items to delete all the invalid events in a batch.
Filter Event	Click γ to expand the filter conditions. Set the conditions and click Filter to filter the events according to the conditions.

12.1.9 Add Event for Access Control Device

You can add an event for the access control devices in the system. When the event is triggered on the device, system can receive and record event for checking and trigger a series of linkage actions (e.g., sending email) for notification.

Steps

- 1. Click Event & Alarm → System-Monitored Event → Add to enter the event adding page.
- **2.** Configure the event's basic information, including source type, triggering event, and event source.

Source Type

Select the source type as Access Control Device.

Triggering Event

The event detected on the access control device will trigger a system-monitored event in the system.

Source

The specific access control device(s) which can trigger this event.

3. Optional: Set the Active Control switch to on, and then set the Threshold for Reactivation.

iNote

- Active Control is used to avoid the same event occurs frequently in a short time, which may aggravate the burden of HikCentral Professional event module. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30** s, the same events from the same camera within 30 s will be regarded as one event on the HikCentral Professional.
- The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.
- 4. Optional: Set the Action switch to on to set the linkage actions for the event.

Arming Schedule Template

The access control device is armed during the arming schedule and the triggering event occurred on the event source during the arming schedule will trigger the configured linkage actions.



For setting customized template, refer to Configure Arming Schedule Template .

Trigger Recording

Click **Add** to select the camera(s) to record video when the event occurs. Select the storage location for storing the video files. You can play back the recorded video files when checking events in the Alarm & Event Search of the Control Client.

View Pre-Event Video: If the camera has recorded video files before the event, you can view the video recorded from periods preceding the event. Specify the number of seconds which you want to view the recorded video for before the event starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.

Post-record: Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.

Lock Video Files for: Set the days for protecting the video file from being overwritten.

Create Tag

Click **Add** to select the camera(s) to record video when the event occurs and add tag to the event triggered video. Select the storage location for storing the video files. The tagged video can be searched and checked via the Control Client.

You can enter the tag name as desired. You can also click the button below to add the related information to the name.

Set the time range to define the tagged video length. For example, you can set to record the tagged video started from 5 seconds before the event and lasted until and 10 seconds after the event. The tagged video can be searched and checked via the Control Client.

Add the description to the tagged video as needed.

Capture Picture

Select one camera to capture pictures during the event, and you can view the captured pictures when checking event in the Alarm & Event Search of the Control Client.

i Note

Only one camera can be set for capturing pictures.

Capture Picture When: Specify the number of seconds at which the camera will capture before/after the event starts/ends. After you set the number of seconds for pre/post-event, the camera will capture one picture at three time points respectively: at the configured

seconds before the event starts, at the configured seconds after the event ends, and at the middle of the event (as shown in the picture below).



Figure 12-10 Capture Pictures

iNote

The pre-event picture is captured from the camera's recorded video files. This pre-event capture function is only supported by the camera which is set to store the video files in the Recording Server (Cloud Storage Server, Hybrid SAN, or pStor).

Link Access Point

You can enable this function to trigger the access point(s) to be locked or unlocked when the event occurs. For example, you can set to trigger all the access points closed when the system detects suspicious person entering.

- All Access Points: When the event occurs, all the access points in the system will be unlocked, locked, remain unlocked, or remain locked.
- **Specified Access Point:** Click **Add** to select the access point(s) as the linkage target(s). You can set the access point action so that the access point will be unlocked, locked, remained unlocked, or remained locked when the event occurs.

iNote

Up to 16 access points can be selected as event linkage.

Link Alarm Output

Select the alarm output (if available) and the external device connected can be activated when the event occurs.

iNote

Up to 64 alarm outputs can be selected as event linkage.

Close Alarm Output: The added alarm output(s) can be closed manually, or you can set the number of seconds in which the alarm output(s) will be closed automatically.

Trigger PTZ

Call the preset, patrol or pattern of the selected camera(s) when the event occurs.

iNote

Up to 64 PTZ linkages can be selected as event linkage.

Send Email

Select an email template to send the event information according to the defined email settings. You can select **Add New** to create a new email template. For details, refer to **Set Email Template**.

Trigger User-Defined Event

Trigger user-defined event(s) when the system-monitored event is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as event linkage.
- For setting the user-defined event, refer to *Configure User-Defined Event* .

5. Finish adding the event.

- Click Add to add the event and back to the event list page.
- Click Add and Trigger Alarm to trigger this event as an alarm for further notification. For details, refer to *Configure Alarm*.

After adding the event, it displays on the event list, and you can view the event name, event source, and triggering event.

6. Optional: Perform the following operation(s) after adding the event.

Trigger Event as Alarm	Click 🔝 in the Operation column of system-monitored event settings page to set the alarm properties, recipients, actions, and other parameters.
	i Note
	For details, refer to Configure Alarm .
Test Event	Click ③ in the Operation column of system-monitored event settings page to trigger the event manually, and you can check whether the linkage actions take effect.
Delete Event	Select the event(s) and click Delete to delete the selected event(s).
Manage Invalid Event	If \bigotimes appears near the event name, it means the event is not supported by the device and it is invalid. You should hover the cursor over the \bigotimes and click Delete on the tooltip to delete the event.
Delete All Invalid Events	Click Delete All Invalid Items to delete all the invalid events in a batch.
Filter Event	Click γ to expand the filter conditions. Set the conditions and click Filter to filter the events according to the conditions.

12.1.10 Add Event for Security Control Device

You can add an event for the security control device in the system. When the event is triggered on the device, system can receive and record event for checking and trigger a series of linkage actions (e.g., sending email) for notification.

Steps

- 1. Click Event & Alarm → System-Monitored Event → Add to enter the event adding page.
- **2.** Configure the event's basic information, including source type, triggering event, and event source.

Source Type

Select the source type as **Security Control Device**.

Triggering Event

The event detected on the security control device will trigger the system-monitored event in the system.

Source

The specific security control device(s) which can trigger this event.

3. Optional: Set the Active Control switch to on, and then set the Threshold for Reactivation.

iNote

- Active Control is used to avoid the same event occurs frequently in a short time, which may aggravate the burden of HikCentral Professional event center. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30 s**, the same events from the same camera within 30 s will be regarded as one event on the HikCentral Professional.
- The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.
- 4. Optional: Set the Action switch to on to set the linkage actions for the event.

Arming Schedule Template

The security control device is armed during the arming schedule and the triggering event occurred on the event source during the arming schedule will trigger the configured linkage actions.

i Note

For setting customized template, refer to Configure Arming Schedule Template .

Trigger Recording

Click **Add** to select the camera(s) to record video when the event occurs. Select the storage location for storing the video files. You can play back the recorded video files when checking events in the Alarm & Event Search of the Control Client.

View Pre-Event Video: If the camera has recorded video files before the event, you can view the video recorded from periods preceding the event. Specify the number of seconds which you want to view the recorded video for before the event starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.

Post-record: Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.

Lock Video Files for: Set the days for protecting the video file from being overwritten.

Create Tag

Click **Add** to select the camera(s) to record video when the event occurs and add tag to the event triggered video. Select the storage location for storing the video files. The tagged video can be searched and checked via the Control Client.

You can enter the tag name as desired. You can also click the button below to add the related information to the name.

Set the time range to define the tagged video length. For example, you can set to record the tagged video started from 5 seconds before the event and lasted until and 10 seconds after the event. The tagged video can be searched and checked via the Control Client.

Add the description to the tagged video as needed.

Capture Picture

Select one camera to capture pictures during the event, and you can view the captured pictures when checking event in the Alarm & Event Search of the Control Client.

iNote

Only one camera can be set for capturing pictures.

Capture Picture When: Specify the number of seconds at which the camera will capture before/after the event starts/ends. After you set the number of seconds for pre/post-event, the camera will capture one picture at three time points respectively: at the configured seconds before the event starts, at the configured seconds after the event ends, and at the middle of the event (as shown in the picture below).





i Note

The pre-event picture is captured from the camera's recorded video files. This pre-event capture function is only supported by the camera which is set to store the video files in the Recording Server (Cloud Storage Server, Hybrid SAN, or pStor).

Link Access Point

You can enable this function to trigger the access point(s) to be locked or unlocked when the event occurs. For example, you can set to trigger all the access points closed when the system detects suspicious person entering.

- All Access Points: When the event occurs, all the access points in the system will be unlocked, locked, remain unlocked, or remain locked.
- **Specified Access Point:** Click **Add** to select the access point(s) as the linkage target(s). You can set the access point action so that the access point will be unlocked, locked, remained unlocked, or remained locked when the event occurs.

iNote

Up to 16 access points can be selected as event linkage.

Link Alarm Output

Select the alarm output (if available) and the external device connected can be activated when the event occurs.

i Note

Up to 64 alarm outputs can be selected as event linkage.

Close Alarm Output: The added alarm output(s) can be closed manually, or you can set the number of seconds in which the alarm output(s) will be closed automatically.

Trigger PTZ

Call the preset, patrol or pattern of the selected camera(s) when the event occurs.

i Note

Up to 64 PTZ linkages can be selected as event linkage.

Send Email

Select an email template to send the event information according to the defined email settings. You can select **Add New** to create a new email template. For details, refer to **Set Email Template**.

Trigger User-Defined Event

Trigger user-defined event(s) when the system-monitored event is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as event linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .
- **5.** Finish adding the event.

- Click Add to add the event and back to the event list page.
- Click Add and Trigger Alarm to trigger this event as an alarm for further notification. For details, refer to *Configure Alarm*.

After adding the event, it displays on the event list, and you can view the event name, event source, and triggering event.

6. Optional: Perform the following operation(s) after adding the event.

Trigger Event as Alarm	Click 🤬 in the Operation column of system-monitored event settings page to set the alarm properties, recipients, actions, and other parameters.
	i Note
	For details, refer to Configure Alarm .
Test Event	Click ③ in the Operation column of system-monitored event settings page to trigger the event manually, and you can check whether the linkage actions take effect.
Delete Event	Select the event(s) and click Delete to delete the selected event(s).
Manage Invalid Event	If \bigotimes appears near the event name, it means the event is not supported by the device and it is invalid. You should hover the cursor over the \bigotimes and click Delete on the tooltip to delete the event.
Delete All Invalid Events	Click Delete All Invalid Items to delete all the invalid events in a batch.
Filter Event	Click γ to expand the filter conditions. Set the conditions and click Filter to filter the events according to the conditions.

12.1.11 Add Event for Dock Station

You can add an event (including dock station offline or dock station online) for the dock station. When the event is triggered on the dock station, system can receive and record event for checking and trigger a series of linkage actions (e.g., sending email) for notification.

Steps

- 1. Click Event & Alarm → System-Monitored Event → Add to enter the event adding page.
- **2.** Configure the event's basic information, including source type, triggering event, and event source.

Source Type

Select the source type as **Dock Station**.

Triggering Event

The event detected dock station will trigger a system-monitored event in the system.

Source

The specific dock station which can trigger this event.

3. Optional: Set the Active Control switch to on, and then set the Threshold for Reactivation.

iNote

- Active Control is used to avoid the same event occurs frequently in a short time, which may aggravate the burden of HikCentral Professional event center. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30 s**, the same events from the same camera within 30 s will be regarded as one event on the HikCentral Professional.
- The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.
- 4. Optional: Set the Action switch to on to set the linkage actions for the event.

Arming Schedule Template

The dock station is armed during the arming schedule and the triggering event occurred on the camera during the arming schedule will trigger the configured linkage actions.

iNote

For setting customized template, refer to Configure Arming Schedule Template .

Trigger Recording

Click **Add** to select the camera(s) to record video when the event occurs. You can play back the recorded video files when checking events in the Alarm & Event Search of the Control Client.

View Pre-Event Video: If the camera has recorded video files before the event, you can view the video recorded from periods preceding the event. Specify the number of seconds which you want to view the recorded video for before the event starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.

Post-record: Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.

Lock Video Files for: Set the days for protecting the video file from being overwritten.

Create Tag

Select the camera(s) to record video when the event occurs and add tag to the event triggered video. The tagged video can be searched and checked via the Control Client.

- To trigger the source camera itself for tagged recording, select **Source Camera** and select the storage location for storing the video files.
- To trigger other cameras for tagged recording, select **Specified Camera** and click **Add** to add other cameras. Select the storage location for storing the video files.

You can enter the tag name as desired. You can also click the button below to add the related information to the name.

Set the time range to define the tagged video length. For example, you can set to record the tagged video started from 5 seconds before the event and lasted until and 10 seconds after the event. The tagged video can be searched and checked via the Control Client.

Add the description to the tagged video as needed.

Capture Picture

Select one camera to capture pictures during the event, and you can view the captured pictures when checking event in the Alarm & Event Search of the Control Client.

- To trigger the source camera itself for capturing pictures, select Source Camera.
- To trigger other camera for capturing pictures, select **Specified Camera** and select one camera for capturing pictures.

iNote

Only one camera can be set for capturing pictures.

Capture Picture When: Specify the number of seconds to define when the camera will capture pictures for the event. After you set the number of seconds for pre/post-event, the camera will capture one picture at three time points respectively: at the configured seconds before the event starts, at the configured seconds after the event ends, and at the middle of the event (as shown in the picture below).



Figure 12-12 Capture Pictures

iNote

The pre-event picture is captured from the camera's recorded video files. This pre-event capture function is only supported by the camera which is set to store the video files in the Recording Server (Cloud Storage Server, Hybrid SAN, or pStor).

Link Access Point

You can enable this function to trigger the access point(s) to be locked or unlocked when the event occurs. For example, you can set to trigger all the access points closed when the system detects suspicious person entering.

- All Access Points: When the event occurs, all the access points in the system will be unlocked, locked, remain unlocked, or remain locked.
- **Specified Access Point:** Click **Add** to select the access point(s) as the linkage target(s). You can set the access point action so that the access point will be unlocked, locked, remained unlocked, or remained locked when the event occurs.

iNote

Up to 16 access points can be selected as event linkage.

Link Alarm Output

Select the alarm output (if available) and the external device connected can be activated when the event occurs.

i Note

Up to 64 alarm outputs can be selected as event linkage.

Close Alarm Output: The added alarm output(s) can be closed manually, or you can set the number of seconds in which the alarm output(s) will be closed automatically.

Trigger PTZ

Call the preset, patrol or pattern of the selected camera(s) when the event occurs.

iNote

Up to 64 PTZ linkages can be selected as event linkage.

Send Email

Select an email template to send the event information according to the defined email settings. You can select **Add New** to create a new email template. For details, refer to **Set Email Template**.

Trigger User-Defined Event

Trigger user-defined event(s) when the system-monitored event is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as event linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .

5. Finish adding the event.

- Click Add to add the event and back to the event list page.
- Click Add and Trigger Alarm to trigger this event as an alarm for further notification. For details, refer to *Configure Alarm*.

After adding the event, it displays on the event list, and you can view the event name, event source, and triggering event.

6. Optional: Perform the following operation(s) after adding the event.

Trigger EventClick in the Operation column of system-monitored event settings pageas Alarmto set the alarm properties, recipients, actions, and other parameters.



For details, refer to Configure Alarm .

Test Event	Click <pre>o in the Operation column of system-monitored event settings page to trigger the event manually, and you can check whether the linkage actions take effect.</pre>
Delete Event	Select the event(s) and click Delete to delete the selected event(s).
Manage Invalid Event	If \bigotimes appears near the event name, it means the event is not supported by the device and it is invalid. You should hover the cursor over the \bigotimes and click Delete on the tooltip to delete the event.
Delete All Invalid Events	Click Delete All Invalid Items to delete all the invalid events in a batch.
Filter Event	Click γ to expand the filter conditions. Set the conditions and click Filter to filter the events according to the conditions.

12.1.12 Add Event for Streaming Server or Recording Server

You can add an event for the added Streaming Servers and Recording Servers in the system. When the event is triggered on these servers, system can receive and record event for checking and trigger a series of linkage actions (e.g., sending email) for notification.

Steps

- 1. Click Event & Alarm → System-Monitored Event → Add to enter the event adding page.
- **2.** Configure the event's basic information, including source type, triggering event, and event source.

Source Type

Select the source type as Streaming Server or Recording Server.

Triggering Event

The event detected on the server will trigger a system-monitored event in the system.

Source

The specific server(s) which can trigger this event.

3. Optional: Set the Active Control switch to on, and then set the Threshold for Reactivation.

iNote

- Active Control is used to avoid the same event occurs frequently in a short time, which may
 aggravate the burden of HikCentral Professional event center. You need to set the Threshold
 for Reactivation. For example, you have set the Threshold for Reactivation as **30 s**, the same
 events from the same camera within 30 s will be regarded as one event on the HikCentral
 Professional.
- The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.
- 4. Optional: Set the Action switch to on to set the linkage actions for the event.

Arming Schedule Template

The server is armed during the arming schedule and the triggering event occurred on the server during the arming schedule will trigger the configured linkage actions.

iNote

For setting customized template, refer to Configure Arming Schedule Template .

Trigger Recording

Click **Add** to select the camera to record video when the event occurs. Select the storage location for storing the video files. You can play back the recorded video files when checking events in the Alarm & Event Search of the Control Client.

View Pre-Event Video: If the camera has recorded video files before the event, you can view the video recorded from periods preceding the event. Specify the number of seconds which you want to view the recorded video for before the event starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.

Post-record: Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.

Lock Video Files for: Set the days for protecting the video file from being overwritten.

Create Tag

Click **Add** to select the camera to record video when the event occurs and add tag to the event triggered video. Select the storage location for storing the video files. The tagged video can be searched and checked via the Control Client.

You can enter the tag name as desired. You can also click the button below to add the related information to the name.

Set the time range to define the tagged video length. For example, you can set to record the tagged video started from 5 seconds before the event and lasted until and 10 seconds after the event. The tagged video can be searched and checked via the Control Client.

Add the description to the tagged video as needed.

Capture Picture

Select one camera to capture pictures during the event, and you can view the captured pictures when checking event in the Alarm & Event Search of the Control Client.

iNote

Only one camera can be set for capturing pictures.

Capture Picture When: Specify the number of seconds at which the camera will capture before/after the event starts/ends. After you set the number of seconds for pre/post-event, the camera will capture one picture at three time points respectively: at the configured

seconds before the event starts, at the configured seconds after the event ends, and at the middle of the event (as shown in the picture below).



Figure 12-13 Capture Pictures

iNote

The pre-event picture is captured from the camera's recorded video files. This pre-event capture function is only supported by the camera which is set to store the video files in the Recording Server (Cloud Storage Server, Hybrid SAN, or pStor).

Link Access Point

You can enable this function to trigger the access point(s) to be locked or unlocked when the event occurs. For example, you can set to trigger all the access points closed when the system detects suspicious person entering.

- All Access Points: When the event occurs, all the access points in the system will be unlocked, locked, remain unlocked, or remain locked.
- **Specified Access Point:** Click **Add** to select the access point(s) as the linkage target(s). You can set the access point action so that the access point will be unlocked, locked, remained unlocked, or remained locked when the event occurs.

iNote

Up to 16 access points can be selected as event linkage.

Link Alarm Output

Select the alarm output (if available) and the external device connected can be activated when the event occurs.

iNote

Up to 64 alarm outputs can be selected as event linkage.

Close Alarm Output: The added alarm output(s) can be closed manually, or you can set the number of seconds in which the alarm output(s) will be closed automatically.

Trigger PTZ

Call the preset, patrol or pattern of the selected camera(s) when the event occurs.

iNote

Up to 64 PTZ linkages can be selected as event linkage.

Send Email

Select an email template to send the event information according to the defined email settings. You can select **Add New** to create a new email template. For details, refer to **Set Email Template**.

Trigger User-Defined Event

Trigger user-defined event(s) when the system-monitored event is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as event linkage.
- For setting the user-defined event, refer to *Configure User-Defined Event* .

5. Finish adding the event.

- Click Add to add the event and back to the event list page.
- Click Add and Trigger Alarm to trigger this event as an alarm for further notification. For details, refer to *Configure Alarm*.

After adding the event, it displays on the event list, and you can view the event name, event source, and triggering event.

6. Optional: Perform the following operation(s) after adding the event.

Trigger Event as Alarm	Click 🔝 in the Operation column of system-monitored event settings page to set the alarm properties, recipients, actions, and other parameters.
	i Note
	For details, refer to Configure Alarm .
Test Event	Click ③ in the Operation column of system-monitored event settings page to trigger the event manually, and you can check whether the linkage actions take effect.
Delete Event	Select the event(s) and click Delete to delete the selected event(s).
Manage Invalid Event	If \bigotimes appears near the event name, it means the event is not supported by the device and it is invalid. You should hover the cursor over the \bigotimes and click Delete on the tooltip to delete the event.
Delete All Invalid Events	Click Delete All Invalid Items to delete all the invalid events in a batch.
Filter Event	Click γ to expand the filter conditions. Set the conditions and click Filter to filter the events according to the conditions.

12.1.13 Add Event for Facial Recognition Server

You can add an event for the added Facial Recognition Server in the system, including server online or server offline event. When the event is triggered on the server, system can receive and record event for checking and trigger a series of linkage actions (e.g., sending email) for notification.

Steps

- 1. Click Event & Alarm → System-Monitored Event → Add to enter the event adding page.
- **2.** Configure the event's basic information, including source type, triggering event, and event source.

Source Type

Select the source type as Facial Recognition Server.

Triggering Event

The event detected on the server will trigger a system-monitored event in the system.

Source

The specific server(s) which can trigger this event.

3. Optional: Set the Active Control switch to on, and then set the Threshold for Reactivation.

iNote

- Active Control is used to avoid the same event occurs frequently in a short time, which may
 aggravate the burden of HikCentral Professional event center. You need to set the Threshold
 for Reactivation. For example, you have set the Threshold for Reactivation as **30 s**, the same
 events from the same camera within 30 s will be regarded as one event on the HikCentral
 Professional.
- The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.
- 4. Optional: Set the Action switch to on to set the linkage actions for the event.

Arming Schedule Template

The server is armed during the arming schedule and the triggering event occurred on the server during the arming schedule will trigger the configured linkage actions.

iNote

For setting customized template, refer to Configure Arming Schedule Template .

Trigger Recording

Click **Add** to select the camera to record video when the event occurs. Select the storage location for storing the video files. You can play back the recorded video files when checking events in the Alarm & Event Search of the Control Client.

View Pre-Event Video: If the camera has recorded video files before the event, you can view the video recorded from periods preceding the event. Specify the number of seconds which you want to view the recorded video for before the event starts. For example, when

someone opens a door, you can view the recorded video to see what happens right before the door opened.

Post-record: Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.

Lock Video Files for: Set the days for protecting the video file from being overwritten.

Create Tag

Click **Add** to select the camera to record video when the event occurs and add tag to the event triggered video. Select the storage location for storing the video files. The tagged video can be searched and checked via the Control Client.

You can enter the tag name as desired. You can also click the button below to add the related information to the name.

Set the time range to define the tagged video length. For example, you can set to record the tagged video started from 5 seconds before the event and lasted until and 10 seconds after the event. The tagged video can be searched and checked via the Control Client.

Add the description to the tagged video as needed.

Capture Picture

Select one camera to capture pictures during the event, and you can view the captured pictures when checking event in the Alarm & Event Search of the Control Client.

iNote

Only one camera can be set for capturing pictures.

Capture Picture When: Specify the number of seconds at which the camera will capture before/after the event starts/ends. After you set the number of seconds for pre/post-event, the camera will capture one picture at three time points respectively: at the configured seconds before the event starts, at the configured seconds after the event ends, and at the middle of the event (as shown in the picture below).



Figure 12-14 Capture Pictures

iNote

The pre-event picture is captured from the camera's recorded video files. This pre-event capture function is only supported by the camera which is set to store the video files in the Recording Server (Cloud Storage Server, Hybrid SAN, or pStor).

Link Access Point

You can enable this function to trigger the access point(s) to be locked or unlocked when the event occurs. For example, you can set to trigger all the access points closed when the system detects suspicious person entering.

- All Access Points: When the event occurs, all the access points in the system will be unlocked, locked, remain unlocked, or remain locked.
- **Specified Access Point:** Click **Add** to select the access point(s) as the linkage target(s). You can set the access point action so that the access point will be unlocked, locked, remained unlocked, or remained locked when the event occurs.

INote

Up to 16 access points can be selected as event linkage.

Link Alarm Output

Select the alarm output (if available) and the external device connected can be activated when the event occurs.

iNote

Up to 64 alarm outputs can be selected as event linkage.

Close Alarm Output: The added alarm output(s) can be closed manually, or you can set the number of seconds in which the alarm output(s) will be closed automatically.

Trigger PTZ

Call the preset, patrol or pattern of the selected camera(s) when the event occurs.



Up to 64 PTZ linkages can be selected as event linkage.

Send Email

Select an email template to send the event information according to the defined email settings. You can select **Add New** to create a new email template. For details, refer to **Set Email Template**.

Trigger User-Defined Event

Trigger user-defined event(s) when the system-monitored event is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

i Note

- Up to 16 user-defined events can be selected as event linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .

5. Finish adding the event.

- Click Add to add the event and back to the event list page.

- Click Add and Trigger Alarm to trigger this event as an alarm for further notification. For details, refer to *Configure Alarm*.

After adding the event, it displays on the event list, and you can view the event name, event source, and triggering event.

6. Optional: Perform the following operation(s) after adding the event.

Trigger Event as Alarm	Click 😥 in the Operation column of system-monitored event settings page to set the alarm properties, recipients, actions, and other parameters.
	i Note
	For details, refer to Configure Alarm .
Test Event	Click ③ in the Operation column of system-monitored event settings page to trigger the event manually, and you can check whether the linkage actions take effect.
Delete Event	Select the event(s) and click Delete to delete the selected event(s).
Manage Invalid Event	If \bigotimes appears near the event name, it means the event is not supported by the device and it is invalid. You should hover the cursor over the \bigotimes and click Delete on the tooltip to delete the event.
Delete All Invalid Events	Click Delete All Invalid Items to delete all the invalid events in a batch.
Filter Event	Click γ to expand the filter conditions. Set the conditions and click Filter to filter the events according to the conditions.

12.1.14 Add Event for HikCentral Professional Server

You can set an event for the exception (including hardware exception and service exception) of the servers which have been installed with the HikCentral Professional services (such as SYS service, third-party device access gateway, NGINX service, keyboard proxy service, smart wall management service, etc.). When the event is triggered, system can receive and record event for checking and trigger a series of linkage actions (e.g., sending email) for notification.

Steps

- 1. Click Event & Alarm → System-Monitored Event → Add to enter the event adding page.
- **2.** Configure the event's basic information, including source type, triggering event, and event source.

Source Type

Select the source type as HikCentral Professional Server.

Triggering Event

The event detected on the HikCentral Professional Server will trigger the system-monitored event in the system.
Source

Select HikCentral Professional Server to trigger this event.

3. Optional: Set the Active Control switch to on, and then set the Threshold for Reactivation.

iNote

- Active Control is used to avoid the same event occurs frequently in a short time, which may aggravate the burden of HikCentral Professional event center. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30 s**, the same events from the same camera within 30 s will be regarded as one event on the HikCentral Professional.
- The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.
- 4. Optional: Set the Action switch to on to set the linkage actions for the event.

Arming Schedule Template

The server is armed during the arming schedule and the triggering event occurred on the server during the arming schedule will trigger the configured linkage actions.

iNote

For setting customized template, refer to Configure Arming Schedule Template .

Trigger Recording

Click **Add** to select the camera to record video when the event occurs. Select the storage location for storing the video files. You can play back the recorded video files when checking events in the Alarm & Event Search of the Control Client.

View Pre-Event Video: If the camera has recorded video files before the event, you can view the video recorded from periods preceding the event. Specify the number of seconds which you want to view the recorded video for before the event starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.

Post-record: Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.

Lock Video Files for: Set the days for protecting the video file from being overwritten.

Create Tag

Click **Add** to select the camera to record video when the event occurs and add tag to the event triggered video. Select the storage location for storing the video files. The tagged video can be searched and checked via the Control Client.

You can enter the tag name as desired. You can also click the button below to add the related information to the name.

Set the time range to define the tagged video length. For example, you can set to record the tagged video started from 5 seconds before the event and lasted until and 10 seconds after the event. The tagged video can be searched and checked via the Control Client.

Add the description to the tagged video as needed.

Capture Picture

Select one camera to capture pictures during the event, and you can view the captured pictures when checking event in the Alarm & Event Search of the Control Client.



Only one camera can be set for capturing pictures.

Capture Picture When: Specify the number of seconds at which the camera will capture before/after the event starts/ends. After you set the number of seconds for pre/post-event, the camera will capture one picture at three time points respectively: at the configured seconds before the event starts, at the configured seconds after the event ends, and at the middle of the event (as shown in the picture below).



Figure 12-15 Capture Pictures

i Note

The pre-event picture is captured from the camera's recorded video files. This pre-event capture function is only supported by the camera which is set to store the video files in the Recording Server (Cloud Storage Server, Hybrid SAN, or pStor).

Link Access Point

You can enable this function to trigger the access point(s) to be locked or unlocked when the event occurs. For example, you can set to trigger all the access points closed when the system detects suspicious person entering.

- All Access Points: When the event occurs, all the access points in the system will be unlocked, locked, remain unlocked, or remain locked.
- **Specified Access Point:** Click **Add** to select the access point(s) as the linkage target(s). You can set the access point action so that the access point will be unlocked, locked, remained unlocked, or remained locked when the event occurs.



Up to 16 access points can be selected as event linkage.

Link Alarm Output

Select the alarm output (if available) and the external device connected can be activated when the event occurs.

iNote

Up to 64 alarm outputs can be selected as event linkage.

Close Alarm Output: The added alarm output(s) can be closed manually, or you can set the number of seconds in which the alarm output(s) will be closed automatically.

Trigger PTZ

Call the preset, patrol or pattern of the selected camera(s) when the event occurs.

iNote

Up to 64 PTZ linkages can be selected as event linkage.

Send Email

Select an email template to send the event information according to the defined email settings. You can select **Add New** to create a new email template. For details, refer to **Set Email Template**.

Trigger User-Defined Event

Trigger user-defined event(s) when the system-monitored event is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click **Add New** below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as event linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .

5. Finish adding the event.

- Click Add to add the event and back to the event list page.
- Click Add and Trigger Alarm to trigger this event as an alarm for further notification. For details, refer to *Configure Alarm*.

After adding the event, it displays on the event list, and you can view the event name, event source, and triggering event.

6. Optional: Perform the following operation(s) after adding the event.

Trigger Event as Alarm	Click ы in the Operation column of system-monitored event settings page to set the alarm properties, recipients, actions, and other parameters.		
i Note			
	For details, refer to Configure Alarm .		
Test Event	Click in the Operation column of system-monitored event settings page to trigger the event manually, and you can check whether the linkage actions take effect.		
Delete Event	Select the event(s) and click Delete to delete the selected event(s).		

Manage Invalid Event	If \bigotimes appears near the event name, it means the event is not supported by the device and it is invalid. You should hover the cursor over the \bigotimes and click Delete on the tooltip to delete the event.
Delete All Invalid Events	Click Delete All Invalid Items to delete all the invalid events in a batch.
Filter Event	Click ∇ to expand the filter conditions. Set the conditions and click Filter to filter the events according to the conditions.

12.1.15 Add Event for User

You can add an event for the users in the system. When the user logs in or out, system can receive and record event for checking and trigger a series of linkage actions (e.g., sending email) for notification.

Steps

- 1. Click Event & Alarm → System-Monitored Event → Add to enter the event adding page.
- **2.** Configure the event's basic information, including source type, triggering event, and event source.

Source Type

Select the source type as User.

Triggering Event

The event detected on the event source and it will trigger the system-monitored event in the system.

Source

The specific user(s) who can trigger this event.

3. Optional: Set the Active Control switch to on, and then set the Threshold for Reactivation.

iNote

- Active Control is used to avoid the same event occurs frequently in a short time, which may aggravate the burden of HikCentral Professional event center. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30 s**, the same events from the same camera within 30 s will be regarded as one event on the HikCentral Professional.
- The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.
- 4. Optional: Set the Action switch to on to set the linkage actions for the event.

Arming Schedule Template

The user is armed during the arming schedule and the triggering event occurred on the event source during the arming schedule will trigger the configured linkage actions.

iNote

For setting customized template, refer to Configure Arming Schedule Template .

Trigger Recording

Click **Add** to select the camera to record video when the event occurs. Select the storage location for storing the video files. You can play back the recorded video files when checking events in the Alarm & Event Search of the Control Client.

View Pre-Event Video: If the camera has recorded video files before the event, you can view the video recorded from periods preceding the event. Specify the number of seconds which you want to view the recorded video for before the event starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.

Post-record: Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.

Lock Video Files for: Set the days for protecting the video file from being overwritten.

Create Tag

Select the camera to record video when the event occurs and add tag to the event triggered video. Select the storage location for storing the video files. The tagged video can be searched and checked via the Control Client.

You can enter the tag name as desired. You can also click the button below to add the related information to the name.

Set the time range to define the tagged video length. For example, you can set to record the tagged video started from 5 seconds before the event and lasted until and 10 seconds after the event. The tagged video can be searched and checked via the Control Client.

Add the description to the tagged video as needed.

Capture Picture

Select one camera to capture pictures during the event, and you can view the captured pictures when checking event in the Alarm & Event Search of the Control Client.

iNote

Only one camera can be set for capturing pictures.

Capture Picture When: Specify the number of seconds at which the camera will capture before/after the event starts/ends. After you set the number of seconds for pre/post-event, the camera will capture one picture at three time points respectively: at the configured seconds before the event starts, at the configured seconds after the event ends, and at the middle of the event (as shown in the picture below).



Figure 12-16 Capture Pictures

iNote

The pre-event picture is captured from the camera's recorded video files. This pre-event capture function is only supported by the camera which is set to store the video files in the Recording Server (Cloud Storage Server, Hybrid SAN, or pStor).

Link Access Point

You can enable this function to trigger the access point(s) to be locked or unlocked when the event occurs. For example, you can set to trigger all the access points closed when the system detects suspicious person entering.

- All Access Points: When the event occurs, all the access points in the system will be unlocked, locked, remain unlocked, or remain locked.
- **Specified Access Point:** Click **Add** to select the access point(s) as the linkage target(s). You can set the access point action so that the access point will be unlocked, locked, remained unlocked, or remained locked when the event occurs.

iNote

Up to 16 access points can be selected as event linkage.

Link Alarm Output

Select the alarm output (if available) and the external device connected can be activated when the event occurs.

iNote

Up to 64 alarm outputs can be selected as event linkage.

Close Alarm Output: The added alarm output(s) can be closed manually, or you can set the number of seconds in which the alarm output(s) will be closed automatically.

Trigger PTZ

Call the preset, patrol or pattern of the selected camera(s) when the event occurs.

iNote

Up to 64 PTZ linkages can be selected as event linkage.

Send Email

Select an email template to send the event information according to the defined email settings. You can select **Add New** to create a new email template. For details, refer to **Set Email Template**.

Trigger User-Defined Event

Trigger user-defined event(s) when the system-monitored event is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click **Add New** below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as event linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .

5. Finish adding the event.

- Click Add to add the event and back to the event list page.
- Click Add and Trigger Alarm to trigger this event as an alarm for further notification. For details, refer to *Configure Alarm*.

After adding the event, it displays on the event list, and you can view the event name, event source, and triggering event.

6. Optional: Perform the following operation(s) after adding the event.

Trigger Event as Alarm	Click 😥 in the Operation column of system-monitored event settings page to set the alarm properties, recipients, actions, and other parameters.
	i Note
	For details, refer to Configure Alarm .
Test Event	Click <a>o in the Operation column of system-monitored event settings page to trigger the event manually, and you can check whether the linkage actions take effect.
Delete Event	Select the event(s) and click Delete to delete the selected event(s).
Manage Invalid Event	If \bigotimes appears near the event name, it means the event is not supported by the device and it is invalid. You should hover the cursor over the \bigotimes and click Delete on the tooltip to delete the event.
Delete All Invalid Events	Click Delete All Invalid Items to delete all the invalid events in a batch.
Filter Event	Click γ to expand the filter conditions. Set the conditions and click Filter to filter the events according to the conditions.

12.1.16 Add Event for User-Defined Event

You can add an event for the added user-defined event in the system. When the user-defined event is triggered, system can receive and record event for checking and trigger a series of linkage actions (e.g., sending email) for notification.

Steps

- 1. Click Event & Alarm → System-Monitored Event → Add to enter the event adding page.
- **2.** Configure the event's basic information, including source type and event source.

Source Type

Select the source type as User-Defined Event.

Source

Select the configured user-defined event as the event source.

3. Optional: Set the Active Control switch to on, and then set the Threshold for Reactivation.

iNote

- Active Control is used to avoid the same event occurs frequently in a short time, which may
 aggravate the burden of HikCentral Professional event center. You need to set the Threshold
 for Reactivation. For example, you have set the Threshold for Reactivation as **30 s**, the same
 events from the same camera within 30 s will be regarded as one event on the HikCentral
 Professional.
- The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.
- 4. Optional: Set the Action switch to on to set the linkage actions for the event.

Arming Schedule Template

The user-defined event is armed during the arming schedule and the user-defined event triggered during the arming schedule will trigger the configured linkage actions.

iNote

For setting customized template, refer to Configure Arming Schedule Template .

Trigger Recording

Click **Add** to select the camera to record video when the event occurs. Select the storage location for storing the video files. You can play back the recorded video files when checking events in the Alarm & Event Search of the Control Client.

View Pre-Event Video: If the camera has recorded video files before the event, you can view the video recorded from periods preceding the event. Specify the number of seconds which you want to view the recorded video for before the event starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.

Post-record: Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.

Lock Video Files for: Set the days for protecting the video file from being overwritten.

Create Tag

Click **Add** to select the camera to record video when the event occurs and add tag to the event triggered video. Select the storage location for storing the video files. The tagged video can be searched and checked via the Control Client.

You can enter the tag name as desired. You can also click the button below to add the related information to the name.

Set the time range to define the tagged video length. For example, you can set to record the tagged video started from 5 seconds before the event and lasted until and 10 seconds after the event. The tagged video can be searched and checked via the Control Client.

Add the description to the tagged video as needed.

Capture Picture

Select one camera to capture pictures during the event, and you can view the captured pictures when checking event in the Alarm & Event Search of the Control Client.

i Note

Only one camera can be set for capturing pictures.

Capture Picture When: Specify the number of seconds at which the camera will capture before/after the event starts/ends. After you set the number of seconds for pre/post-event, the camera will capture one picture at three time points respectively: at the configured seconds before the event starts, at the configured seconds after the event ends, and at the middle of the event (as shown in the picture below).



Figure 12-17 Capture Pictures

iNote

The pre-event picture is captured from the camera's recorded video files. This pre-event capture function is only supported by the camera which is set to store the video files in the Recording Server (Cloud Storage Server, Hybrid SAN, or pStor).

Link Access Point

You can enable this function to trigger the access point(s) to be locked or unlocked when the event occurs. For example, you can set to trigger all the access points closed when the system detects suspicious person entering.

- All Access Points: When the event occurs, all the access points in the system will be unlocked, locked, remain unlocked, or remain locked.
- **Specified Access Point:** Click **Add** to select the access point(s) as the linkage target(s). You can set the access point action so that the access point will be unlocked, locked, remained unlocked, or remained locked when the event occurs.

iNote

Up to 16 access points can be selected as event linkage.

Link Alarm Output

Select the alarm output (if available) and the external device connected can be activated when the event occurs.

i Note

Up to 64 alarm outputs can be selected as event linkage.

Close Alarm Output: The added alarm output(s) can be closed manually, or you can set the number of seconds in which the alarm output(s) will be closed automatically.

Trigger PTZ

Call the preset, patrol or pattern of the selected camera(s) when the event occurs.

iNote

Up to 64 PTZ linkages can be selected as event linkage.

Send Email

Select an email template to send the event information according to the defined email settings. You can select **Add New** to create a new email template. For details, refer to **Set Email Template**.

Trigger User-Defined Event

Trigger user-defined event(s) when the system-monitored event is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as event linkage.
- For setting the user-defined event, refer to *Configure User-Defined Event* .

5. Finish adding the event.

- Click Add to add the event and back to the event list page.
- Click Add and Trigger Alarm to trigger this event as an alarm for further notification. For details, refer to *Configure Alarm*.

After adding the event, it displays on the event list, and you can view the event name, event source, and triggering event.

6. Optional: Perform the following operation(s) after adding the event.

Trigger EventClick : in the Operation column of system-monitored event settings pageas Alarmto set the alarm properties, recipients, actions, and other parameters.



For details, refer to Configure Alarm .

Test Event	Click in the Operation column of system-monitored event settings page to trigger the event manually, and you can check whether the linkage actions take effect.
Delete Event	Select the event(s) and click Delete to delete the selected event(s).
Manage Invalid Event	If \bigotimes appears near the event name, it means the event is not supported by the device and it is invalid. You should hover the cursor over the \bigotimes and click Delete on the tooltip to delete the event.
Delete All Invalid Events	Click Delete All Invalid Items to delete all the invalid events in a batch.
Filter Event	Click γ to expand the filter conditions. Set the conditions and click Filter to filter the events according to the conditions.

12.1.17 Add Event for Generic Event

You can add an event for the added generic events in the system. When the generic event is triggered, system can receive and record event for checking and trigger a series of linkage actions (e.g., sending email) for notification.

Steps

- 1. Click Event & Alarm → System-Monitored Event → Add to enter the event adding page.
- **2.** Configure the event's basic information, including source type, triggering event, and event source.

Source Type

Select the source type as Generic Event.

Source

Select the configured generic event as the event source.

3. Optional: Set the Active Control switch to on, and then set the Threshold for Reactivation.

iNote

- Active Control is used to avoid the same event occurs frequently in a short time, which may aggravate the burden of HikCentral Professional event center. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30 s**, the same events from the same camera within 30 s will be regarded as one event on the HikCentral Professional.
- The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.
- 4. Optional: Set the Action switch to on to set the linkage actions for the event. Arming Schedule Template

The event is armed during the arming schedule and the generic event triggered during the arming schedule will trigger the configured linkage actions.

i Note

For setting customized template, refer to Configure Arming Schedule Template .

Trigger Recording

Click **Add** to select the camera to record video when the event occurs. Select the storage location for storing the video files. You can play back the recorded video files when checking events in the Alarm & Event Search of the Control Client.

View Pre-Event Video: If the camera has recorded video files before the event, you can view the video recorded from periods preceding the event. Specify the number of seconds which you want to view the recorded video for before the event starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.

Post-record: Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.

Lock Video Files for: Set the days for protecting the video file from being overwritten.

Create Tag

Click **Add** to select the camera to record video when the event occurs and add tag to the event triggered video. Select the storage location for storing the video files. The tagged video can be searched and checked via the Control Client.

You can enter the tag name as desired. You can also click the button below to add the related information to the name.

Set the time range to define the tagged video length. For example, you can set to record the tagged video started from 5 seconds before the event and lasted until and 10 seconds after the event. The tagged video can be searched and checked via the Control Client.

Add the description to the tagged video as needed.

Capture Picture

Select one camera to capture pictures during the event, and you can view the captured pictures when checking event in the Alarm & Event Search of the Control Client.

iNote

Only one camera can be set for capturing pictures.

Capture Picture When: Specify the number of seconds at which the camera will capture before/after the event starts/ends. After you set the number of seconds for pre/post-event, the camera will capture one picture at three time points respectively: at the configured seconds before the event starts, at the configured seconds after the event ends, and at the middle of the event (as shown in the picture below).



Figure 12-18 Capture Pictures

iNote

The pre-event picture is captured from the camera's recorded video files. This pre-event capture function is only supported by the camera which is set to store the video files in the Recording Server (Cloud Storage Server, Hybrid SAN, or pStor).

Link Access Point

You can enable this function to trigger the access point(s) to be locked or unlocked when the event occurs. For example, you can set to trigger all the access points closed when the system detects suspicious person entering.

- All Access Points: When the event occurs, all the access points in the system will be unlocked, locked, remain unlocked, or remain locked.
- **Specified Access Point:** Click **Add** to select the access point(s) as the linkage target(s). You can set the access point action so that the access point will be unlocked, locked, remained unlocked, or remained locked when the event occurs.

iNote

Up to 16 access points can be selected as event linkage.

Link Alarm Output

Select the alarm output (if available) and the external device connected can be activated when the event occurs.

iNote

Up to 64 alarm outputs can be selected as event linkage.

Close Alarm Output: The added alarm output(s) can be closed manually, or you can set the number of seconds in which the alarm output(s) will be closed automatically.

Trigger PTZ

Call the preset, patrol or pattern of the selected camera(s) when the event occurs.

iNote

Up to 64 PTZ linkages can be selected as event linkage.

Send Email

Select an email template to send the event information according to the defined email settings. You can select **Add New** to create a new email template. For details, refer to **Set Email Template**.

Trigger User-Defined Event

Trigger user-defined event(s) when the system-monitored event is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click **Add New** below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as event linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .

5. Finish adding the event.

- Click Add to add the event and back to the event list page.
- Click Add and Trigger Alarm to trigger this event as an alarm for further notification. For details, refer to *Configure Alarm*.

After adding the event, it displays on the event list, and you can view the event name, event source, and triggering event.

6. Optional: Perform the following operation(s) after adding the event.

Trigger Event as Alarm	Click 😥 in the Operation column of system-monitored event settings page to set the alarm properties, recipients, actions, and other parameters.			
	i Note			
	For details, refer to Configure Alarm .			
Test Event	Click i in the Operation column of system-monitored event settings page to trigger the event manually, and you can check whether the linkage actions take effect.			
Delete Event	Select the event(s) and click Delete to delete the selected event(s).			
Manage Invalid Event	If \bigotimes appears near the event name, it means the event is not supported by the device and it is invalid. You should hover the cursor over the \bigotimes and click Delete on the tooltip to delete the event.			
Delete All Invalid Events	Click Delete All Invalid Items to delete all the invalid events in a batch.			
Filter Event	Click ∇ to expand the filter conditions. Set the conditions and click Filter to filter the events according to the conditions.			

12.1.18 Edit System-Monitored Event

After adding the system-monitored event, you can edit the event settings and trigger the event as alarm.

Before You Start

Add the system-monitored event. See Configure System-Monitored Event for details.

Perform this task when you need to edit the added system-monitored event or trigger it as alarm.

Steps

- 1. Click Event & Alarm on home page.
- 2. Click System-Monitored Event tab to enter the event list page.
- **3.** Click the event name to enter the event details page.
- 4. Optional: Perform the following operations to edit the event details.

Configure Event on Device (If Supported)	For some of the source types, click 🔅 to log in to the device and configure the event. See the user manual of the device for details.
Edit Event Name	Edit the event name as desired.
Edit Active Control	Set the Active Control switch to on, and then set the threshold for reactivation.
Edit Actions	Edit the event linkage action settings. For details, refer to Configure System-Monitored Event .

iNote

For the ANPR camera event or person event, you can view the vehicle list or person comparison group of the event in the Group column.

* Triggered by	Source	Area	Group	Triggering Event	Operation
	IPCamera 04	10.18	VIP Vehicle List	License Plate Mismatched	-
	<				>

Figure 12-19 Event Basic Information

- 5. Save the event settings.
 - Click **Save** to save the event settings and back to the event list page.
 - Click **Save and Trigger Alarm** to save the event as alarm and enter the alarm settings page for setting alarm. See *Configure Alarm* for details.

12.2 Configure Generic Event

You can customize the expression to create a generic event to analyze the received TCP and/or UDP data packages, and trigger events when specified conditions are met. In this way, you can easily integrate your system with a very wide range of external sources, such as access control systems and alarm systems.

Steps

1. Click Event & Alarm → Generic Event to enter the generic event settings page.

+ Add 📋 Delete			Event Name Q
Event Name	Transport Type	Match Type	Expression
Generic Event 1	ТСР	Search	"Motion" AND "Line Crossing"

Figure 12-20 Generic Event Settings Page

2. Click Add to enter the Add Generic Event page.

\bigcirc	Add Generic Eve	ent
		Generic event is the signal that resource (e.g., other software, device) sends when something occurs, and is received by system in TCP or UDP data packages.
	Basic Information	
	* Event Name	
	Copy from	•
	Event Definition	
	* Transport Type	€ TCP ○ UDP
	* Match Type	● Search ⁽ⁱ⁾
		○ Match [®]
	* Expression	Add
		AND
		OR
		Add Add and Continue Cancel 🔀

Figure 12-21 Add Generic Event Page

- 3. Set a name for the event in the Event Name field.
- 4. Optional: Copy the settings from other defined generic events in the Copy from field.
- 5. Select TCP or UDP to analyze the packages using TCP or UDP protocol.
- **6.** Select the matched type which indicating how particular your system should be when analyzing the received data packages:

Search

The received package must contain the text defined in the Expression field.

For example, if you have defined that the received packages should contain "Motion" and "Line Crossing", the alarm will be triggered when the received packages contain "Motion", "Intrusion" and "Line Crossing".

Match

The received package must exactly contain the text defined in the Expression field, and nothing else.

- 7. Define the event rule for analyzing the received package in the Expression field.
 - 1) Enter the term which should be contained in the expression in the text field.
 - 2) Click Add to add it to the expression.
 - 3) Click parenthesis or operator button to add it to the expression.

- 4) To add a term, parenthesis or operator to the expression, position the cursor inside the expression field in order to determine where a new item (term, parenthesis or the operator) should be included, and click Add or one of the parenthesis or operator buttons.
- 5) To remove an item from the expression, position the cursor inside the field in order to determine where an item should be removed, and click \times . The item immediately to the left of the cursor will be removed.

The parenthesis or operator buttons are described in the following:

AND

You specify that the terms on both sides of the AND operator must be included.

For example, if you define the rule as "Motion" AND "Line Crossing" AND "Intrusion", the term Motion, and Line Crossing as well as the term Intrusion must be all contained in the received package for the conditions to be met.

i Note

In generally, the more terms you combine with AND, the fewer events will be detected.

OR

You specify that any term should be contained.

For example, if you define the rule as "Motion" OR "Line Crossing" OR "Intrusion", any of the terms (Motion, Line Crossing, or Intrusion) must be contained in the received package for the conditions to be met.

iNote

In generally, the more terms you combine with OR, the more events will be detected.

(

Add the left parenthesis to the rule. Parentheses can be used to ensure that related terms are processed together as a unit; in other words, they can be used to force a certain processing order in the analysis.

For example, if you define the rule as ("Motion" OR "Line Crossing") AND "Intrusion", the two terms inside the parentheses will be processed first, then the result will be combined with the last part of the rule. In other words, the system will first search any packages containing either of the terms Motion or Line Crossing, then it search the results to look for the packages that contained the term Intrusion.

)

Add the right parenthesis to the rule.

8. Finish adding the event.

- Click Add to add the event and back to the event list page.
- Click Add and Continue to save the event settings and continue to add event.
- **9.** View in the Generic Event list to check whether the event has been added successfully.

10. Optional: Perform the following operations after adding the event.

Edit Event Settings	Click the name in the Event Name column to edit the corresponding event settings.
Enable Receiving Generic Event	If \bigotimes appears near the event name, it means the system has not enabled receiving generic event. You should hover the cursor over the \bigotimes and click Configuration on the tooltip to enable receiving generic event for the system. For details, refer to Enable Receiving Generic Event .
Delete Event Settings	Check the event(s) and click Delete to delete the selected event settings.
Delete All Event Settings	Check the checkbox in the heading row, and click Delete to delete all the event settings.

12.3 Configure User-Defined Event

If the event you need is not in the provided system-monitored event list, or the generic event cannot properly define the event received from third-party system, you can customize a user-defined event.

Steps

1. Click Event & Alarm → User-Defined Event to enter the user-defined event management page.

2. Click Add to open the following window.

Add User-define	d Event		
* User-Defined Event Name			
Description			
	Add	Add and Continue	Cancel

Figure 12-22 Add User-Defined Event

- **3.** Create a name for the event.
- 4. Optional: Enter the description information to describe the event details.
- 5. Finish adding the event.
 - Click Add to add the event and go back to the event list page.
 - Click Add and Continue to add the event and continue to add other events.

With the customized user-defined event, it provides the following functions:

- The user can trigger a user-defined event manually in Monitoring and Alarm Center module on the Control Client when viewing the video or checking the alarm information.
- A user-defined event can trigger an alarm if configured.
- You can define the arming time period by the user-defined event: An alarm's arming schedule will start or end when the user-defined event is triggered.
- An alarm can trigger a user-defined event as alarm actions.
- Integrate other third-party systems with HikCentral Professional by using the data received from the third-party system. You can trigger the user-defined events outside the HikCentral Professional. For details, contact our technical support.

iNote

- For configuring the alarm source, arming schedule, and alarm action, refer to **Configure Alarm**.
- For triggering the user-defined event on the Control Client, refer to User Manual of HikCentral Professional Control Client.

12.4 Configure Alarm

Alarm is used to notify security personnel of the particular situation which helps handle the situation promptly. Alarm can trigger a series of linkage actions (e.g., popping up window on the Control Client, showing the alarm details) for notification and alarm handling.

You can set the alarms for the resources on the current site.

If the system is a Central System with Remote Site Management module, you can also set the alarm for the camera on Remote Site which has configured with alarm, so that you can receive alarms in the Central System when the alarm is triggered.

You can set different linkage actions for the following alarms:

Camera Alarm:

The video exception or the events detected in the monitoring area of the cameras, such as motion detection, video loss, line crossing, etc.

Access Point Alarm

The alarm triggered at the access points (door, lane, etc.), such as access event, door status event, etc.

Alarm Input Alarm

The alarm triggered by the alarm inputs (including alarm inputs of encoding devices, access control devices, and security control devices).

ANPR Alarm

The alarm triggered when the license plates detected by the ANPR camera and UVSS matches or mismatches the vehicle information in vehicle list.

Person Alarm

The alarm triggered when the person's face detected by the face recognition device matches or mismatches the face picture in the face comparison group.

UVSS Alarm

The alarm trigger by the UVSS device, including device getting online and offline.

Remote Site Alarm

The alarm triggered by the added Remote Site, including site getting offline.

iNote

Remote Site alarm is available for the system with Remote Site Management module (based on the license you purchased).

Device Exception

The alarm triggered by encoding device's, access control device's, security control device's or dock station's exceptions.

Server Exception

The alarm triggered by Recording Server, Streaming Server, or HikCentral Professional Server.

User Alarm

The alarm triggered by system users, including user login and logout.

User-Defined Event

The alarm triggered by the configured user-defined event.

Generic Event

The alarm triggered by the configured generic event.

iNote

You can check the received alarm message via the Control Client. For details, see User Manual of HikCentral Professional Control Client.

12.4.1 Alarm Settings

The system predefines several alarm priorities and alarm categories for basic needs. You can edit the predefined alarm priority and alarm category, and set customized alarm priority and alarm category according to actual needs.

Perform this task when you need to configure the alarm priority and alarm category.

Alarm Priority

Define the priority for the alarm when add the alarm and filter alarms in the Control Client.

Alarm Category

Alarm category is used when the user acknowledges the alarm in the Control Client and categories what kind of alarm it is, e,g., false alarm, or alarm to be verified. You can search the alarms by the alarm type in the Alarm Center of Control Client.

Steps

- 1. Click Event & Alarm → Alarm → Alarm Settings to enter the alarm settings page.
- 2. Set the alarm priority according to actual needs. By default, three kinds of alarm priority exist.

Alarm Priority	③ You can set up to 255 levels.		
	+ Add		
	Level	Name	Operation
	1	High	Ľ
	2	Medium	Ľ
	3	Low	Ľ

Figure 12-23 Alarm Priority Page

1) Click **Add** to add a customized priority.

iNote

Up to 255 levels of alarm priority can be added. The priority levels can be used for sorting alarms in Alarm Center of Control Client.

- 2) Select a level No. for the priority.
- 3) Enter a descriptive name for the priority.
- 4) Select the color for the priority.

*Level	8 •	
*Name		
*Color	#ff0000	
	Save	
	Save	

Figure 12-24 Alarm Priority Settings Window

5) Click Save to add the priority.

The priority will be displayed on the alarm priority list.

3. Set the alarm category according to actual needs. By default, four alarm categories exist.

Alarm Category	 1.Use when you ackn 2.Up to 25 categories 	owledge the alarm in Control Client to indicate what kind of configurable.	alarm it is, e,g., false alarm, or alarm t
	+ Add		
	No.	Name	Operation
	1	True	Ľ
	2	False	Ľ
	3	To Be Acknowledged	Ľ
	4	To Be Verified	Ľ

Figure 12-25 Alarm Category Page

1) Click Add to add the customized alarm category.

iNote

- Up to 25 alarm categories can be added.
- 2) Select a No. for the alarm category.
- 3) Enter a descriptive name for the alarm category.

No.	5	~
*Name		
		Save

Figure 12-26 Alarm Category Settings Window

4) Click Save to add the alarm category.

The alarm category will be displayed on the alarm category list.

4. Perform the following operation(s) after adding alarm priority and category.

Edit Click \square to edit the alarm priority and category.

	i Note		
	You cannot edit the No. of predefined alarm priorities and categories.		
Delete	Click $ imes$ to delete the alarm priority and category.		
	i Note		
	You cannot delete the predefined alarm priorities and categories.		

12.4.2 Add Alarm for Camera on Current Site

You can set alarms for added cameras on current site and configure a series of linkage actions (e.g., triggering pop-up window on the Control Client) for notification when alarm is triggered.

Steps

1. Click Event & Alarm → Alarm → Add to enter the Add Alarm page.

	by Source Type	Triggering Event	Source	
	Camera	▲ Search	ItikCentral_XXX	
	Access Point	Abnormal Face	Camera/Area	
	Alarm Input	Audio Exception Detection	> 🗌 💼 10.12.97.30	
	ANPR	Blacklist Alarm	> ☐ ₫ 10.18.64.228 > ☐ ₫ 20.18.65.17	
	Person	Camera Communication Exception		
	uvss	Camera Communication Recover	red > 101865149	
	Remote Site	Camera Offline	> 10.18.65.170	
		Camera Online	>] 20.18.65.222	
	Encoding Device	Camera Recording Exception	> _ ff 10.18.65.223 > _ ff 20.18.65.224	
	Access Control Device	Camera Recording Recovered)] @10.18.65.225	
	Security Control Device	Channel Armed	→ □ @101865226 → □ @10186718	
Descripti	S r r	g the alarm or enter remarks for the alarm.	7	
weschpu	DD District and account on interests	g det annere anne remera de une marre.		

Figure 12-27 Add Alarm for Camera on Current Site

- 2. Set the source type as Camera in the Source Type field.
- **3.** Select a triggering event as the source for triggering the alarm.
- **4.** In the site drop-down list, select the current site.
- 5. Select a specific camera for triggering the alarm.
- 6. Optional: Enter the instructions for handling the alarm or enter remarks for the alarm.
- 7. Set the required information.

Arming Schedule

The camera is armed during the arming schedule and the event occurred during the arming schedule will be triggered as alarm and notify the user. It provides two types of arming schedule:

- Schedule Template: Select an arming schedule template for the alarm to define when the alarm can be triggered. For setting customized template, refer to *Configure Arming Schedule Template*.
- Event Based: Specify a user-defined event or an alarm input as the start or end event of the arming schedule. When the user defined event or alarm input is triggered, the arming schedule will start or end. You can set the Auto-End Arming switch to on and set the specified time to automatically end arming for this alarm even if the end event does not occur.

iNote

For example, you have set event A as start event, event B as end event, and set the **Auto-End Arming in** as *60 s*, when event A occurs at T1, the alarm will be armed from T1 until event B occurs within 60 s (See the following figure Arming Schedule 1), or end arming 60 s later and event B doesn't occur (See the following figure Arming Schedule 2).





Figure 12-29 Arming Schedule 2

When A occurs at time T1, the alarm will be armed from T1, if A occurs again at time T2 but B doesn't occur, the alarm will be armed from T2 again.



Figure 12-30 Arming Schedule 3

Alarm Priority

Define the priority for the alarm. Priority can be used for filtering alarms in the Control Client. You can click **Add New** to set alarm priority. For setting alarm priority, refer to **Alarm Settings**.

Active Control

Active Control is used to avoid the same alarm being received frequently in a short time. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30** *s*, the same alarms from the same camera within 30 s will be regarded as one alarm on the system.

The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.

Alarm Recipient

Select the user to send the alarm information to and the user can receive the alarm information when he/she logs in to HikCentral Professional via the Control Client or Mobile Client.

8. Optional: Set the alarm's additional settings such as alarm related cameras and map, and alarm linkage actions.

Related Camera

Select the related camera to record the alarm video when the alarm is triggered. You can view the live video and play back these video files in the Alarm Center of the Control Client.

- To relate the source camera itself for recording, select **Source Camera** and select the storage location for storing the video files.
- To relate other cameras, select **Specified Camera** and click **Add** to add other cameras as related cameras. Select the storage location for storing the video files.
- View Pre-Alarm Video: You can view the video recorded from periods preceding the alarm. Specify the number of seconds which you want to view the recorded video for before the alarm starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.
- **Post-record:** Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.
- Lock Video Files for: Set the days for protecting the video file from being overwritten.
- **Display Video by Default:** Set the video to be displayed by default on the Control Client when receiving the triggered alarm information. You can select the recorded video or the live video to be displayed.

iNote

- Make sure the related camera(s) have been configured with recording schedule.
- Up to 16 cameras can be set as related camera.

Related Map

Select a map to show the alarm information and you should add the camera to the map as a hot spot (refer to **Add Hot Spot**). You can check the map in the Alarm Center and Alarm & Event Search of the Control Client.

Trigger Pop-up Window

Display the alarm window on the Control Client to show the alarm details and all the alarm related cameras' live videos and playback when alarm occurs.

Display on Smart Wall

Display the alarm video of the alarm's related camera or display the specified public view on the smart wall. You can select the added smart wall and select which window to display the alarm.

- Alarm's Related Cameras: Display the video of the alarm's related cameras on the smart wall. You can select to display the video on which smart wall and which window and set the alarm video's stream type.
- **Public View:** A view enables you to save the window division and the correspondence between cameras and windows as favorites to quickly access the related cameras later. If you select **Public View**, when the alarm is triggered, the system can display the selected

public view on the specified smart wall and users can view the video of the cameras predefined in the view.

- Wall Related to Graphic Card: Display the alarm video on the wall which adopts graphic card of the PC that running the Control Client to decode video.
- Wall Related to Decoding Device: Display the alarm video on the wall which adopts decoding device (namely the wall that related to the decoding device) to decode the video.
- Smart Wall No.: Select the No. of smart wall window to display the alarm video.
- Stream Type: Select the stream type of the alarm video displaying on the smart wall.
- **Stop Displaying Alarm:** Define when the system will stop displaying the alarm on the smart wall. The system can stop displaying alarm within specified seconds, or replace the original alarm when other alarm with higher alarm priority is triggered.

Restrict Alarm Handling Time

When the alarm is triggered, you need to handle the alarm on the Control Client. Enable this function to trigger user-defined event(s) or alarm output(s) if the alarm is not handled within the configured alarm handling time.

i Note

- Up to 16 user-defined events and alarm outputs can be set as the triggered event when handling alarm timed out.
- For configuring the user-defined event, refer to Configure User-Defined Event .

Trigger Audible Warning

Set the voice text for playing on the PC when alarm is triggered.

iNote

You should set voice engine as the alarm sound on System Settings page of Control Client.

Trigger User-Defined Event

Trigger the user-defined event(s) when alarm is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click **Add New** below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as alarm linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .

9. Finish adding the alarm.

- Click Add to add the alarm and back to the alarm list page.
- Click Add and Continue to add the alarm and continue to add other alarm.

The alarm will be displayed on the alarm list and you can view the alarm name and alarm status.

10. Optional: Perform the following operation(s) after adding the alarm.

Edit Alarm	Click 🕜 in the Operation column to edit the alarm.
Copy to Other Alarms	You can copy the current alarm's specified parameters to other added alarms for batch configuration.
	Click 🗹 in the Operation column to enter the alarm details page and click Copy to .
	Specify the settings of the source alarm, select target alarm(s), and click OK .
Delete Alarm	Click $ imes$ in the Operation column to delete the alarm.
Delete All Alarms	Click Delete All to delete all the added alarm.
Delete All Invalid Alarms	Click Delete All Invalid Items to delete all the invalid alarms in a batch.
Enable Alarm	Click \odot in the Operation column to enable the alarm.
Enable All Alarms	Click Enable All to enable all the added alarms.
Disable Alarm	Click \ominus in the Operation column to disable the alarm.
Disable All Alarms	Click Disable All to disable all the added alarms.
Test Alarm	Click ② to trigger this alarm automatically. You can test if the linkage actions work properly.

12.4.3 Add Alarm for Camera on Remote Site

If the system is a Central System with Remote Site Management module (based on the license you purchased), you can also add the alarms configured for the cameras on the Remote Site to the Central System, and configure a series of linkage actions for notification in Central System when alarm is triggered.

Before You Start

You should configure the alarm for the camera on the Remote Site via the Remote Site's Web Client.

Steps

- 1. Click Event & Alarm → Alarm → Add to enter the Add Alarm page.
- 2. Set the source type as Camera in the Source Type field.
- **3.** Select the alarm source.
 - 1) In the Triggering Event list, select the source event type.
 - 2) In the **Source** list, select a Remote Site from the drop-down list.

The alarms configured on the Remote Site of the selected triggering event type will be displayed.

3) Select the alarm configured on the Remote Site as the source to trigger an alarm in Central System.

iNote

Please make sure the alarm configured on the Remote Site is enabled. The alarm will be effective after enabled on Remote Site and in Central System.

- **4. Optional:** Enter the instructions for handling the alarm or enter remarks for the alarm.
- 5. Set the required information.

Alarm Priority

Define the priority for the alarm. Priority can be used for filtering alarms in the Control Client. For setting alarm priority, refer to *Alarm Settings*.

Active Control

Active Control is used to avoid the same alarm being received frequently in a short time. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30** *s*, the same alarms from the same camera within 30 s will be regarded as one alarm on the system.

The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.

Alarm Recipient

Select a user to send the alarm information to and the user can receive the alarm information when he/she logs in to HikCentral Professional via Control Client or Mobile Client.

6. Optional: Set the alarm's additional settings such as alarm linkage actions.

Related Camera

If the selected alarm is configured with related camera on Remote Site, you can view its video files when checking the alarm in Central System.

Related Map

If the selected alarm is configured with related map on Remote Site, you can view the alarm source location when checking the alarm in Central System.

Trigger Pop-up Window

Display the alarm window on Control Client to show the alarm details and all the alarm related cameras' live videos and playback when alarm occurs.

Display on Smart Wall

Display the alarm video of the alarm's related camera or display the specified public view on the smart wall. You can select the added smart wall and select which window to display the alarm.

- Alarm's Related Cameras: Display the video of the alarm's related cameras on the smart wall. You can select to display the video on which smart wall and which window and set the alarm video's stream type.
- **Public View:** A view enables you to save the window division and the correspondence between cameras and windows as favorites to quickly access the related cameras later. If you select **Public View**, when the alarm is triggered, the system can display the selected public view on the specified smart wall and users can view the video of the cameras predefined in the view.
- Wall Related to Graphic Card: Display the alarm video on the wall which adopts graphic card of the PC that running the Control Client to decode video.
- Wall Related to Decoding Device: Display the alarm video on the wall which adopts decoding device (namely the wall that related to the decoding device) to decode the video.
- Smart Wall No.: Select the No. of smart wall window to display the alarm video.
- Stream Type: Select the stream type of the alarm video displaying on the smart wall.
- **Stop Displaying Alarm:** Define when the system will stop displaying the alarm on the smart wall. The system can stop displaying alarm within specified seconds, or replace the original alarm when other alarm with higher alarm priority is triggered.

Restrict Alarm Handling Time

When the alarm is triggered, you need to handle the alarm on the Control Client. Enable this function to trigger user-defined event(s) or alarm output(s) if the alarm is not handled within the configured alarm handling time.

iNote

- Up to 16 user-defined events and alarm outputs can be set as the triggered event when handling alarm timed out.
- For configuring the user-defined event, refer to Configure User-Defined Event .

Trigger Audible Warning

Set the voice text for playing on the PC when alarm is triggered.

i Note

You should set voice engine as the alarm sound on System Settings page of Control Client.

Trigger User-Defined Event

Trigger the user-defined event(s) when alarm is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as alarm linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .

- **7.** Finish adding the alarm.
 - Click Add to add the alarm and go back to the alarm list page.
 - Click Add and Continue to add the alarm and continue to add other alarms.

The alarm will be displayed on the alarm list. You can view the alarm name and alarm status.

8. Optional: Perform the following operation(s) after adding the alarm.

Edit Alarm	Click 🖂 in the Operation column to edit the alarm.
Copy to Other Alarms	You can copy the current alarm's specified parameters to other added alarms for batch configuration.
	Click 🗹 in the Operation column to enter the alarm details page and click Copy to .
	Specify the settings of the source alarm, select target alarm(s), and click OK .
Delete Alarm	Click $ imes$ in the Operation column to delete the alarm.
Delete All Alarms	Click Delete All to delete all the added alarms.
Delete All Invalid Alarms	Click Delete All Invalid Items to delete all the invalid alarms in a batch.
Enable Alarm	Click \odot in the Operation column to enable the alarm.
Enable All Alarms	Click Enable All to enable all the added alarms.
Disable Alarm	Click \ominus in the Operation column to disable the alarm.
	chek of in the operation column to disable the diam.
Disable All Alarms	Click Disable All to disable all the added alarms.

12.4.4 Add Alarm for Access Point

You can set alarms for the access points of the added access control devices and configure a series of linkage actions (e.g., triggering pop-up window on the Control Client) for notification when alarm is triggered.

Steps

- 1. Click Event & Alarm → Alarm → Add to enter the Add Alarm page.
- 2. Set the source type as Access Point in the Source Type field.
- **3.** Select a triggering event and a specific access point as the source for triggering the alarm.
- 4. Optional: Enter the instructions for handling the alarm or enter remarks for the alarm.
- 5. Set the required information.

Arming Schedule

The access point is armed during the arming schedule and when an event occurs during the arming schedule, an alarm will be triggered to notify the user. Two types of arming schedules are provided:

- Schedule Template: Select an arming schedule template for the alarm to define when the alarm can be triggered. For setting customized template, refer to *Configure Arming Schedule Template*.
- Event Based: Specify a user-defined event or an alarm input as the start or end event of the arming schedule. When the user defined event or alarm input is triggered, the arming schedule will start or end. You can set the Auto-End Arming switch to on and set the specified time to automatically end arming for this alarm even if the end event does not occur.

iNote

For example, you have set event A as start event, event B as end event, and set the **Auto-End Arming in** as *60 s*, when event A occurs at T1, the alarm will be armed from T1 until event B occurs within 60 s (See the following figure Arming Schedule 1), or end arming 60 s later and event B doesn't occur (See the following figure Arming Schedule 2).



Figure 12-32 Arming Schedule 2

When A occurs at time T1, the alarm will be armed from T1, if A occurs again at time T2 but B doesn't occur, the alarm will be armed from T2 again.



Figure 12-33 Arming Schedule 3

Alarm Priority

Define the priority for the alarm. Priority can be used for filtering alarms in the Control Client. For setting alarm priority, refer to *Alarm Settings*.

Active Control

Active Control is used to avoid the same alarm being received frequently in a short time. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30** *s*, the same alarms from the same camera within 30 s will be regarded as one alarm on the system.

The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.

Alarm Recipients

Select the user to send the alarm information to and the user can receive the alarm information when he/she logs in to HikCentral Professional via the Control Client or Mobile Client.

Related Camera

Select the related camera to record the alarm video when the alarm is triggered. You can view the live video and play back the recorded video files when alarm occurs in the Alarm Center of the Control Client.

- To relate the access point's related camera for recording, select **Source Related Camera** and select the storage location for storing the video files.
- To relate other cameras, select **Specified Camera** and Click **Add** to add other cameras as related cameras. Select the storage location for storing the video files.
- View Pre-Alarm Video: If the camera has recorded video files before the alarm, you can view the video recorded from periods preceding the alarm. Specify the number of seconds which you want to view the recorded video for before the alarm starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.
- **Post-record:** Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.
- Lock Video Files for: Set the days for protecting the video file from being overwritten.
- **Display Video by Default:** Set the video to be displayed by default on the Control Client when receiving the triggered alarm information, you can select the recorded video or the live video to be displayed.

iNote

- For setting the access point's related camera in the Logical View, refer to *Edit Access Point for Current Site*.
- Make sure the related camera(s) have been configured with recording schedule.
- Up to 16 cameras can be set as related camera.

Related Map

Select the map to show the alarm information and you should add the access point to the map as a hot spot (refer to *Add Hot Spot*). You can check the map in the Alarm Center and Alarm & Event Search of the Control Client.

Trigger Pop-up Window

Display the alarm window on the Control Client to show the alarm details and all the alarm related cameras' live videos and playback when alarm occurs.

Display on Smart Wall

Display the alarm video of the alarm's related camera or display the specified public view on the smart wall. You can select the added smart wall and select which window to display the alarm.

- Alarm's Related Cameras: Display the video of the alarm's related cameras on the smart wall. You can select to display the video on which smart wall and which window and set the alarm video's stream type.
- **Public View:** A view enables you to save the window division and the correspondence between cameras and windows as favorites to quickly access the related cameras later. If you select **Public View**, when the alarm is triggered, the system can display the selected public view on the specified smart wall and users can view the video of the cameras predefined in the view.
- Wall Related to Graphic Card: Display the alarm video on the wall which adopts graphic card of the PC that running the Control Client to decode video.
- Wall Related to Decoding Device: Display the alarm video on the wall which adopts decoding device (namely the wall that related to the decoding device) to decode the video.
- Smart Wall No.: Select the No. of smart wall window to display the alarm video.
- Stream Type: Select the stream type of the alarm video displaying on the smart wall.
- **Stop Displaying Alarm:** Define when the system will stop displaying the alarm on the smart wall. The system can stop displaying alarm within specified seconds, or replace the original alarm when other alarm with higher alarm priority is triggered.

Restrict Alarm Handling Time

When the alarm is triggered, you need to handle the alarm on the Control Client. Enable this function to trigger user-defined event(s) or alarm output(s) if the alarm is not handled within the configured alarm handling time.

iNote

- Up to 16 user-defined events and alarm outputs can be set as the triggered event when handling alarm timed out.
- For configuring the user-defined event, refer to Configure User-Defined Event .

Trigger Audible Warning

Set the voice text for playing on the PC when alarm is triggered.

iNote

You should set voice engine as the alarm sound on System Settings page of Control Client.

Trigger User-Defined Event

Trigger the user-defined event(s) when alarm is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as alarm linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .
- **6.** Finish adding the alarm.
 - Click **Add** to add the alarm and go back to the alarm list page.
 - Click Add and Continue to add the alarm and continue to add other alarm.

After adding the alarm, it displays on the alarm list, and you can view the alarm name and alarm status.

7. Optional: Perform the following operation(s) after adding the alarm.

Edit Alarm	Click 🗹 in the Operation column to edit the alarm.
Copy to Other Alarms	You can copy the current alarm's specified parameters to other added alarms for batch configuration.
	Click 🗹 in the Operation column to enter the alarm details page and click Copy to .
	Specify the settings of the source alarm, select target alarm(s), and click OK .
Delete Alarm	Click $ imes$ in the Operation column to delete the alarm.
Delete All Alarms	Click Delete All to delete all the added alarm.
Delete All Invalid Alarms	Click Delete All Invalid Items to delete all the invalid alarms in a batch.
Enable Alarm	Click \odot in the Operation column to enable the alarm.
Enable All Alarms	Click Enable All to enable all the added alarms.
Disable Alarm	Click \ominus in the Operation column to disable the alarm.
Disable All Alarms	Click Disable All to disable all the added alarms.
Test Alarm	Click @ to trigger this alarm automatically. You can test if the linkage actions work properly.

12.4.5 Add Alarm for Alarm Input

You can set alarm input alarm for alarm inputs of the added device and configure a series of linkage actions (e.g., triggering pop-up window on the Control Client) for notification when alarm is triggered.

Steps

- 1. Click Event & Alarm → Alarm → Add to enter the adding alarm page.
- 2. Set the source type as Alarm Input in the Source Type field.
- **3.** Select a specific alarm input as the source for triggering the alarm.
- 4. Optional: Enter the instructions for handling the alarm or enter remarks for the alarm.
- **5.** Set the required information.

Arming Schedule

The alarm input is armed during the arming schedule and when an event occurs during the arming schedule, an alarm will be triggered to notify the user. Two types of arming schedule are provided:

- Schedule Template: Select an arming schedule template for the alarm to define when the alarm can be triggered. For setting customized template, refer to *Configure Arming Schedule Template*.
- Event Based: Specify a user-defined event or an alarm input as the start or end event of the arming schedule. When the user defined event or alarm input is triggered, the arming schedule will start or end. You can set the Auto-End Arming switch to on and set the specified time to automatically end arming for this alarm even if the end event does not occur.

iNote

For example, you have set event A as start event, event B as end event, and set the **Auto-End Arming in** as *60 s*, when event A occurs at T1, the alarm will be armed from T1 until event B occurs within 60 s (See the following figure Arming Schedule 1), or end arming 60 s later and event B doesn't occur (See the following figure Arming Schedule 2).





Figure 12-35 Arming Schedule 2

When A occurs at time T1, the alarm will be armed from T1, if A occurs again at time T2 but B doesn't occur, the alarm will be armed from T2 again.



Figure 12-36 Arming Schedule 3

Alarm Priority

Define the priority for the alarm. Priority can be used for filtering alarms in the Control Client. For setting alarm priority, refer to *Alarm Settings*.

Active Control

Active Control is used to avoid the same alarm being received frequently in a short time. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30** *s*, the same alarms from the same camera within 30 s will be regarded as one alarm on the system.

The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.

Alarm Recipient

Select the user to send the alarm information to and the user can receive the alarm information when he/she logs in to HikCentral Professional via the Control Client or Mobile Client.

6. Optional: Set the alarm's additional settings such as alarm related cameras and map, and alarm linkage actions

Related Camera

You can view the live video and play back the recorded video files when alarm occurs in the Alarm Center of the Control Client.

- Select the camera(s) to record the alarm video when the alarm is triggered.
- **Post-record:** Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.
- View Pre-Alarm Video: If the camera has recorded video files before the alarm, you can view the video recorded from periods preceding the alarm. Specify the number of seconds which you want to view the recorded video for before the alarm starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.
- Lock Video Files for: Set the days for protecting the video file from being overwritten.
- **Display Video by Default:** Set the video to be displayed by default on the Control Client when receiving the triggered alarm information, you can select the recorded video or the live video to be displayed.
- Make sure the related camera(s) have been configured with recording schedule.
- Up to 16 cameras can be set as related camera.

Related Map

Select the map to show the alarm information and you should add the alarm input to the map as a hot spot (refer to *Add Hot Spot*). You can check the map in the Alarm Center and Alarm & Event Search of Control Client.

Trigger Pop-up Window

Display the alarm window on Control Client to show the alarm details and all the alarm related cameras' live videos and recorded video files when alarm occurs.

Display on Smart Wall

Display the alarm video of the alarm's related camera or display the specified public view on the smart wall. You can select the added smart wall and select which window to display the alarm.

- Alarm's Related Cameras: Display the video of the alarm's related cameras on the smart wall. You can select to display the video on which smart wall and which window and set the alarm video's stream type.
- **Public View:** A view enables you to save the window division and the correspondence between cameras and windows as favorites to quickly access the related cameras later. If you select **Public View**, when the alarm is triggered, the system can display the selected public view on the specified smart wall and users can view the video of the cameras predefined in the view.
- Wall Related to Graphic Card: Display the alarm video on the wall which adopts graphic card of the PC that running the Control Client to decode video.
- Wall Related to Decoding Device: Display the alarm video on the wall which adopts decoding device (namely the wall that related to the decoding device) to decode the video.
- Smart Wall No.: Select the No. of smart wall window to display the alarm video.
- Stream Type: Select the stream type of the alarm video displaying on the smart wall.
- **Stop Displaying Alarm:** Define when the system will stop displaying the alarm on the smart wall. The system can stop displaying alarm within specified seconds, or replace the original alarm when other alarm with higher alarm priority is triggered.

Restrict Alarm Handling Time

When the alarm is triggered, you need to handle the alarm on the Control Client. Enable this function to trigger user-defined event(s) or alarm output(s) if the alarm is not handled within the configured alarm handling time.

- Up to 16 user-defined events and alarm outputs can be set as the triggered event when handling alarm timed out.
- For configuring the user-defined event, refer to *Configure User-Defined Event* .

Trigger Audible Warning

Set the voice text for playing on the PC when alarm is triggered.

∎Note

You should set voice engine as the alarm sound on System Settings page of Control Client.

Trigger User-Defined Event

Trigger the user-defined event(s) when alarm is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as alarm linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .

7. Finish adding the alarm.

- Click Add to add the alarm and back to the alarm list page.
- Click Add and Continue to add the alarm and continue to add other alarm.

After adding the alarm, it displays on the alarm list, and you can view the alarm name and alarm status.

8. Optional: Perform the following operation(s) after adding the alarm:

Edit Alarm	Click 🕜 in the Operation column to edit the alarm.
Delete Alarm	Click $ imes$ in the Operation column to delete the alarm.
Copy to Other Alarms	You can copy the current alarm's specified parameters to other added alarms for batch configuration.
	Click 🗹 in the Operation column to enter the alarm details page and click Copy to .
	Specify the settings of the source alarm, select target alarm(s), and click OK .
Delete All Alarms	Click Delete All to delete all the added alarms.
Delete All Invalid Alarms	Click Delete All Invalid Items to delete all the invalid alarms in a batch.
Enable Alarm	Click \oslash in the Operation column to enable the alarm.
Enable All Alarms	Click Enable All to enable all the added alarms.

Disable Alarm	Click \ominus in the Operation column to disable the alarm.
Disable All Alarms	Click Disable All to disable all the added alarms.
Test Alarm	Click (2) to trigger this alarm automatically. You can test if the linkage actions work properly as you want.

12.4.6 Add Alarm for ANPR Camera

You can set plate number matched and mismatched alarm for the added ANPR camera (including professional ANPR traffic cameras and camera in UVSS (under vehicle surveillance system)) and configure a series of linkage actions (e.g., triggering pop-up window on the Control Client) for notification when alarm is triggered.

Steps

- 1. Click Event & Alarm → Alarm → Add to enter the Add Alarm page.
- 2. Set the source type as ANPR in the Source Type field.
- **3.** Select a defined vehicle list as the source for matching or mismatching the license plate recognized by and then select a specific ANPR camera or UVSS camera as the source for triggering the alarm.

iNote

Before setting ANPR alarm, vehicles information should be added for matching the license plate recognized by ANPR device. For adding vehicle list and vehicle information, refer to *Manage Vehicle*.

- 4. Optional: Enter instructions for handling the alarm or enter remarks for the alarm.
- 5. Set the required information.

Arming Schedule

The device is armed during the arming schedule and when an event occurs during the arming schedule, an alarm will be triggered to notify the user. Two types of arming schedule are provided:

- Schedule Template: Select an arming schedule template for the alarm to define when the alarm can be triggered. For setting customized template, refer to *Configure Arming Schedule Template*.
- Event Based: Specify a user-defined event or an alarm input as the start or end event of the arming schedule. When the user defined event or alarm input is triggered, the arming schedule will start or end. You can set the Auto-End Arming switch to on and set the specified time to automatically end arming for this alarm even if the end event does not occur.

For example, you have set event A as start event, event B as end event, and set the **Auto-End Arming in** as *60 s*, when event A occurs at T1, the alarm will be armed from T1 until event B occurs within 60 s (See the following figure Arming Schedule 1), or end arming 60 s later and event B doesn't occur (See the following figure Arming Schedule 2).





Figure 12-38 Arming Schedule 2

When A occurs at time T1, the alarm will be armed from T1, if A occurs again at time T2 but B doesn't occur, the alarm will be armed from T2 again.



Figure 12-39 Arming Schedule 3

Alarm Priority

Define the priority for the alarm. Priority can be used for filtering alarms in the Control Client. For setting alarm priority, refer to *Alarm Settings*.

Active Control

Active Control is used to avoid the same alarm being received frequently in a short time. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30** *s*, the same alarms from the same camera within 30 s will be regarded as one alarm on the system.

The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.

Alarm Recipient

Select the user to send the alarm information to and the user can receive the alarm information when he/she logs in to HikCentral Professional via the Control Client or Mobile Client.

6. Optional: Set the alarm's additional settings such as alarm related cameras and map, and alarm linkage actions

Related Camera

Select the related camera to record the alarm video when the alarm is triggered. You can view the live video and play back the recorded video files when alarm occurs in the Alarm Center of the Control Client.

- To relate the source ANPR camera itself, or the UVSS's related camera for recording, select **Source or Source Related Camera** and select the storage location for storing the video files.
- To relate other cameras, select **Specified Camera** and Click **Add** to add other cameras as related cameras. Select the storage location for storing the video files.
- View Pre-Alarm Video: If the camera has recorded video files before the alarm, you can view the video recorded from periods preceding the alarm. Specify the number of seconds which you want to view the recorded video for before the alarm starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.
- **Post-record:** Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.
- Lock Video Files for: Set the days for protecting the video file from being overwritten.
- **Display Video by Default:** Set the video to be displayed by default on the Control Client when receiving the triggered alarm information, you can select the recorded video or the live video to be displayed.

iNote

- Make sure the related camera(s) have been configured with recording schedule.
- Up to 16 cameras can be set as related camera.

Related Map

Select the map to show the alarm information and you should add the camera or UVSS to the map as a hot spot (refer to **Add Hot Spot**). You can check the map in the Alarm Center and Alarm & Event Search of Control Client.

Trigger Pop-up Window

Display the alarm window on Control Client to show the alarm details and all the alarm related cameras' live videos and playback when alarm occurs.

Display on Smart Wall

Display the alarm video of the alarm's related camera or display the specified public view on the smart wall. You can select the added smart wall and select which window to display the alarm.

- Alarm's Related Cameras: Display the video of the alarm's related cameras on the smart wall. You can select to display the video on which smart wall and which window and set the alarm video's stream type.
- **Public View:** A view enables you to save the window division and the correspondence between cameras and windows as favorites to quickly access the related cameras later. If

you select **Public View**, when the alarm is triggered, the system can display the selected public view on the specified smart wall and users can view the video of the cameras predefined in the view.

- Wall Related to Graphic Card: Display the alarm video on the wall which adopts graphic card of the PC that running the Control Client to decode video.
- Wall Related to Decoding Device: Display the alarm video on the wall which adopts decoding device (namely the wall that related to the decoding device) to decode the video.
- Smart Wall No.: Select the No. of smart wall window to display the alarm video.
- Stream Type: Select the stream type of the alarm video displaying on the smart wall.
- **Stop Displaying Alarm:** Define when the system will stop displaying the alarm on the smart wall. The system can stop displaying alarm within specified seconds, or replace the original alarm when other alarm with higher alarm priority is triggered.

Restrict Alarm Handling Time

When the alarm is triggered, you need to handle the alarm on the Control Client. Enable this function to trigger user-defined event(s) or alarm output(s) if the alarm is not handled within the configured alarm handling time.

iNote

- Up to 16 user-defined events and alarm outputs can be set as the triggered event when handling alarm timed out.
- For configuring the user-defined event, refer to Configure User-Defined Event .

Trigger Audible Warning

Set the voice text for playing on the PC when alarm is triggered.

iNote

You should set voice engine as the alarm sound on System Settings page of Control Client.

Trigger User-Defined Event

Trigger the user-defined event(s) when alarm is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click **Add New** below to set new user-defined event(s).

i Note

- Up to 16 user-defined events can be selected as alarm linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .

7. Finish adding the alarm.

- Click **Add** to add the alarm and go back to the alarm list page.
- Click Add and Continue to add the alarm and continue to add other alarm.

After adding the alarm, it displays on the alarm list, and you can view the alarm name and alarm status.

8. Optional: Perform the following operation(s) after adding the alarm.

Edit Alarm	Click 🗹 in the Operation column to edit the alarm information.
Copy to Other Alarms	You can copy the current alarm's specified parameters to other added alarms for batch configuration.
	Click 🗹 in the Operation column to enter the alarm details page and click Copy to .
	Specify the settings of the source alarm, select target alarm(s), and click OK .
Delete Alarm	Click $ imes$ in the Operation column to delete the alarm.
Delete All Alarms	Click Delete All to delete all the added alarms.
Delete All Invalid Alarms	Click Delete All Invalid Items to delete all the invalid alarms in a batch.
Enable Alarm	Click \odot in the Operation column to enable the alarm.
Enable All Alarms	Click Enable All to enable all the added alarms.
Disable Alarm	Click \ominus in the Operation column to disable the alarm.
Disable All Alarms	Click Disable All to disable all the added alarms.
Test Alarm	Click @ to trigger this alarm automatically. You can test if the linkage actions work properly as you want.

12.4.7 Add Alarm for Person

You can set face matched and mismatched alarm for the added face recognition camera and configure a series of linkage actions (e.g., triggering pop-up window on the Control Client) for notification when alarm is triggered.

Steps

- 1. Click Event & Alarm → Alarm → Add to enter the adding alarm page.
- 2. Set the source type as **Person** in the **Source Type** field.
- **3.** Select a face comparison group applied to the camera and select a specific face recognition camera as the source for matching or mismatching the person face recognized by the face recognition camera.

iNote

For configuring the face comparison group and applying to the device, refer to *Manage Face Comparison Group*.

- 4. Optional: Enter instructions for handling the alarm or enter remarks for the alarm.
- 5. Set the required information.

Arming Schedule

The camera is armed during the arming schedule and when an event occurs during the arming schedule, an alarm will be triggered to notify the user. Two types of arming schedule are provided:

- Schedule Template: Select an arming schedule template for the alarm to define when the alarm can be triggered. For setting customized template, refer to *Configure Arming Schedule Template*.
- Event Based: Specify a user-defined event or an alarm input as the start or end event of the arming schedule. When the user defined event or alarm input is triggered, the arming schedule will start or end. You can set the Auto-End Arming switch to on and set the specified time to automatically end arming for this alarm even if the end event does not occur.

iNote

For example, you have set event A as start event, event B as end event, and set the **Auto-End Arming in** as *60 s*, when event A occurs at T1, the alarm will be armed from T1 until event B occurs within 60 s (See the following figure Arming Schedule 1), or end arming 60 s later and event B doesn't occur (See the following figure Arming Schedule 2).



Figure 12-40 Arming Schedule 1



Figure 12-41 Arming Schedule 2

When A occurs at time T1, the alarm will be armed from T1, if A occurs again at time T2 but B doesn't occur, the alarm will be armed from T2 again.



Figure 12-42 Arming Schedule 3

Alarm Priority

Define the priority for the alarm. Priority can be used for filtering alarms in the Control Client. For setting alarm priority, refer to *Alarm Settings*.

Active Control

Active Control is used to avoid the same alarm being received frequently in a short time. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30** *s*, the same alarms from the same camera within 30 s will be regarded as one alarm on the system.

The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.

Alarm Recipient

Select the user to send the alarm information to and the user can receive the alarm information when he/she logs in to HikCentral Professional via the Control Client or Mobile Client.

6. Optional: Set the alarm's additional settings such as alarm related cameras and map, and alarm linkage actions

Related Camera

Select the related camera to record the alarm video when the alarm is triggered. You can view the live video and play back the recorded video files when alarm occurs in the Alarm Center of the Control Client.

- To relate the source camera itself for recording, select **Source Camera** and select the storage location for storing the video files.
- To relate other cameras, select **Specified Camera** and Click **Add** to add other cameras as related cameras. Select the storage location for storing the video files.
- View Pre-Alarm Video: If the camera has recorded video files before the alarm, you can view the video recorded from periods preceding the alarm. Specify the number of seconds which you want to view the recorded video for before the alarm starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.
- **Post-record:** Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.
- Lock Video Files for: Set the days for protecting the video file from being overwritten.
- **Display Video by Default:** Set the video to be displayed by default on the Control Client when receiving the triggered alarm information, you can select the recorded video or the live video to be displayed.

iNote

- Make sure the related camera(s) have been configured with recording schedule.
- Up to 16 cameras can be set as related camera.

Related Map

Select a map to show the alarm information and you should add the camera to the map as a hot spot (refer to **Add Hot Spot**). You can check the map in the Alarm Center and Alarm & Event Search of Control Client.

Trigger Pop-up Window

Display the alarm window on Control Client to show the alarm details and all the alarm related cameras' live videos and recorded video files when alarm occurs.

Display on Smart Wall

Display the alarm video of the alarm's related camera or display the specified public view on the smart wall. You can select the added smart wall and select which window to display the alarm.

- Alarm's Related Cameras: Display the video of the alarm's related cameras on the smart wall. You can select to display the video on which smart wall and which window and set the alarm video's stream type.
- **Public View:** A view enables you to save the window division and the correspondence between cameras and windows as favorites to quickly access the related cameras later. If you select **Public View**, when the alarm is triggered, the system can display the selected public view on the specified smart wall and users can view the video of the cameras predefined in the view.
- Wall Related to Graphic Card: Display the alarm video on the wall which adopts graphic card of the PC that running the Control Client to decode video.
- Wall Related to Decoding Device: Display the alarm video on the wall which adopts decoding device (namely the wall that related to the decoding device) to decode the video.
- Smart Wall No.: Select the No. of smart wall window to display the alarm video.
- Stream Type: Select the stream type of the alarm video displaying on the smart wall.
- **Stop Displaying Alarm:** Define when the system will stop displaying the alarm on the smart wall. The system can stop displaying alarm within specified seconds, or replace the original alarm when other alarm with higher alarm priority is triggered.

Restrict Alarm Handling Time

When the alarm is triggered, you need to handle the alarm on the Control Client. Enable this function to trigger user-defined event(s) or alarm output(s) if the alarm is not handled within the configured alarm handling time.

iNote

- Up to 16 user-defined events and alarm outputs can be set as the triggered event when handling alarm timed out.
- For configuring the user-defined event, refer to Configure User-Defined Event .

Trigger Audible Warning

Set the voice text for playing on the PC when alarm is triggered.

You should set voice engine as the alarm sound on System Settings page of Control Client.

Trigger User-Defined Event

Trigger the user-defined event(s) when alarm is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as alarm linkage.
- For setting the user-defined event, refer to *Configure User-Defined Event* .

7. Finish adding the alarm.

- Click **Add** to add the alarm and back to the alarm list page.
- Click Add and Continue to add the alarm and continue to add other alarm.

After adding the alarm, it displays on the alarm list, and you can view the alarm name and alarm status.

8. Optional: Perform the following operation(s) after adding the alarm.

Edit Alarm	Click 🗹 in the Operation column to edit the alarm.
Copy to Other Alarms	You can copy the current alarm's specified parameters to other added alarms for batch configuration.
	Click 🗹 in the Operation column to enter the alarm details page and click Copy to .
	Specify the settings of the source alarm, select target alarm(s), and click OK .
Delete Alarm	Click $ imes$ in the Operation column to delete the alarm.
Delete All Alarms	Click Delete All to delete all the added alarm.
Enable Alarm	Click \oslash in the Operation column to enable the alarm.
Enable All Alarms	Click Enable All to enable all the added alarms.
Disable Alarm	Click \ominus in the Operation column to disable the alarm.
Disable All Alarms	Click Disable All to disable all the added alarms.
Delete All Invalid Alarms	Click Delete All Invalid Items to delete all the invalid alarms in a batch.
Test Alarm	Click @ to trigger this alarm automatically. You can test if the linkage actions work properly as you want.

12.4.8 Add Alarm for UVSS

You can set alarms for added UVSSs, including UVSS online and offline, and trigger a series of linkage actions (e.g., triggering pop-up window on the Control Client) for notification.

Steps

- **1.** Click **Event & Alarm** \rightarrow **Alarm** \rightarrow **Add** to enter the adding alarm page.
- 2. Set UVSS as the source type in the Source Type field.
- 3. Select a specific triggering event and a specific UVSS as the source for triggering the alarm.
- 4. Optional: Enter instructions for handling the alarm or enter remarks for the alarm.
- **5.** Set the required information.

Arming Schedule

The UVSS is armed during the arming schedule and when an event occurs during the arming schedule, an alarm will be triggered to notify the user. Two types of arming schedule are provided:

- Schedule Template: Select an arming schedule template for the alarm to define when the alarm can be triggered. For setting customized template, refer to *Configure Arming Schedule Template*.
- Event Based: Specify a user-defined event or an alarm input as the start or end event of the arming schedule. When the user defined event or alarm input is triggered, the arming schedule will start or end. You can set the Auto-End Arming switch to on and set the specified time to automatically end arming for this alarm even if the end event does not occur.

iNote

For example, you have set event A as start event, event B as end event, and set the **Auto-End Arming in** as *60 s*, when event A occurs at T1, the alarm will be armed from T1 until event B occurs within 60 s (See the following figure Arming Schedule 1), or end arming 60 s later and event B doesn't occur (See the following figure Arming Schedule 2).



Figure 12-43 Arming Schedule 1

Alarming Starts	Alarming Ends
T1	T1 + 60 s
Event A occurs	Event B doesn't occur within 60

Figure 12-44 Arming Schedule 2

When A occurs at time T1, the alarm will be armed from T1, if A occurs again at time T2 but B doesn't occur, the alarm will be armed from T2 again.



Figure 12-45 Arming Schedule 3

Alarm Priority

Define the priority for the alarm. Priority can be used for filtering alarms in the Control Client. For setting alarm priority, refer to *Alarm Settings*.

Active Control

Active Control is used to avoid the same alarm being received frequently in a short time. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30** *s*, the same alarms from the same camera within 30 s will be regarded as one alarm on the system.

The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.

Alarm Recipient

Select the user to send the alarm information to and the user can receive the alarm information when he/she logs in to HikCentral Professional via the Control Client or Mobile Client.

6. Optional: Set the alarm's additional settings such as alarm related cameras and map, and alarm linkage actions

Related Camera

You can view the live video and play back the recorded video files when alarm occurs in the Alarm Center of the Control Client.

- To relate the UVSS's related camera for recording, select **Source Related Camera** and select the storage location for storing the video files.
- To relate other cameras, select **Specified Camera** and Click **Add** to add other cameras as related cameras. Select the storage location for storing the video files.
- **Post-record:** Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.
- View Pre-Alarm Video: If the camera has recorded video files before the alarm, you can view the video recorded from periods preceding the alarm. Specify the number of seconds which you want to view the recorded video for before the alarm starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.

- Lock Video Files for: Set the days for protecting the video file from being overwritten.
- **Display Video by Default:** Set the video to be displayed by default on the Control Client when receiving the triggered alarm information, you can select the recorded video or the live video to be displayed.

- For setting the UVSS's related camera, refer to *Edit Under Vehicle Surveillance System for Current Site*
- Make sure the related camera(s) have been configured with recording schedule.
- Up to 16 cameras can be set as related camera.

Trigger Pop-up Window

Display the alarm window on the Control Client to show the alarm details.

Display on Smart Wall

Display the alarm video of the alarm's related camera or display the specified public view on the smart wall. You can select the added smart wall and select which window to display the alarm.

- Alarm's Related Cameras: Display the video of the alarm's related cameras on the smart wall. You can select to display the video on which smart wall and which window and set the alarm video's stream type.
- **Public View:** A view enables you to save the window division and the correspondence between cameras and windows as favorites to quickly access the related cameras later. If you select **Public View**, when the alarm is triggered, the system can display the selected public view on the specified smart wall and users can view the video of the cameras predefined in the view.
- Wall Related to Graphic Card: Display the alarm video on the wall which adopts graphic card of the PC that running the Control Client to decode video.
- Wall Related to Decoding Device: Display the alarm video on the wall which adopts decoding device (namely the wall that related to the decoding device) to decode the video.
- Smart Wall No.: Select the No. of smart wall window to display the alarm video.
- Stream Type: Select the stream type of the alarm video displaying on the smart wall.
- **Stop Displaying Alarm:** Define when the system will stop displaying the alarm on the smart wall. The system can stop displaying alarm within specified seconds, or replace the original alarm when other alarm with higher alarm priority is triggered.

Restrict Alarm Handling Time

When the alarm is triggered, you need to handle the alarm on the Control Client. Enable this function to trigger user-defined event(s) or alarm output(s) if the alarm is not handled within the configured alarm handling time.

- Up to 16 user-defined events and alarm outputs can be set as the triggered event when handling alarm timed out.
- For configuring the user-defined event, refer to *Configure User-Defined Event* .

Trigger Audible Warning

Set the voice text for playing on the PC when alarm is triggered.

∎Note

You should set voice engine as the alarm sound on System Settings page of Control Client.

Trigger User-Defined Event

Trigger the user-defined event(s) when alarm is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as alarm linkage.
- For setting the user-defined event, refer to *Configure User-Defined Event* .

7. Finish adding the alarm.

- Click Add to add the alarm and back to the alarm list page.
- Click Add and Continue to add the alarm and continue to add other alarm.

After adding the alarm, it displays on the alarm list, and you can view the alarm name and alarm status.

8. Optional: Perform the following operation(s) after adding the alarm.

Edit Alarm	Click 🗷 in the Operation column to edit the alarm.
Copy to Other Alarms	You can copy the current alarm's specified parameters to other added alarms for batch configuration.
	Click 🗹 in the Operation column to enter the alarm details page and click Copy to .
	Specify the settings of the source alarm, select target alarm(s), and click OK .
Delete Alarm	Click $ imes$ in the Operation column to delete the alarm.
Delete All Alarms	Click Delete All to delete all the added alarms.
Delete All Invalid Alarms	Click Delete All Invalid Items to delete all the invalid alarms in a batch.
Enable Alarm	Click \oslash in the Operation column to enable the alarm.
Enable All Alarms	Click Enable All to enable all the added alarms.

Disable Alarm	Click \ominus in the Operation column to disable the alarm.
Disable All Alarms	Click Disable All to disable all the added alarms.
Test Alarm	Click log to trigger this alarm automatically. You can test if the linkage actions work properly.

12.4.9 Add Alarm for Encoding Device

You can set alarms for the added encoding devices and configure a series of linkage actions (e.g., triggering pop-up window on the Control Client) for notification when alarm is triggered.

Steps

- 1. Click Event & Alarm → Alarm → Add to enter the Add Alarm page.
- 2. Set the source type as Encoding Device in the Source Type field.
- **3.** Select triggering event and a specific encoding device as the source for triggering the alarm.
- **4. Optional:** Configure the alarm definition including alarm name and description.
- **5.** Set the required information.

Arming Schedule

The device is armed during the arming schedule and when an event occurs during the arming schedule, an alarm will be triggered to notify the user. Two types of arming schedule are provided:

- Schedule Template: Select an arming schedule template for the alarm to define when the alarm can be triggered. For setting customized template, refer to *Configure Arming Schedule Template*.
- Event Based: Specify a user-defined event or an alarm input as the start or end event of the arming schedule. When the user defined event or alarm input is triggered, the arming schedule will start or end. You can set the **Auto-End Arming** switch to on and set the specified time to automatically end arming for this alarm even if the end event does not occur.

iNote

For example, you have set event A as start event, event B as end event, and set the **Auto-End Arming in** as *60 s*, when event A occurs at T1, the alarm will be armed from T1 until event B occurs within 60 s (See the following figure Arming Schedule 1), or end arming 60 s later and event B doesn't occur (See the following figure Arming Schedule 2).



Figure 12-46 Arming Schedule 1



Figure 12-47 Arming Schedule 2

When A occurs at time T1, the alarm will be armed from T1, if A occurs again at time T2 but B doesn't occur, the alarm will be armed from T2 again.



Figure 12-48 Arming Schedule 3

Alarm Priority

Define the priority for the alarm. Priority can be used for filtering alarms in the Control Client. For setting alarm priority, refer to *Alarm Settings*.

Active Control

Active Control is used to avoid the same alarm being received frequently in a short time. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30** s, the same alarms from the same camera within 30 s will be regarded as one alarm on the system.

The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.

Alarm Recipient

Select a user to send the alarm information to and the user can receive the alarm information when he/she logs in to HikCentral Professional via the Control Client or Mobile Client.

6. Optional: Set the alarm's additional settings such as alarm related cameras and map, and alarm linkage actions

Related Camera

You can view the live video and play back the recorded video files when alarm occurs in the Alarm Center of the Control Client.

- Select the camera(s) to record the alarm video when the alarm is triggered.
- **Post-record:** Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.
- View Pre-Alarm Video: If the camera has recorded video files before the alarm, you can view the video recorded from periods preceding the alarm. Specify the number of seconds which you want to view the recorded video for before the alarm starts. For example, when

someone opens a door, you can view the recorded video to see what happens right before the door opened.

- Lock Video Files for: Set the days for protecting the video file from being overwritten.
- **Display Video by Default:** Set the video to be displayed by default on the Control Client when receiving the triggered alarm information, you can select the recorded video or the live video to be displayed.

iNote

- Make sure the related camera(s) have been configured with recording schedule.
- Up to 16 cameras can be set as related camera.

Trigger Pop-up Window

Display the alarm window on the Control Client to show the alarm details.

Display on Smart Wall

Display the alarm video of the alarm's related camera or display the specified public view on the smart wall. You can select the added smart wall and select which window to display the alarm.

- Alarm's Related Cameras: Display the video of the alarm's related cameras on the smart wall. You can select to display the video on which smart wall and which window and set the alarm video's stream type.
- **Public View:** A view enables you to save the window division and the correspondence between cameras and windows as favorites to quickly access the related cameras later. If you select **Public View**, when the alarm is triggered, the system can display the selected public view on the specified smart wall and users can view the video of the cameras predefined in the view.
- Wall Related to Graphic Card: Display the alarm video on the wall which adopts graphic card of the PC that running the Control Client to decode video.
- Wall Related to Decoding Device: Display the alarm video on the wall which adopts decoding device (namely the wall that related to the decoding device) to decode the video.
- Smart Wall No.: Select the No. of smart wall window to display the alarm video.
- Stream Type: Select the stream type of the alarm video displaying on the smart wall.
- **Stop Displaying Alarm:** Define when the system will stop displaying the alarm on the smart wall. The system can stop displaying alarm within specified seconds, or replace the original alarm when other alarm with higher alarm priority is triggered.

Restrict Alarm Handling Time

When the alarm is triggered, you need to handle the alarm on the Control Client. Enable this function to trigger user-defined event(s) or alarm output(s) if the alarm is not handled within the configured alarm handling time.

- Up to 16 user-defined events and alarm outputs can be set as the triggered event when handling alarm timed out.
- For configuring the user-defined event, refer to Configure User-Defined Event .

Trigger Audible Warning

Set the voice text for playing on the PC when alarm is triggered.

iNote

You should set voice engine as the alarm sound on System Settings page of Control Client.

Trigger User-Defined Event

Trigger the user-defined event(s) when alarm is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as alarm linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .

7. Finish adding the alarm.

- Click Add to add the alarm and go back to the alarm list page.
- Click Add and Continue to add the alarm and continue to add other alarms.

The alarm will be displayed on the alarm list, and you can view the alarm name and alarm status.

8. Optional: Perform the following operation(s) after adding the alarm.

Edit Alarm	Click 🕜 in the Operation column to edit the alarm.
Copy to Other Alarms	You can copy the current alarm's specified parameters to other added alarms for batch configuration.
	Click 🗹 in the Operation column to enter the alarm details page and click Copy to .
	Specify the settings of the source alarm, select target alarm(s), and click OK .
Delete Alarm	Click $ imes$ in the Operation column to delete the alarm.
Delete All Alarms	Click Delete All to delete all the added alarms.
Delete All Invalid Alarms	Click Delete All Invalid Items to delete all the invalid alarms in a batch.
Enable Alarm	Click \oslash in the Operation column to enable the alarm.
Enable All Alarms	Click Enable All to enable all the added alarms.

Disable Alarm	Click \ominus in the Operation column to disable the alarm.
Disable All Alarms	Click Disable All to disable all the added alarms.
Test Alarm	Click (a) to trigger this alarm automatically. You can test if the linkage actions work properly as you want.

12.4.10 Add Alarm for Access Control Device

You can set alarms for added access control devices, such as device online/offline, tampering alarm, low battery, etc., and configure a series of linkage actions (e.g., triggering pop-up window on the Control Client) for notification when alarm is triggered.

Steps

- 1. Click Event & Alarm → Alarm → Add to enter the Add Alarm page.
- 2. Set Access Control Device as the source type in the Source Type field.
- **3.** Select a triggering event and a specific device as the source for triggering the alarm.
- **4. Optional:** Enter instructions for handling the alarm or enter remarks for the alarm.
- 5. Set the required information.

Arming Schedule

The device is armed during the arming schedule and when an event occurs during the arming schedule, an alarm will be triggered to notify the user. Two types of arming schedule are provided:

- Schedule Template: Select an arming schedule template for the alarm to define when the alarm can be triggered. For setting customized template, refer to *Configure Arming Schedule Template*.
- Event Based: Specify a user-defined event or an alarm input as the start or end event of the arming schedule. When the user defined event or alarm input is triggered, the arming schedule will start or end. You can set the **Auto-End Arming** switch to on and set the specified time to automatically end arming for this alarm even if the end event does not occur.

iNote

For example, you have set event A as start event, event B as end event, and set the **Auto-End Arming in** as *60 s*, when event A occurs at T1, the alarm will be armed from T1 until event B occurs within 60 s (See the following figure Arming Schedule 1), or end arming 60 s later and event B doesn't occur (See the following figure Arming Schedule 2).



Figure 12-49 Arming Schedule 1



Figure 12-50 Arming Schedule 2

When A occurs at time T1, the alarm will be armed from T1, if A occurs again at time T2 but B doesn't occur, the alarm will be armed from T2 again.



Figure 12-51 Arming Schedule 3

Alarm Priority

Define the priority for the alarm. Priority can be used for filtering alarms in the Control Client. For setting alarm priority, refer to *Alarm Settings*.

Active Control

Active Control is used to avoid the same alarm being received frequently in a short time. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30** *s*, the same alarms from the same camera within 30 s will be regarded as one alarm on the system.

The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.

Alarm Recipient

Select a user to send the alarm information to and the user can receive the alarm information when he/she logs in to HikCentral Professional via the Control Client or Mobile Client.

6. Optional: Set the alarm's additional settings such as alarm related cameras and map, and alarm linkage actions

Related Camera

You can view the live video and play back the recorded video files when alarm occurs in the Alarm Center of the Control Client.

Select the camera(s) to record the alarm video when the alarm is triggered.

Post-record

Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.

View Pre-Alarm Video

If the camera has recorded video files before the alarm, you can view the video recorded from periods preceding the alarm. Specify the number of seconds which you want to view the recorded video for before the alarm starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.

Lock Video Files for

Set the days for protecting the video file from being overwritten.

Display Video by Default

Set the video to be displayed by default on the Control Client when receiving the triggered alarm information, you can select the recorded video or the live video to be displayed.

iNote

- Make sure the related camera(s) have been configured with recording schedule.
- Up to 16 cameras can be set as related camera.

Trigger Pop-up Window

Display the alarm window on the Control Client to show the alarm details and all the alarm related cameras' live videos and recorded video files when alarm occurs.

Display on Smart Wall

Display the alarm video of the alarm's related camera or display the specified public view on the smart wall. You can select the added smart wall and select which window to display the alarm.

- Alarm's Related Cameras: Display the video of the alarm's related cameras on the smart wall. You can select to display the video on which smart wall and which window and set the alarm video's stream type.
- **Public View:** A view enables you to save the window division and the correspondence between cameras and windows as favorites to quickly access the related cameras later. If you select **Public View**, when the alarm is triggered, the system can display the selected public view on the specified smart wall and users can view the video of the cameras predefined in the view.
- Wall Related to Graphic Card: Display the alarm video on the wall which adopts graphic card of the PC that running the Control Client to decode video.
- Wall Related to Decoding Device: Display the alarm video on the wall which adopts decoding device (namely the wall that related to the decoding device) to decode the video.
- Smart Wall No.: Select the No. of smart wall window to display the alarm video.

- Stream Type: Select the stream type of the alarm video displaying on the smart wall.
- **Stop Displaying Alarm:** Define when the system will stop displaying the alarm on the smart wall. The system can stop displaying alarm within specified seconds, or replace the original alarm when other alarm with higher alarm priority is triggered.

Restrict Alarm Handling Time

When the alarm is triggered, you need to handle the alarm on the Control Client. Enable this function to trigger user-defined event(s) or alarm output(s) if the alarm is not handled within the configured alarm handling time.

iNote

- Up to 16 user-defined events and alarm outputs can be set as the triggered event when handling alarm timed out.
- For configuring the user-defined event, refer to Configure User-Defined Event .

Trigger Audible Warning

Set the voice text for playing on the PC when alarm is triggered.

i Note

You should set voice engine as the alarm sound on System Settings page of the Control Client.

Trigger User-Defined Event

Trigger the user-defined event(s) when alarm is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as alarm linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .

7. Finish adding the alarm.

- Click Add to add the alarm and go back to the alarm list page.
- Click Add and Continue to add the alarm and continue to add other alarms.

The alarm will be displayed on the alarm list, and you can view the alarm name and alarm status.

8. Optional: Perform the following operation(s) after adding the alarm.

Edit Alarm	Click 🕜 in the Operation column to edit the alarm.
Copy to Other Alarms	You can copy the current alarm's specified parameters to other added alarms for batch configuration.
	Click 🕜 in the Operation column to enter the alarm details page and click Copy to .

Specify the settings of the source alarm, select target alarm(s), and click **OK**.

Delete Alarm	Click $ imes$ in the Operation column to delete the alarm.
Delete All Alarms	Click Delete All to delete all the added alarms.
Enable Alarm	Click \odot in the Operation column to enable the alarm.
Enable All Alarms	Click Enable All to enable all the added alarms.
Disable Alarm	Click \ominus in the Operation column to disable the alarm.
Disable All Alarms	Click Disable All to disable all the added alarms.
Delete All Invalid Alarms	Click Delete All Invalid Items to delete all the invalid alarms in a batch.
Test Alarm	Click @ to trigger this alarm automatically. You can test if the linkage actions work properly as you want.

12.4.11 Add Alarm for Security Control Device

You can set alarms for the added security control devices, such as device online/offline, tampering alarm, low battery, etc., and configure a series of linkage actions (e.g., triggering pop-up window on the Control Client) for notification when alarm is triggered.

Steps

- **1.** Click **Event & Alarm \rightarrow Alarm \rightarrow Add to enter the adding alarm page.**
- 2. Set Security Control Device as the source type in the Source Type field.
- 3. Select a triggering event and a specific device as the source for triggering the alarm.
- 4. Optional: Enter instructions for handling the alarm or enter remarks for the alarm.
- **5.** Set the required information.

Arming Schedule

The device is armed during the arming schedule and when an event occurs during the arming schedule, an alarm will be triggered to notify the user. Two types of arming schedule are provided:

- Schedule Template: Select an arming schedule template for the alarm to define when the alarm can be triggered. For setting customized template, refer to *Configure Arming Schedule Template*.
- Event Based: Specify a user-defined event or an alarm input as the start or end event of the arming schedule. When the user defined event or alarm input is triggered, the arming schedule will start or end. You can set the **Auto-End Arming** switch to on and set the specified time to automatically end arming for this alarm even if the end event does not occur.

For example, you have set event A as start event, event B as end event, and set the **Auto-End Arming in** as *60 s*, when event A occurs at T1, the alarm will be armed from T1 until event B occurs within 60 s (See the following figure Arming Schedule 1), or end arming 60 s later and event B doesn't occur (See the following figure Arming Schedule 2).





Figure 12-53 Arming Schedule 2

When A occurs at time T1, the alarm will be armed from T1, if A occurs again at time T2 but B doesn't occur, the alarm will be armed from T2 again.



Figure 12-54 Arming Schedule 3

Alarm Priority

Define the priority for the alarm. Priority can be used for filtering alarms in the Control Client. For setting alarm priority, refer to *Alarm Settings*.

Active Control

Active Control is used to avoid the same alarm being received frequently in a short time. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30** *s*, the same alarms from the same camera within 30 s will be regarded as one alarm on the system.

The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.

Alarm Recipient

Select a user to send the alarm information to and the user can receive the alarm information when he/she logs in to HikCentral Professional via the Control Client or Mobile Client.

6. Optional: Set the alarm's additional settings such as alarm related cameras and map, and alarm linkage actions

Related Camera

You can view the live video and play back the recorded video files when alarm occurs in the Alarm Center of the Control Client.

- Select the camera(s) to record the alarm video when the alarm is triggered.
- **Post-record:** Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.
- View Pre-Alarm Video: If the camera has recorded video files before the alarm, you can view the video recorded from periods preceding the alarm. Specify the number of seconds which you want to view the recorded video for before the alarm starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.
- Lock Video Files for: Set the days for protecting the video file from being overwritten.
- **Display Video by Default:** Set the video to be displayed by default on the Control Client when receiving the triggered alarm information, you can select the recorded video or the live video to be displayed.

iNote

- Make sure the related camera(s) have been configured with recording schedule.
- Up to 16 cameras can be set as related camera.

Trigger Pop-up Window

Display the alarm window on the Control Client to show the alarm details and all the alarm related cameras' live videos and recorded video files when alarm occurs.

Display on Smart Wall

Display the alarm video of the alarm's related camera or display the specified public view on the smart wall. You can select the added smart wall and select which window to display the alarm.

- Alarm's Related Cameras: Display the video of the alarm's related cameras on the smart wall. You can select to display the video on which smart wall and which window and set the alarm video's stream type.
- **Public View:** A view enables you to save the window division and the correspondence between cameras and windows as favorites to quickly access the related cameras later. If you select **Public View**, when the alarm is triggered, the system can display the selected public view on the specified smart wall and users can view the video of the cameras predefined in the view.
- Wall Related to Graphic Card: Display the alarm video on the wall which adopts graphic card of the PC that running the Control Client to decode video.
- Wall Related to Decoding Device: Display the alarm video on the wall which adopts decoding device (namely the wall that related to the decoding device) to decode the video.
- Smart Wall No.: Select the No. of smart wall window to display the alarm video.

- Stream Type: Select the stream type of the alarm video displaying on the smart wall.
- **Stop Displaying Alarm:** Define when the system will stop displaying the alarm on the smart wall. The system can stop displaying alarm within specified seconds, or replace the original alarm when other alarm with higher alarm priority is triggered.

Restrict Alarm Handling Time

When the alarm is triggered, you need to handle the alarm on the Control Client. Enable this function to trigger user-defined event(s) or alarm output(s) if the alarm is not handled within the configured alarm handling time.

iNote

- Up to 16 user-defined events and alarm outputs can be set as the triggered event when handling alarm timed out.
- For configuring the user-defined event, refer to Configure User-Defined Event .

Trigger Audible Warning

Set the voice text for playing on the PC when alarm is triggered.

iNote

You should set voice engine as the alarm sound on System Settings page of the Control Client.

Trigger User-Defined Event

Trigger the user-defined event(s) when alarm is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as alarm linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .

7. Finish adding the alarm.

- Click Add to add the alarm and go back to the alarm list page.
- Click Add and Continue to add the alarm and continue to add other alarms.

The alarm will be displayed on the alarm list, and you can view the alarm name and alarm status.

8. Optional: Perform the following operation(s) after adding the alarm.

Edit Alarm	Click 📝 in the Operation column to edit the alarm.
Copy to Other Alarms	You can copy the current alarm's specified parameters to other added alarms for batch configuration.
	Click 🕜 in the Operation column to enter the alarm details page and click Copy to .

Specify the settings of the source alarm, select target alarm(s), and click **OK**.

Delete Alarm	Click $ imes$ in the Operation column to delete the alarm.
Delete All Alarms	Click Delete All to delete all the added alarms.
Delete All Invalid Alarms	Click Delete All Invalid Items to delete all the invalid alarms in a batch.
Enable Alarm	Click \odot in the Operation column to enable the alarm.
Enable All Alarms	Click Enable All to enable all the added alarms.
Disable Alarm	Click \bigcirc in the Operation column to disable the alarm.
Disable All Alarms	Click Disable All to disable all the added alarms.
Test Alarm	Click @ to trigger this alarm automatically. You can test if the linkage actions work properly.

12.4.12 Add Alarm for Dock Station

You can set alarms (including dock station offline and dock station online) for dock station, and configure a series of linkage actions (e.g., triggering pop-up window on the Control Client) for notification when alarm is triggered.

Steps

- 1. Click Event & Alarm → Alarm → Add to enter the Add Alarm page.
- 2. Set the source type as Dock Station in the Source Type field.
- **3.** Select a triggering event as the source for triggering the alarm.
- **4.** In the **Source** field, select a specific dock station for triggering the alarm.
- 5. Optional: Enter the instructions for handling the alarm or enter remarks for the alarm.
- **6.** Set the required information.

Arming Schedule

The dock station is armed during the arming schedule and the event occurred during the arming schedule will be triggered as alarm and notify the user. It provides two types of arming schedule:

- Schedule Template: Select an arming schedule template for the alarm to define when the alarm can be triggered. For setting customized template, refer to *Configure Arming Schedule Template*.
- Event Based: Specify a user-defined event or an alarm input as the start or end event of the arming schedule. When the user defined event or alarm input is triggered, the arming schedule will start or end. You can set the **Auto-End Arming** switch to on and set the specified time to automatically end arming for this alarm even if the end event does not occur.

For example, you have set event A as start event, event B as end event, and set the **Auto-End Arming in** as *60 s*, when event A occurs at T1, the alarm will be armed from T1 until event B occurs within 60 s (See the following figure Arming Schedule 1), or end arming 60 s later and event B doesn't occur (See the following figure Arming Schedule 2).





Figure 12-56 Arming Schedule 2

When A occurs at time T1, the alarm will be armed from T1, if A occurs again at time T2 but B doesn't occur, the alarm will be armed from T2 again.



Figure 12-57 Arming Schedule 3

Alarm Priority

Define the priority for the alarm. Priority can be used for filtering alarms in the Control Client. You can click **Add New** to set alarm priority. For setting alarm priority, refer to **Alarm Settings**.

Active Control

Active Control is used to avoid the same alarm being received frequently in a short time. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30** *s*, the same alarms from the same camera within 30 s will be regarded as one alarm on the system.

The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.

Alarm Recipient

Select the user to send the alarm information to and the user can receive the alarm information when he/she logs in to HikCentral Professional via the Control Client or Mobile Client.

7. Optional: Set the alarm's additional settings such as alarm related cameras and map, and alarm linkage actions.

Related Camera

Select the related camera to record the alarm video when the alarm is triggered. You can view the live video and play back these video files in the Alarm Center of the Control Client.

- To relate the source camera itself for recording, select **Source Camera** and select the storage location for storing the video files.
- To relate other cameras, select **Specified Camera** and click **Add** to add other cameras as related cameras. Select the storage location for storing the video files.
- View Pre-Alarm Video: You can view the video recorded from periods preceding the alarm. Specify the number of seconds which you want to view the recorded video for before the alarm starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.
- **Post-record:** Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.
- Lock Video Files for: Set the days for protecting the video file from being overwritten.
- **Display Video by Default:** Set the video to be displayed by default on the Control Client when receiving the triggered alarm information, you can select the recorded video or the live video to be displayed.

iNote

- Make sure the related camera(s) have been configured with recording schedule.
- Up to 16 cameras can be set as related camera.

Trigger Pop-up Window

Display the alarm window on the Control Client to show the alarm details and all the alarm related cameras' live videos and playback when alarm occurs.

Display on Smart Wall

Display the alarm video of the alarm's related camera or display the specified public view on the smart wall. You can select the added smart wall and select which window to display the alarm.

- Alarm's Related Cameras: Display the video of the alarm's related cameras on the smart wall. You can select to display the video on which smart wall and which window and set the alarm video's stream type.
- **Public View:** A view enables you to save the window division and the correspondence between cameras and windows as favorites to quickly access the related cameras later. If you select **Public View**, when the alarm is triggered, the system can display the selected public view on the specified smart wall and users can view the video of the cameras predefined in the view.
- Wall Related to Graphic Card: Display the alarm video on the wall which adopts graphic card of the PC that running the Control Client to decode video.

- Wall Related to Decoding Device: Display the alarm video on the wall which adopts decoding device (namely the wall that related to the decoding device) to decode the video.
- Smart Wall No.: Select the No. of smart wall window to display the alarm video.
- Stream Type: Select the stream type of the alarm video displaying on the smart wall.
- **Stop Displaying Alarm:** Define when the system will stop displaying the alarm on the smart wall. The system can stop displaying alarm within specified seconds, or replace the original alarm when other alarm with higher alarm priority is triggered.

Restrict Alarm Handling Time

When the alarm is triggered, you need to handle the alarm on the Control Client. Enable this function to trigger user-defined event(s) or alarm output(s) if the alarm is not handled within the configured alarm handling time.

iNote

- Up to 16 user-defined events and alarm outputs can be set as the triggered event when handling alarm timed out.
- For configuring the user-defined event, refer to *Configure User-Defined Event* .

Trigger Audible Warning

Set the voice text for playing on the PC when alarm is triggered.

i Note

You should set voice engine as the alarm sound on System Settings page of Control Client.

Trigger User-Defined Event

Trigger the user-defined event(s) when alarm is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click **Add New** below to set new user-defined event(s).

i Note

- Up to 16 user-defined events can be selected as alarm linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .

8. Finish adding the alarm.

- Click **Add** to add the alarm and back to the alarm list page.
- Click Add and Continue to add the alarm and continue to add other alarm.

The alarm will be displayed on the alarm list and you can view the alarm name and alarm status.

9. Optional: Perform the following operation(s) after adding the alarm.

Copy to OtherYou can copy the current alarm's specified parameters to other addedAlarmsalarms for batch configuration.

	Click 📝 in the Operation column to enter the alarm details page and click Copy to . Specify the settings of the source alarm, select target alarm(s), and click OK .
Delete Alarm	Click \times in the Operation column to delete the alarm.
	•
Delete All Alarms	Click Delete All to delete all the added alarm.
Delete All Invalid Alarms	Click Delete All Invalid Items to delete all the invalid alarms in a batch.
Enable Alarm	Click \oslash in the Operation column to enable the alarm.
Enable All Alarms	Click Enable All to enable all the added alarms.
Disable Alarm	Click \ominus in the Operation column to disable the alarm.
Disable All Alarms	Click Disable All to disable all the added alarms.
Test Alarm	Click ③ to trigger this alarm automatically. You can test if the linkage actions work properly.

12.4.13 Add Alarm for Streaming Server and Recording Server

You can set server exception alarms for added servers (Streaming Server and Recording Server) and configure a series of linkage actions (e.g., triggering pop-up window on the Control Client) for notification when alarm is triggered.

Steps

- 1. Click Event & Alarm → Alarm → Add to enter the adding alarm page.
- 2. Set Recording Server or Streaming Server as the source type in the Source Type field.
- **3.** Select a specific triggering event and a specific server as the source for triggering the alarm.
- **4. Optional:** Enter instructions for handling the alarm or enter remarks for the alarm.
- 5. Set the required information.

Arming Schedule

The server is armed during the arming schedule and when an event occurs during the arming schedule, an alarm will be triggered to notify the user. Two types of arming schedule are provided:

- Schedule Template: Select an arming schedule template for the alarm to define when the alarm can be triggered. For setting customized template, refer to *Configure Arming Schedule Template*.
- Event Based: Specify a user-defined event or an alarm input as the start or end event of the arming schedule. When the user defined event or alarm input is triggered, the arming schedule will start or end. You can set the Auto-End Arming switch to on and set the

specified time to automatically end arming for this alarm even if the end event does not occur.

iNote

For example, you have set event A as start event, event B as end event, and set the **Auto-End Arming in** as *60 s*, when event A occurs at T1, the alarm will be armed from T1 until event B occurs within 60 s (See the following figure Arming Schedule 1), or end arming 60 s later and event B doesn't occur (See the following figure Arming Schedule 2).



Figure 12-59 Arming Schedule 2

When A occurs at time T1, the alarm will be armed from T1, if A occurs again at time T2 but B doesn't occur, the alarm will be armed from T2 again.



Figure 12-60 Arming Schedule 3

Alarm Priority

Define the priority for the alarm. Priority can be used for filtering alarms in the Control Client. For setting alarm priority, refer to *Alarm Settings*.

Active Control

Active Control is used to avoid the same alarm being received frequently in a short time. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30** *s*, the same alarms from the same camera within 30 s will be regarded as one alarm on the system.

The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.

Alarm Recipient

Select the user to send the alarm information to and the user can receive the alarm information when he/she logs in to HikCentral Professional via the Control Client or Mobile Client.

6. Optional: Set the alarm's additional settings such as alarm related cameras and map, and alarm linkage actions

Related Camera

You can view the live video and play back the recorded video files when alarm occurs in the Alarm Center of the Control Client.

- Select the camera(s) to record the alarm video when the alarm is triggered.
- **Post-record:** Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.
- View Pre-Alarm Video: If the camera has recorded video files before the alarm, you can view the video recorded from periods preceding the alarm. Specify the number of seconds which you want to view the recorded video for before the alarm starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.
- Lock Video Files for: Set the days for protecting the video file from being overwritten.
- **Display Video by Default:** Set the video to be displayed by default on the Control Client when receiving the triggered alarm information, you can select the recorded video or the live video to be displayed.

iNote

- Make sure the related camera(s) have been configured with recording schedule.
- Up to 16 cameras can be set as related camera.

Trigger Pop-up Window

Display the alarm window on Control Client to show the alarm details.

Display on Smart Wall

Display the alarm video of the alarm's related camera or display the specified public view on the smart wall. You can select the added smart wall and select which window to display the alarm.

- Alarm's Related Cameras: Display the video of the alarm's related cameras on the smart wall. You can select to display the video on which smart wall and which window and set the alarm video's stream type.
- **Public View:** A view enables you to save the window division and the correspondence between cameras and windows as favorites to quickly access the related cameras later. If you select **Public View**, when the alarm is triggered, the system can display the selected public view on the specified smart wall and users can view the video of the cameras predefined in the view.
- Wall Related to Graphic Card: Display the alarm video on the wall which adopts graphic card of the PC that running the Control Client to decode video.

- Wall Related to Decoding Device: Display the alarm video on the wall which adopts decoding device (namely the wall that related to the decoding device) to decode the video.
- Smart Wall No.: Select the No. of smart wall window to display the alarm video.
- Stream Type: Select the stream type of the alarm video displaying on the smart wall.
- **Stop Displaying Alarm:** Define when the system will stop displaying the alarm on the smart wall. The system can stop displaying alarm within specified seconds, or replace the original alarm when other alarm with higher alarm priority is triggered.

Restrict Alarm Handling Time

When the alarm is triggered, you need to handle the alarm on the Control Client. Enable this function to trigger user-defined event(s) or alarm output(s) if the alarm is not handled within the configured alarm handling time.

iNote

- Up to 16 user-defined events and alarm outputs can be set as the triggered event when handling alarm timed out.
- For configuring the user-defined event, refer to *Configure User-Defined Event* .

Trigger Audible Warning

Set the voice text for playing on the PC when alarm is triggered.

i Note

You should set voice engine as the alarm sound on System Settings page of Control Client.

Trigger User-Defined Event

Trigger the user-defined event(s) when alarm is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click **Add New** below to set new user-defined event(s).

i Note

- Up to 16 user-defined events can be selected as alarm linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .

7. Finish adding the alarm.

- Click **Add** to add the alarm and back to the alarm list page.
- Click Add and Continue to add the alarm and continue to add other alarm.

After adding the alarm, it displays on the alarm list, and you can view the alarm name and alarm status.

8. Optional: Perform the following operation(s) after adding the alarm.

Edit Alarm	Click 🕜 in the Operation column to edit the alarm.
------------	----------------------------------------------------

Copy to OtherYou can copy the current alarm's specified parameters to other addedAlarmsalarms for batch configuration.

	 Click ☑ in the Operation column to enter the alarm details page and click Copy to. Specify the settings of the source alarm, select target alarm(s), and click OK.
Delete Alarm	Click $ imes$ in the Operation column to delete the alarm.
Delete All Alarms	Click Delete All to delete all the added alarms.
Delete All Invalid Alarms	Click Delete All Invalid Items to delete all the invalid alarms in a batch.
Enable Alarm	Click \odot in the Operation column to enable the alarm.
Enable All Alarms	Click Enable All to enable all the added alarms.
Disable Alarm	Click \ominus in the Operation column to disable the alarm.
Disable All Alarms	Click Disable All to disable all the added alarms.
Test Alarm	Click log to trigger this alarm automatically. You can test if the linkage actions work properly.

12.4.14 Add Alarm for Facial Recognition Server

You can set server exception alarms for added facial recognition server and configure a series of linkage actions (e.g., triggering pop-up window on the Control Client) for notification when alarm is triggered.

Steps

- **1.** Click **Event & Alarm \rightarrow Alarm \rightarrow Add to enter the adding alarm page.**
- 2. Set Facial Recognition Server as the source type in the Source Type field.
- **3.** Select a specific triggering event and a specific server as the source for triggering the alarm.
- 4. Optional: Enter instructions for handling the alarm or enter remarks for the alarm.
- **5.** Set the required information.

Arming Schedule

The server is armed during the arming schedule and when an event occurs during the arming schedule, an alarm will be triggered to notify the user. Two types of arming schedule are provided:

- Schedule Template: Select an arming schedule template for the alarm to define when the alarm can be triggered. For setting customized template, refer to *Configure Arming Schedule Template*.
- **Event Based:** Specify a user-defined event or an alarm input as the start or end event of the arming schedule. When the user defined event or alarm input is triggered, the arming schedule will start or end. You can set the **Auto-End Arming** switch to on and set the
specified time to automatically end arming for this alarm even if the end event does not occur.

iNote

For example, you have set event A as start event, event B as end event, and set the **Auto-End Arming in** as *60 s*, when event A occurs at T1, the alarm will be armed from T1 until event B occurs within 60 s (See the following figure Arming Schedule 1), or end arming 60 s later and event B doesn't occur (See the following figure Arming Schedule 2).



Figure 12-62 Arming Schedule 2

When A occurs at time T1, the alarm will be armed from T1, if A occurs again at time T2 but B doesn't occur, the alarm will be armed from T2 again.



Figure 12-63 Arming Schedule 3

Alarm Priority

Define the priority for the alarm. Priority can be used for filtering alarms in the Control Client. For setting alarm priority, refer to *Alarm Settings*.

Active Control

Active Control is used to avoid the same alarm being received frequently in a short time. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30** *s*, the same alarms from the same camera within 30 s will be regarded as one alarm on the system.

The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.

Alarm Recipient

Select the user to send the alarm information to and the user can receive the alarm information when he/she logs in to HikCentral Professional via the Control Client or Mobile Client.

6. Optional: Set the alarm's additional settings such as alarm related cameras and map, and alarm linkage actions

Related Camera

You can view the live video and play back the recorded video files when alarm occurs in the Alarm Center of the Control Client.

- Select the camera(s) to record the alarm video when the alarm is triggered.
- **Post-record:** Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.
- View Pre-Alarm Video: If the camera has recorded video files before the alarm, you can view the video recorded from periods preceding the alarm. Specify the number of seconds which you want to view the recorded video for before the alarm starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.
- Lock Video Files for: Set the days for protecting the video file from being overwritten.
- **Display Video by Default:** Set the video to be displayed by default on the Control Client when receiving the triggered alarm information, you can select the recorded video or the live video to be displayed.

iNote

- Make sure the related camera(s) have been configured with recording schedule.
- Up to 16 cameras can be set as related camera.

Trigger Pop-up Window

Display the alarm window on Control Client to show the alarm details.

Display on Smart Wall

Display the alarm video of the alarm's related camera or display the specified public view on the smart wall. You can select the added smart wall and select which window to display the alarm.

- Alarm's Related Cameras: Display the video of the alarm's related cameras on the smart wall. You can select to display the video on which smart wall and which window and set the alarm video's stream type.
- **Public View:** A view enables you to save the window division and the correspondence between cameras and windows as favorites to quickly access the related cameras later. If you select **Public View**, when the alarm is triggered, the system can display the selected public view on the specified smart wall and users can view the video of the cameras predefined in the view.
- Wall Related to Graphic Card: Display the alarm video on the wall which adopts graphic card of the PC that running the Control Client to decode video.

- Wall Related to Decoding Device: Display the alarm video on the wall which adopts decoding device (namely the wall that related to the decoding device) to decode the video.
- Smart Wall No.: Select the No. of smart wall window to display the alarm video.
- Stream Type: Select the stream type of the alarm video displaying on the smart wall.
- **Stop Displaying Alarm:** Define when the system will stop displaying the alarm on the smart wall. The system can stop displaying alarm within specified seconds, or replace the original alarm when other alarm with higher alarm priority is triggered.

Restrict Alarm Handling Time

When the alarm is triggered, you need to handle the alarm on the Control Client. Enable this function to trigger user-defined event(s) or alarm output(s) if the alarm is not handled within the configured alarm handling time.

iNote

- Up to 16 user-defined events and alarm outputs can be set as the triggered event when handling alarm timed out.
- For configuring the user-defined event, refer to *Configure User-Defined Event* .

Trigger Audible Warning

Set the voice text for playing on the PC when alarm is triggered.

i Note

You should set voice engine as the alarm sound on System Settings page of Control Client.

Trigger User-Defined Event

Trigger the user-defined event(s) when alarm is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click **Add New** below to set new user-defined event(s).

i Note

- Up to 16 user-defined events can be selected as alarm linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .

7. Finish adding the alarm.

- Click **Add** to add the alarm and back to the alarm list page.
- Click Add and Continue to add the alarm and continue to add other alarm.

After adding the alarm, it displays on the alarm list, and you can view the alarm name and alarm status.

8. Optional: Perform the following operation(s) after adding the alarm.

Edit Alarm Click 🛛 in the Operation column to edit the alarn	n.
--------------------------------------------------------------	----

Copy to OtherYou can copy the current alarm's specified parameters to other addedAlarmsalarms for batch configuration.

	Click 🗹 in the Operation column to enter the alarm details page and click Copy to . Specify the settings of the source alarm, select target alarm(s), and click OK .
Delete Alarm	Click $ imes$ in the Operation column to delete the alarm.
Delete All Alarms	Click Delete All to delete all the added alarms.
Delete All Invalid Alarms	Click Delete All Invalid Items to delete all the invalid alarms in a batch.
Enable Alarm	Click \oslash in the Operation column to enable the alarm.
Enable All Alarms	Click Enable All to enable all the added alarms.
Disable Alarm	Click \ominus in the Operation column to disable the alarm.
Disable All Alarms	Click Disable All to disable all the added alarms.
Test Alarm	Click ③ to trigger this alarm automatically. You can test if the linkage actions work properly.

12.4.15 Add Alarm for HikCentral Professional Server

You can set alarm for the exception (including hardware exception and service exception) of the servers which have been installed with the HikCentral Professional services (such as SYS service, third-party device access gateway, NGINX service, keyboard proxy service, smart wall management service, etc.) and configure a series of linkage actions (e.g., triggering pop-up window on the Control Client) for notification when alarm is triggered.

Steps

- **1.** Click **Event & Alarm \rightarrow Alarm \rightarrow Add to enter the Add Alarm page.**
- 2. Set HikCentral Professional Server as the source type in the Source Type field.
- **3.** Select a specific triggering event and select **HikCentral Professional Server** in the **Source** list as the source for triggering the alarm.
- 4. Optional: Enter instructions for handling the alarm or enter remarks for the alarm.
- **5.** Set the required information.

Arming Schedule

The server is armed during the arming schedule and when an event occurs during the arming schedule, an alarm will be triggered to notify the user. Two types of arming schedule are provided:

- Schedule Template: Select an arming schedule template for the alarm to define when the alarm can be triggered. For setting customized template, refer to *Configure Arming Schedule Template*.
- Event Based: Specify a user-defined event or an alarm input as the start or end event of the arming schedule. When the user defined event or alarm input is triggered, the arming schedule will start or end. You can set the Auto-End Arming switch to on and set the specified time to automatically end arming for this alarm even if the end event does not occur.

iNote

For example, you have set event A as start event, event B as end event, and set the **Auto-End Arming in** as *60 s*, when event A occurs at T1, the alarm will be armed from T1 until event B occurs within 60 s (See the following figure Arming Schedule 1), or end arming 60 s later and event B doesn't occur (See the following figure Arming Schedule 2).





Figure 12-65 Arming Schedule 2

When A occurs at time T1, the alarm will be armed from T1, if A occurs again at time T2 but B doesn't occur, the alarm will be armed from T2 again.



Figure 12-66 Arming Schedule 3

Alarm Priority

Define the priority for the alarm. Priority can be used for filtering alarms in the Control Client. For details about setting alarm priority, refer to *Alarm Settings*.

Active Control

Active Control is used to avoid the same alarm being received frequently in a short time. You need to set the Threshold for Reactivation. For example, you have set the Threshold for

Reactivation as **30** s, the same alarms from the same camera within 30 s will be regarded as one alarm on the system.

The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.

Alarm Recipient

Select a user to send the alarm information to and the user can receive the alarm information when he/she logs in to HikCentral Professional via Control Client or Mobile Client.

6. Optional: Set the alarm's additional settings such as alarm related cameras and map, and alarm linkage actions

Related Camera

You can view the live video and play back the recorded video files when alarm occurs in the Alarm Center of the Control Client.

- Select the camera(s) to record the alarm video when the alarm is triggered.
- **Post-record:** Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.
- View Pre-Alarm Video: If the camera has recorded video files before the alarm, you can view the video recorded from periods preceding the alarm. Specify the number of seconds which you want to view the recorded video for before the alarm starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.
- Lock Video Files for: Set the days for protecting the video file from being overwritten.
- **Display Video by Default:** Set the video to be displayed by default on the Control Client when receiving the triggered alarm information, you can select the recorded video or the live video to be displayed.

iNote

- Make sure the related camera(s) have been configured with recording schedule.
- Up to 16 cameras can be set as related camera.

Trigger Pop-up Window

Display the alarm window on Control Client to show the alarm details and all the alarm related cameras' live videos and recorded video files when alarm occurs.

Display on Smart Wall

Display the alarm video of the alarm's related camera or display the specified public view on the smart wall. You can select the added smart wall and select which window to display the alarm.

- Alarm's Related Cameras: Display the video of the alarm's related cameras on the smart wall. You can select to display the video on which smart wall and which window and set the alarm video's stream type.
- **Public View:** A view enables you to save the window division and the correspondence between cameras and windows as favorites to quickly access the related cameras later. If you select **Public View**, when the alarm is triggered, the system can display the selected public view on the specified smart wall and users can view the video of the cameras predefined in the view.
- Wall Related to Graphic Card: Display the alarm video on the wall which adopts graphic card of the PC that running the Control Client to decode video.
- Wall Related to Decoding Device: Display the alarm video on the wall which adopts decoding device (namely the wall that related to the decoding device) to decode the video.
- Smart Wall No.: Select the No. of smart wall window to display the alarm video.
- Stream Type: Select the stream type of the alarm video displaying on the smart wall.
- **Stop Displaying Alarm:** Define when the system will stop displaying the alarm on the smart wall. The system can stop displaying alarm within specified seconds, or replace the original alarm when other alarm with higher alarm priority is triggered.

Restrict Alarm Handling Time

When the alarm is triggered, you need to handle the alarm on the Control Client. Enable this function to trigger user-defined event(s) or alarm output(s) if the alarm is not handled within the configured alarm handling time.

iNote

- Up to 16 user-defined events and alarm outputs can be set as the triggered event when handling alarm timed out.
- For details about configuring the user-defined event, refer to *Configure User-Defined Event*.

Trigger Audible Warning

Set the voice text for playing on the PC when alarm is triggered.

i Note

You should set voice engine as the alarm sound on System Settings page of Control Client.

Trigger User-Defined Event

Trigger the user-defined event(s) when alarm is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as alarm linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .
- **7.** Finish adding the alarm.
 - Click Add to add the alarm and back to the alarm list page.
 - Click Add and Continue to add the alarm and continue to add other alarm.

After adding the alarm, it displays on the alarm list, and you can view the alarm name and alarm status.

8. Perform the following operation(s) after adding the alarm.

Edit Alarm	Click 📝 in the Operation column to edit the alarm information.
Copy to Other Alarms	You can copy the current alarm's specified parameters to other added alarms for batch configuration.
	Click 🗹 in the Operation column to enter the alarm details page and click Copy to .
	Specify the settings of the source alarm, select target alarm(s), and click OK .
Delete Alarm	Click $ imes$ in the Operation column to delete the alarm.
Delete All Alarms	Click Delete All to delete all the added alarms.
Delete All Invalid Alarms	Click Delete All Invalid Items to delete all the invalid alarms in a batch.
Enable Alarm	Click \oslash in the Operation column to enable the alarm.
Enable All Alarms	Click Enable All to enable all the added alarms.
Disable Alarm	Click \ominus in the Operation column to disable the alarm.
Disable All Alarms	Click Disable All to disable all the added alarms.
Test Alarm	Click log to trigger this alarm automatically. You can test if the linkage actions work properly .

12.4.16 Add Alarm for User

You can set alarms for the users, including user login and user logout, and configure a series of linkage actions (e.g., triggering pop-up window on the Control Client) for notification when alarm is triggered.

Steps

- 1. Click Event & Alarm → Alarm → Add to enter the Add Alarm page.
- 2. Set User as the source type in the Source Type field.

- **3.** Select a specific triggering event and a specific user as the source for triggering the alarm.
- 4. Optional: Enter instructions for handling the alarm or enter remarks for the alarm.
- 5. Set the required information.

Arming Schedule

The user is armed during the arming schedule and when an event occurs during the arming schedule, an alarm will be triggered to notify other user. Two types of arming schedule are provided:

- Schedule Template: Select an arming schedule template for the alarm to define when the alarm can be triggered. For setting customized template, refer to *Configure Arming Schedule Template*.
- Event Based: Specify a user-defined event or an alarm input as the start or end event of the arming schedule. When the user defined event or alarm input is triggered, the arming schedule will start or end. You can set the **Auto-End Arming** switch to on and set the specified time to automatically end arming for this alarm even if the end event does not occur.

iNote

For example, you have set event A as start event, event B as end event, and set the **Auto-End Arming in** as *60 s*, when event A occurs at T1, the alarm will be armed from T1 until event B occurs within 60 s (See the following figure Arming Schedule 1), or end arming 60 s later and event B doesn't occur (See the following figure Arming Schedule 2).



Figure 12-67 Arming Schedule 1



Figure 12-68 Arming Schedule 2

When A occurs at time T1, the alarm will be armed from T1, if A occurs again at time T2 but B doesn't occur, the alarm will be armed from T2 again.



Figure 12-69 Arming Schedule 3

Alarm Priority

Define the priority for the alarm. Priority can be used for filtering alarms in the Control Client. For setting alarm priority, refer to *Alarm Settings*.

Active Control

Active Control is used to avoid the same alarm being received frequently in a short time. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30** *s*, the same alarms from the same camera within 30 s will be regarded as one alarm on the system.

The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.

Alarm Recipient

Select the user to send the alarm information to and the user can receive the alarm information when he/she logs in to HikCentral Professional via the Control Client or Mobile Client.

6. Optional: Set the alarm's additional settings such as alarm related cameras and map, and alarm linkage actions

Related Camera

You can view the live video and play back the recorded video files when alarm occurs in the Alarm Center of the Control Client.

- Select the camera(s) to record the alarm video when the alarm is triggered.
- **Post-record:** Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.
- View Pre-Alarm Video: If the camera has recorded video files before the alarm, you can view the video recorded from periods preceding the alarm. Specify the number of seconds which you want to view the recorded video for before the alarm starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.
- Lock Video Files for: Set the days for protecting the video file from being overwritten.
- **Display Video by Default:** Set the video to be displayed by default on the Control Client when receiving the triggered alarm information, you can select the recorded video or the live video to be displayed.

iNote

- Make sure the related camera(s) have been configured with recording schedule.
- Up to 16 cameras can be set as related camera.

Trigger Pop-up Window

Display the alarm window on the Control Client to show the alarm details and all the alarm related cameras' live videos and playback when alarm occurs.

Display on Smart Wall

Display the alarm video of the alarm's related camera or display the specified public view on the smart wall. You can select the added smart wall and select which window to display the alarm.

- Alarm's Related Cameras: Display the video of the alarm's related cameras on the smart wall. You can select to display the video on which smart wall and which window and set the alarm video's stream type.
- **Public View:** A view enables you to save the window division and the correspondence between cameras and windows as favorites to quickly access the related cameras later. If you select **Public View**, when the alarm is triggered, the system can display the selected public view on the specified smart wall and users can view the video of the cameras predefined in the view.
- Wall Related to Graphic Card: Display the alarm video on the wall which adopts graphic card of the PC that running the Control Client to decode video.
- Wall Related to Decoding Device: Display the alarm video on the wall which adopts decoding device (namely the wall that related to the decoding device) to decode the video.
- Smart Wall No.: Select the No. of smart wall window to display the alarm video.
- Stream Type: Select the stream type of the alarm video displaying on the smart wall.
- **Stop Displaying Alarm:** Define when the system will stop displaying the alarm on the smart wall. The system can stop displaying alarm within specified seconds, or replace the original alarm when other alarm with higher alarm priority is triggered.

Restrict Alarm Handling Time

When the alarm is triggered, you need to handle the alarm on the Control Client. Enable this function to trigger user-defined event(s) or alarm output(s) if the alarm is not handled within the configured alarm handling time.

iNote

- Up to 16 user-defined events and alarm outputs can be set as the triggered event when handling alarm timed out.
- For configuring the user-defined event, refer to Configure User-Defined Event .

Trigger Audible Warning

Set the voice text for playing on the PC when alarm is triggered.

iNote

You should set voice engine as the alarm sound on System Settings page of Control Client.

Trigger User-Defined Event

Trigger the user-defined event(s) when alarm is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as alarm linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .
- **7.** Finish adding the alarm.
 - Click Add to add the alarm and back to the alarm list page.
 - Click Add and Continue to add the alarm and continue to add other alarm.

The alarm will be displayed in the alarm list, and you can view the alarm name and alarm status.

8. Optional: Perform the following operation(s) after adding the alarm.

Edit Alarm	Click 📝 in the Operation column to edit the alarm information.
Copy to Other Alarms	You can copy the current alarm's specified parameters to other added alarms for batch configuration.
	Click 🗹 in the Operation column to enter the alarm details page and click Copy to .
	Specify the settings of the source alarm, select target alarm(s), and click OK .
Delete Alarm	Click $ imes$ in the Operation column to delete the alarm.
Delete All Alarms	Click Delete All to delete all the added alarms.
Delete All Invalid Alarms	Click Delete All Invalid Items to delete all the invalid alarms in a batch.
Enable Alarm	Click \oslash in the Operation column to enable the alarm.
Enable All Alarms	Click Enable All to enable all the added alarms.
Disable Alarm	Click \ominus in the Operation column to disable the alarm.
Disable All Alarms	Click Disable All to disable all the added alarms.
Test Alarm	Click @ to trigger this alarm automatically. You can test if the linkage actions work properly.

12.4.17 Add Alarm for User-Defined Event

You can set alarms for the added user-defined event and configure a series of linkage actions (e.g., triggering pop-up window on the Control Client) for notification when alarm is triggered.

Before You Start

You should have created at least one user-defined event. For details, refer to **Configure User-Defined Event** .

Steps

1. Click Event & Alarm → Alarm → Add to enter the Add Alarm page.

- 2. Set User-Defined Event as the source type in the Source Type field.
- 3. Select a specific user-defined event as the source for triggering the alarm.
- 4. Optional: Enter instructions for handling the alarm or enter remarks for the alarm.
- 5. Set the required parameters.

Arming Schedule

The event is armed during the arming schedule and the event occurred during the arming schedule will be triggered as alarm and notify the user. It provides two types of arming schedule:

- Schedule Template: Select an arming schedule template for the alarm to define when the alarm can be triggered. For setting customized template, refer to *Configure Arming Schedule Template*.
- Event Based: Specify a user-defined event or an alarm input as the start or end event of the arming schedule. When the user defined event or alarm input is triggered, the arming schedule will start or end. You can set the Auto-End Arming switch to on and set the specified time to automatically end arming for this alarm even if the end event does not occur.

iNote

For example, you have set event A as start event, event B as end event, and set the **Auto-End Arming in** as *60 s*, when event A occurs at T1, the alarm will be armed from T1 until event B occurs within 60 s (See the following figure Arming Schedule 1), or end arming 60 s later and event B doesn't occur (See the following figure Arming Schedule 2).





Figure 12-71 Arming Schedule 2

When A occurs at time T1, the alarm will be armed from T1, if A occurs again at time T2 but B doesn't occur, the alarm will be armed from T2 again.



Figure 12-72 Arming Schedule 3

Alarm Priority

Define the priority for the alarm. Priority can be used for filtering alarms in the Control Client. For setting alarm priority, refer to *Alarm Settings*.

Active Control

Active Control is used to avoid the same alarm being received frequently in a short time. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30** *s*, the same alarms from the same camera within 30 s will be regarded as one alarm on the system.

The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.

Alarm Recipient

Select a user to send the alarm information to and the user can receive the alarm information when he/she logs in to HikCentral Professional via the Control Client or Mobile Client.

6. Optional: Set the alarm's additional settings such as alarm related cameras and map, and alarm linkage actions

Related Camera

You can view the live video and play back the recorded video files when alarm occurs in the Alarm Center of the Control Client.

- Select the camera(s) to record the alarm video when the alarm is triggered.
- **Post-record:** Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.
- View Pre-Alarm Video: If the camera has recorded video files before the alarm, you can view the video recorded from periods preceding the alarm. Specify the number of seconds which you want to view the recorded video for before the alarm starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.
- Lock Video Files for: Set the days for protecting the video file from being overwritten.
- **Display Video by Default:** Set the video to be displayed by default on the Control Client when receiving the triggered alarm information, you can select the recorded video or the live video to be displayed.

iNote

- Make sure the related camera(s) have been configured with recording schedule.
- Up to 16 cameras can be set as related camera.

Trigger Pop-up Window

Display the alarm window on Control Client to show the alarm details and all the alarm related cameras' live videos and playback when alarm occurs.

Display on Smart Wall

Display the alarm video of the alarm's related camera or display the specified public view on the smart wall. You can select the added smart wall and select which window to display the alarm.

- Alarm's Related Cameras: Display the video of the alarm's related cameras on the smart wall. You can select to display the video on which smart wall and which window and set the alarm video's stream type.
- **Public View:** A view enables you to save the window division and the correspondence between cameras and windows as favorites to quickly access the related cameras later. If you select **Public View**, when the alarm is triggered, the system can display the selected public view on the specified smart wall and users can view the video of the cameras predefined in the view.
- Wall Related to Graphic Card: Display the alarm video on the wall which adopts graphic card of the PC that running the Control Client to decode video.
- Wall Related to Decoding Device: Display the alarm video on the wall which adopts decoding device (namely the wall that related to the decoding device) to decode the video.
- Smart Wall No.: Select the No. of smart wall window to display the alarm video.
- Stream Type: Select the stream type of the alarm video displaying on the smart wall.
- **Stop Displaying Alarm:** Define when the system will stop displaying the alarm on the smart wall. The system can stop displaying alarm within specified seconds, or replace the original alarm when other alarm with higher alarm priority is triggered.

Restrict Alarm Handling Time

When the alarm is triggered, you need to handle the alarm on the Control Client. Enable this function to trigger user-defined event(s) or alarm output(s) if the alarm is not handled within the configured alarm handling time.

iNote

- Up to 16 user-defined events and alarm outputs can be set as the triggered event when handling alarm timed out.
- For configuring the user-defined event, refer to Configure User-Defined Event .

Trigger Audible Warning

Set the voice text for playing on the PC when alarm is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

i Note

You should set voice engine as the alarm sound on System Settings page of Control Client.

Trigger User-Defined Event

Trigger the user-defined event(s) when alarm is triggered.

iNote

- Up to 16 user-defined events can be selected as alarm linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .
- **7.** Finish adding the alarm.
 - Click Add to add the alarm and back to the alarm list page.
 - Click Add and Continue to add the alarm and continue to add another alarm.

The alarm will be displayed on the alarm list, and you can view the alarm name and alarm status.

8. Optional: Perform the following operation(s) after adding the alarm.

Edit Alarm	Click 📝 in the Operation column to edit the alarm.
Copy to Other Alarms	You can copy the current alarm's specified parameters to other added alarms for batch configuration.
	Click 🗹 in the Operation column to enter the alarm details page and click Copy to .
	Specify the settings of the source alarm, select target alarm(s), and click OK .
Delete Alarm	Click $ imes$ in the Operation column to delete the alarm.
Delete All Alarms	Click Delete All to delete all the added alarms.
Delete All Invalid Alarms	Click Delete All Invalid Items to delete all the invalid alarms in a batch.
Enable Alarm	Click \oslash in the Operation column to enable the alarm.
Enable All Alarms	Click Enable All to enable all the added alarms.
Disable Alarm	Click \ominus in the Operation column to disable the alarm.
Disable All Alarms	Click Disable All to disable all the added alarms.
Test Alarm	Click log to trigger this alarm automatically. You can test if the linkage actions work properly as you want.

12.4.18 Add Alarm for Generic Event

You can set alarms for the added generic event and configure a series of linkage actions (e.g., triggering pop-up window on the Control Client) for notification when alarm is triggered.

Before You Start

You should have created at least one generic event. Refer to *Configure Generic Event* for details about creating generic event.

Steps

- 1. Click Event & Alarm → Alarm → Add on home page.
- 2. Select Generic Event as the source type in the Source Type field.
- **3.** Select a specific generic event as the source for triggering the alarm.
- 4. Optional: Enter instructions for handling the alarm or enter remarks for the alarm.
- 5. Set the required parameters.

Arming Schedule

The event is armed during the arming schedule and when an event occurs during the arming schedule, an alarm will be triggered to notify the user. Two types of arming schedule are provided:

- Schedule Template: Select an arming schedule template for the alarm to define when the alarm can be triggered. For setting customized template, refer to *Configure Arming Schedule Template*.
- Event Based: Specify a user-defined event or an alarm input as the start or end event of the arming schedule. When the user defined event or alarm input is triggered, the arming schedule will start or end. You can set the Auto-End Arming switch to on and set the specified time to automatically end arming for this alarm even if the end event does not occur.

iNote

For example, you have set event A as start event, event B as end event, and set the **Auto-End Arming in** as *60 s*, when event A occurs at T1, the alarm will be armed from T1 until event B occurs within 60 s (See the following figure Arming Schedule 1), or end arming 60 s later and event B doesn't occur (See the following figure Arming Schedule 2).





Figure 12-74 Arming Schedule 2

When A occurs at time T1, the alarm will be armed from T1, if A occurs again at time T2 but B doesn't occur, the alarm will be armed from T2 again.



Figure 12-75 Arming Schedule 3

Alarm Priority

Define the priority for the alarm. Priority can be used for filtering alarms in the Control Client. For details about setting alarm priority, refer to *Alarm Settings*.

Active Control

Active Control is used to avoid the same alarm being received frequently in a short time. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30** *s*, the same alarms from the same camera within 30 s will be regarded as one alarm on the system.

The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.

Alarm Recipient

Select a user to send the alarm information to and the user can receive the alarm information when he/she logs in to HikCentral Professional via the Control Client or Mobile Client.

6. Optional: Set the alarm's additional settings such as alarm related cameras and map, and alarm linkage actions

Related Camera

You can view the live video and play back the recorded video files when alarm occurs in the Alarm Center of the Control Client.

- Select the camera(s) to record the alarm video when the alarm is triggered.
- **Post-record:** Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.
- View Pre-Alarm Video: If the camera has recorded video files before the alarm, you can view the video recorded from periods preceding the alarm. Specify the number of seconds which you want to view the recorded video for before the alarm starts. For example, when someone opens a door, you can view the recorded video to see what happens right before the door opened.
- Lock Video Files for: Set the days for protecting the video file from being overwritten.
- **Display Video by Default:** Set the video to be displayed by default on the Control Client when receiving the triggered alarm information, you can select the recorded video or the live video to be displayed.

iNote

- Make sure the related camera(s) have been configured with recording schedule.
- Up to 16 cameras can be set as related camera.

Trigger Pop-up Window

Select to display the alarm window on the Control Client to show the alarm details when alarm occurs.

Display on Smart Wall

Display the alarm video of the alarm's related camera or display the specified public view on the smart wall. You can select the added smart wall and select which window to display the alarm.

- Alarm's Related Cameras: Display the video of the alarm's related cameras on the smart wall. You can select to display the video on which smart wall and which window and set the alarm video's stream type.
- **Public View:** A view enables you to save the window division and the correspondence between cameras and windows as favorites to quickly access the related cameras later. If you select **Public View**, when the alarm is triggered, the system can display the selected public view on the specified smart wall and users can view the video of the cameras predefined in the view.
- Wall Related to Graphic Card: Display the alarm video on the wall which adopts graphic card of the PC that running the Control Client to decode video.
- Wall Related to Decoding Device: Display the alarm video on the wall which adopts decoding device (namely the wall that related to the decoding device) to decode the video.
- Smart Wall No.: Select the No. of smart wall window to display the alarm video.
- Stream Type: Select the stream type of the alarm video displaying on the smart wall.
- **Stop Displaying Alarm:** Define when the system will stop displaying the alarm on the smart wall. The system can stop displaying alarm within specified seconds, or replace the original alarm when other alarm with higher alarm priority is triggered.

Restrict Alarm Handling Time

When the alarm is triggered, you need to handle the alarm on the Control Client. Enable this function to trigger user-defined event(s) or alarm output(s) if the alarm is not handled within the configured alarm handling time.

iNote

- Up to 16 user-defined events and alarm outputs can be set as the triggered event when handling alarm timed out.
- For details about configuring the user-defined event, refer to *Configure User-Defined Event*.

Trigger Audible Warning

Set the voice text for playing on the PC when alarm is triggered.

iNote

You should set voice engine as the alarm sound on System Settings page of Control Client.

Trigger User-Defined Event

Trigger the user-defined event(s) when alarm is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click **Add New** below to set new user-defined event(s).

iNote

- Up to 16 user-defined events can be selected as alarm linkage.
- For setting the user-defined event, refer to Configure User-Defined Event .
- **7.** Finish adding the alarm.
 - Click **Add** to add the alarm and go back to the alarm list page.
 - Click Add and Continue to add the alarm and continue to add other alarms.

The alarm will be displayed on the alarm list, and you can view the alarm name and alarm status.

8. Optional: Perform the following operation(s) after adding the alarm.

Edit Alarm	Click 📝 in the Operation column to edit the alarm.
Copy to Other Alarms	You can copy the current alarm's specified parameters to other added alarms for batch configuration.
	Click 🗹 in the Operation column to enter the alarm details page and click Copy to .
	Specify the settings of the source alarm, select target alarm(s), and click OK .
Delete Alarm	Click $ imes$ in the Operation column to delete the alarm.
Delete All Alarms	Click Delete All to delete all the added alarms.
Delete All Invalid Alarms	Click Delete All Invalid Items to delete all the invalid alarms in a batch.
Enable Alarm	Click \oslash in the Operation column to enable the alarm.
Enable All Alarms	Click Enable All to enable all the added alarms.
Disable Alarm	Click \ominus in the Operation column to disable the alarm.
Disable All Alarms	Click Disable All to disable all the added alarms.
Test Alarm	Click log to trigger this alarm automatically. You can test if the linkage actions work properly as you want.

12.4.19 Add Alarm for Remote Site

If the system is Central System with Remote Site Management module (based on the license you purchased), you can set site offline alarm for the added Remote Site and configure a series of linkage actions (e.g., triggering pop-up window on the Control Client) for notification when alarm is triggered.

Steps

iNote

You can set alarms for added Remote Site only when the system has Remote Site Management module.

- 1. Click Event & Alarm → Alarm → Add to enter the Add Alarm page.
- 2. Set Remote Site as the source type in the Source Type field.
- 3. Select a triggering event and a specific Remote Site as the source for triggering the alarm.
- 4. Optional: Enter instructions for handling the alarm or enter remarks for the alarm.
- **5.** Set the required information.

Arming Schedule

The resources on Remote Site are armed during the arming schedule and when an event occurs during the arming schedule, an alarm will be triggered to notify the user. Two types of arming schedule are provided:

- Schedule Template: Select an arming schedule template for the alarm to define when the alarm can be triggered. For setting customized template, refer to *Configure Arming Schedule Template*.
- Event Based: Specify a user-defined event or an alarm input as the start or end event of the arming schedule. When the user defined event or alarm input is triggered, the arming schedule will start or end. You can set the **Auto-End Arming** switch to on and set the specified time to automatically end arming for this alarm even if the end event does not occur.

iNote

For example, you have set event A as start event, event B as end event, and set the **Auto-End Arming in** as *60 s*, when event A occurs at T1, the alarm will be armed from T1 until event B occurs within 60 s (See the following figure Arming Schedule 1), or end arming 60 s later and event B doesn't occur (See the following figure Arming Schedule 2).



Figure 12-76 Arming Schedule 1



Figure 12-77 Arming Schedule 2

When A occurs at time T1, the alarm will be armed from T1, if A occurs again at time T2 but B doesn't occur, the alarm will be armed from T2 again.



Figure 12-78 Arming Schedule 3

Alarm Priority

Define the priority for the alarm. Priority can be used for filtering alarms in the Control Client. For setting alarm priority, refer to *Alarm Settings*.

Active Control

Active Control is used to avoid the same alarm being received frequently in a short time. You need to set the Threshold for Reactivation. For example, you have set the Threshold for Reactivation as **30** s, the same alarms from the same camera within 30 s will be regarded as one alarm on the system.

The Threshold for Reactivation is 15 s by default. You can set it from 15 s to 1800 s.

Alarm Recipient

Select a user to send the alarm information to and the user can receive the alarm information when he/she logs in to HikCentral Professional via the Control Client or Mobile Client.

6. Optional: Set the alarm's additional settings such as alarm related cameras and map, and alarm linkage actions

Related Camera

You can view the live video and play back the recorded video files when alarm occurs in the Alarm Center of the Control Client.

- Select the camera(s) to record the alarm video when the alarm is triggered.
- **Post-record:** Record video from periods following detected alarms. Specify the number of seconds which you want to record video for after the alarm stops.
- View Pre-Alarm Video: If the camera has recorded video files before the alarm, you can view the video recorded from periods preceding the alarm. Specify the number of seconds which you want to view the recorded video for before the alarm starts. For example, when

someone opens a door, you can view the recorded video to see what happens right before the door opened.

- Lock Video Files for: Set the days for protecting the video file from being overwritten.
- **Display Video by Default:** Set the video to be displayed by default on the Control Client when receiving the triggered alarm information, you can select the recorded video or the live video to be displayed.

iNote

- Make sure the related camera(s) have been configured with recording schedule.
- Up to 16 cameras can be set as related camera.

Related Map

 \sim

View the Remote Site's location on GIS map or when you checking alarm details in the Alarm Center and Alarm & Event Search of the Control Client.

	٠			
			- 4	L
	_	N	n	ге
\sim	\sim		-	

You should locate the map on the GIS map first. For details, refer to Locate Sites on Map .

Trigger Pop-up Window

Display the alarm window on Control Client to show the alarm details.

Display on Smart Wall

Display the alarm video of the alarm's related camera or display the specified public view on the smart wall. You can select the added smart wall and select which window to display the alarm.

- Alarm's Related Cameras: Display the video of the alarm's related cameras on the smart wall. You can select to display the video on which smart wall and which window and set the alarm video's stream type.
- **Public View:** A view enables you to save the window division and the correspondence between cameras and windows as favorites to quickly access the related cameras later. If you select **Public View**, when the alarm is triggered, the system can display the selected public view on the specified smart wall and users can view the video of the cameras predefined in the view.
- Wall Related to Graphic Card: Display the alarm video on the wall which adopts graphic card of the PC that running the Control Client to decode video.
- Wall Related to Decoding Device: Display the alarm video on the wall which adopts decoding device (namely the wall that related to the decoding device) to decode the video.
- Smart Wall No.: Select the No. of smart wall window to display the alarm video.
- Stream Type: Select the stream type of the alarm video displaying on the smart wall.
- **Stop Displaying Alarm:** Define when the system will stop displaying the alarm on the smart wall. The system can stop displaying alarm within specified seconds, or replace the original alarm when other alarm with higher alarm priority is triggered.

Restrict Alarm Handling Time

When the alarm is triggered, you need to handle the alarm on the Control Client. Enable this function to trigger user-defined event(s) or alarm output(s) if the alarm is not handled within the configured alarm handling time.



- Up to 16 user-defined events and alarm outputs can be set as the triggered event when handling alarm timed out.
- For configuring the user-defined event, refer to Configure User-Defined Event .

Trigger Audible Warning

Set the voice text for playing on the PC when alarm is triggered.

iNote

You should set voice engine as the alarm sound on System Settings page of Control Client.

Trigger User-Defined Event

Trigger the user-defined event(s) when alarm is triggered.

You can select the pre-defined user-defined event(s) in the event list.

You can also click Add New below to set new user-defined event(s).

i Note

- Up to 16 user-defined events can be selected as alarm linkage.
- For setting the user-defined event, refer to *Configure User-Defined Event* .

7. Finish adding the alarm.

- Click Add to add the alarm and go back to the alarm list page.
- Click Add and Continue to add the alarm and continue to add other alarms.

The alarm will be displayed on the alarm list, and you can view the alarm name and alarm status.

8. Optional: Perform the following operation(s) after adding the alarm.

Edit Alarm	Click 🕜 in the Operation column to edit the alarm.
Copy to Other Alarms	You can copy the current alarm's specified parameters to other added alarms for batch configuration.
	Click 🗹 in the Operation column to enter the alarm details page and click Copy to .
	Specify the settings of the source alarm, select target alarm(s), and click OK .
Delete Alarm	Click $ imes$ in the Operation column to delete the alarm.
Delete All Alarms	Click Delete All to delete all the added alarms.

Delete All Invalid Alarms	Click Delete All Invalid Items to delete all the invalid alarms in a batch.
Enable Alarm	Click \odot in the Operation column to enable the alarm.
Enable All Alarms	Click Enable All to enable all the added alarms.
Disable Alarm	Click \ominus in the Operation column to disable the alarm.
Disable All Alarms	Click Disable All to disable all the added alarms.
Test Alarm	Click @ to trigger this alarm automatically. You can test if the linkage actions work properly.

12.5 Configure Arming Schedule Template

When setting event and alarm, you can select the predefined arming schedule template to define when the event or alarm will be triggered. The system predefines three default arming schedule templates: All-day Template, Weekday Template, and Weekend Template. You can also add a customized template according to actual needs.

Steps

- 1. Click System on the home page.
- 2. Click Schedule → Arming Schedule Template on the left.
- 3. Click Add to enter the adding arming schedule page.



Figure 12-79 Add Arming Schedule Template Page

4. Set the required information.

Name

Set a name for the template.

Copy from

Optionally, you can select to copy the settings from other defined templates.

5. Click Arming Duration and drag on the time bar to set the time periods.

iNote

Up to 4 time periods can be set for each day.

- 6. Optional: Click Erase and click on the drawn time period to clear the corresponding time period.
- 7. Finish adding the arming schedule template.
 - Click Add to add the template and go back to the arming schedule template list page.
 - Click Add and Continue to add the template and continue to add other template.

The arming schedule template will be displayed on the arming schedule template list.

8. Optional: Perform the following operations after adding the arming schedule template.

View Template Details	Click the template to view its details.
Edit Template	Click 🗹 in the Operation column to edit template details.
Delete Template	Click $ imes$ in the Operation column to delete the template.
Delete All Templates	Click Delete All to delete all the added templates (except the default templates). If the added templates have been used by events or alarms, you will be asked whether or not to replace the schedule.

Chapter 13 Manage Map

Two types of map are available: GIS map and E-map. On the GIS map, you can set and view the current site, Remote Site, and element's geographic location. On the e-map, which is a static map, you can set and view the geographic locations of the installed cameras, alarm inputs, and alarm outputs, etc. After configuring the map via Web Client, you can view the live video and playback of the resources added to the map via Control Client, and get a notification message from the map via Control Client when an alarm is triggered.

With GIS map, you can see the geographic locations of your surveillance system. This type of map uses a geographic information system to accurately show all the hot spots' (resources (e.g., camera, alarm input) placed on the map are called hot spots) geographic locations in the real world. GIS map lets you view and access cameras at multiple locations around the world in a geographically correct way. If the resources locate in multiple locations (e.g., different cities, different countries), GIS map can give you a single view to show them all and help you quickly go to each location to view video from the cameras. With the hot region, you can link to the e-map to view the detailed monitoring scenario, for example, the monitoring scenario of a building.

E-map is a static image (it does not have to be geographical maps, although they often are. Depending on your organization's needs, photos and other kinds of image files can also be used as e-maps) which gives you a visual overview of the locations and distributions of the hot spots (resources (e.g., camera, alarm input) placed on the map are called hot spots). You can see the physical locations of the cameras, alarm inputs, and alarm outputs, etc., and in what direction the cameras are pointing. With the function of hot region, e-maps can be organized into hierarchies to navigate from large perspectives to detailed perspectives, e.g., from floor level to room level.

After configuring the e-map via Web Client, you can view the live video and playback of the elements via Control Client, and get a notification message from the map via Control Client when an alarm is triggered.

13.1 Set GIS Map and Icons

This page allows you to enable GIS (Geographic Information System) map function to display the GIS map on the Web Client and Control Client, so that the geographic location of the resources (such as current site, Remote Sites, cameras) can be shown on the map.

Perform this task for setting GIS map API URL and customized icons.

Steps

- **1.** Click **System** \rightarrow **Normal** \rightarrow **Map** to enter the map settings page.
- **2.** Set the GIS Map.
 - 1) Set the **GIS Map** switch to ON to enable the GIS map function.
 - 2) Input the GIS map API URL.

iNote

- The Google map API is supported currently.
- Google Maps are provided by Google Inc. (Hereinafter referred to as "Google"). We only provides you the URLs to use Google Maps. You shall apply by yourself for the use of Google Maps from Google. You shall comply with Google terms and provide certain information to Google if required.
- **3.** Set the customized icons.
 - 1) Select hot region or hot spot as the icon type in the **Type** field.
 - 2) Set the icon size, including width (px) and height (px).
 - 3) **Optional:** Click the icon 👄 to cancel the aspect ratio.

iNote

By default, the aspect ratio is maintained.

4) Click Add in the Picture field to select a picture file from the local path.

iNote

The icon picture format can only be PNG, JPG, or JPEG.

The added pictures display as thumbnail preview in the Picture field.

4. Click Save.

Result

You can view the GIS map in the Logical View page and perform the following operations in the map area.

Filter	Click \bigotimes and select the object type you want to show on the map.
Full Screen	Click Solution to show the map in full-screen mode.
Zoom In/Out	Scroll the mouse wheel or click $+ / -$ to zoom in or zoom out the map.
Adjust Map Area	Click-and-drag the map to adjust the map area for view.

13.2 Link E-Map to Area

You can add and link e-maps to the area so that the elements assigned to the area can be added to e-map.

Perform the task when you want to link e-map to area.

Steps

1. Click Logical View.

2. Three ways are available for adding e-map.

	Add E-Map When Adding Area	 a. Click + on the area list panel. b. Set the parameters for adding area. c. Set the Related Map switch to ON. d. Hover the mouse over the Map field and link a map for the area. You can click Upload Picture and select a picture from local PC as the emap. Or click Existing Map and select an existing map for linking to current area. e. Optional: Repeat the previous step to add more e-maps for the area.
	Add E-Map When Editing Area	 a. Select a map and click is on the area list panel to enter the area editing page. b. Edit the area settings as desired. c. Set the Related Map switch to ON if it is OFF. d. Hover the mouse over the empty Map field and link a map for the area. You can click Upload Picture and select a picture from local PC as the empty. Or click Existing Map and select an existing map for linking to current area. e. Optional: Repeat the previous step to add more e-maps for the area.
Directly Link Map to Existing You can adopt this way		iNote
		You can adopt this way when the GIS map is not enabled.
2 0	Area	 a. Click in to show the map area. b. Click Relate Map for adding and linking map. c. Select the areas for linking e-maps. d. Hover the mouse over the Map field and link a map for the area. You can click Upload Picture and select a picture from local PC as the e-map. Or click Existing Map and select an existing map for linking to current area. e. Optional: Repeat the previous step to add more e-maps for the area.
3. 0	-	
	Edit Picture	Click and change a picture.
	Edit Map Nam	
Unlink Map 4. Click Save to confin 5. Optional: Perform		Click to remove the map or cancel the linkage between the map and area. rm the settings. the following operations after adding map in the map area.
	Filter	Click \odot and select the object type you want to show on the map.
	Full Screen	Click 💱 to show the map in full-screen mode.
	Zoom In/Out	Scroll the mouse wheel or click $+$ / $-$ to zoom in or zoom out the map.

Adjust MapDrag the map or the red window in the lower part to adjust the map areaAreafor view.

13.3 Search Locations

You can search the locations on the GIS map.

Before You Start

You should enable the GIS Map function and set the GIS Map API URL properly. For details, refer to **Set GIS Map and Icons** .

Perform this task when you need to search the locations on the GIS map.

Steps

- 1. Click Logical View on home page.
- 2. Click 🖽 to show the map area.
- **3.** Enter a location name you want to search in the *Q* field. The related locations display in the search field.
- **4.** Click to select the location you want to locate from the related locations.

Result

The location will be located on the map.

13.4 Locate Sites on Map

You can set the current site's and added Remote Site's location to the GIS map.

Before You Start

You should enable the GIS Map function and set the GIS Map API URL properly. For details, refer to **Set GIS Map and Icons**.

Perform this task when you need to set the sites' location to the GIS map.

Steps

- 1. Click Logical View on home page.
- **2.** Click (1) to show the map area.
- **3.** Select current site or Remote Site from the drop-down list on area list panel.

iNote

The icon 💿 indicates that the site is current site, and 💽 indicates Remote Site.

4. Click **Locate** on the GIS map area.

iNote

The **Locate** button is only available when the site is not located on GIS map.

5. Operate the GIS map to find the location of the site and click on the map to locate the site on the map.

iNote

You can use you mouse to drag, zoom in, and zoom out the map.

After successfully located, the site icon will be displayed at the location you select.

6. Optional: Perform the following operations after adding the site to the GIS map.

View Site Details	Click the site icon to view the site details, including site address, location, and remark information
Edit	Click the site icon and click Edit to edit the site information.
Delete	Click the site icon and click Delete to remove the site from the map.
View Site's Resources	Click the site icon and click View Site's Resources to view the resources of the site.

13.5 Add Hot Spot

You can add elements (e.g., cameras, access points, alarm inputs, etc.) as the hot spot and place the hot spot on the e-map or GIS map. Then you can view the elements on the map and perform further operations via Control Client. For example, you can get the live view, actual access points, and alarm information of the surveillance scenarios, lock access point, unlock access point, and so on.

Before You Start

A map should have been added. Refer to *Link E-Map to Area* or *Set GIS Map and Icons* for details about adding e-map or GIS map.

Steps

- 1. Click Logical View on the home page.
- 2. Select current site from the drop-down list on area list panel.

iNote

The icon (a) indicates that the site is current site, you can only add current site's elements as the hot spots.

3. Three ways are available for adding hot spot.

Add Hot	 Click the tab to enter the corresponding element page.
Spot When	b. Click $+$ in the element area.
Adding	c. Set the required parameters for adding the element to area.
Element to Area	i Note For details, refer to Add Element to Area .

- e. In the map area, click to select a map to add the hot spot to.
- f. Click Add and you can see the adding element result in the pop-up dialog.

Drag Element to Map	I Note You can adopt this way when the element is added to the area but not added to map.
	 a. Click the tab to enter the corresponding element page. b. Optional: Click to select an area so that the elements of this area display. c. Click is to show the map area. d. In the map area, click to select a map to add the hot spot to. e. Drag an element with Added to Map as No to the map.
Add Hot Spot When Editing the Element	Note You can adopt this way when the element is added to the area but not added to map.
4. Optional: Perform	 a. Click the tab to enter the corresponding element page. b. Optional: Click to select an area so that the elements of this area can be displayed. c. Click the Name field of the element with Added to Map as No. d. Set the Add to Map switch to ON. e. In the map area, click to select a map to add the hot spot to. f. Configure the required settings for the hot spot. g. Click Save. the following operations after adding the hot spot.
Adjust Hot Spot Location	Drag the added hot spot on the map to the desired locations.
Edit Hot Spot	Click the added hot spot icon on the map and click Edit to edit the detailed information (such as setting GPS location (only available when parent map is GIS map, and refer to Search Locations for details), and selecting icon style). For camera hot spot, you can also edit the detection area, including radius, direction and angle, or drag the displayed sector on the map to directly
Delete Hot Spot	adjust the detection area. Click the hot spot icon on the map and click Delete to remove the hot spot from the map.

13.6 Add Hot Region

The hot region function links a map to another map. When you add a map to another map as a hot region, an icon of the link to the added map is shown on the main map. The added map is called child map while the map to which you add the hot region is the parent map.

Before You Start

At least 2 maps should have been added. Refer to *Link E-Map to Area* or *Set GIS Map and Icons* for details about adding maps.

Perform this task when you want to link a map to another map for convenient access.

Steps

- 1. Click Logical View on the home page.
- 2. Select a current site from the drop-down list on area list panel.

iNote

The icon 🐼 indicates that the site is current site, you can only add hot region for current site.

- **3.** Click (1) to show the map area.
- 4. Select an added e-map or GIS map as the parent map.
- **5.** Click □ on the map area and click on the spot where you want to place the hot region. A dialog for setting child map appears.
- 6. Select a child map on the panel to set it as the hot region of the current map.
- 7. Click Save on dialog to add the hot region.

The added hot region icon will be displayed on the parent map.

8. Optional: Perform the following operation(s) after adding the hot region.

Adjust Hot Region Location	Drag the added hot region on the parent map to the desired locations.
Edit Hot Region	Click the added hot region icon on the map to view and edit the detailed information, including GPS location (only available when parent map is GIS map, and refer to <i>Search Locations</i> for details), hot region name, icon style, name color, and remarks on the appearing dialog.
Delete Hot Region	Click the hot region icon on the map and click Delete on the appearing dialog to delete the hot region.

13.7 Add Label

You can add labels with description on the map.

Before You Start

At least one map should have been added. Refer to *Link E-Map to Area* or *Set GIS Map and Icons* for details about adding e-map or GIS map.

Perform this task when you need to add label on the map.

Steps

- 1. Click Logical View on the home page.
- 2. Select current site from the drop-down list on area list panel.

iNote

The icon 🐼 indicates that the site is current site, you can only add label for current site.

- **3.** Click is to show the map area.
- 4. Select a map to add label to.
- **5.** Click \bowtie on the map area and click on the map where you want to place the label.
- 6. Customize a name for the label, and you can input content for the label as desired.
- 7. Click Save.

The added label icon will be displayed on the map.

8. Optional: Perform the following operation(s) after adding the label.

Adjust Label Location	Drag the added label on the map to the desired locations.
Edit Label	Click the added label icon on the map to view and edit the detailed information, including name and content on the appearing dialog.
Delete Label	Click the label icon on the map and click Delete on the appearing dialog to delete the label.

Chapter 14 Manage Vehicle

You can import the vehicle information according to the pre-defined template and you can add the vehicle information manually. The added vehicle information can be used for ANPR alarm when adding the alarm.

iNote

Refer to Add Alarm for ANPR Camera for detailed information about adding alarm.

14.1 Add Vehicle List

To add vehicle information to the system, you should create the vehicle list.

Steps

iNote

Up to 100 vehicle lists can be added to the system.

- 1. Click Vehicle to enter the Vehicle Management page.
- 2. Click + on the left to open the adding vehicle list window.

*List Name		
Import Vehicle Plate Number		000
	Download Template	
	Replace Repeated License Plate Num	ber
		Add

Figure 14-1 Adding Vehicle List Window

- **3.** Set a descriptive name for the vehicle list.
- **4. Optional:** Click **Download Template** and import vehicle information in a batch, or you can import vehicle information when checking vehicle list details. Refer to *Add Vehicle Information* for details.
- **5. Optional:** Check **Replace Repeated License Plate Number** to replace the existing one with the new vehicle information if the license plate number for importing already exists in other vehicle list. Otherwise, the original vehicle information will be reserved.
- 6. Click Add.

The added vehicle list will be displayed on the left of the Vehicle page.

7. Optional: Perform the following operations on the vehicle list area.

Edit Vehicle List	Click \square on the vehicle list area to edit the vehicle list name.
Delete Vehicle List	Select a vehicle list and click in to delete it, or press Ctrl on your keyboard and select multiple vehicle lists and then click in to delete the vehicle lists in a batch.

14.2 Add Vehicle Information

After adding the vehicle list, you can check the vehicle information in the vehicle list or you can add the vehicle information to the list.

The added vehicle information can be used for ANPR alarm when adding the alarm.

You can import the vehicle information in batch or you can add the vehicle information manually.

iNote

Each vehicle list can contain up to 5,000 vehicles.

14.2.1 Import Vehicle Information in a Batch

You can import multiple vehicle information at one time.

Before You Start

You should add the vehicle list before you can add the vehicle information. Refer to *Add Vehicle List* for details.

Steps

i Note

Each vehicle list can contain up to 5,000 vehicles.

- 1. Click Vehicle to enter the Vehicle Management page.
- 2. Select a vehicle list.
- **3.** Click **Import** to open the Import window.

*Select File		000
	Download Template	
	Replace Repeated License Plate Number	
		mport

Figure 14-2 Import Window
- **4.** Click **Download Template** on the Import window to save the template file (CSV format) to your PC.
- 5. Open the downloaded template file.
- 6. Enter the required vehicle information in the corresponding column.
- 7. Click and select the template file.
- 8. Optional: Check Replace Repeated License Plate Number to replace the existing one with the new vehicle information if the template contains the license plate number which already exists in the current or other vehicle list. Otherwise, the original vehicle information will be reserved.
- 9. Click Import.
- **10. Optional:** Perform the following operations after importing the vehicle information.

Edit Vehicle Information	Click the plate number in License Plate Number column to edit the vehicle information.
Edit Effective Period	Select the vehicle(s) and click Edit Effective Period to edit the effective period of the selected vehicle(s) in a batch.
	If the license plate number is expired, it cannot trigger an event or alarm when license plate number matched if license plate number matched event/alarm is configured.
Delete Vehicle Information	Check the vehicle information and click Delete to delete the selected vehicle information.
Export Vehicle Information	Click Export All to save the vehicle information of the list (CSV file) to your PC, which can be imported to other vehicle list.

14.2.2 Manually Add Vehicle Information

You can add single vehicle information manually.

Before You Start

You should add the vehicle list before you can add the vehicle information. Refer to *Add Vehicle List* for details.

Steps

- 1. Click Vehicle to enter the Vehicle Management page.
- 2. Select a vehicle list.
- 3. Click Add to enter the adding vehicle page.

⊖ Add Vehicle		
Basic Information		
* License Plate Number		
Effective Period	ri=i, Etti	
Owner		
Phone		
1 Undercarriage Picture		
	Add Add and Co	ontinue Cancel

Figure 14-3 Add Vehicle

- 4. Enter the license plate number.
- 5. Optional: Set a effective period for this vehicle.

If the license plate number is expired, it cannot trigger an event or alarm when license plate number matched if license plate number matched event/alarm is configured.

- 6. Optional: Enter the vehicle owner information including name and phone number.
- 7. Optional: Upload an undercarriage picture for this vehicle.
 - 1) Move the cursor to the image area and click **Upload**.
 - 2) In the pop-up window, select the undercarriage picture to upload it.

After uploading an undercarriage picture, you can view both the current vehicle's captured undercarriage picture and this uploaded picture for comparison on the Control Client.

- 8. Finish adding the vehicle information.
 - Click Add to add the vehicle information and back to the vehicle list page.
 - Click Add and Continue to save the settings and continue to add other vehicles.

iNote

If the license plate number already exists (in current vehicle list or other vehicle lists), a prompt box will be displayed and you can select whether to replace the existing vehicle with a new one.

9. Optional: Perform the following operations after importing the vehicle information.

Edit Vehicle Information	Click the plate number in License Plate Number column to edit the vehicle information
Edit Effective Period	Select the vehicle(s) and click Edit Effective Period to edit the effective period of the selected vehicle(s) in a batch.

	If the license plate number is expired, it cannot trigger an event or alarm when license plate number matched if license plate number matched event/alarm is configured.
Delete Vehicle Information	Check the vehicle information and click Delete to delete the selected vehicle information
Export Vehicle Information	Click Export All to save the vehicle information of the list (CSV file) to your PC, which can be imported to other vehicle list.

Chapter 15 Manage Person List

You can add person information to the system for further operations such as access control (adding the person to access group), face comparison (adding the person to face comparison group), time and attendance (adding the person to attendance group), etc. After adding the persons, you can edit and delete the person information if needed.

15.1 Add a Person

You can add the person information to the system one by one.

Steps

1.	Click Person	→ Person	List and	click Add	to enter	the adding	person page.
----	--------------	----------	----------	-----------	----------	------------	--------------

Add Person				
Basic Information				
* ID	3926654034			
* First Name				
* Last Name				
Gender	 Male 			
	 Female 			
	 Unknown 			
Email				
Phone				
Remark				
Additional Information				
No availab	le additional information	item. Configuration		
Face Comparison				
i Face Comparison Group	Search			
	🗆 🚉 liu			
	🗌 🤽 liu22			
	Add	Add and Continue	Cancel	

Figure 15-1 Add a Person

2. Set the person basic information.

ID

The default ID is generated by the system. You can edit it if needed.

i Note

- It should contain 1 to 16 characters and the first character cannot be 0.
- If the person is police officer or security guard with body cameras, make sure the person ID is same with the police ID configured on the body camera.

Person Picture

Upload a person's face picture. You can click **Take a Picture** to use the PC's webcam to take a picture. Or click **Upload Picture** to select a picture from your PC.

iNote

It is recommended that the face in the picture should be in full-face view directly facing the camera, without a hat or head covering.

3. Optional: Set the person's additional information.

iNote

You can customize these items according to actual needs as the person's additional information. For details, refer to *Custom Additional Information*.

4. Optional: Add the person to the existing face comparison group(s) which will be used for face recognition and comparison.

iNote

After adding the person to the face comparison group, you should apply the face comparison group to a device to make the settings effective. For details about applying face comparison group to the device, refer to **Apply Face Comparison Group to Device**.

5. Optional: Set the access control and time & attendance information.

Effective Period

Set the effective period for the person in access control application and time & attendance application. For example, if the person is a visitor, his/her effective period may be short and temporary.

Access Group

Add the person to the existing access group(s) which can be linked with access level(s). The linkage of access level and access group defines the access permission that which person(s) can access which access point(s) in the authorized period.

You can click the access group name to view its linked access levels.

Move the cursor to the access level to view its access point(s) and access schedule.

iNote

You can click Add New to add a new access group. For details, refer to Add Access Group .

Super User

If the person is set as a super user, he/she will be exempted from remaining locked (credential failed) restrictions, all anti-passback rules, and first card authorization.

	•	
~		Note

For details about setting these functions, refer to Edit Access Point for Current Site .

Extended Access

When the person accessing door, grant this person more time to pass through doors which have been configured with extended open duration. Use this function for the persons with reduced mobility.



You should set the door's extended open duration in Logical View. For details, refer to *Edit Access Point for Current Site* .

Attendance Group

Add the person to the existing attendance group if your need to monitor the person's working hours and absenteeism.

iNote

You can click **Add New** to add a new attendance group. For details, refer to **Add Attendance Group**.

iNote

The extended access and super user functions cannot be enabled concurrently.

6. Set the person's credential information, including PIN, face credential, card number, fingerprint, and duress credentials.

PIN Code

The PIN code must be used after card or fingerprint when accessing. It cannot be used independently.

iNote

It should contain 1 to 8 digits.

Set Profile as Face Credential

If you want to use turnstile with face recognition function, you need to set the person's profile picture as her\his face credential so that the person can scan her\his face on the face

recognition terminal when he/she wants to access the turnstile. Make sure you have uploaded a picture as the person profile.

Card

Issue a card to the person to assign the card number to the person. You can enter the card number manually, or swipe a card on the card enrollment station or card reader to get the card number, and then issue it to the person.

- a. Click + in the **Card** field.
- b. Place the card that you want to issue to this person on the card enrollment station or on the card reader and the card number will be read automatically. Or you can enter the card number manually

iNote

If the card enrollment station is not detected or the issuing configuration is incorrect, you can click **Configuration** to set the issuing mode. For details, refer to **Set Card Issuing Parameters**.



Figure 15-2 Card Number Read

iNote

Up to 5 cards can be issued to one person.

Fingerprint

System provides two ways to collect fingerprint: via a USB fingerprint recorder connected to the PC running the Web Client or via a fingerprint and card reader of the access control device managed in the system.

Click **Configuration** to set the collection mode as **USB Fingerprint Recorder** or **Fingerprint and Card Reader**.

USB Fingerprint Recorder

Collect fingerprint via a USB fingerprint recorder connected to the PC running the Web Client, which is plug-and-play and doesn't require any settings. This mode is suitable for face-to-face scenario that the person and the system administrator are in the same location.

After connecting the fingerprint recorder to your PC, click +, place and lift your fingerprint on the recorder following the prompts and it will collect your fingerprint automatically.

Fingerprint and Card Reader

Collect fingerprint via the fingerprint scanner of an access control device which is managed in the system. This mode is suitable for non-face-to-face scenario that the person and the system administrator are in different locations.

Select an access control device from the managed device list and select a fingerprint and card reader.

Click +, place and lift your fingerprint on the selected fingerprint and card reader following the prompts and it will collect your fingerprint automatically.



Figure 15-3 Fingerprint Recorded

iNote

Up to 10 fingerprints can be added to one person.

Credential under Duress

Set the credentials (card number and fingerprint) so that when you are under duress, you can swipe the card or scan the fingerprint configured here. The door will be unlocked and the Control Client will receive a duress alarm (if configured) to notify the security personnel.

iNote

When the person accesses with credentials under duress, he/she cannot be exempted from remaining locked (credential failed) restrictions, all anti-passback rules, and first card authorization. Extended access is not allowed as well.

7. Optional: Add the person to the existing dock station group(s) and set the login password which is used for the dock station(s) in the group to log into the body cameras.

iNote

- You can click Add New to add a new dock station group. For details, refer to Add Dock Station Group.
- By default, the login password is 123456.

The videos and pictures stored on the person's body camera can be copied to the person's linked dock station(s).

8. Finish adding the person.

- Click Add to add the person and return the person list.
- Click Add and Continue to add the person and continue to add other persons.

The person will be displayed in the person list and you can view the details.

9. Optional: After adding the person, you can do one or more of the followings:

Edit Person	Click the person name to edit the person details.
Delete Person	Select the person(s) and click Delete to delete.
Delete All Persons	Click <a> near Delete button and click Delete All to delete all the persons in the person list.
Export Added Person Information	Click Export All to export all the added person information and you can save the file in your PC. For data security, you are required to set a password before exporting which is required when decompressing the downloaded ZIP file.

15.2 Batch Add Persons by Importing Person Information File

You can add the information of multiple persons to the system by importing an excel file with person information. Also, by entering the access group of multiple persons in the excel file, you can add them to a group in a batch.

Steps

1. Click Person → Person List → Import → Import an Excel File .



Figure 15-4 Import Person Information

- 2. Click Download Template to save the template file in your PC.
- 3. In the downloaded template, enter the person information following the rules in the template.
- 4. Click Import → Import an Excel File to enter the Import Person Information page.
- 5. Select the excel file with the person information
- 6. Click Import to start importing.

iNote

- If the imported person ID is the same with an existing person in the list, it will replace the existing person's information.
- The importing cannot stop once started.
- You can issue cards to persons in a batch by importing the excel file with card No. entered.

The importing progress shows and you can check the results.

7. Optional: Perform the following operation(s).

Edit Person	Click the person name to edit the person details.
Delete Person	Select one or more person and click Delete to delete the person(s).
Export Added Person Information	Click Export All to export all the added person information and you can save the file in your PC. For data security, you are required to set a password before exporting which is required when decompressing the downloaded ZIP file.
Filter Person	Click γ to filter persons by setting conditions, after which click Export All to export information of the filtered persons.

15.3 Import Domain Persons

You can import the users in the AD domain in a batch to the system as persons. After importing the person information (including person name and account name) in the AD domain, you can set other information for the persons, such as credentials.

Before You Start

You should configure the active directory settings. See Set Active Directory for details.

Steps

- **1.** Click **Person** \rightarrow **Person List** to enter the Person List Management page.
- 2. Click Import → Import Domain Persons to enter the following page.

Import Domain	Persons			
Basic Information				
1 Importing Mode	Person			
	O Group			
* Select Domain Person	Organizational Unit	C	Domain Person	
	Search	Q	Search	Q
	~ #	^	Person Name	Name
		۰.		A
	> =			
	> 34			
	> #			1
	> #			
	> 표 > 표			*
	> AA . M	-	Total 17 Record(s) 100 -	$ \langle \langle \rangle \rangle 1 /1 $ Go
Face Comparison				
1 Face Comparison Group	Search			
	~ A II			
	<u>.</u>			
	🗆 🚉 liu			
	Add New			
Access Control and Time & At	tendance			
	Add and Continue	Ca	Cancel	

Figure 15-5 Import Domain Persons

3. Select the importing mode. **Person**

Import the specified persons. Select the organization unit and select the persons under the organization unit which are displayed in the Domain Person list on the right. It will synchronize person information based on each person.

Group

Import all the persons in the organization unit. It will synchronize person information based on each group.

4. Add the persons to the existing face comparison group(s) which will be used for face recognition and comparison.

iNote

After adding the persons to the face comparison group, you should apply the face comparison group to a device to make the settings effective. For details about applying face comparison group to the device, refer to **Apply Face Comparison Group to Device**.

5. Set the access control and time & attendance information.

Effective Period

Set the effective period for the person in access control application and time & attendance application. For example, if the person is a visitor, his/her effective period may be short and temporary.

Access Group

Add the persons to the existing access group(s) which can be linked with access level(s). The linkage of access level and access group defines the access permission that which person(s) can access which access point(s) in the authorized period.

You can click the access group name to view its linked access levels.

Move the cursor to the access level to view its access point(s) and access schedule.

iNote

You can click Add New to add a new access group. For details, refer to Add Access Group .

Super User

If the persons are set as super users, they will be exempted from remaining locked (credential failed) restrictions, all anti-passback rules, and first card authorization.

iNote

For details about setting these functions, refer to Edit Access Point for Current Site .

Extended Access

When the persons accessing access point, grant these person more time to pass through doors which have been configured with extended open duration. Use this function for the persons with reduced mobility.

iNote

You should set the access point's extended open duration in Logical View. For details, refer to *Edit Access Point for Current Site* .

Attendance Group

Add the persons to the existing attendance group if your need to monitor the persons' working hours and absenteeism.

iNote

You can click **Add New** to add a new attendance group. For details, refer to **Add Attendance Group**.

iNote

The extended access and super user functions cannot be enabled concurrently.

- 6. Complete importing the domain persons.
 - Click Add to add the persons.
 - Click Add and Continue to save the settings and continue to add persons.
- **7. Optional:** After importing the person information in the domain to the system, you can click the person name to view and edit her/his details.

iNote

- If the profile/email in the domain is linked to the profile/email in the system, the persons' profile/email will be imported to the system from the domain as well. You can view the profile/email in the person details page but you cannot edit it.
- If the profile/email in the domain is NOT linked to the profile/email in the system, you can take a picture or upload a picture as the person's profile and enter the email address.
- For linking the person information in the domain to the person information in the system, refer to *Set Active Directory*.
- 8. Optional: After importing the person information in the domain to the system, if the person information in domain is changed, click **Synchronize Domain Persons** to get the latest information of the persons imported to the system. If the persons are imported by group, it will synchronize the latest person information from the domain group (including added persons, deleted persons, edited persons, etc., in the group).

15.4 Batch Add Profiles

You can add multiple person pictures to the system. If you access the system via the Web Client running on the SYS server, you need to specify a path where the profiles are stored. If you access the system via the Web Client running on other computers, you can import a ZIP file containing person pictures. In this way, you can also add these person to specific face comparison group(s).

Steps

i Note

If the ID in the profile name is duplicate with the person's in the system, it will edit the existing person's ID. If the ID in the profile name doesn't exist in the system, or the profile name only contains person name, the system will create a new person with the profile, person name, or ID.

1. Name the profile photos according to the person name or person ID.

iNote

- The photos' naming rule is: Person Name or Person Name_ID. The person name should contain first name and then last name, separated with one space.
- Recommendation for each photo: Dimensions: 295×412. Size: 60 KB to 100 KB.
- The photos should be in JPG, JPEG, or PNG format.
- **2. Optional:** If you access the system via the Web Client running on the SYS server, packet these photos in one folder and compress it in ZIP format.

iNote

The ZIP file should be smaller than 4 GB, or the uploading will fail.

- **3.** Click **Person** \rightarrow **Person List** to enter the person list page.
- 4. Click Import → Import by Importing Profiles .
- 5. Select the profiles.
 - If you access the system via the Web Client running on the SYS server, select a path where the profiles are stored.
 - If you access the system via the Web Client running on other computers, select the ZIP file containing the person photos.

i Note

You can hold CTRL key and select multiple ZIP files. Each file should be no larger than 4 GB.

- 6. Optional: Set the Add to Face Comparison Group switch to on and select the face comparison group(s) to add the persons to these group after importing.
- 7. Click Import to start importing.

The importing progress shows and you can check the results.

15.5 Import Persons from Device

If the added access control device has been configured with person information, you can get the person information from the device and import them to the system for further operations. The person information stored on the device, including person names, profiles, credentials (PIN codes, cards, and fingerprints), can be imported to the system.

Steps

- **1.** Click **Person** \rightarrow **Person List** to enter the Person List Management page.
- 2. Click Import → Import from Device to enter the following page.

* Select Device	Search	
	> _ All	
	_	
	In	nport

Figure 15-6 Import Persons from Device

- 3. Select the access control device(s) from the device list.
- 4. Click Import to start importing.

iNote

When importing, the system will compare the persons between device and system based on the person name. If the person name exists on the device but not exists in the system, the system will create a new person. If the person name exists both on the device and in the system, the person information in the system will be replaced with the data on the device.

15.6 Batch Issue Cards to Persons

The system provides a convenient way to issue card to multiple persons in a batch.

Steps

iNote

- Up to 5 cards can be issued to one person.
- You cannot issue cards to persons who have temporary card.
- **1.** Click **Person** \rightarrow **Person List** to enter the person list page.

iNote

The selected persons who have less than 5 cards will be displayed.

- 2. Select the persons to issue the card to.
- 3. Click Credential Management → Batch Issue Cards to Persons to enter the following page.

Issue Card to Person			
ssued / Total : 0/1			Card Issuing Setti
Issuing Mode Card Enrollment Sta Card Formal Audio ON OFF	tion Card Reader Enter Manually Reading Frequency Single	Card Encryption Disable	Start
Name	ID	Card Number	
Wendy Tang	6452420977		

Figure 15-7 Issue Card to Persons in Batch

4. Click Card Issuing Settings to select the issuing mode and set the parameters.

iNote

For details about setting the card issuing mode and parameters, refer to **Set Card Issuing Parameters**.

- 5. Issue one card to one person according to the issuing mode you select.
 - If you select the issuing mode as **Card Enrollment Station**, place the card on the card enrollment station. The card number will be read automatically and the card will be issued to the first person in the list.
 - If you select the issuing mode as **Card Reader**, swipe the card on the card reader. The card number will be read automatically and the card will be issued to the first person in the list.
 - If you select the issuing mode as **Enter Manually**, enter the card number manually in the Card Number field. Press **Enter** key on the keyboard to issue the card to the person.

You can check **Auto Increment Card Number** and enter a start card number. Then click **Start** to issue cards with incremental numbers to the selected persons in the list.

6. Repeat the above step to issue the cards to the persons in the list in sequence.

iNote

You cannot change the card issuing mode once you issue one card to one person.

7. Click Save.

15.7 Set Card Issuing Parameters

HikCentral Professional provides two modes for reading a card's number: via card enrollment station or via the card reader of the access control device. If a card enrollment station is available, connect it to the PC running the Web Client, and place the card on the card enrollment to read the card number. If not, you can also swipe the card on the card reader of the added access control device to get the card number. As a result, before issuing a card to one person, you need to set the card issuing parameters including the issuing mode and related parameters.

Steps

- 1. Click Person on the home page and enter the Person List page.
- 2. You can enter the card issuing parameters settings page when adding single person or issuing cards to persons in a batch.
 - For entering the card issuing parameters settings page when adding single person, refer to *Add a Person*.
 - For entering the card issuing parameters settings page when issuing cards to persons in a batch, refer to **Batch Issue Cards to Persons**.
- 3. Set the issuing mode and set related parameters.

Card Enrollment Station

Connect a card enrollment station to the PC running the Web Client. You can place the card on the card enrollment station to get the card number.

If you select this mode, you should set the card format and card encryption function.

Card Format

If the card is Wiegand card, select Wiegand. Otherwise select Normal.

Reading Frequency

If your card supports dual frequency (both IC and ID), you need to select **Dual**. Otherwise, select **Single**.

i Note

If you select **Dual**, you can not set card encryption for the card.

Card Encryption

If you set the card format as **Normal**, you can enable the card encryption function for security purpose. After enabled, you should enable the card encryption in the access control device's configuration page to take effect.

Audio

Turn on or off the audio.

Card Reader

Select one card reader of one access control device added to the system. You can swipe the card on the card reader to get the card number.

iNote

- One card reader can be set to issue card by up to one user at the same time.
- If you set a third-party card reader to read the card number, you should set the device's custom Wiegand protocol to configure the communication rule first.

4. Click Save.

15.8 Report Card Loss

If the person cannot find his/her card, he/she should contact the card issuer as quickly as possible and the card issuer should report card loss via Web Client immediately to freeze the access level on the lost card. The card issuer can issue a temporary card with effective period and access level to the person. When his/her card is found, the card issuer will recycle the temporary card and cancel the card loss, then the found card will be active again.

15.8.1 Report Loss for One Card

If the person cannot find his/her card, you can report the card loss so that the related access level will be inactive.

Steps

- **1.** Click Person \rightarrow Person List .
- **2.** Optional: Click ∇ to search the person you want to report card loss for.
- **3.** Click the name in the added person list to enter editing person information page.
- 4. In the Card area, move the cursor on the lost card and click riangleq .

20021028	C A ×

Figure 15-8 Report Card Loss

- 5. Click OK to confirm the operation.
- 6. Click Save.

After reporting card loss, the access level of this card will be inactive. However, the biometric credentials (such as fingerprints or faces) linked with the lost card are also inactive via linking to other normal card, temporary card, ect.

15.8.2 Issue a Temporary Card to Person

If the card is reported loss, you can issue a temporary card to the person and set the card's effective period, which is used for temporary purpose. When you issue a temporary card to the person, other cards linked to this person will be inactive, and the biometric credentials (such as fingerprints and profile) linked to these inactive cards will be linked to this temporary card.

Before You Start

The person has the card reported loss.

Steps

- **1.** Click Person \rightarrow Person List .
- **2.** Optional: Click ∇ to search the person you want to issue temporary card to.
- **3.** Click the name in the added person list to enter editing person information page.
- **4.** In the Card area, click + (Temporary Card).



Figure 15-9 Add Temporary Card

- 5. Click OK to confirm the operation.
- 6. Enter the card number.
- 7. Set the expiry date when the temporary card becomes invalid.
- 8. Click Save.

iNote

You can delete the temporary card for the person. After that, the inactive cards of the person will recover to active, and their previously linked fingerprints and profiles will recover, too.

15.8.3 Cancel Card Loss

If the lost card is found, you can cancel the card loss for the person. After that, the card's access level will be active and the original biometric credentials (such as fingerprints and profile) will be linked to this card again.

Before You Start

The person has the card reported card loss and has no temporary card.

Steps

- **1.** Click **Person** → **Person** List .
- **2.** Optional: Click γ to search the person you want to report card loss for.
- **3.** Click the name in the added person list to enter editing person information page.
- 4. In the Card area, move the cursor on the found card and click \bigcirc .



Figure 15-10 Cancel Card Loss

- 5. Click OK to confirm the operation.
- 6. Click Save.

15.9 Custom Additional Information

You can customize the additional information items which are not pre-defined in the basic information according to actual needs.

Steps

iNote

Up to 20 additional information can be customized.

- **1.** Click Person \rightarrow Person List \rightarrow .
- 2. Click <a>Custom Additional Information to enter the custom addition information page.
- 3. Click Add.
- 4. Create a name for this item.

iNote

Up to 32 characters are allowed in the name.

5. Select the type to restrict the format for the additional item .

Example

For example, if you select general text, you need to enter words for the item. If you select date, you can only set the date for the item.

- 6. Click Save.
- 7. Optional: After adding the additional information, you can do one or more of the followings.
 - Edit Name Click 🗹 to edit its name.

Delete Click \times to delete the additional information.

iNote

The additional information which is linked with person information in domain cannot be deleted.

Chapter 16 Manage Access Control

After adding the persons to the person list, you can assign the access permission to persons to define when they can get access to which door(s). To define the access permission, you should create an access level to group the doors and an access group to group the persons. After assigning the access level to the access group, the persons in the access group will be authorized to access the doors in the access level with their credentials during the authorized time period.

16.1 Add Access Group

Access group is a group of persons who have the same access permission. The persons in the access group can access the same doors (the doors in the linked access level) during the same authorized time period. You need to assign the access level(s) to the access group so that these persons in the access group can access the door(s) in the access level.

Before You Start

Add person to the system, for details, refer to Manage Person List .

Steps

iNote

Up to 64 access groups can be added.

1. Click Person → Access Group → Add to enter the adding access group page.

Add Access Grou	ıp
Basic Information	
* Access Group Name	
Description	
Person Information	
Copy from	•
Person Information	C No resource selected. Click Add to select person(s).
Access Information	
Access Level	Add Add and Continue Cancel

Figure 16-1 Add Access Group

2. Set the basic information.

Access Group Name

Create a name for the access group.

- **3. Optional:** Set the person(s) to add to the access group.
 - 1) Click 😭 .

All the persons added to the system display. You can view the person name, picture, person ID, and remark information.

2) Filter the persons by setting the filtering conditions.

Person List

Filter persons in the person list by person name or additional information.

Enter the keyword or search scope and press Enter or click ${\bf Q}$ to search.

Imported Domain Group

The imported domain groups will display. Enter the keyword of group name to search the group.

Click the group to add all the persons in the group.

3) **Optional:** You can also select the existing access group or attendance group from the **Copy from** drop-down list to copy person information from other group.

iNote

For setting the attendance group, refer to Add Attendance Group .

iNote

Up to 1,000 persons can be added to one access group.

4. Optional: Select the access level(s) to link the access group to the access level(s) so that the person(s) you selected in step 3 can access the doors linked to the access level(s) during the authorized time period.

iNote

- Up to 8 access levels can be assigned to one access group.
- You can click Add New to add a new access level. For details, refer to Add Access Level .
- Move the cursor to the access level and you can view its door(s) and access schedule.
- **5.** Finish adding the access group.
 - Click Add to add the access group and return to the access group management page.
 - Click Add and Continue to add the access group and continue to add other access groups.
- 6. Optional: After adding the access group, you can do one or more of the followings.

Edit Access Group	Click 🕜 in the Operation column to edit its details.
Delete Access Group	Click $ imes$ in the Operation column to delete it.
Delete All Access Groups	Click Delete All to delete all the added access groups.

16.2 Manage Access Level

In access control, access level is a group of door(s). After assigning the access level to certain access group(s), it defines the access permission that which person(s) can get access to which door(s) during the authorized time period.

16.2.1 Add Access Level

To define the access permission, you need to add an access level first and group the access points.

Steps

i Note

Up to 128 access levels can be added to the system.

1. Click Access Level on the Home page to enter the access level management page.

2. Click Add.

Second Access Leve	ļ
*Access Level Name	
Description	
*Door	Search
	✓ ☑ 12_vtd ✓ ☑ Door 01
	 ✓ ■ <u>1</u> 10.18.139.121 ✓ ■ Door 01
	 E Door 02 E Door 03
	🗌 📓 Door 04
*Access Schedule	All-day Template View
	Add and Assign Cancel

Figure 16-2 Add Access Level

- 3. Create a name for the access level.
- **4. Optional:** Enter the description for the access level.
- 5. Select the door(s) to add the access point(s) to the access level.
- **6.** Select the access schedule to define in which time period, the persons are authorized to access the doors (selected in step 5).

iNote

The default and customized access schedules are displayed in the drop-down list. You can click **Add New** to customize a new schedule. For details, refer to **Set Access Schedule Template**.

- 7. Finish adding the access level.
 - Click Add to add the access level and return to the access level management page.
 - Click Add and Assign to assign the access level to some access group(s) so that the person(s) in the access group(s) will have the access permission to access the door(s) selected in step 5.

iNote

- For details about assigning the access level to the access group, refer to Assign Access Level to Access Group.
- For setting the access group, refer to Add Access Group .
- 8. Optional: After adding the access level, you can do one or more of the followings.

Edit Access Level	Click 🗹 in the Operation column to edit its details. If you want to change the assigned access group(s), or assign it to another access group, click Configuration .
Assign to Access Group	Click 🔌 in the Operation column to assign the access level to the added access group(s). For details, refer to Assign Access Level to Access Group .
Delete Access Level	Click $ imes$ in the Operation column to delete the access level.
Delete All Access Levels	Click Delete All to delete all the added access levels.

16.2.2 Assign Access Level to Access Group

After adding the access level, you need to assign it to access group(s). After that, the persons in the access group(s) will have the permission to access the access point(s) linked to the access level.

Before You Start

Add the access group(s). For details, refer to Add Access Group.

Steps

iNote

You can also link the access group to access level(s) when adding or editing the access group. The latest configured linkage will take effect. For details, refer to **Add Access Group**.

- 1. Click Access Level on the Home page to enter the access level management page.
- 2. Enter the Assign to Access Group page.
 - After you setting the parameters of access level when adding, click Add and Assign.
 - When editing the access level, click **Configuration** in the access level details page.
 - Click 🖄 in the Operation column.
- **3.** In the Assign to Access Group field, select the access group(s) you want to assign the access level to.
- 4. Optional: Click Add New to add a new access group.
- 5. Click Save.

16.3 Apply Persons' Access Levels to Device

After setting the linkage between access group and access levels, or if the person's access level and access group settings are changed, you need to apply the person's access level settings to the access control device of the access point linked to the access level to take effect. After that, the persons in the access group can access the access points during the authorized time period defined by the related access level.

16.3.1 Manually Apply Persons' Access Levels to Device

After setting the access levels and assigning access levels to access group, you should apply the relation between persons and access points to the access control device. In other words, after setting or changing the access groups and access levels, you need to apply these settings to the access control device to take effect.

Before You Start

Link the access group with access level to define the access permission. For details, refer to **Assign Access Level to Access Group** or **Add Access Group**.

Steps

- **1.** Click **Person** \rightarrow **Access Group** to enter the access group management page.
- 2. Click Apply to Device to open the Apply window.

Apply ×
Apply Changes: Apply the persons' changed (newly added, edited, deleted) access levels to the devices. It will keep the configured and applied access levels on the devices. Apply All: First, clear all the access levels configured on the device. Then apply all the persons' access levels configured in the system to the devices. This mode is mainly used for first time deployment.
Select the access point(s) to apply the persons' access levels.
Search
V V 1. Area
Door 01
Door_01
Apply Changes Apply All Cancel

Figure 16-3 Apply to Device Manually

3. Select the access point(s) to apply the persons' access levels.

4. Select the applying mode.

Apply Changes

Apply the persons' changed (newly added, edited, deleted) access levels to the devices. It will keep the configured and applied access levels on the devices.

Apply All

First, clear all the access levels configured on the device. Then, apply all the persons' access levels configured in the system to the devices. This mode is mainly used for first time deployment.

During this process, the devices will be offline for a while, and persons cannot access via these access points.

5. Optional: If the person's access permission settings are changed (such as changes in linked access level, person credentials, etc.), the () icon will display near the Apply to Device icon, indicating that these new access permission settings should be applied to the device. You can hover the cursor to it to view that the access levels of how many persons' should be applied to the device.

16.3.2 Regularly Apply Person's Access Levels to Devices

Besides manually applying to device, you can also set a schedule and the system can apply the access levels assigned to persons configured in the system to the device automatically every day.

Before You Start

Link the access group with access level to define the access permission. For details, refer to **Assign Access Level to Access Group** or **Add Access Group**.

Steps

iNote

By default, the system will apply the persons' access levels automatically to the device at 01:00 every day.

1. Click **Person** → **Access Group** to enter the access group management page.

2. Click Apply to Device (Scheduled) to open the following window.

*Apply Automatically at (Daily)	05:00 👻
	Save

Figure 16-4 Apply to Device Regularly

3. Set a time and the system will apply the changed access levels linked with persons, as well as the applying failed access levels, to device at the configured time automatically.

iNote

The time here is the SYS server's time.

4. Click Save.

16.4 Set Access Schedule Template

The access schedule defines when the person can open the access point with credentials, or when the access point remains unlocked so that person can open the access point with free access. The system predefines three default access control schedule templates: All-day Template, Weekday Template, and Weekend Template. You can also add a customized template according to actual needs.

Steps

- 1. Click System on the home page.
- 2. Click Schedule → Access Schedule Template tab on the left.
- 3. Click Add in the Access Schedule page to enter the adding access schedule template page.

⊖ Add Access Co	ntrol S	che	edul	e Te	mpl	ate								
Basic Information														
* Nam	ne													
Copy fro	m				•									
Weekly Schedule	🔏 Auth	orized											🕢 Era	150
	Sun.	00	02	04	06	08	10	12	14	16	18	20	22	24
	Mon.													
	Tue.													
	Wed.													
	Thu.													
	Fri.													
	Sat.													
		00	02	04	06	08	10	12	14	16	18	20	22	24
Holiday Schedule	+ Add	Holida	y											
		Add		Add	and Cor	itinue		Cano	el.					

Figure 16-5 Set Access Control Schedule Template

4. Set the required information.

Name

Create a name for the template.

Copy from

Optionally, you can select to copy the settings from other defined templates.

5. Draw a time period on the time bar.

iNote

Up to 8 time periods can be set for each day.

- **6. Optional:** Click **Erase** and click on the drawn time period to clear the corresponding drawn time period.
- **7. Optional:** Set the holiday schedule if you want to set different schedules for some special days. The priority of holiday schedule is higher than the weekly schedule which means the predefined holidays will adopt the holiday schedule rather than the weekly schedule.
 - 1) Click Add Holiday.
 - 2) Select the predefined holiday(s), or click **Add New** to create a new holiday (see *Set Holiday* for details).
 - 3) Click Add.
 - 4) Draw a time period on the time bar.

iNote

Up to 8 time periods can be set for each day.

- 5) **Optional:** Click **Erase** and click on the drawn time period to clear the corresponding drawn time period.
- 8. Finish adding the access schedule template.
 - Click Add to add the template and back to the access schedule template list page.
 - Click Add and Continue to add the template and continue to add other template.

The access schedule template will be displayed on the access schedule template list.

9. Optional: Perform the following operations after adding the template.

View Template Details	Click the template to view its details.
Edit Template	Click 🗹 in the Operation column to edit template details.
Delete Template	Click $ imes$ in the Operation column to delete the template.
Delete All Templates	Click Delete All to delete all the schedule templates (except the default templates and the template(s) in use).

16.5 Configure Anti-Passback Rules

The anti-passback feature is designed to minimizes the misuse or fraudulent use of access credentials such as passing back card to an unauthorized person, or tailed access. The anti-passback function establishes a specific sequence in which cards must be used in order to grant access. The person should exit via the access point in the anti-passback if he/she enters via the access point in the anti-passback.

Steps

- 1. Click Logical View on the home page.
- 2. Select one area which contains the access point you want to configure an anti-passback rule for.
- **3.** Click \square to enter the editing area page.
- **4.** In the Anti-Passback field, click **Add** to add an anti-passback rule.

In the Add Anti-Passback page, all the areas with access points display.

5. Select the access point(s) to add to the anti-passback rule.

iNote

- Up to 16 access points can be added to one anti-passback rule.
- Select at least one access point in the current area.

6. Click Add.

The anti-passback rule is added in the table and you can view the access points in the rule.

16.6 Configure Multi-Door Interlocking

Multi-door interlocking is used to control the entry of persons to a secure area such as a clean room, where dust or small particles may be a problem. One rule is composed of at least two doors and only one door can be opened simultaneously.

Steps

- 1. Click Logical View on the home page.
- **2.** Select one area which contains the access point you want to configure a multi-door interlocking rule for.
- **3.** Click \square to enter the editing area page.
- 4. In the Multi-Door Interlocking field, click Add to add a multi-door interlocking rule.

In the Add Multi-Door Interlocking page, all the areas with access points display.

- 5. Create a name for the rule.
- 6. Select at least two access points of one access control device.
- 7. Click Add.

The multi-door interlocking rule is added in the table and you can view the doors in the rule.

16.7 Configure Entry and Exit Counting Rules

The entry and exit counting rule is used to group the access points (doors or turnstiles) of certain region. You can set some access points as the region border. Only the persons accessing these access points are calculated, and other access points inside the region are ignored. By grouping these access points, the system provide counting functions based on the entry and exit records on these access points. With this function, you can know who enters/exits this region and how many

persons still stay in this region. This is available for certain emergency scene. For example, during a fire escape, the number of the stayed persons and name list are required.

Steps

iNote

After setting rules, the security personnel can perform entry and exit counting on the Control Client. For details, refer to User Manual of HikCentral Professional Control Client.

- 1. Click Logical View on the home page.
- 2. Select one area which contains the access point you want to configure an entry & exit counting for.
- **3.** Click \square to enter the editing area page.
- 4. In the Entry & Exit Counting field, click Add to add an entry & exit counting rule.
- 5. Create a name for the rule.
- 6. Click Add to select the doors.
- 7. Set the entering or exiting direction of the card readers of the selected access points.

The access records on the entering card reader will be calculated as person entering this region while the access records on the exiting one will be calculated as person exiting this region.

8. Click Add.

The entry & exit counting rule is added in the table and you can view the access points in the rule.

Chapter 17 Manage Time and Attendance

After adding the persons to the person list, if you want to track and monitor when the persons start/stop work and monitor their working hours and late arrivals, early departures, time taken on breaks, and absenteeism, you can add the person to the attendance group and assign a shift schedule (a rule for the attendance defining how the schedule repeats, the shift type, break settings, and the card swiping rule.) to the attendance group to define the attendance parameters for the persons in the attendance group.

17.1 Add Attendance Group

After adding the persons, you can group the persons into different attendance groups. The persons in the same attendance group are assigned with the same shift schedule.

Steps

iNote

- Up to 64 attendance groups can be added.
- For each person, he/she can be added to up to one attendance group.

1. Click Person → Attendance Group → Add to enter the adding attendance group page.

Add Attendance	Group
Basic Information	
* Attendance Group Name	
* Effective Period	2019/03/04 16:06:25-2021/03/04 16:06:25
Description	
Time Zone	
Time Zone	(UTC+08:00) Beijing, Chongqing 🔻 View
Person Information	
Copy from	~
Person Information	[]
	Add Add and Continue Cancel

Figure 17-1 Add Attendance Group

2. Set the basic information of the group.

Attendance Group Name

Create a name for the attendance group.

Effective Period

Set the effective period for the group. Once expired, the attendance records of the persons in the group will not be recorded.

3. Optional: Select a time zone for the attendance group in drop-down list of **Time Zone** when the persons are in the different time zones.

iNote

The default time zone is where the SYS server is located. For certain across-timezone scene, such as the attendance persons in different time zones, you need to set the time zone for them.

- **4.** Set the person(s) to add to the attendance group.
 - Click 😭 , select **Person List**, and search the person name or custom additional information to add the searched person(s).
 - Click 😭 and select **Imported Domain Group** to select a domain group to add the persons in the domain group.

- Click **Copy from** to select the existing access group from the drop-down list to add the person(s) from other groups to this group. The added person(s) will be deleted from other groups.

i Note

For setting the access group, refer to Add Access Group .

iNote

Up to 1,000 persons can be added to one attendance group.

5. Optional: Set the shift schedule for the persons in the group so that they need to attend according to this shift schedule.

iNote

Click Add New to add a new shift schedule. For details, refer to Add Shift Schedule .

- 6. Finish adding the attendance group.
 - Click Add to add the attendance group and return to the attendance group list page.
 - Click Add and Continue to add the attendance group and continue to add other groups.
- 7. After adding the attendance group, you can do one or more of the followings:

Edit Attendance Group	Click 🛯 in the Operation column to edit its details.
Delete Attendance Group	Click $ imes$ in the Operation column to delete it.
Delete All Attendance Groups	Click Delete All to delete all the added attendance groups.

17.2 Add Shift Schedule

An shift schedule is an attendance schedule which defines the scheduled work time and how it repeats. You can create an shift schedule to compare the employees' attendance with it so as to identify those who are tardy, leave early, take long break, or are absent, etc.

Perform this task to add a shift schedule.

Steps

- 1. Click Time & Attendance → Shift Schedule → Add to enter the adding shift schedule page.
- 2. Set the shift schedule's basic information, including a custom name and the description.
- **3. Optional:** Select another shift schedule from the drop-down list of **Copy from** field to copy the schedule information to the current schedule. You can edit the schedule settings on this basis.
- 4. Set the schedule's repeating mode.

Week

The schedule will repeat every 7 days based on the week.

Day(s)

You can customize the number of days in one period. You should set a start date of one period for reference which can define how the schedule repeats.

i Note

The number of days should be between 1 to 14.

- 5. Draw the scheduled work time on the timeline.
 - 1) Drag on the timeline to set the range of the scheduled work time.

The detailed schedule rule parameters will be displayed.

Scheduled Work Time 08 : 00 \$ - 18 : 00 \$
Shift Type 💿 Fixed 🔘 Flexible
Break Duration 01 : 00 🗘
Work Hours 09:00
1 Card Swiping Rule
06:00 10:00 16:00 20:00 22 24 00 02 04 06 08 10 12 14 16 18 20 22 24 00
08:00 18:00
Valid Check-in/out Period Invalid Check-in/out Period
Save Save and Copy to

Figure 17-2 Set Detailed Schedule Rule

- 2) **Optional:** Edit the required work time to make it more accurate if necessary.
- 3) Select the shift type.

Fixed

The scheduled start-work time and end-work time is fixed. Only when the employee checks-in before the start-work time and checks-out after the end-work time, the attendance status is normal. Or it may be late, early leave, or absent.

Flexible

Flexible work schedule is an alternative to the fixed schedule. It allows employees to extend their start-work time and end-work time and you can set the allowable extended duration for both start-work and end-work time.

4) **Optional:** For flexible schedule, set the flexible duration, which defines the extended duration for both start-work and end-work time. During this flexible schedule, the check-in/out will be recorded and the status will be **Normal**.

Example

If the required work time is set as 09:00 to 18:00, and the flexible duration is 30 min, if the employee checks-in at 09:15, and checks-out at 18:15, the attendance status on that day will be **Normal**.

5) Set the break duration such as lunch time.

For fixed schedule, the required work hours will be calculated automatically according to the above settings (except flexible duration).

- 6) **Optional:** For flexible schedule, set the minimum work hours.
- 7) Set the valid check-in/out period on the timeline. If the employee checks-in/out during the valid check-in/out period, the check-in/out will be recorded and the attendance status will not be absent.



Figure 17-3 Flexible Shift Schedule

Example

In the above image, if you set the parameters as above, if the employee checks in during 08:00 to 09:00, the check-in will be normal. If the employee checks in during 09:00 to 11:00, the check-in will be late.

If the employee checks out during 18:00 to 19:00, the check-out will be normal. If the employee checks out during 16:00 to 18:00, the check-out will be early leave.

If the employee checks in after 11:00, the check-in will be invalid and he/she will be marked as absent.

If the employee checks out before 16:00, the check-out will be invalid and he/she will be marked as absent.

8) Click Save. You can click Save and Copy to to copy the schedule to other days.

6. Select the holidays on which days the shift schedule will not be effective.

iNote

For setting the holiday, refer to Set Holiday .

- 7. Finish adding the shift schedule.
 - Click **Add** to add the shift schedule and return to the shift schedule management page.
 - Click Add and Assign to add the shift schedule and assign it to the attendance group. For details, refer to Assign Shift Schedule to Attendance Group.

17.3 Assign Shift Schedule to Attendance Group

After setting the shift schedule, you need to assign it to the attendance group so that it will calculate the attendance records for persons in the attendance group according to this shift schedule.

Before You Start

- Add a shift schedule and set the rule. For details, refer to Add Shift Schedule .
- Add an attendance group. For details, refer to Add Attendance Group .

Perform this task to assign a shift schedule to attendance group(s).

Steps

- 1. Click Time & Attendance → Shift Schedule to enter the shift schedule management page.
- 2. Enter the Assign to Attendance Group page.
 - After you set the parameters of shift schedule when adding, click Add and Assign.
 - When editing the shift schedule, click **Configuration** in the shift schedule details page.
 - Click 🖄 in the Operation column.
- **3.** In the Assign to Attendance Group field, select the attendance group(s) you want to assign the shift schedule to.

iNote

Only the attendance groups which haven't been linked to a shift schedule will display.

- 4. Optional: Click Add New to add a new attendance group.
- 5. Click Save.

17.4 Add Attendance Check Point

You should set a door as an attendance check point, so that the check-in/out by credentials (such as swiping card on the door's card reader) will be valid and will be recorded.

Perform this task to add a attendance check point.

Steps

 Click Time & Attendance → Attendance Check Point to enter the attendance check point management page.
2. Click Add.

\bigcirc Add Attendance	Check Point
*Door	Search
	Door 03 Door 04 Door-SyncName Door-SyncXXX
	Add Cancel

Figure 17-4 Add Attendance Check Point

All the doors which haven't been set as attendance check point will be displayed.

- 3. Select the door(s).
- 4. Click Add.

The selected door(s) will be displayed in the attendance check point list.

5. To delete the added attendance check point, select the door(s) and click **Delete**.

iNote

If the attendance check point is deleted, the attendance records on this attendance check point will be deleted as well, and it will affect the persons' attendance results for the days on which the attendance data haven't been calculated.

17.5 Manage Attendance Record

The persons' attendance records will be recorded and stored in the system. You can search the records by setting the search conditions to view the attendance details and view the person's attendance report. You can also correct check-in/out time for the exceptional records according to actual needs.

17.5.1 Search Attendance Record

You can search the attendance records to view the person's attendance status by setting the search conditions.

Before You Start

- Make sure the person is not expired.
- Make sure the person's attendance group is not expired. Or the attendance records will not be recorded. For setting the attendance group's effective period, refer to **Add Attendance Group**.

Steps

- 1. Click Time & Attendance → Attendance Record to enter the attendance record page.
- **2.** In the filter panel, set the search conditions.

Time

Set the time range of the attendance records you want to search. You can search the persons' attendance records recorded within three years.

3. Click Filter to filter the attendance records according to the search conditions.

If you search the attendance records on one day, you can view the persons' attendance status and detailed work time (including scheduled work time and actual work time).

If you search the attendance records on multiple days, you can view the persons' attendance report including the times of normal, late, early leave, absent status during the time period, and the total work hours.

- **4. Optional:** If you search the attendance records on multiple days, hover the cursor on the number of late, early leave, or absent times to view the specific date.
- 5. Optional: Click the person name to view the person's attendance records.

iNote

Hover the cursor on the date to view the detailed work time, including scheduled work time and actual work time.

- **6. Optional:** You can also correct the check-in/out for the exceptional attendance status if necessary. For details, refer to *Correct Attendance Record for Single Person*.
- **7. Optional:** Click **Export** and select the items to export the filtered attendance records and save in your PC.

iNote

The exported file is in CSV format. If the file is larger than 50 MB, the file will be compressed to a ZIP package.

17.5.2 Correct Attendance Record for Single Person

After searching the person's attendance record, you can correct one person's check-in/out time according to actual needs if the attendance status is not normal.

Perform this task if you need to correct the person's attendance check-in/check-out time.

Steps

1. Click Time & Attendance → Attendance Record to enter the attendance record page.

2. Search the attendance records.

iNote

For details, refer to Search Attendance Record .

- **3. Optional:** If you search the attendance records on one single day, you can perform the following steps to correct the check-in/out time.
 - 1) Click 🖶 in the Operation column.
 - 2) Set the correct check-in/out time.
 - 3) **Optional:** Enter the reason for correction.
 - 4) Click **OK**.

The person's attendance status on that day changes according to the correction.

- **4. Optional:** If you search the attendance records on multiple days, you can perform the following steps to correct the check-in/out time.
 - 1) Click the person name to enter the detailed attendance record page.



Figure 17-5 Attendance Detailed Page

The person's attendance statuses are displayed on the calendar.

- 2) Hover the cursor to the date which attendance status is not normal and click **Correct Check-***in/out*.
- 3) Set the correct check-in/out time.
- 4) **Optional:** Enterthe reason for correction.
- 5) Click **OK**.

The person's attendance status on that day changes according to the correction and the icon will show, indicating that the status is corrected.

17.5.3 Correct Attendance Records for Multiple Persons

You can correct multiple persons' check-in/out time in a batch according to actual needs if the attendance status is not normal.

Perform this task if you need to correct multiple persons' check-in/out time.

Steps

iNote

Up to 50,000 attendance records can be corrected at a time.

- **1.** Click **Time & Attendance → Attendance Record** to enter the attendance record page.
- 2. Click Batch Correct Check-in/out to open the following window.

* Select File	
	Download Template
	The system will recalculate the attendance results according to the imported attendance records.
	ОК

Figure 17-6 Batch Correct Attendance Records

- 3. Click Download Template to download the template file and you can save it to your PC.
- **4.** In the downloaded template, enter the actual start-work time or/and end-work time following the rules in the template.
- 5. Click Batch Correct Check-in/out and upload the template with the corrected attendance records.
- 6. Click OK and the progress will be displayed.

iNote

The system will recalculate the attendance results according to the imported attendance records.

Chapter 18 Manage Face Comparison Group

After adding the persons to the person list, you should create a face comparison group, and then add persons (selected from the person list) to the group before you can perform face comparison. Finally, you need to apply the face comparison group with person information to the face recognition device to take effect. When a person's face is detected and it matches or mismatches the person information in the face comparison group, an event/alarm (if configured) will be triggered to notify the security personnel and you can view the face comparison information during live view on the Control Client.

18.1 Add Face Comparison Group

After adding the person(s), you can add a face comparison group and add person(s) to the group for face comparison.

Steps

iNote

Up to 64 face comparison groups can be added.

1. Click **Person** \rightarrow **Face Comparison Group** to enter the face comparison group management page.

Add Face Compa	arison Group
Basic Information	
* Name	
i * Similarity Threshold (%)	80
Description	
	Add and Continue Cancel
	Add and Continue Cancel

Figure 18-1 Add Face Comparison Group

- 2. Add a new face comparison group.
 - 1) Click Add.
 - 2) Create a name for the face comparison group.
 - 3) Set the face comparison similarity threshold which affects the frequency and accuracy of face picture comparison alarm. When the face comparison similarity is higher than the configured threshold, the camera will regard the person as matched.
 - 4) **Optional:** Enter the description information if needed.

- 5) Click **Add** to add the group and go back to the face comparison group list. You can also click **Add and Continue** to add other groups.
- **3.** Add person(s) to the group.
 - 1) In the face comparison group list page, click > to show the persons added to the group.
 - 2) Click + to open the following window.

Name		•
Name	 	Q
👥 All		

Figure 18-2 Add Person to Face Comparison Group

3) Select the adding mode.

Person List

All the persons in the person list who haven't been added to the current group will be displayed.

Filter persons in the person list by person name or additional information.

Enter the keyword or search scope and press **Enter** or click \bigcirc to search.

Added Face Comparison Group

The added face comparison groups will display. Enter the keyword of group name to search the group.

Add all the persons in other existing face comparison groups to the current group.

Imported Domain Group

The imported domain groups will display. Enter the keyword of group name to search the group.

Click the group name to add all the persons in the domain group to the face comparison group.

4) Click Add.

iNote

- Up to 10,000 persons can be added to one face comparison group.
- The original persons in the current group will not be replaced after adding person from existing group.
- **4. Optional:** After adding the persons to the face comparison group, you can do one or more of the followings.

Remove Person from Face Comparison Group	Hover the cursor to the face picture and click $\overline{\mathbb{M}}$.
Edit Face Comparison Group	Click \square in the Operation column to edit its details and edit the cameras that it is applied to.
Delete Face Comparison	Click $ imes$ in the Operation column to delete it.
Delete All Face Comparison Groups	Click Delete All to delete all the added face comparison groups.

What to do next

After adding the face comparison group and configuring the persons in the group, apply the group to the camera which supports face picture comparison to take effect. For details, refer to **Apply Face Comparison Group to Device**.

18.2 Apply Face Comparison Group to Device

After setting the face comparison group and adding person(s) to the group, you need to apply the group settings to the camera which supports face picture comparison so that the camera can compare the detected faces with the face pictures in the face comparison group and trigger alarms (if configured). After applying the face comparison group to the device, if the data in the group are changed (such as adding a person to the group, removing person from the group, etc.), the system will automatically apply the data in the group to the device to take effect.

Before You Start

Add camera which supports face picture comparison to the system.

Perform this task if you need to apply the person information in the face comparison group to the camera to take effect.

Steps

iNote

- Currently it only supports applying to camera which supports face picture comparison.
- The maximum number of groups that can be applied to the camera depends on the camera capability.
- 1. Click Person → Face Comparison Group to enter the face comparison group management page.
- 2. Click Apply to Device.

 I.It only supports applying to camera which supports face picture comparison. 2. The maximum number of groups that can be applied to the camera depends on the camera capal 3. One camera can only have one similarity threshold. The latest applied threshold will take effect. Apply Group Search \$ Apply to Camera Search \$ apply to Camera Search \$ apply to Camera Search \$ apply u \$ apply to Camera 	⊖ Apply to Device	
Search ■ \$\$ All ✓ \$\$ 11 • \$\$ \$\$ 12 • \$\$ \$\$ 11111 • \$\$ \$\$ \$\$ \$\$ \$\$ \$\$ \$\$ \$\$ \$\$ \$\$ \$\$ \$\$ \$\$	(2. The maximum number of groups that can be applied to the camera depends on the camera capability.
Apply to Camera Search Q ✓ ■ ■ jingyu ✓ ● ● ■ jingyu ✓ ● ● ■ jingyu	* Apply Group	 ■ 並 All ✓ ± 11 ■ ± 12 ■ ± 1111
	* Apply to Camera	Search Q
IPCamera 01 IPCamera 02 IPCamera 02		Image: Wight of the second

Figure 18-3 Apply Face Comparison Group to Device

- **3.** Select the face comparison group(s) to be applied.
- **4.** Select the camera(s) to apply the selected face comparison group(s) to.
- 5. Click Apply to start applying.

The applying progress will display in the Operation column.

6. Optional: If there exists applying failed face comparison group, the ① icon will display near the group name. Hover the cursor to the icon to check the prompt.

iNote

You can click **Retry** to apply this group to the linked camera(s) again. Click **Details** to view the exception details.

Chapter 19 Add Dock Station Group

Dock station group is a group of persons who are linked to the same dock station(s). After linking persons to dock station(s), the videos and pictures on the persons' body cameras can be copied to these dock station(s).

Steps

iNote

Up to 64 dock station groups can be added.

1.	Click Person → Dock Station	• Group → Add to enter	r the adding access grou	up page
	• • • • • • • • • • • • • • • • • • • •			

Basic Information		
* Dock Station Group Name		
Description		
Person Information		
Copy from	-	
Person Information	£	
	No resource selected. Click Add to select person(s).	
	Click Add to select person(s).	
Dock Station		
i Dock Station	Search	

Figure 19-1 Add Dock Station Group

2. Set the basic information.

Dock Station Group Name

Create a name for the group.

3. Set the person(s) to add to the dock station group.

iNote

Up to 20 persons can be added to one dock station group.

- 1) Click 📸 .
- 2) Filter the persons by setting the filtering conditions.

Person List

Filter persons in the person list by person name or additional information.

Enter the keyword or search scope and press **Enter** or click \bigcirc to search.

Imported Domain Group

The imported domain groups will display. Enter the keyword of group name to search the group.

Click the group to add all the persons in the group.

- 3) **Optional:** You can also select the existing dock station group from the **Copy from** drop-down list to copy person information from other group.
- 4. Select the dock station(s) to link them to the selected persons.

iNote

You can click **Add New** to add a new dock station to the system. For details, refer to *Manage Dock Station*.

- 5. Finish adding the dock station group.
 - Click **Add** to add the dock station group and return to the dock station group management page.
 - Click Add and Continue to add the dock station group and continue to add other dock station groups.

Chapter 20 Manage Security Control

A security control device detects people, vehicles, etc., entering a pre-defined region, triggers events and alarms, and reports events/alarms information (such as location) to security personnel.

After adding a security control device to the system, you need to group the device's alarm inputs into security control partitions in the system. You also need to set one defense schedule for the alarm inputs in a security control partition which defines when and how to arm the alarm inputs in this security control partition. For example, area 1 is created for the first floor, and all the resources on the first floor are managed in area 1. If there is one security control device mounted on the first floor, you should add its zones (alarm inputs) into area 1 first, then link the zones into security control partitions and set a defense schedule to these security control partitions. After that, the zones can be armed according to the schedules respectively.

20.1 Link Alarm Inputs to Security Control Partition

After adding the security control device's zones to the system (called "alarm inputs" after added to the system), you should link them to different security control partitions in the system according to the relation between zones and partitions configured on the device.

Before You Start

Make sure the security control device's zones are added to the system and grouped into areas. For details, refer to *Add Alarm Input to Area*.

Steps

- 1. Click Logical View on the home page.
- 2. Select one area which contains alarm inputs you want to set a defense schedule for and click Z to enter the editing area page.
- **3.** In the Security Control Partition field, click **Add**.
- **4.** Create a name for the security control partition.
- In the drop-down list of Alarm Input field, select a security control device.
 The alarm inputs of the security control device added to this area and haven't been added to any security control partitions are displayed.
- 6. Select the alarm inputs which you want to add to the security control partition.
- **7.** Select a security control partition No. in the drop-down list which is gotten from the device you selected in Step 5.
- **8. Optional:** Set a defense schedule for this partition, which defines how and when to arm the alarm inputs in the security control partition.

iNote

For setting a new defense schedule, refer to Configure Defense Schedule Template .

9. Click Add.

10. Optional: Perform one or more of the following operations after linking alarm inputs to security control partition.

Edit Security Control Partition	Click 📝 to edit the partition settings. You can uncheck the alarm input(s) to remove the added alarm input(s) from the security control partition.
	After removing the alarm input(s) from the security control panel, the
	zones will be removed from this partition on the device, too.
Delete Security Control Partition	Click $ imes$ to delete the added security control partition.

20.2 Configure Defense Schedule Template

The defense schedule defines the arming mode in different time periods for the partitions of the added security control devices. You can set a weekly schedule to schedule time periods for stay arming, instant arming, or away arming in one week. The system predefines two default defense schedule templates: All-day Template and Weekday Template. You can also add a customized template according to actual needs.

Steps

- **1.** Click **System** on the home page and enter **Schedule** → **Defense Schedule Template** page.
- 2. Click Add to enter the adding defense schedule template page.
- **3.** Set the required information.

Name

Set a name for the template.

Copy from

Optionally, you can select to copy the settings from other defined templates.

4. Select an arming mode and drag on the time bar to draw a time period.

iNote

By default, the Time-based is selected.

Instant Arming

It is used when people leave the detection area. The zone will be immediately triggered when it detects event or alarm with no delay and notify the security personnel.

Away Arming

It is used when people leave the detection area. Event or alarms will be activated when the zone is triggered or tampered. For delayed zone, the alarm will not be activated when the zone detects triggering event during entry/exit delay.

Stay Arming

It is used when people stay inside the detection area. During stay arming, all the perimeter burglary detections (such as perimeter detector, magnetic contacts, curtain detector in the balcony) will be turned on. Meanwhile, the detectors inside the detection area are bypassed (such as PIR detectors). People can move inside the area and not trigger an event or alarm.

iNote

Up to 8 time periods can be set for each day.

- **5. Optional:** Click **Erase** and click on the drawn time period to clear the corresponding drawn time period.
- **6.** Finish adding the defense schedule template.
 - Click Add to add the template and back to the defense schedule template list page.
 - Click Add and Continue to add the template and continue to add other template.

The defense schedule template will be displayed on the defense schedule template list.

7. Optional: Perform the following operations after adding the template.

View Template Details	Click the template to view its details.
Edit Template	Click 🗹 in the Operation column to edit template details (except the template(s) in use).
Delete Template	Click $ imes$ in the Operation column to delete the template.
Delete All Templates	Click Delete All to delete all the schedule templates (except the default templates and the template(s) in use).

Chapter 21 Manage Role and User

The system allows you to add users and assign user's permissions for accessing and managing the system. Before adding users to the system, you should create roles to define the user's access rights to system resources and then assign the role to the user for granting the permissions to the user. A user can have many different roles.

21.1 Add Role

You can assign the permissions to the roles as required, and the users can be assigned with different roles to obtain different permissions.

Steps

1. Click **Security** \rightarrow **Roles** to enter the Role Management page.

iNote

The system pre-defines two default roles: administrator and operator. You can click the role name to view the details and operations. But you cannot edit or delete the two default roles. **Administrator**

The role that has all the permission of the system.

Operator

The role that has all the permission for operating the Control Client and has the permission for operating the Applications (Live View, Playback, and Local Configuration) on the Web Client.

2. Click Add to enter the Add Role page.

Add Role		
Basic Information		
* Role Name		
Copy from	•	
Effective Period		
Permission Schedule Template	All-day Template View	
Description		
Permission Settings		
-		
Permission Settings Permission	Area Display Rule Resource Access User Permission	
-	Area Display Rule Resource Access User Permission ① If an area is hidden, all its resources are invisible to the user, and the area will not display on any interface, e.g., live view infit	erface.
-		eríace.
-	() If an area is hidden, all its resources are invisible to the user, and the area will not display on any interface, e.g., live view interface, e.g., live	
-	If an area is hidden, all its resources are invisible to the user, and the area will not display on any interface, e.g., live view initial HikCentral_XOX Search	⊖ Show ● Hi
-	① If an area is hidden, all its resources are invisible to the user, and the area will not display on any interface, e.g., live view into ③ HitGentral_XOX > ④	⊖ Show ⊛ Hi ⊖ Show ⊛ Hi
-	() If an area is hidden, all its resources are invisible to the user, and the area will not display on any interface, e.g., live view init () Hiscentral yoo	Show ● Hi Show ● Hi Show ● Hi
-	If an area is hidden, all its resources are invisible to the user, and the area will not display on any interface, e.g., live view init whick-entral_XOX v	Show ● H Show ● H Show ● H Show ● H
-	() If an area is hidden, all its resources are invisible to the user, and the area will not display on any interface, e.g., live view left () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () <td< td=""><td>Show & H Show & H Show & H Show & H Show & H</td></td<>	Show & H Show & H Show & H Show & H Show & H
-	() If an area is hidden, all its resources are invisible to the user, and the area will not display on any interface, e.g., live view into () HitkCentral_XOX () HitkCentral_XOX Search () () 10.18.64.233 () 10.18.65.177 () () 10.18.65.177 () () 10.18.65.177 () () 10.18.65.147 ()	erface. Show • H Show • H Show • H Show • H Show • H Show • H
-	① If an area is hidden, all its resources are invisible to the user, and the area will not display on any interface, e.g., live view init ③ HikGentral_COX Search ✓ ▲ All 10.18.64.22) ▲ 10.18.65.147 ▲ 10.18.65.143 ▲ 10.18.65.148 ▲ 10.18.65.148	Show • Hi Show • Hi Show • Hi Show • Hi Show • Hi Show • Hi
-	() If an area is hidden, all its resources are invisible to the user, and the area will not display on any interface, e.g., live view left () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () () ()	Show # H Show # H Show # H Show # H Show # H Show # H

Figure 21-1 Add Role Page

3. Set the role name, effective period, permission schedule template, and description as desired. **Effective Period**

The date that this role takes effective and turns invalid.

Permission Schedule Template

Set the authorized time period when the role's permissions are valid. Select **All-day Template**/ **Weekday Template/Weekend Template** as the permission schedule of the role, or click **Add New** customize a permission schedule for the role.

iNote

- The role's permissions will expire when the current time is not in the authorized time period of the permission schedule.
- When the permissions expire, the role will be logged out and not allowed to login.
- The permission schedule's time zone is consistent with that of the system.
- If the role's permissions are invalid after editing the permission schedule, the role will be forced to login to the system again.
- By default, the role will be linked with All-day Template after updating the system.
- The permission schedule also goes for RSM client and OpenSdk client.

4. Set the permission for the role.

- Select the default or pre-defined role from the **Copy form** drop-down list to copy the permission settings of selected role.
- Assign the permissions to the role.

Area Display Rule

Show or hide the specific area(s) for the role. If the area is hidden, the user with the role cannot view and access the area and its resources on any interface.

HikCentral Professional Web Client User Manual

a few few the set of t	vill not display on any interface, e.g., live	2 VIEW
erface.For the roles except pre-defined roles, one role only supports to show	v the areas of one site.	
⊗ HikCentral232 Search		
10.18.147.142	◯ Show	 Hide
RSM_NOSMS_Local	◯ Show	Hide
RSM_NOSMS_CVR	⊖ Show	Hide
RSM_NOSMS_Cloud	◯ Show	Hide
RSM_SMS_Local	◯ Show	Hide
RSM_SMS_CVR	◯ Show	Hide
RSM_SMS_Cloud	◯ Show	Hide
🔳 test	⊖ Show	• Hide
pos_duyinyinadd_147.143	◯ Show	• Hide
r⊟ fk-test-area	⊖ Show	Hide

Figure 21-2 Area Display Rule

Resource Access Permission

Select the functions from the left panel and select resources from right panel to assign the selected resources' permissions to the role.

iNote

If you do not check the resources, the resource permission cannot be applied to the role.

elect Resource Type	Select Resources	
Logical Resource	Search	
Entry & Exit Counting		A
Encoding Device	10.18.67.156	
	10.18.69.5	
Decoding Device	0.18.69.247	
Access Control Device	10.18.135.231	
Smart Wall	10.18.147.36	
	10.18.147.87	
Server	10.18.147.97	
Custom Additional Info.	1041.7.1	
User Defined Scort	10.41.7.2	
User-Defined Event	▼ □ □ 10 41 7 2	

Figure 21-3 Resource Access Permission

User Permission

Assign the resource permissions, configuration permissions on the Web Client, and the control permissions on the Control Client to the role.

Area Display Rule	Resource Access	User Permission	
elect Permission			
Search			
> 🗌 🖳 Resource Pe	rmission		
Configuration	Permission		
> 🔽 Resource Ma	nagement		
> 🔽 Event & Alarn	ı		
> 🗌 Access Level			
> 🗌 Time & Attend	lance		
> 🗌 Person			
> 🗌 Vehicle			
> 🗌 Security			
> 🗌 System 🛈			

Figure 21-4 User Permission

- 5. Complete adding the role.
 - Click Add to add the role.
 - Click Add and Continue to save the settings and continue to add roles.
- 6. Optional: After adding the role, you can do one or more of the following:
 - **Edit Role** Click the **Name** field to edit the settings of the role.
 - **Refresh Role** Click **Refresh All** to get the latest status of the roles.
 - **Delete Role** Click **Delete** to delete the role.
 - Filter RoleClick ∇ to expand the filter conditions. Set the conditions and click Filter to
filter the roles according to the set conditions.

21.2 Add Normal User

You can add normal users for accessing the system and assign role to the normal user. Normal users refer to all the users except the admin user.

Steps

- 1. Click Security → Users to enter the User Management page.
- 2. Click Add to enter the Add User page.

Add User	
* User Name	
1 Password	•••••
Expiry Date	
() Email	
* User Status	Active Inactive
Restrict Concurrent Logins	0
Description	
Permission	
* PTZ Control Permission	1
* Assign Role	Role Name Description
	Role Name
	Administrator
	Coperator
	1213
	L 121-door01,door02
	□ 1 21-door01,door03
	Add New Role
	Add Add and Continue Cancel
	Add and Continue Cancel

Figure 21-5 Add User Page

3. Set the required parameters.

User Name

For user name, only letters(a-z, A-Z), digits(0-9), and "-" can be contained.

Password

Create an initial password for the user which should be changed by the user for first time login.

iNote

We highly recommend you to create a strong password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Expiry Date

The date when this user account becomes invalid.

Email

The system can notify user by sending an email to the email address. If the normal user forget his/her password, he/she can reset the password via email.

iNote

The email address of the admin user can be edited by the user with the role of administrator.

Restrict Concurrent Logins

If necessary, switch **Restrict Concurrent Logins** to on and input the maximum number of concurrent logins.

User Status

Two kinds of status are available. If you select freeze, the user account is inactive until you set the user status to active.

4. Set the permission level (1-100) for PTZ control in PTZ Control Permission.

iNote

The larger the value is, the higher permission level the user has. The user with higher permission level has the priority to control the PTZ unit.

Example

When user1 and user 2 control the PTZ unit at the same time, the user with higher PTZ control permission level will take the control of the PTZ movement.

5. Check the existing roles to assign the role(s) for the user.

iNote

• If no role has been added, two default roles are selectable: administrator and operator. Administrator

The role that has all permissions of the system.

Operator

The role that has all permissions of the system Control Client.

• If you want to add customized roles, you can click **Add New Role** to quickly enter the Add Role page. See *Add Role* for details.

6. Complete adding the user.

- Click Add to add the user.
- Click Add and Continue to save the settings and continue to add users.

iNote

You will be asked to change the password when logging in for first time. See *First Time Login for Normal User* for details.

7. Optional: Perform the following operations after adding the normal user.

Edit User	Click the Name field of the user to edit the information
Reset	In the Edit User page, click Reset to enter a new password for the user.
Password	i Note
	The admin user can reset the passwords of all the other users (except domain user). Other users with Security permission (in Configuration and Control Permission) can reset the passwords of the users without Security permission. For changing the password, refer to Change Password for Reset User .
Delete User	Click Delete to delete the user.
Force Logout	You can also select the online user and click Force Logout to log out the online user.
Refresh All	Click Refresh All to get the latest status of the users.
Filter User	Click γ to expand the filter conditions. Set the conditions and click Filter to filter the users according to the set conditions.

iNote

The administrator user named admin was pre-defined by default. It cannot be edited ,deleted, or forced to log out.

21.3 Import Domain Users

You can import the users in the AD domain in a batch to the system (including user name, real name, and email) and assign roles to the domain users.

Before You Start

You should configure the active directory settings. See *Set Active Directory* for details.

Steps

1. Click Security → Users to enter the User Management page.

2. Click Import Domain Users to enter the Import Domain Users page.

Basic Information					
basic information					
Importing Mode	 User 				
	Group				
* Select Domain Users	Organizational Unit		Domain User		
	Search	Q	Search		
	~ 11	*	User Name	Name	Email
	> 1				
	> 보 > 보				
	> 11				
	> 11				
	> 12		C anat	aviat tast	nent@bilaucan.com
	21. < 21. <	-	Total 17 Record(s) 100	• K <	> > 1 /1 Go
Restrict Concurrent Logins	0				
Permission					
Permission					
* PTZ Control Permission	1				
* Assign Role	Role Name		Description		
	Search		View Role Details		
		*			

Figure 21-6 Import Domain Users

3. Select the importing mode.

User

Import the specified users. Select the organization unit and select the user accounts under the organization unit which are displayed in the Domain User list on the right.

Group

Import all the users in the group.

- **4. Optional:** Set **Restrict Concurrent Logins** switch to ON and enter the maximum number of concurrent logins.
- 5. Set the permission level (1-100) for PTZ control in PTZ Control Permission.

iNote

The larger the value is, the higher permission level the user has. The user with higher permission level has the priority to control the PTZ unit.

Example

When user1 and user2 control the PTZ unit at the same time, the user who has the higher PTZ control permission level will take the control of the PTZ movement.

6. Check the existing roles to assign the role(s) for the selected domain user.

iNote

• If no role has been added, two default roles are selectable: administrator and operator. Administrator

The role that has all permissions of the HikCentral Professional.

Operator

The role that has all permissions of the HikCentral Professional Control Client.

- If you want to add customized roles, you can click **Add New Role** to quickly enter the Add Role page. See *Add Role* for details.
- 7. Complete importing the domain user.
 - Click Add to add the user.
 - Click Add and Continue to save the settings and continue to add users.
- 8. Optional: After importing the user information in the domain to the system, if the user information in domain is changed, click **Synchronize Domain Users** to get the latest information of the users imported to the system. If the users are imported by group, it will synchronize the latest user information from the domain group (including added users, deleted users, edited users, etc., in the group).

Result

After successfully adding the domain users, the users can log in to the HikCentral Professional via the Web Client, Control Client and Mobile Client by their domain account and password.

21.4 Change Password of Current User

When you log in via Web Client, you can change your password as desired.

Perform this task when you need to change the password of the current login user.

Steps

1. Move the cursor on the name of the current user at the top-right corner of the system and .

2. From the drop-down list, select Change Password to open the Change Password dialog.

Change Password	×
	n required by your system: Medium ^① ions of the system. We recommend the strength of admin's
* Old Password	
* New Password	Example: 11AAaa##
	Risky
* Confirm Password	
	OK Cancel

Figure 21-7 Change Password Dialog

3. Enter the old password, new password, and confirm password.

ACaution

The password strength of the device can be checked by the system. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

4. Click OK to change the password.

21.5 Reset Password for Admin User

When you forgot the password of admin user, you can reset the password and set a new password for admin user.

Steps

1. In the address bar of the web browser, enter the address of the PC running SYS service and press Enter.

Example

If the IP address of PC running SYS is 172.6.21.96, you should enter *http://172.6.21.96* in the address bar.

iNote

You should configure the SYS's IP address in **System** \rightarrow **Network** \rightarrow **WAN Access** before accessing the SYS via WAN. For details, refer to *Set WAN Access*.

A login page will pop up.

2. Optional: When you log in via current Internet Explorer browser for the first time, you should install the plug-in before you can access the functions.

iNote

If a new version of plug-in is detected, you should update it to ensure the proper usage and better user experience.

- 1) Click **OK** in the pop-up dialog to install the plug-in. Or click **Download Plug-in** to download it.
- 2) Save the plug-in file to your PC and close the web browser.
- 3) Find the plug-in that stores on your PC and install the plug-in according to the prompt.
- 4) Re-open the web browser and log in to the SYS (step 1).

iNote

Please allow the browser to run the plug-in in the pop-up prompt.

- 3. Input *admin* in the User Name field.
- 4. Click Forgot Password to open the Reset Password dialog.

HikCentral Professional Web Client User Manual

Reset Password	×
1、Minimum password strength required by your system: Medium ^① 2、admin user owns all permissions of the system. We recommend the strength of admin's password should be: Strong ^①	
* Activation Code	
* New Password Password	
Risky	
* Confirm Password	
OK Cance	əl

Figure 21-8 Reset Password

5. Enter the required parameters in the pop-up dialog, including activation code, new password, and confirm password.

iNote

The password strength can be checked by the system and should meet the system requirements. If password strength is lower than the required minimum strength, you will be asked to change your password. For detailed settings of minimum password strength, refer to *Manage System Security* Security.

The password strength of the device can be checked by the system. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

6. Click OK to reset the admin password.

iNote

If you forgot the password of other users, contact the administrator user to reset the password and then change the password for login.

21.6 Reset Password for Normal User

If the user forgot the password, he/she can contact the users with administrator role to reset the password.

Steps

iNote

The admin user can reset the passwords of all the other users. Other users with administrator role can reset the passwords of the users without administrator role. See *Add Normal User* for details about user's role settings.

- 1. Click Security to enter the Security Management page.
- 2. Click Users on the left.
- 3. Select one user and click the Name field to enter the user details page.
- 4. Click Reset to enter a new password of the user.

21.7 Configure Permission Schedule

The permission schedule defines when the role's permissions are valid. During the authorized time periods, the permissions will be valid. In unauthorized time periods, the user with the role will be forced to logout and he/she cannot login again. The system predefines three default permission schedule templates: All-day Template, Weekday Template, and Weekend Template. You can also add a customized template according to actual needs.

Steps

- 1. Click System on the home page.
- 2. Click Schedule → Permission Schedule Template tab on the left.
- **3.** Click **Add** in the Permission Schedule page to enter the adding permission schedule template page.
- 4. Set the required information.

Name

Create a name for the template.

Copy from

Optionally, you can select to copy the settings from other defined templates.

5. Draw a time period on the time bar.

iNote

Up to 8 time periods can be set for each day.

- **6. Optional:** Click **Erase** and click on the drawn time period to clear the corresponding drawn time period.
- **7. Optional:** Set the holiday schedule. The priority of holiday schedule is higher than the weekly schedule which means the predefined holidays will adopt the holiday schedule rather than the weekly schedule.
 - 1) Click Add Holiday.
 - 2) Select the predefined holiday(s), or click **Add New** to create a new holiday (see *Set Holiday* for details).
 - 3) Click Add.
 - 4) Draw a time period on the time bar.



Up to 8 time periods can be set for each day.

- 5) **Optional:** Click **Erase** and click on the drawn time period to clear the corresponding drawn time period.
- 8. Finish adding the permission schedule template.
 - Click Add to add the template and back to the permission schedule template list page.
 - Click Add and Continue to add the template and continue to add other template.

The permission schedule template will be displayed on the permission schedule template list.

9. Optional: Perform the following operations after adding the template.

View Template Details	Click the template to view its details.
Edit Template	Click 🖂 in the Operation column to edit template details.
Delete Template	Click $ imes$ in the Operation column to delete the template.
Delete All Templates	Click Delete All to delete all the schedule templates (except the default templates and the template(s) in use).

Chapter 22 Maintenance

The system provides Service Manager to manage the installed services on the SYS server. You can check the service's running status, edit the service port, start/stop service via the Service Manager.

The system also provides backup of the database, so that your data can be well protected and recovered when an exception occurs.

You can also export the system's configuration data and save it to the local PC.

22.1 Service Manager

After successfully installing the service module(s), you can run the Service Manager and perform related operations of service, such as starting, stopping, or restarting the service.

Steps

1. Right-click Pand select Run as Administrator to run the Service Manager.

		-		- ×
	.⊥. Download Log			
Service Manager HikCentral Professional	Service Name	Port No	Status	Operation
	System Management Service	15300;14200;7660;7332;7661	⊘ Started	$\square \Theta$
	Application Data Service		⊘ Started	
😑 Stop All	HikCentral Professional Management Service	80;443	⊘ Started	$\square \Theta$
	HikCentral Professional Streaming Gateway	554;10000;559;16000	⊘ Started	$\square \Theta$
🔿 Restart All	3rd Party Device Access Gateway		⊘ Started	\square Θ
Run Time:				
0 Day(s) 03:08:40				
				 Auto-Launch

Figure 22-1 Service Manager Main Page

iNote

The displayed items vary with the service modules you selected for installation.

2. Optional: Perform the following operation(s) after starting the Service Manager.

Stop All	Click Stop All to stop all the services.
Restart All	Click Restart All to run all the services again.
Stop Specific Service	Select one service and click \bigcirc to stop the service.
Edit Service	Click the service name to edit the port of the service.

iNote

If the port number of the service is occupied by other service, the port No. will be shown in red. You should change the port number to other value before the service can work properly.

Open Service	Select one service and click 🛅 to go to the installation directory of the
Location	service.

3. Optional: Check **Auto-Launch** to enable launching the Service Manager automatically after the PC started up.

22.2 Set System Data Backup

For purpose of restoring the original system data after a data loss event or recovering data from an earlier time, you can manually back up the data in the system, or configure a schedule to run the backup task regularly. The system data includes data configured in the system, pictures configured in the system, received events and alarms, face comparison data, card swiping data, server logs, etc.

Perform this task when you need to configure the schedule to run the system data backup task regularly or manually back up the data.

Steps

iNote

The backups are stored in the SYS server. If you want to edit the default saving path, you should enter Back Up and Restore System Data page via the Web Client running on the SYS server.

1. Click Back Up and Restore System Data on the home page.

2. Click Back Up in the pop-up dialog to enter the backup page.

Back Up and Restore System Data	r	×
Back Up Restore		
	Face Comparison Data	*
	Card Swiping Records	
	Attendance Records	
	Vehicle Passing Records	
	Video Analysis Data	
	✓ Server Logs	
* How Often	Weekly -	
* Which Day	Monday 👻	
* When	0:00 -	
* Max. Number of Backups	3	
	(i) You can view and edit the saving	
	path only on the Web Client	
	running on the VSM server.	Ŧ
	Save and Back Up Now Cancel	

Figure 22-2 Set System Data Backup

3. Select the system data type for backup.

Configured Data

The data configured via the Web Client, including physical resources, logical resources, user permissions, etc. It is selected by default.

Configured Pictures

The pictures uploaded when setting maps, persons, vehicles, etc.

- 4. Set the backup schedule to run backup regularly.
 - 1) Select the frequency to back up the system data.

iNote

- If you select the data type besides configured data, you cannot set the frequency as **Daily**.
- If you select Weekly or Monthly for running the backup task, select which day to run.
- 2) Select what time of the day to start backup.
- 3) Set the **Max. Number of Backups** to define the maximum number of backup files available on the system.

iNote

The value ranges from 1 to 5.

5. Optional: Click Save and Back Up Now if you need to perform the backup immediately.

6. Click Save.

22.3 Restore Database

When an exception occurs, you can restore the database if you have backed up the database.

Before You Start

You should have backed up the database. Refer to Set System Data Backup for details.

Perform this task when you need to restore the database.

Steps

iNote

Database recovery will restore the database to an earlier state. Thus the data added after that state will be lost.

- 1. Click Back Up and Restore Database on the home page.
- 2. Click **Restore** in the pop-up dialog to enter the database restore page.
- **3.** Select a backup file to restore the database to an earlier state.

Back Up a	nd Restore Database		×
Back U	p Restore		
1	File Name	Backup Time	
0	20180305102514_Backup.zip	2018-03-05 10:25:14	
0	20180306000007_Backup.zip	2018-03-06 00:00:08	
0	20180308000009_Backup.zip	2018-03-08 00:00:10	
0	20180308011036_Backup.zip	2018-03-08 01:10:36	
		Restore	Cancel

Figure 22-3 Database Restore

4. Click Restore to confirm the database recovery.

What to do next

After restoring the database, you must reboot the SYS service via Service Manager and log in again via Web Client.

22.4 Export Configuration File

You can export and save configuration data to the local PC, including Remote Site, recording settings and etc.

Perform this task when you need to export configuration data.

Steps

- **1.** Click **Export Configuration Data** on the home page to open the Export Configuration Data dialog.
- **2.** Select the configuration data type to export.
- **3.** Click **Export** to save the data to your local PC.

iNote

- You can set the saving path by following the prompt of the browser.
- The configuration data file is in CSV format.

Chapter 23 Manage System Security

System security is crucial for your system and property, you can set the password strength and lock IP address to prevent malicious attacks, and set other security policies to increase the security of the system.

Perform this task to set the minimum password strength, IP address locking, and other security policy settings to prevent malicious attacks.

Steps

- 1. Click Security → Security Settings to open the Security Settings page.
- Set Lock IP Address switch to ON and the number of failed login attempts is limited.
 Select the allowable login attempts for accessing HikCentral Professional.

iNote

Failed login attempt includes failed password attempt and failed verification code attempt.

2) Set the locking duration for this IP address. During the locking duration, the login attempt from this IP address is not allowed.

The number of login attempts is limited.

- **3.** Select the **Minimum Password Strength** to define the minimum complexity requirements that the password should meet.
- 4. Set the maximum password age.
 - 1) Set **Enable Maximum Password Age** switch as ON to force user to change the password when password expires.
 - 2) Set the maximum number of days that the password is valid.

i Note

After this number of days, you will have to change the password. You can select the predefined time length or customize the time length.

- 5. Configure the settings to automatically lock the Control Client after a time period of inactivity on the Control Client.
 - 1) Set **Auto Lock Control Client** switch to ON to lock the Control Client after a time period of inactivity on Control Client.
 - 2) Select time period for user inactivity. You can select the pre-defined time period or customize the time period.
- 6. Click Save.

Chapter 24 System Configuration

The System page allows you to set basic parameters for the system, such as defining a customized name for your site, setting the WAN IP address for allowing to access your system via WAN (Wide Area Network), and configuring NTP (Network Time Protocol) settings to synchronizing the time between the system and the NTP server.

- For the system with Remote Site Management module, you can enable it to receive the registration from Remote Site.
- For the system without Remote Site Management module, you can set to register it to the Central System as a Remote Site.

24.1 Set Site Name

You can set a name for the current system.

Steps

- 1. Click System → Normal → Site Name on home page.
- 2. Edit the site name for the current system.
- 3. Click Save.

24.2 Set First Day of the Week

The first day of the week varies all over the world. You can set it based on the culture of your country.

Click **System** → **Normal** → **First Day of the Week** on the Home page, and then select and save the first day of the week.

24.3 Set Temperature Unit

You can set the temperature unit used in the system to Celsius degree, Fahrenheit degree or Kelvin degree.

Click System \rightarrow Normal \rightarrow Temperature Unit to enter the Temperature Unit page and then set and save the temperature unit.

24.4 Set Warning Threshold for Server Usage

You can enable the system to trigger an alarm if the SYS server's CPU usage and RAM usage reaches a pre-defined warning threshold and lasts for a pre-defined time. The related threshold value can be checked via the Control Client.

Steps

- 1. Click System → Normal → Server Usage Thresholds on the home page.
- 2. Drag the \bigtriangleup to adjust the CPU and RAM threshold value.
- 3. Define the duration in the Notify if Value Exceeds for (s) field for CPU Usage and RAM Usage.

Example

- If you set warning threshold as 60%, and set 20 in the **Notify if Value Exceeds for (s)** field of CPU Usage, you can view the CPU status changes to Waring in Health Monitoring in Control Client when the CPU usage reaches the warning threshold and lasts for 20 seconds.
- If you set 60% as the warning threshold, and set 20 in the Notify if Value Exceeds for (s) field of CPU Usage, and set an alarm for CPU Warning (see Add Alarm for HikCentral Professional Server), the alarm will be triggered when the CPU usage reaches the warning threshold and lasts for 20 seconds.

24.5 Set NTP

You can set the NTP server for syncing the time between the SYS and the NTP server.

Steps

- 1. Click System → Network → NTP Settings .
- 2. Set the Time Synchronization switch to ON to enable the NTP function.
- 3. Set the NTP server address and NTP port.
- **4.** Enter the interval for the auto time synchronization.
- 5. Optional: Click Test to test the communication between the SYS and NTP server.
- 6. Click Save.

24.6 Set Active Directory

If you have the AD (Active Directory) domain controller which contains the information (e.g., user data, computer information), you can configure the settings to get the related information. In this way, you can add the users that belong to an organization unit (OU) (e.g., a department of your company) to HikCentral Professional conveniently.

Perform this task when you need to set active directory.

Steps

- 1. Click System → Network → Active Directory on the home page.
- 2. Configure the basic information parameters to connect to the AD domain controller.

Domain Name

The domain name of the AD domain controller.

iNote

- HikCentral Professional only supports the NetBIOS format: e.g TEST\user and not the DNS Domain name format.
- To get the NetBIOS domain name, open the CMD window and enter *nbtstat n*. The NetBIOS domain name is the one in **GROUP** type.

: VJse	ers \s	∫)nbtst	at -n			
ode 1	IpAddress:	[] Scope Id: []				
		NetBIOS	Local Na	me Table		
	Name		Туре	Status		
		<20>	UNIQUE	Registered		
		<00>	UNIQUE	Registered		
		<00>	GROUP	Registered		
		<1E>	GROUP	Registered		

Figure 24-1 How to Get NetBIOS Domain Name

Host Name

The DNS server's IP address. You can get it in Network Connection Details.

Network Connection Details:			
Property	Value		-
Connection-specific DN Description	Intel(R) Eth	nemet Connection I217-V	
Physical Address DHCP Enabled IPv4 Address	Yes		
IPv4 Subnet Mask	255,255,255.0		
Lease Obtained	2017	14:21:21	
Lease Expires IPv4 Default Gateway IPv4 DHCP Server	2017	11:33:06	H
IPv4 DNS Servers			
IPv4 WINS Servers	-		
NetBIOS over Tcpip En	Yes		
Link-local IPv6 Address IPv6 Default Gateway	fi		

Figure 24-2 How to Get Host Name

Port No.

The port No. of the AD domain controller. By default, it is 389.

Enable SSL (Optional)

Enable SSL if required by the AD domain controller.
User Name

The user name of the AD domain controller. This needs to be the domain administrator.

Password

The password of the AD domain controller.

Base DN (Distinguished Name)

Enter the filter condition in the text filed if you are familiar with the format. Or you can click **Fetch DN** to get the filter condition entered automatically.

iNote

- Only users found within an Organizational Unit (OU) in the domain can be imported. Click **Fetch DN** to have the filter condition entered automatically.
- If you enter the Base DN manually, you need to define the root node as desired. If you click **Fetch DN**, then the entire structure stored on the AD domain controller will be obtained.
- **3. Optional:** Link the person information you concerned stored in the domain to the person information in the system.
 - 1) Set the Link Person Information switch to ON.

The default and custom additional information items (see *Custom Additional Information*) are displayed in the Person Information area by default. You can set the link relationship for those or add new person information items as you desired.

2) Optional: Click Add New to add a person information item you concerned.

i Note

- You needn't add the basic person information items, including ID, First Name, Last Name, Phone, and Remark) manually, which has the default link relationship with the domain.
- The new person information item is also displayed on Custom Additional Information page, where you can edit or delete the items. Refer to *Custom Additional Information* for details.
- The person information item is case-sensitive.
- 3) **Optional:** Click + to show the person information items stored in the domain.
- 4) Check the checkbox in the domain to link it to the added person information items when importing the domain persons.
- 5) **Optional:** Hover over the linked person information in domain and click × to remove the relationship. You can also change the link relationship among each other by clicking and dragging the one item to anther.
- 4. Click Save.

After the configuration, the organization unit and domain user information will be displayed when you click **Import Domain User** on User Management page.

If the Link Person Information function is enabled, the corresponding person information in the system will match the linked person information in the domain and cannot be edited.

24.7 Enable Receiving Generic Event

After creating a generic event to analyze the received TCP and/or UDP data packages from a very wide range of external systems, you can enable the receiving generic event function so that the system can receive the configured generic events.

Steps

- 1. Click System → Network → Receiving Generic Event .
- 2. Check Receiving Generic Event to enable this function.
- 3. Click Save.

iNote

You can configure the system's port No. for generic event: Open Service Manager (installed on the PC running SYS service), and click **HikCentral Professional System Management Service** to edit.

24.8 Allow for Remote Site Registration

This page allows the system with Remote Site Management module (as we called Central System) to receive the registration from Remote Sites. Remote Site is the system that does not have Remote Site Management module and can register to Central System to form a larger-scale union. The purpose of joining Central System and Remote Sites is to allow Central System's users to view and manage resources belonging to multiple Remote Sites simultaneously as if they were on the same system.

Before You Start

If a remote site needs to register to the Central System, it should open the Remote Site's Web Client and enter **Registering to Central System** to configure the Central System's parameters. See **Register to Central System** for details.

Steps

i Note

Allowing for Remote Site registration is only available for the system with Remote Site Management module.

- 1. Click System → Network → Receiving Site Registration .
- 2. Check Receiving Site Registration to enable this function.
- 3. Click Save.

24.9 Register to Central System

This page allows the system without Remote Site Management module (as we called Remote Site) to register to the Central System. Central System is the system that has Remote Site Management module and can join multiple Remote Sites together to form a larger-scale union. The purpose of joining Central System and Remote Sites is to allow Central System's users to view and manage resources belonging to multiple Remote Sites simultaneously as if they were on the same system.

Before You Start

For Central System, it should enable the receiving site registration function so that it can receive the Remote Site registration. See *Allow for Remote Site Registration* for details.

Steps

iNote

Registering to Central System is only available for the system without Remote Site Management module.

- 1. Click System → Network → Registering to Central System .
- 2. Set the Registering to Central System switch to ON to enable this function.
- **3.** Enter the IP address and port No. of Central System.

iNote

Open Service Manager (installed on the PC running central system's SYS service), and click **HikCentral Professional System Management Service** if you need to view or edit the Central System's port.

4. Click Save.

24.10 Set WAN Access

In complicated network environments, you need to set a static IP address and ports for HikCentral Professional to enable it to access the SYS server via WAN (Wide Area Network). For example, if the SYS server is in a local area network, and you need to visit the system via the Web Client or Control Client running in WAN, you should enable WAN access and set a static IP address and ports for HikCentral Professional.

Steps

- **1.** Click System \rightarrow Network \rightarrow WAN Access .
- 2. Set the WAN Access switch to ON to enable the WAN access function.
- 3. Enter a static IP address for WAN access.
- **4.** Set the port for HikCentral Professional, including HTTP, HTTPS, RTSP (Real Time Streaming Port), video file streaming port, and WebSocket port.

5. Optional: If you adopts generic event to integrate HikCentral Professional with external sources, you need to set the TCP port and UDP port to receiving the TCP and/or UDP data packages.

i Note

For setting the generic event, refer to Configure Generic Event .

6. Optional: For the system with Remote Site Management module, set the port to receive the registration from a Remote Site.

iNote

This configuration item is only available for the Central System with a Remote Site Management module based on the License you purchased.

7. Click Save.

24.11 Set Network Timeout

Network timeout duration refers to the default waiting time for the configurations on the Web Client. The configuration will be regarded as failure if no response within the configured timeout time.

The minimum default waiting time of the interactions between the configurations and SYS server is 60s, the minimum time between SYS server and devices is 5s, and the minimum time between the configurations and devices is 5s.

iNote

This parameter affects all the Web Clients accessing the current SYS server.

24.12 Set Device Access Mode

Device Access Mode page allows you to define how the system accesses all the added encoding devices and decoding devices.

Perform this task to define how the system accesses all the added encoding devices and decoding devices.

Steps

- **1.** Click System → Network → Device Access Mode .
- 2. Set the device access mode as automatically judge or proxy mode.

Automatically Judge

The system will automatically judge the condition of network connection and then set the device access mode accordingly as accessing directly or accessing via Streaming Gateway and Management Service.

Proxy

The system will access the device via Streaming Gateway and Management Service. It is less effective and less efficient than accessing directly.

3. Click Save to confirm the settings.

System accesses all the added encoding devices and decoding devices via the selected mode.

24.13 Set Server NIC

You can select the NIC of the current SYS server so that the system can receive the alarm information of the device connected via ONVIF protocol.

Steps

- 1. Click System → Network → Server NIC .
- 2. Select the currently used NIC name of SYS in the drop-down list.

The NIC information including description, MAC address, and IP address will display.

3. Click Save.

24.14 Set Data Retention Period

The data retention period specifies how long you can keep the events, logs, and some records SYS server, such as recording tags, face comparison data.

Steps

- 1. Click System → Storage → Data Recorded in System .
- 2. Set the data recorded period from the drop-down list for the required data types.

Data Recorded in S	ystem
*Received Events	One Year 🔹
*Recording Tags	Two Years 🔹
*Face Comparison Data	Two Years 🔻
*Card Swiping Records	Two Years 🔹
*Attendance Records	Two Years 👻
*Vehicle Passing Records	Two Years 👻
*Video Analysis Data	Two Years 👻
*Service Error Logs	Two Years 👻
*Service Warning Logs	Six Months 👻
*Service Information Logs	Two Years 👻
	Save

Figure 24-3 Set Data Recorded Period

iNote

The card swiping records are saved as the configured period. The user with the permission can search the persons' swiping records and view related information during this period, even if the searched persons have been deleted from the SYS server.

3. Click Save.

24.15 Set Holiday

You can add the holiday to define the special days that can adopt different shift schedule or access control schedule.

Perform this task to add some special days as holiday.

Steps

- 1. Click System → Schedule → Holiday Settings .
- 2. Click Add to open the adding holiday dialog.

iNote

You can add up to 16 holidays.

- **3.** Set a customized name.
- 4. Click the Time field and define the start date and end date for the holiday period.
- 5. Click Add to save the holiday.
- 6. Optional: Perform the following operations after adding the holiday.

Edit Holiday	Click 🗹 in the Operation column to edit holiday (including the holiday(s) in use).
Delete Holiday	Click $ imes$ in the Operation column to delete the holiday.
Delete All Holidays	Click Delete All to delete all the holidays (except the holiday(s) in use).

24.16 Set Email Template

You should set the email template properly before sending the event message to the designate email account(s) as email linkage. The email template can also be used when sending report to the designate recipients.

24.16.1 Configure Email Account

You should configure the parameters of sender's email account before the system can send the message to the designate email account(s) as email linkage.

Perform this task when you need to configure the sender's email account.

Steps

- **1.** Click **System** \rightarrow **Email** to enter the email page.
- 2. Click Email Settings to enter the Email Settings page.

Email Settings	
Email Settings	
Server Authentication	
Cryptographic Protocol	None •
* Sender Email Address	
* Sender Name	
* SMTP Server Address	
* SMTP Server Port	25
* User Name	
* Password	
	Email Test
	Save Cancel

Figure 24-4 Email Settings

3. Configure the parameters according to actual needs.

Server Authentication (Optional)

If your mail server requires authentication, check this checkbox to use authentication to log in to this server.

Cryptographic Protocol

Select the cryptographic protocol of the email to protect the email content if required by the SMTP server.

SMTP Server Address

The SMTP Server IP address or host name (e.g., smtp.263xmail.com).

SMTP Server Port

The default TCP/IP port used for SMTP is 25.

4. Click Email Test to test whether the email settings work or not.

The corresponding attention message box will pop up.

5. Click Save.

24.16.2 Add Email Template

You can set email templates including specifying the recipient, email subject, and content, so that the system can send the information to the designate recipient according to the pre-defined email template.

Before You Start

Before adding the email template, you should set the sender's email account first. See *Configure Email Account* for details.

Perform this task when you need to add a new email template.

Steps

- **1.** Enter **System** \rightarrow **Email** to enter the email page.
- 2. Click Add to enter the Add Email Template page.
- 3. Enter the required parameters.

Name

Create a name for the template.

Recipients

Click **Add User** and select the person's email as the recipient, which is configured when adding the person.

Click Add Email and enter the recipient(s) email address to send the email to.



You can enter multiple recipients and separate them by ";".

Subject

Enter the email subject as desired. You can also click the button in the lower part of the window to add the related information to the subject.

Content

Define the event information to be sent. You can also click the button in the lower part of the window to add the related information to the content.

i Note

If you select to add the event time to the email subject or content, and the email application (such as Outlook) and the system are in different time zones, the displayed evnet time may have some deviations.

- 4. Optional: Check Attach Image to send email with image attachment.
- 5. Finish adding the email template.

- Click Add to add the template and go back to the email template list page.
- Click **Add and Continue** to add the template and continue to add other templates. The email template will be displayed on the email template list.

6. Perform the following operation(s) after adding the email template:

Edit Template	Click \square in the Operation column to edit template details.
Delete Template	Click $ imes$ in the Operation column to delete the template.
Delete All Templates	Click Delete All to delete all the added templates.

24.17 Send Report Regularly

Reports are essential documents in order to submitting performance to users to make business run smoothly and effectively. Users can use reports as basis in creating decisions, addressing problems, checking tendency and comparison, etc. HikCentral Professional provides report functions that the system can send reports automatically and regularly to target users by emails, showing the occurred events and alarms, number of passing vehicles, people counting, queue management, and temperature status during specified time period.

24.17.1 Send Event Report Regularly

You can set a regular report rule for specified system-monitored events, and the system can send an email with a report attached to the target recipients daily or weekly, showing the details of specified system-monitored events triggered in the day or the week.

Before You Start

- Set the email template with recipient information, subject, and content. For details, refer to **Set Email Template**.
- Set the email settings such as sender address, SMTP server address and port, etc. For details, refer to *Configure Email Account*.

Steps

iNote

One report can contain up to 10,000 event records in total.

- 1. Click System on the home page and enter Report page.
- 2. Select the report category as Event.
- **3.** Create a name for the report.
- **4.** Set the system-monitored event(s) contained in the report.
 - 1) In the Report Target field, click Add.
 - All the added system-monitored events are displayed.
 - 2) (Optional) Filter the events by event source type and triggering event.
 - 3) Select the event(s).

iNote

Up to 32 events can be added in one report rule.

4) Click Add.

5. Set the report type as Daily or Weekly and set the sending time.

Daily Report

Daily report shows data on a daily basis. The system will send one report at the sending time every day, which contains information of the events triggered on the day (24 hours) before the current day.

For example, if you set the sending time as 20:00, the system will send a report at 20:00. every day, containing details of all the events triggered between 00:00. and 24:00. before the current day.

Weekly Report

As compared to daily report, weekly report can be less time-consuming, since it is not to be submitted every day. The system will send one report at the sending time every week, which contains information of the events triggered on the last 7 days before the sending date.

For example, if you set the sending time as 6:00 on Monday, the system will send a report at 6:00 in the morning on every Monday, containing details of all the events triggered between last Monday and Sunday.

6. Select the email template from the drop-down list to define the recipient information and email format.

iNote

You can click **Add New** to add a new email template. For setting the email template, refer to **Set Email Template**.

- 7. Select Excel or PDF as the report format.
- **8.** Finish adding the report.
 - Click Add to add the report and go back to the report list page.
 - Click Add and Continue to add the report and continue adding other reports.

24.17.2 Send Alarm Report Regularly

You can set a regular report rule for specified alarms, and the system can send an email with a report attached to the target recipients daily or weekly, showing the details of specified alarms triggered in the day or the week.

Before You Start

- Set the email template with recipient information, subject, and content. For details, refer to **Set Email Template**.
- Set the email settings such as sender address, SMTP server address and port, etc. For details, refer to *Configure Email Account*.

Steps

i Note

One report can contain up to 10,000 alarm records in total.

- 1. Click System on the home page and enter Report page.
- 2. Select the report category as Alarm.
- **3.** Create a name for the report.
- 4. Set the alarm(s) contained in the report.
 - 1) In the Report Target field, click Add.

All the added alarms are displayed.

- 2) (Optional) Filter the alarms by alarm source type, triggering event, and alarm priority.
- 3) Select the alarm(s).

iNote

Up to 32 alarms can be added in one report rule.

- 4) Click Add.
- 5. Set the report type as Daily or Weekly and set the sending time.

Daily Report

Daily report shows data on a daily basis. The system will send one report at the sending time every day, which contains information of the alarms triggered on the day (24 hours) before the current day.

For example, if you set the sending time as 20:00, the system will send a report at 20:00 every day, containing details of all the alarms triggered between 00:00 and 24:00 before the current day.

Weekly Report

As compared to daily report, weekly report can be less time-consuming, since it is not to be submitted every day. The system will send one report at the sending time every week, which contains information of the alarms triggered on the last 7 days before the sending date.

For example, if you set the sending time as 6:00 on Monday, the system will send a report at 6:00 in the morning on every Monday, containing details of all the alarms triggered between last Monday and Sunday.

6. Select the email template from the drop-down list to define the recipient information and email format.

iNote

You can click **Add New** to add a new email template. For setting the email template, refer to **Set Email Template**.

- 7. Select Excel or PDF as the report format.
- 8. Finish adding the report.
 - Click Add to add the report and go back to the report list page.

- Click Add and Continue to add the report and continue adding other reports.

24.17.3 Send Passing Vehicle Report Regularly

You can set a regular report rule for specified ANPR cameras, and the system can send an email with a report attached to the target recipients daily, weekly, or monthly, showing the number of passing vehicles detected by these ANPR cameras during the specified time periods.

Before You Start

- Set the email template with recipient information, subject, and content. For details, refer to **Set Email Template**.
- Set the email settings such as sender address, SMTP server address and port, etc. For details, refer to *Configure Email Account*.

Steps

iNote

- One report can contain up to 10,000 records in total.
- The report will be an Excel file.
- 1. Click System on the home page and enter Report page.
- 2. Select the report category as Vehicle.
- **3.** Create a name for the report.
- **4.** Set the ANPR camera(s) contained in the report.
 - 1) In the Report Target field, click Add.
 - All the ANPR camera(s) added to the current site are displayed.
 - 2) Select the ANPR camera(s).
 - 3) Click Add.
- 5. Set the report type as Daily, Weekly, or Monthly and set the sending time.

Daily Report

Daily report shows data on a daily basis. The system will send one report at the sending time every day, which contains data detected on the day (24 hours) before the current day.

For example, if you set the sending time as 20:00, the system will send a report at 20:00 every day, containing the number of passing vehicles detected between 00:00 and 24:00 before the current day.

Weekly Report and Monthly Report

As compared to daily report, weekly report and monthly report can be less time-consuming, since they are not to be submitted every day. The system will send one report at the sending time every week or every month, which contains the number of passing vehicles detected on the last 7 days or last month before the sending date.

For example, for weekly report, if you set the sending time as 6:00 on Monday, the system will send a report at 6:00 in the morning on every Monday, containing number of passing vehicles detected between last Monday and Sunday.

6. After setting the report time, set how the report will present the data detected in the specified time period.

Example

For example, if you select the report type as **Daily**, you can select **Calculate by Hour** or **Calculate by Minute**. There will be 24 or 24×60 records for each camera respectively in the report, showing the number of passing vehicles detected in each hour or each minute for one camera.

7. Select the email template from the drop-down list to define the recipient information and email format.

iNote

You can click **Add New** to add a new email template. For setting the email template, refer to **Set Email Template**.

- 8. Finish adding the report.
 - Click **Add** to add the report and go back to the report list page.
 - Click Add and Continue to add the report and continue adding other reports.

24.17.4 Send People Counting Report Regularly

You can set a regular report rule for specified people counting cameras, and the system can send an email with a report attached to the target recipients daily, weekly, or monthly, showing the number of people entered or exited, detected by these people counting cameras during the specified time periods.

Before You Start

- Set the email template with recipient information, subject, and content. For details, refer to **Set Email Template**.
- Set the email settings such as sender address, SMTP server address and port, etc. For details, refer to *Configure Email Account*.

Steps

i Note

- One report can contain up to 10,000 records in total.
- The report will be an Excel file.
- 1. Click System on the home page and enter Report page.
- 2. Select the report category as People Counting.
- **3.** Create a name for the report.

4. Set the people counting camera(s) contained in the report.

1) In the Report Target field, click Add.

All the people counting camera(s) added to the current site are displayed.

- 2) Select the people counting camera(s).
- 3) Click Add.

5. Set the report type as Daily, Weekly, or Monthly and set the sending time.

Daily Report

Daily report shows data on a daily basis. The system will send one report at the sending time every day, which contains data detected on the day (24 hours) before the current day.

For example, if you set the sending time as 20:00, the system will send a report at 20:00 every day, containing the number of people entered and exited detected between 00:00 and 24:00 before the current day.

Weekly Report and Monthly Report

As compared to daily report, weekly report and monthly report can be less time-consuming, since they are not to be submitted every day. The system will send one report at the sending time every week or every month, which contains the number of people entered and exited detected on the last 7 days or last month before the sending date.

For example, for weekly report, if you set the sending time as 6:00 on Monday, the system will send a report at 6:00 in the morning on every Monday, containing number of people entered and exited detected between last Monday and Sunday.

6. After setting the report type, set how the report will present the data detected in the specified time period.

Example

For example, if you select the report type as **Daily**, you can select **Calculate by Hour** or **Calculate by Minute**. There will be 24 or 24×60 records for each camera respectively in the report, showing the number of people entered and exited detected in each hour or each minute for one camera.

- **7.** Set the sending time according to the report type.
- **8.** Select the email template from the drop-down list to define the recipient information and email format.

iNote

You can click **Add New** to add a new email template. For setting the email template, refer to **Set Email Template**.

9. Finish adding the report.

- Click **Add** to add the report and go back to the report list page.
- Click Add and Continue to add the report and continue adding other reports.

24.17.5 Send Queue Analysis Report Regularly

You can set a regular report rule for specified cameras which support queue management, and the system can send an email with a report attached to the target recipients daily, weekly, or monthly, showing queue exceptions, number of persons in the queue, and queue status, detected by these people counting cameras during the specified time periods.

Before You Start

- Set the email template with recipient information, subject, and content. For details, refer to **Set Email Template**.
- Set the email settings such as sender address, SMTP server address and port, etc. For details, refer to *Configure Email Account*.

Steps

iNote

- One report can contain up to 10,000 records in total.
- The report will be an Excel file.
- 1. Click System on the home page and enter Report page.
- 2. Select the report category as Queue.
- **3.** Create a name for the report.
- **4.** Set the camera(s) which support queue management contained in the report.
 - 1) In the Report Target field, click Add.

All the camera(s) which support queue management added to the current site are displayed.

- 2) Select the camera(s).
- 3) Click Add.

The report will show the data of all the queues configured on the cameras.

iNote

For configuring the queue, refer to the user manual of the camera.

5. Set the report type as Daily, Weekly, or Monthly.

Daily Report

Daily report shows data on a daily basis. The system will send one report at the sending time every day, which contains data detected on the day (24 hours) before the current day.

For example, if you set the sending time as 20:00, the system will send a report at 20:00 every day, containing queue data detected between 00:00 and 24:00 before the current day.

Weekly Report and Monthly Report

As compared to daily report, weekly report and monthly report can be less time-consuming, since they are not to be submitted every day. The system will send one report at the sending

time every week or every month, which contains the queue data detected on the last 7 days or last month before the sending date.

For example, for weekly report, if you set the sending time as 6:00 on Monday, the system will send a report at 6:00 in the morning on every Monday, containing queue data detected between last Monday and Sunday.

6. Set the content in the report.

Queue Exception

The number of exceptions (people amount exceeding and waiting timeout) of each queue.

People Amount Exceeding

The number of persons in the queue exceeds the configured threshold.

Waiting Timeout

The waiting duration for the persons in the queue exceeds the configured threshold.

Person Amount in Queue

The number of persons in each queue.

Queue Status

The status of each queue, including persons' waiting duration and number of persons in the queue.

If you select **Queue Status**, you should select the **Analysis Type** as waiting duration or queue length, and set the range.

Waiting Duration

The report will show the number of persons in each queue who have waited for specified duration.

For example, if you set the report range as **Range 1 < 300 \le Range 2 \le 600 < Range 3**, the report will show that in each queue, how many persons have waited for less than 300s, how many persons have waited for 300 to 600s, and how many persons have waited for more than 300s.

Queue Length

The report will show how many seconds each queue status (number of persons in different ranges) lasts.

For example, if you set the report range as **Range 1** < 5 ≤ **Range 2** ≤ 10 < **Range 3**, the report will show that in each queue, how many seconds the status lasts when there are less then 5 persons, how many seconds the status lasts when there are 5 to 10 persons, and how many seconds the status lasts when there are more than 10 persons.

- **7.** Set the sending time according to the report type.
- **8.** Select the email template from the drop-down list to define the recipient information and email format.

iNote

You can click **Add New** to add a new email template. For setting the email template, refer to **Set Email Template**.

- **9.** Finish adding the report.
 - Click **Add** to add the report and go back to the report list page.
 - Click Add and Continue to add the report and continue adding other reports.

24.17.6 Send Heat Map Report Regularly

You can set a regular report rule for specified heat map cameras, and the system can send an email with a report attached to the target recipients daily, weekly, or monthly, showing the heat map data (people dwell time at each location and number of people detected) during the specified time periods.

Before You Start

- Set the email template with recipient information, subject, and content. For details, refer to **Set Email Template**.
- Set the email settings such as sender address, SMTP server address and port, etc. For details, refer to *Configure Email Account*.

Steps

iNote

- One report can contain up to 10,000 records in total.
- The report will be an Excel file.
- 1. Click System → Report to enter the report settings page.
- 2. Select the report category as Heat Map.
- **3.** Create a name for the report.
- 4. Set the heat map camera(s) contained in the report.
 - 1) In the Report Target field, click Add.

All the heat map camera(s) added to the current site are displayed.

- 2) Select the heat map camera(s).
- 3) Click Add.
- 5. Set the report type as Daily, Weekly, or Monthly and set the sending time.

Daily Report

Daily report shows data on a daily basis. The system will send one report at the sending time every day, which contains data detected on the day (24 hours) before the current day.

For example, if you set the sending time as 20:00, the system will send a report at 20:00 every day, containing the heat map data detected between 00:00 and 24:00 before the current day.

Weekly Report and Monthly Report

As compared to daily report, weekly report and monthly report can be less time-consuming, since they are not to be submitted every day. The system will send one report at the sending time every week or every month, which contains the heat map data detected on the last 7 days or last month before the sending date.

For example, for weekly report, if you set the sending time as 6:00 on Monday, the system will send a report at 6:00 in the morning on every Monday, containing heat map data detected between last Monday and Sunday.

6. After setting the report type, set how the report will present the data detected in the specified time period.

Example

For example, if you select the report type as **Weekly**, you can select **Calculate by Day** or **Calculate by Hour**. There will be 7 or 7×24 records for each camera respectively in the report, showing the people amount or dwell time detected on each day or each hour for one camera.

7. Set the content in the report.

Dwell Time

The minutes that the people stay at the same location during each time period for each camera.

People Amount

The number of people detected during each time period for each camera.

- **8.** Set the sending time according to the report type.
- **9.** Select the email template from the drop-down list to define the recipient information and email format.

iNote

You can click **Add New** to add a new email template. For setting the email template, refer to **Set Email Template**.

10. Finish adding the report.

- Click Add to add the report and go back to the report list page.
- Click Add and Continue to add the report and continue adding other reports.

24.17.7 Send Pathway Report Regularly

You can set a regular report rule for specified fisheye cameras which support pathway analysis, and the system can send an email with a report attached to the target recipients daily, weekly, or monthly, showing the people counting data (people dwell time at each location and number of people) on the configured pathways, detected by these fisheye cameras, during the specified time periods.

Before You Start

- Set the email template with recipient information, subject, and content. For details, refer to **Set Email Template**.
- Set the email settings such as sender address, SMTP server address and port, etc. For details, refer to *Configure Email Account*.

Steps

iNote

- One report can contain up to 10,000 records in total.
- The report will be an Excel file.
- 1. Click System on the home page and enter Report page.
- 2. Select the report category as Pathway.
- **3.** Create a name for the report.
- 4. Set the fisheye camera contained in the report, which support pathway analysis.
 - 1) In the Report Target field, click Add.

All the fisheye cameras added to the current site which support pathway analysis are displayed.

- 2) Select one fisheye camera.
- 3) Click Add.
- 5. Set the report type as Daily, Weekly, or Monthly.

Daily Report

Daily report shows data on a daily basis. The system will send one report at the sending time every day, which contains data detected on the day (24 hours) before the current day.

For example, if you set the sending time as 20:00, the system will send a report at 20:00 every day, containing people amount and dwell time detected between 00:00 and 24:00 before the current day.

Weekly Report and Monthly Report

As compared to daily report, weekly report and monthly report can be less time-consuming, since they are not to be submitted every day. The system will send one report at the sending time every week or every month, which contains the heat map data detected on the last 7 days or last month before the sending date.

For example, for weekly report, if you set the sending time as 6:00 on Monday, the system will send a report at 6:00 in the morning on every Monday, containing people amount and dwell time detected between last Monday and Sunday.

6. After setting the report type, set how the report will present the data detected in the specified time period.

Example

For example, if you select the report type as **Weekly**, you can select **Calculate by Day** or **Calculate by Hour**. There will be 7 or 7×24 records for each camera respectively in the report, showing the people amount and dwell time detected on each day or each hour for one camera.

- **7.** Set the sending time according to the report type.
- **8.** Select the email template from the drop-down list to define the recipient information and email format.

iNote

You can click **Add New** to add a new email template. For setting the email template, refer to **Set Email Template**.

- **9.** Finish adding the report.
 - Click Add to add the report and go back to the report list page.
 - Click Add and Continue to add the report and continue adding other reports.

24.17.8 Send Temperature Report Regularly

You can set a regular report rule for specified thermal cameras, and the system can send an email with a report attached to the target recipients daily, weekly, or monthly, showing temperature exceptions or min./max. temperature, detected by these thermal cameras during the specified time periods.

Before You Start

- Set the email template with recipient information, subject, and content. For details, refer to **Set Email Template**.
- Set the email settings such as sender address, SMTP server address and port, etc. For details, refer to *Configure Email Account*.

Steps

iNote

- One report can contain up to 10,000 records in total.
- The report will be an Excel file.
- 1. Click System on the home page and enter Report page.
- 2. Select the report category as Temperature.
- **3.** Create a name for the report.
- **4.** Set the thermal camera(s) and presets contained in the report.
 - 1) In the Report Target field, click Add.

All the thermal camera(s) added to the current site are displayed.

- 2) Select the thermal camera(s) and preset.
- 3) Click Add.

The report will show the temperature exceptions (including temperature too high or too low) or maximum and minimum temperature of different thermometry points on these presets.

5. Set the report type as Daily, Weekly, or Monthly and set the sending time.

Daily Report

Daily report shows data on a daily basis. The system will send one report at the sending time every day, which contains data detected on the day (24 hours) before the current day.

For example, if you set the sending time as 20:00, the system will send a report at 20:00 every day, containing the temperature exceptions or min./max. temperature detected between 00:00 and 24:00 before the current day.

Weekly Report and Monthly Report

As compared to daily report, weekly report and monthly report can be less time-consuming, since they are not to be submitted every day. The system will send one report at the sending time every week or every month, which contains the temperature exceptions or min./max. temperature detected on the last 7 days or last month before the sending date.

For example, for weekly report, if you set the sending time as 6:00 on Monday, the system will send a report at 6:00 in the morning on every Monday, containing temperature exceptions or min./max. temperature detected between last Monday and Sunday.

6. After setting the report time, set how the report will present the data detected in the specified time period.

Example

For example, if you select the report type as **Daily**, you can select **Calculate by Hour** or **Calculate by Minute**. There will be 24 or 24×60 records for each thermometry point respectively in the report, showing the temperature exceptions or min./max. temperature detected in each hour or each minute.

7. Set the content in the report.

Temperature Exception

The number of exceptions on temperature (temperature too high or too low) of each thermometry point.

Temperature Status

The maximum temperature and minimum temperature of each thermometry point.

8. Select the email template from the drop-down list to define the recipient information and email format.

iNote

You can click **Add New** to add a new email template. For setting the email template, refer to **Set Email Template** .

- **9.** Finish adding the report.
 - Click Add to add the report and go back to the report list page.
 - Click Add and Continue to add the report and continue adding other reports.

24.17.9 Send Attendance Report Regularly

You can set a regular report rule for specified attendance groups, and the system can send an email with a report attached to the target recipients daily, weekly, or monthly, showing the attendance records of the persons during the specified time periods in these attendance groups.

Before You Start

- Set the email template with recipient information, subject, and content. For details, refer to **Set Email Template**.
- Set the email settings such as sender address, SMTP server address and port, etc. For details, refer to *Configure Email Account*.

Steps

iNote

- One report can contain up to 10,000 records in total.
- The report will be an Excel file.
- **1.** Click **System** \rightarrow **Report** to enter the report setting page.
- 2. Select the report category as Attendance.
- **3.** Create a name for the report.
- 4. Click Add to select the attendance group for this report.

The attendance records of the persons in the selected attendance group will be calculated in this report.

5. Set the report type as Daily, Weekly, or Monthly and set the sending time.

Daily Report

Daily report shows data on a daily basis. The system will send one report at the sending time every day, which contains data detected on the day (24 hours) before the current day.

For example, if you set the sending time as 20:00, the system will send a report at 20:00 every day, containing the persons' attendance records detected between 00:00 and 24:00 before the current day.

Weekly Report and Monthly Report

As compared to daily report, weekly report and monthly report can be less time-consuming, since they are not to be submitted every day. The system will send one report at the sending time every week or every month, which contains the persons' attendance records detected on the last 7 days or last month before the sending date.

For example, for weekly report, if you set the sending time as 6:00 on Monday, the system will send a report at 6:00 in the morning on every Monday, containing persons' attendance records detected between last Monday and Sunday.

iNote

The system will calculate the attendance records of the previous day at 4 a.m. every day. For accuracy of the report time, you cannot set to send the report between 0 a.m. to 4:59 a.m.

6. Select the email template from the drop-down list to define the recipient information and email format.

iNote

You can click **Add New** to add a new email template. For setting the email template, refer to **Set Email Template**.

- 7. Finish adding the report.
 - Click Add to add the report and go back to the report list page.
 - Click Add and Continue to add the report and continue adding other reports.

24.18 Enable Evidence Collection

Only when evidence collection is enabled, can the operators save specific video footage as evidence and search the saved evidence on the Control Client. Evidence collection can help to settle issues such as traffic disputes and criminal cases.

Before You Start

You should have configured a SFTP (Secure File Transfer Protocol) server.

Steps

iNote

Operator is the role that has all the permission for operating the Control Client and the permission for operating the Applications (Live View, Playback, and Local Configuration) on the Web Client. For details about configuring users and roles, see *Manage Role and User*.

- **1.** Click **System** → **Evidence Collection** to enter the Evidence Collection page.
- 2. Set the Evidence Collection switch to ON.

The required information for enabling evidence collection will be displayed.

3. Set the required SFTP parameters.

SFTP Address

Enter the IP address of the SFTP server.

Port

Enter the port number of the SFTP server.

User Name

Enter the user name of the SFTP server.

Password

Enter the password of the SFTP server.

4. Set other required parameters for the evidence.

Evidence Type

Define the evidence types that the operators can select when they edit evidence information on the Control Client.

Organization on Site

Define the type(s) of organization on site that the operators can select when they edit the evidence information on the Control Client.

Organization on site refers to the organization or personnel (e.g., police, fire department) on the site of the accident or criminal incident.

Result/Conclusion

Define the evidence-related incidents' results or conclusions that the operators can select when they edit evidence information on the Control Client.

5. Click Save to enable evidence collection.

24.19 Set Transfer Protocol

You can set the SYS server's transfer protocol to define the access mode for the SYS (via Web Client, Control Client, or Mobile Client) as HTTP or HTTPS. The HTTPS protocol provides higher data security. For system with distributed deployment License, you can also enable encrypted transmission to encrypt the data transmission between Application Data Server and System Management Server, thus enhancing the system security.

Steps

iNote

Setting transfer protocol is only available when accessing the Web Client on the SYS server locally.

- 1. Click System → Advanced → Transfer Protocol .
- 2. In the Clients and SYS Transfer field, select HTTP or HTTPS as the transfer protocol between the clients (Web Client, Control Client, and Mobile Client) and the SYS servers.
- **3.** If you select **HTTPS**, you are required to set the certificate. You can use the system provided certificate, or select **New Certificate** and click _____ to select a new certificate file.

iNote

- The new certificate should be in PEM format.
- The public key and private key should be in the same certificate file.
- **4. Optional:** Check **Encrypted Transmission** to encrypt the data transmission between Application Data Server and System Management Server.

iNote

This field will show when the system's License support server distributed deployment.

- 5. Click Save.
 - The SYS server will reboot automatically after changing the clients and SYS server transmission settings.
 - All the users logged in will be forced logout during reboot. The reboot takes about one minute and after that, the users can login again.

24.20 Set Camera ID

When displaying live view on smart wall, you may use a keyboard for convenience operations such as starting live view on smart wall, PTZ control, etc. If you want to display certain camera's live view on smart wall, you should press the camera's identifier number on the keyboard, which is called **Camera ID**. As a result, HikCentral Professional provides this module for you to set a unique ID for each camera.

Click System \rightarrow Advanced \rightarrow Camera ID to enter the camera ID settings page.

You can filter the cameras by setting the site and area, or entering keywords of camera name or camera ID.

The system provides a default ID for each camera. You can edit the default value for the cameras if needed.

iNote

The camera ID should be unique in the system.

24.21 Set Working Mode

In access control, if you adopt DS-K5600 face recognition series (such as DS-K5603-Z) in actual application, you need to set the working mode for these devices after adding them to the system according to actual needs.

If the DS-K5600 series device is applied with our turnstile, select **Face Recognition Terminal** mode to form a turnstile with face recognition function. The persons can access the turnstile by scanning their faces with the DS-K5600 series device after setting the face credentials and access levels.

If the DS-K5600 series device is applied with other third-party turnstile, select **Access Control Terminal** mode and you can set access levels in the system to define the access permissions.

24.22 Export Service Component Certificate

For data security, before adding the Streaming Server or Cloud Storage Server to the system, you should export the service component certificate stored in the SYS server and import it to the Streaming Server or Cloud Storage Server you want to add so that the certificates of the Streaming Server or Cloud Storage Server and SYS server are the same.

Steps

i Note

Exporting SYS server's service component certificate is only available when you access the Web Client on the SYS server locally.

1. Click System → Advanced → Service Component Certificate .

2. Click Export to export the service component certificate and save it in the local PC.

What to do next

Import the exported certificate file to the Cloud Storage Server and Streaming Server you want to add. For the following operations, see *Add Cloud Storage Server* and *Add Streaming Server* for details.

24.23 Set Health Check Frequency

The SYS server will perform health check to the resources managed in the system, including devices, servers, and configurations. The system will display the health check results in the Health Monitoring module on the Control Client, including the devices' online/offline status, recording status, etc. You can set the frequency which controls how often the system gets the latest status of the devices, servers, and configurations.

Enter System \rightarrow Advanced \rightarrow Health Check Frequency .

Device Health Status

You can set the health check frequency for the devices managed in the system, including encoding devices, access control devices, security control devices, and dock stations. It controls how often the system pings these devices to determine if they're online.

After disabled, the system will not update the status of the managed devices. You need to refresh manually to get the latest status.

Server Health Status

You can set the health check frequency for the managed Recording Servers and facial recognition servers. It controls how often the system pings these servers to determine if they're online. After disabled, the system will not update the status of the managed servers. You need to refresh manually to get the latest status.

Others

- **Device Capabilities:** Set how often the system gets the managed devices' capabilities. After disabled, the system will not update the capability changes of all the managed devices. You need to refresh manually to get the latest status.
- **Recording:** Set how often the system checks the camera's recording status. After disabled, the system will not update the cameras' recording status.
- Alarm/Event Enabled or Not: Set how often the system checks whether the events and alarms are enabled or not. After disabled, the system will not update the configured event and alarm rules status.
- **Remote Alarm Enabled or Not:** Set how often the system checks whether the events and alarms configured on the Remote Sites are enabled or not. After disabled, the system will not update the configured alarm rules status configured on the Remote Sites.

24.24 Configure System Hot Spare

A hot spare is used as a failover mechanism to provide reliability for your system. If you build the hot spare system when installing the SYS service, you can enable the hot spare function and configure the hot spare property of the current SYS server as host server or spare server. When the host server fails, the spare server switches into operation, thus ensuring the stability of the system.

Steps

- 1. Click System → Advanced → Hot Spare .
- **2.** Set the **Hot Spare Configuration** switch to ON to enable the hot spare function. The current SYS server's server name and available IP address will be displayed.
- **3.** Set the server as host server or spare server in Hot Spare Property.
- 4. Click Save.

24.25 Reset Device Network Information

When system network domain changes (such as server migration), you must reset the network information of the added device to adapt to the new network environment. Otherwise the device live view, playback and other functions will be affected.

Perform this task when you need to reset the network information of the added device.

Steps

1. Click System → Advanced → Reset Network Information .

2. Click Reset to one-touch reset the device network information.

Chapter 25 Applications

The HikCentral Professional provides functionalities of live view, playback, and local configuration through web browser.

iNote

- If the SYS's transfer protocol is HTTPS, the Applications module (including Live View, Playback, and Local Configuration) is available only when accessing the Web Client via Internet Explorer.
- If the SYS's transfer protocol is HTTP, the Live View and Playback modules are available for Internet Explorer, Google Chrome, Firefox, and Safari 11 and above. But Local Configuration module is available for Internet Explorer only.

25.1 Live View

In the Live View module of Web Client, you can view the live video of the added cameras and do some basic operations, including picture capturing, recording, PTZ control, and so on.

25.1.1 Start Live View

After adding the cameras into areas, you can start live view to view the camera's live video, and perform some basic operations via the Web Client.

Before You Start

An area with cameras assigned to is required to be defined for live view.

Perform this task when you need to view the live video of the camera via Web Client.

Steps

- 1. Click Live View on home page to enter the Live View page.
- **2.** Select a site from the drop-down list.

The area and cameras of the selected site is displayed.

3. Optional: Enter a keyword of camera name or area name in the search field and click **Search in All Sites** or **Search in Current Site** to search the cameras or areas.

All the search results display.

iNote

You can move the cursor to the camera name to view the image thumbnail.



Figure 25-1 Thumbnail

4. Optional: Click e on the live view toolbar, and select a window division mode.

iNote

Up to16-window mode is available when you access the Web Client via the Google Chrome, Firefox, Internet Explorer, or Safari.

5. Drag the camera to the display window, or double-click the camera name after selecting the display window to start the live view. The selected window is outlined in red.

\sim	\sim	
	•	
		Note
		ΙΝΟΤΡ
\sim	\sim	HOLC

- If the system is Central System with Remote Site Management module, you can also view the live video of the cameras imported from remote site. For managing remote site's cameras in areas, refer to *Add Camera to Area for Remote Site*.
- You can also double-click the area name to start the live view of cameras in the area. The display windows adapt to the number of cameras in the area.
- **6. Optional:** Move the cursor over the display window during live view, and you can perform some operations, such as digital zoom, instant playback, two-way audio, fisheye dewarping, and PTZ control, etc.

25.1.2 PTZ Control

Cameras with the pan/tilt/zoom functionality can be controlled through the web browser. You can also set the preset, patrol, and pattern for the cameras.

Configure Preset

A preset is a predefined image position which contains configuration parameters for pan, tilt, zoom, focus and other parameters. You can also set a virtual preset after enabling digital zoom.

Steps

- **1.** Click **Live View** on the home page to enter the live view page.
- **2.** Start live view of camera.

iNote

See Start Live View for details about how to start live view.

- **3.** Click on the live view toolbar to open the PTZ control panel.
- 4. Click 💌 to enter the PTZ preset configuration panel.

(a a)	đđ	\$
<u>)</u>	. <u>.</u> .	♠ 🗶
*	S	~*
V Preset1	ହ	*~
	ç	*~
Preset1	Ş	*~~
Preset1 Preset2	ତ	[™] ~
Preset1 Preset2 Preset3	Ş	*~~

Figure 25-2 Configure Preset

5. Click the direction buttons to move the camera to the desired view or zoom in/out the view.

iNote

You can also scroll the mouse wheel to zoom in or zoom out the view.

- 6. Select a PTZ preset number from the preset list and click $\ensuremath{\boxtimes}$.
- 7. Create a name for the preset.
- 8. Click OK to save the settings.

iNote

- Up to 256 presets can be added.
- The unconfigured preset is gray.

The configured preset is highlighted.

9. Optional: After setting the preset, you can do one or more of the followings:

Call Preset	Double-click the configured preset in the list, or select the preset and click to call the preset.
Edit Preset	Select the configured preset from the list and click 🗹 to edit it.
Delete Preset	Select the configured preset from the list and click 🗙 to delete it.

Configure Patrol

A patrol is a scanning track specified by a group of user-defined presets (including virtual presets), with the scanning speed between two presets and the dwell time of the preset separately programmable.

Before You Start

Two or more presets for one PTZ camera need to be added.

iNote

See *Configure Preset* for details.

Steps

- 1. Click Live View on the home page.
- **2.** Start live view of camera.



See *Start Live View* for details about how to start live view.

- **3.** Click on the live view toolbar to open the PTZ control panel.
- 4. Click 🔁 to enter the patrol configuration panel.



Figure 25-3 Configure Patrol

- 5. Select a patrol and click $\ensuremath{\mathbb{Z}}$.
- 6. Click + to add a configured preset, and set the dwell time and the patrol speed.

iNote

- The preset dwell time ranges from 15 to 30s.
- The patrol speed ranges from 1 to 40.
- The unconfigured patrol is gray. The configured patrol is highlighted.
- **7.** Repeat the above step to add other presets to the patrol.

+ oeed •	× ↓ Time 15 ▼ 30 ▼	
•	15 🔻	e
•	30 👻	
Ca	ancel	
		Cancel

Figure 25-4 Add Preset to Patrol

8. Optional: Perform the following operations after adding the preset.

Remove Preset from Patrol	Select the added preset and click \times to remove the preset from the patrol.
Adjust Preset Sequence	Select the added preset and click $\uparrow \downarrow$ to adjust the preset sequence.

9. Click **OK** to save the patrol settings.

iNote

Up to eight patrols can be configured.

10. Optional: Perform the following operations after setting the patrol.

Call Patrol Click () to start the patrol.

Stop Calling Patrol Click **O** to stop the patrol.

Configure Pattern

You can set patterns to record the movement of the PTZ.

Perform this task when you need to add a pattern for the camera.

Steps

- **1.** Click **Live View** on the home page to enter the Live View page.
- **2.** Start live view of the camera.

iNote

See Start Live View for details about how to start live view.

- **3.** Click on the live view toolbar to open the PTZ control panel.
- 4. Click 📈 to enter the PTZ pattern configuration panel.

	 <th></th><th>×</th>		×
	d d		0
<u>(</u>) (1)	·@·	Ŷ	36
1	\odot		~*
Pattern 1			

Figure 25-5 Configure Pattern

- 5. Click () to start recording movement pattern path.
- 6. Click the direction buttons and other buttons to control the PTZ movement.
- 7. Click O to stop and save the pattern recording.

iNote

Only one pattern can be configured each time, and the newly-defined pattern will overwrite the previous pattern.

8. Optional: Perform the following operations after setting the pattern.

Call Pattern Click (b) to call the pattern.

Stop Calling Pattern Click
Click

Delete Pattern Click **x** to delete the pattern.

25.2 Playback

The video files stored on the local storage devices such as HDDs, Net HDDs and SD/SDHC cards or the Recording Server can be searched and played back remotely through the web browser.

25.2.1 Search Video File

You can search the video files of cameras and filter the searched video files by video type or by storage location.

Perform this task when you need to search the specific video files.

Steps

- 1. Click Playback on home page to open the Playback page.
- 2. Optional: Enter a keyword of camera name or area name in the search field and click Search in All Sites or Search in Current Site to search the cameras or areas.

All the search results display.

iNote

You can move the cursor to the camera name to view the image thumbnail.



Figure 25-6 Thumbnail

3. Drag the camera to the display window, or double-click the camera to start the playback.

iNote

If the system is central system with Remote Site Management module, you can also play back the recorded video of the cameras imported from remote site. For managing remote site's cameras in areas, refer to *Manage Area*.

4. Optional: Click the date and time on the toolbar to select the date and time to search the video files.

iNote

- In the calendar panel, the date with video files will be marked with a triangle.
- The calendar is not supported by cameras on remote site.
- **5. Optional:** Click on the playback toolbar to select the video file type for playback.
- 6. Optional: Select the storage location and the stream type of the video files for playback.

For camera configured with auxiliary storage:	Select the storage location of the video files for playback.
For camera configured with dual- stream recording:	Select the stream type of the video files for playback.

i Note

For setting the storage location of recording, refer to Configure Recording.

25.2.2 Play Video File

After searching the video files, the playback starts. You can control the video playback via timeline. The timeline indicates the time duration for the video file.

Perform this task when you need to control the playback.

Steps

- **1.** Click **Playback** on home page to open the Playback page.
- **2.** Search the video file of cameras for playback. For details, refer to *Search Video File*. The playback starts.
- **3.** Click the icons on the toolbar to control the playback.
- 4. Click on the timeline or drag the timeline to play back the video of the specific time.
- 5. Optional: Click 🖬 or 🗐 or use the mouse wheel to scale up or scale down the timeline bar.
- **6. Optional:** Move the cursor to the display window in playback to access further functions, including capture, clipping, and other functions.

Open Digital	Click 💽 to enable the digital zoom function and draw a rectangle on the video. Click again to disable the function.	
Zoom	i Note	
	When in software decoding mode, you can also capture the zoomed in picture after enabling digital zoom function.	
Camera Status	Click 👿 to show the camera's recording status, signal status, connection number, etc.	

Stream Switch	Click 😭 , 😭 , or 😭 (if supported) to switch the live view stream to main stream, sub-stream, or smooth stream (if supported).
	iNote
	The smooth stream will show if the device supports smoothing function. You can switch to smooth stream if in low bandwidth situation to make live view more fluent.
Audio Control	Click 👩 or 💐 to turn off/on the sound.
Control	iNote
	You can adjust the volume when moving the cursor on $_{40}$.

25.3 Local Configuration

HikCentral Professional provides live view and playback functions via the Web Client. You can set the related network transmission parameters (such as hardware decoding, stream type, etc.) for the performance of live view and playback via the current Web Client. You can also view the saving path of video files and captured pictures on your current PC.

Steps

iNote

The parameters in Local Configuration only affect the current Web Client.

- **1.** Click **Local Configuration** on home page to enter the Local Configuration page.
- 2. Click Network Transmission tab on the left.
- **3.** Set the following parameters as desired.

GPU Hardware Decoding

Enable the GPU decoding for live view and playback to save CPU resources.

iNote

- Your PC must support GPU hardware decoding.
- After enabling GPU hardware decoding, restart live view and playback to take effect.
- If the client shows a blurred screen after enabling GPU hardware decoding, disable it.

Global Stream

The default stream type for global usage in the current Web Client.

If the device doesn't support smooth stream, it will use sub-stream. If the device doesn't support sub-stream, it will use main stream.

If the network is in good condition, select main stream or sub-stream. If the network is in poor condition, select smooth stream.

Threshold for Main/Sub-Stream

If a window's proportion of the displaying area is larger than the configured threshold, the stream type will be main stream. If the proportion is smaller than the threshold, it will be switched to sub-stream.

For example, if you set the threshold as ¼, when the window division turns to 5-window, the camera's stream type will be switched from main-stream to sub-stream.



This parameter is only available when the Global Stream is set as Main Stream.

Network Timeout

The default waiting time for the operations in Applications on the current Web Client. The operations will be regarded as failure if no response within the configured time.

The minimum default waiting time of the interactions between the Applications and SYS server is 60s, the minimum time between SYS server and devices is 5s, and the minimum time between the Applications and devices is 5s.

Video Caching

Video caching should be determined based on network performance, computer performance, and bit rate. You can set is as **Small (1 Frame)**, **Medium (6 Frames)**, or **Large (15 Frame)**. Larger frame caching will result in better video performance.

Picture Format

Set the file format for the captured pictures during live view or playback. Currently it supports **BMP** and **JPEG** formats.

Device Access Mode

Restore Default

Restore the device access mode as configured in the **System** \rightarrow **Device Access Mode** on Web Client.

Automatically Judge

Judge the device access mode according to the current network.

Directly Access

Access the device directly, not via HikCentral Professional Streaming Service.

Proxy

Access the device via HikCentral Professional Streaming Gateway and HikCentral Professional Management Service.

iNote

By default, the system will judge the device access mode according to the current network. If you change to other mode, it only affects the client you logged in currently.

4. Optional: Click Default Value to restore the defaults of the settings.

- 5. Click Save.
- **6. Optional:** Click **Saving Path** on the left to view the saving path of the recorded or clipped video files and captured pictures during live view or playback in your local PC.

Chapter 26 Important Ports

HikCentral Professional uses particular ports when communicating with other servers, devices, and so on.

Make sure that the following ports are not occupied for data traffic on your network and you should forward these ports on router for WAN access or open these ports in the firewall in case you may need to access the system via other networks.

Destination	Port No.	Description
System Manager	nent Service (SYS) Port	
NGINX	80 (HTTP/WebSocket)	Used for web browser access in HTTP protocol.
NGINX	443 (HTTPS/ WebSocket over TLS)	Used for web browser access in HTTPS protocol.
SYS	14200 (HTTP/HTTPS)	Used for Remote Site registration to central system.
SYS	15300 (TCP and UDP)	Used for receiving generic event.
SYS	7332 (TCP)	Used for receiving alarms from EHome device.
SYS	7660 (TCP)	Used for receiving registration from EHome device.
SYS	7661 (TCP)	Used for getting stream from EHome device via Streaming Server
SYS	30051 (HTTP)	Used for communication between SYS and ADS in server distributed deployment.
SYS	30053 (HTTPS)	Used for communication between SYS and ADS in server distributed deployment, after encrypted transmission enabled.
Streaming Gateway	554 (RTSP)	Used for getting stream (real time streaming port).
Streaming Gateway	559 (WebSocket)	Used for getting stream for Google Chrome or Firefox (WebSocket port).
Streaming Gateway	10000 (TCP)	Used for getting stream for playback (video file streaming port).
Streaming Gateway	16000 (TCP)	Used for getting stream from EHome device via plugin.
Keyboard Proxy Service (KPS)	8910 (HTTP)	Used for network keyboard to access the Keyboard Proxy Service.

Destination	Port No.	Description
NTP Service	123 (UDP)	NTP port used for time synchronization.
PostgreSQL	5432 (TCP)	Used for database access.
		i Note
		This port is available in distributed deployment.
Application Data	Service (ADS) Port	
ADS	30054 (HTTPS)	Used for communication between SYS and ADS in server distributed deployment, after encrypted transmission enabled.
ADS	30052 (HTTP)	Used for communication between SYS and ADS.
ADS	19999 (HTTP)	Used for communication between SYS's NGINX and ADS.
ADS	19443 (HTTPS)	Used for communication between SYS's NGINX and ADS.
WDS	6208 (WebSocket)	Listen port for Service Manager.
WDS	8208 (WebSocket over TLS)	Listen port for Service Manager after encrypted transmission enabled.
PostgreSQL	5432 (TCP)	Used for real-time data synchronization between Application Data Server and Application Data Standby Server.
		i Note
		This port is available in distributed deployment.
Streaming Servic	e Port	
Streaming Service	554 (RTSP)	Used for Streaming Service to get stream (real time streaming port).
Streaming Service	559 (WebSocket)	Used for getting stream for Google Chrome or Firefox (WebSocket port).
Streaming Service	10000 (TCP)	Used for Streaming Service to get stream for playback (video file streaming port).
Streaming Service	6001 (TCP)	Network management port.
Streaming Service	16000 (TCP)	Used for getting stream from EHome device via plugin.

