



## Education Flat Panel

Device Command

**© 2020 Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.**

This Manual (hereinafter referred to be “the Manual”) is the property of Hangzhou Hikvision Digital Technology Co., Ltd. or its affiliates (hereinafter referred to as “Hikvision”), and it cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of Hikvision. Unless otherwise expressly stated herein, Hikvision does not make any warranties, guarantees or representations, express or implied, regarding to the Manual, any information contained herein.

### **About this Manual**

Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to updates or other reasons. Please use this Manual with the guidance and assistance of professionals trained in supporting the Product.

### **LEGAL DISCLAIMER**

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE MANUAL IS PROVIDED "AS IS" AND “WITH ALL FAULTS AND ERRORS”. HIKVISION MAKES NO REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT. IN NO EVENT WILL HIKVISION BE LIABLE FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), OR OTHERWISE, IN CONNECTION WITH THE USE OF THE MANUAL, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.

| Command Type (Optional) | Command Name  | Command Function  | Format   | More Information | Usage Example (Optional) |
|-------------------------|---|---|--|------------------|--------------------------|
| Production/Test         | POWER_Off<br>POWER_On<br>Mute<br>1<br>2<br>3<br>4<br>5<br>6<br>7<br>8<br>9<br>0<br>VOL+<br>VOL-<br>OSD<br>LEFT<br>RIGHT<br>DOWN<br>UP<br>Enter<br>VGA1<br>VGA2<br>HDMI1<br>HDMI2<br>HDMI3<br>HDMI<br>OPS<br>Android | Use serial port to control device.<br>Serial port baud rate is 115200, 8N1. | 30 02 76 20<br>20 20 53 43<br>30 02 01 5F<br>30 02 01 01<br>30 02 01 02<br>30 02 01 03<br>30 02 01 04<br>30 02 01 05<br>30 02 01 06<br>30 02 01 07<br>30 02 01 08<br>30 02 01 09<br>30 02 01 00<br>30 02 01 14<br>30 02 01 11<br>30 02 01 7D<br>30 02 01 33<br>30 02 01 30<br>30 02 01 53<br>30 02 01 50<br>30 02 01 51<br>30 02 01 A1<br>30 02 01 A2<br>30 02 01 A3<br>30 02 01 A4<br>30 02 01 A5<br>30 02 01 A6<br>30 02 01 A7<br>30 02 01 A8<br>30 02 01 F1<br>30 02 01 F2<br>30 02 01 F3<br>30 02 01 B0<br>30 02 01 F5<br>30 02 01 B1<br>30 02 01 B2<br>30 02 01 B3<br>30 02 01 B4<br>30 02 01 B5<br>30 02 01 B6<br>30 02 01 B7<br>30 02 01 B8 |                  |                          |
| Status Viewing          | encryption<br>upgrade main program<br>upgrade MCU<br>get serial No.<br>device ready for test  | Use serial port to control device.<br>Serial port baud rate is 115200, 8N1. | 30 02 01 F1<br>30 02 01 F2<br>30 02 01 F3<br>30 02 01 B0<br>30 02 01 F5  |                  |                          |
| Parameter Configuration |   |   |  |                  |                          |