# **HIKVISION**

## **Face Recognition Terminal**

Quick Start Guide

UD19294B-D

© 2021 Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved. This Manual is the property of Hangzhou Hikvision Digital Technology Co., Ltd. or its affiliates (hereinafter referred to as 'Hikvision'), and it cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of Hikvision. Unless otherwise expressly stated herein, Hikvision does not make any warranties, guarantees or representations, express or implied, regarding to the Manual, any information contained herein. About this Manual

The Manual includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of this Manual at the Hikvision website (https://www.hikvision.com/). Please use this Manual with the guidance and assistance of professionals trained in supporting the Product.

Product.
Trademarks Acknowledgement
Trademarks Acknowledgement
HIKVISION and other Hikvision's trademarks and logos are the properties of Hikvision in various

Other trademarks and logos mentioned are the properties of their respective owners. LEGAL DISCLAIMER


INVALIDATION UNITED THE VISION STATEMENT OF THE PROPERTY OF TH

Scan the QR code to get the user manual for detailed information. Note that mobile data charges may apply if Wi-Fi is unavailable.



Use only power supplies listed in the user instructions

ose only power supplies listed in the user listingtions.		
Model	Manufacturer	Standar
C2000IC12.0-24P-DE	MOSO Power Supply Technology Co., Ltd.	CEE
C2000IC12.0-24P-GB	MOSO Power Supply Technology Co., Ltd.	BS
KBI -U4UE-MI	Channel Well Technology Co., Ltd.	CEE




## **Moutning with Bracket**

### **Installation Environment:**

**2** Installation

· Avoid backlight, direct sunlight, and indirect sunlight. For better recognition, there should be light source in or near the installation environment.





#### **Temperature Measurement Environment:**

- Sunlight, wind, hot/cool air from air conditioner and other external factors, which may affect surface temperature, will create the deviation of the temperature measurement. In order to get an accurate result, make sure the device is applied indoors and windlessly (where is relatively isolated from the outdoors). The working temperature should keep between 10 °C and 35 °C. If there are no suitable environments for temperature measurement (the area faces the indoor and connects the outdoor, the area at the door of the indoor environment, etc.), building a temporary temperature measurement environment is suggested.

  • Influence Factors of Temperature Measurement:
- Wind: The wind will take the heat away, which may affect the measurement result.

Sweat: The sweat will take the heat away, which may affect the measurement result Air Conditioner (Cool Air): If the indoor temperature is low, the surface temperature may also lower than the actual temperature, which may

affect the measurement result. **Air Conditioner (Heat) or Heating:** If the indoor temperature is high, the surface temperature may also higher than the actual temperature, which may affect the measurement result.

In order to make the device work properly, you should wait for 90 min after the device is powered on.


## Before you start:


1. Use 4 screws (M3 or M4), secured by flange nuts, to install the reinforcing board on the inner surface of the turnstile.

The distance between the turnstile and the edge should be no longer than 10 mm.

2. Drill holes on the turnstile's inner surface according to the figure displayed below. And install water-proof nut.

Solder after pressing rivets to avoid water from





Turnstile

1 Rotate to open the lower cover.

**Upper Cover** 

Lower Cover

Screw —

Base


2 Route the cables through the cable hole on the turnstile. Align the holes on the base with those on the turnstile and place the device with bracket on the tunstile. Use 4 screws to secure the bracket and the turnstile.

3 Cover the lower cover on the base and rotate to secure.


4 Loosen the screws inside and adjust the device elevation. After adjustment, secure the screws and install the upper

 $\begin{bmatrix} i \end{bmatrix}$ The default elevation angle is 15°. The adjustable elevation angle is from 0° to 15°.

**3** After installation, for the proper use of the device (outdoor use), stick the protection film (parts of models supplied) on



## 3.2 Device Wiring (With Secure Door Control Unit)



## 4 Activation

Power on and wire the network cable after installation. You should activate the device before the first login.

If the device is not activated yet, it will enter the Activate Device page after powering on. Steps:

- 1. Create a password and confirm the password.
- 2. Tap Activate to activate the device.
- i For other activation methods, see the device user manual.



STRONG PASSWORD RECOMMENDED-

We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product. 

## **5** Temperature Measurement Settings

- 1 Hold the screen surface for 3 s and slide to right/left and verify the identity to enter the main page.
- 2. Tap "Temperature" to enter the Temperature Settings page. Configure the parameters.

### • Enable Temperature Detection:

When enabling the function, the device will authenticate the permissions and at the same time take the tempearture. When disabling the device, the device will authenticate the permissions only.

#### Over-Temperature Alarm Threshold:

Edit the threshold according to actual situation. If the detected temperature is higher than the configured one, an alarm will be triggered. By default, the value is 37.3°.

#### Temperature Compensation:

If the measured temperature is higher/lower than the actual object's temperature, you can set the compensation temperature here. Available range: -99 °C to 99 °C.

#### Door Not Open When Detecting Abnormal Termperature:

When Enabling the function, the door will not open when the detected temperature is higher than the configured temperature threshold. By default, the temperature is enabled.

#### Temperature Measurement Only:

When enabling the function, the device will not authenticate the permissions, but only take the temperature. When disabling the function, the device will authenticate the permsissions and at the same time take the temperature.

Unit: Select a temperature unit according to your preference.

## **6** Add Face Picture

- 1. Hold the screen surface for 3 s and slide to right/left and verify the identity to enter the main page.
- 2. Enter the User Management page, tap + to enter the Add User
- 3. Set the user parameters according to actual needs.
- 4. Tap Face add the face information according to the instructions

You can view the captured picture on the screen.

Make sure the face picture is in good quality and size. For details about the tips and positions when collecting or

comparing the

face picture, see the contents on the right

- 5. If the picture is in good condition, tap Or tap 🔯 to take another face picture
- 6. Tap the save icon to save the settings. Go back to the initial page to start authentication. For other authentication methods, see the device user manual.
- Use other authentication methods if the device is affected by the light or other items.



Biometric recognition products are not completely applicable to an ti-spoofing environments . If you require a higher security level, use multiple authentication modes.

# **Tips When Collecting/ Comparing Face Picture**

## **Expression**

- Keep your expression naturally when collecting or comparing face pictures, just like the expression in the picture on the right
- Do not wear hat, sunglasses, or other accessories that can affect the facial recognition function.
- Do not make your hair cover your eyes, ears, etc. and heavy makeup is not allowed.

### **Posture**

In order to get a good quality and accurate face picture, position your face looking at the camera when collecting or comparing face pictures.



## Size


Make sure your face is in the middle of the collecting window.








## **Positions When Collecting/ Comparing Face Picture** (Recommended Distance: 0.5m)





# Regulatory Information

Please take attention that changes or modification not expressly approved by the party responsible for mpliance could void the user's authority to operate the equipment.

FCC compliance: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause armful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is

-Consult the dealer or an experienced radio/TV technician for help

This equipment should be installed and operated with a minimum distance 20cm between the radiator and your body

### **FCC Conditions**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two

This device may not cause harmful interference

2. This device must accept any interference received, including interference that may cause undesired operation.



This product and - if applicable - the supplied accessories too are marked with "CE" and comply therefore with the applicable harmonized European standards listed under the RE Directive 2014/53/EU, the EMC Directive 2014/30/EU, the RoHS Directive 2011/65/EU 2006/66/EC (battery directive): This product contains a battery that cannot be disposed of as unsorted municipal waste in the European Union. See the

product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead



(Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point. For more information see: www.recycle-2012/19/EU (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of

equivalent new equipment, or dispose of it at designated collection points. For COMPLIANCE NOTICE: The thermal series products might be subject to export controls in various countries or regions, including without limitation, the United States, European Union, United Kingdom and/or other member countries of the Wassenaar Arrangement. Please consult your professional legal or compliance expert or local government authorities for any necessary export license requirements if

These instructions are intended to ensure that user can use the product correctly to avoid danger or property loss.

you intend to transfer, export, re-export the thermal series products between different countries.

The precaution measure is divided into Warnings and Cautions:

Warnings: Neglecting any of the warnings may cause serious injury or death. Cautions: Neglecting any of the cautions may cause injury or equipment damage.

Warnings

■Itheelectronicoperationshouldbestrictly compliance with the electrical safety regulations, fire prevention regulations and other related regulations in your local region. • easeusethepoweradapter, which is provided by normal company. The power consumption

cannot be less than the required value. Opports and a supply of the control of the contr

fire hazard. easemakesurethatthepowerhasbeen disconnected before you wire, install or dismantle the

Thentheproductisinstalledonwall or ceiling, the device shall be firmly fixed.

moke,odorsornoiserisefromthe device, turn off the power at once and unplug the power

cable, and then please contact the service center. please contact your dealer or the nearest service center heproductdoesnotworkproperly,

Never attempt to disassemble the device yourself. (We shall not assume any responsibility for problems caused by unauthorized repair or maintenance.)



notdropthedeviceorsubjectitto physical shock, and do not expose it to high electromagnetism radiation. Avoid the equipment installation on vibrations surface or places subject to shock ignorance can cause equipment damage).

notplacethedeviceinextremelyhot (refer to the specification of the device for the detailed operating temperature), cold, dusty or damp locations, and do not expose it to high electromagnetic

• The device cover for indoor use shall be kept from rain and moisture.

posingtheequipmenttodirectsunlight, low ventilation or heat source such as heater or radiate s forbidden (ignorance can cause fire danger). notaimthedeviceatthesunor extra bright places. A blooming or smear may occur otherwise

which is not a malfunction however), and affecting the endurance of sensor at the same time. easeusetheprovidedglovewhenopenup the device cover, avoid direct contact with the device

cover, because the acidic sweat of the fingers may erode the surface coating of the device cover measeuseasoftanddryclothwhenclean inside and outside surfaces of the device cover, do not

measekeepallwrappersafterunpackthemfor future use. In case of any failure occurred, you need to return the device to the factory with the original wrapper. Transportation without the original wrapper may result in damage on the device and lead to additional costs.

properuseorreplacementofthebattery may result in hazard of explosion. Replace with the same or equivalent type only. Dispose of used batteries according to the instructions provided by the battery manufacturer.

Completely applicable to anti-spoofing environments. If you require a higher security level, use multiple authentication modes.

• dooruse.Ifinstallingthedeviceindoors, the device should be at le should be at least 2 meters away from the

ight, and at least 3 meters away from the window or the door.

• Input voltage should meet both the SELV (Safety Extra Low Voltage) and the Limited Power Source with 100~240 VAC or 12 VDC according to the IEC60950-1 standard. Please refer to technical