

WEB Configuration Command

Table of Contents

1.1 ip http language	1
1.2 ip http port.....	1
1.3 ip http secure-port	2
1.4 ip http server	2
1.5 ip http http-access enable	3
1.6 ip http ssl-access enable	3
1.7 ip http web max-vlan	4
1.8 ip http web igmp-groups	4
1.9 show ip http	5

Chapter 1 HTTP Configuration Commands

1.1 ip http language

Syntax

To set the prompt language when a command is configured, run the following command.

```
[no] ip http language { english}
```

Parameters

Parameters	Notes:
english	Sets the language to English.

Default Value

None

Usage Guidelines

This command is configured in global configuration mode.

Example

The following example shows how to set the language to English.

```
Switch_config#ip http language english
```

1.2 ip http port

Syntax

To set the HTTP port, run the following command. To return to the default setting, use the no form of this command.

```
ip http port { portNumber }
no ip http port
```

Parameters

Parameters	Description
<i>portNumber</i>	Means the HTTP port's valid range is from 1 to 65535.

Default Value

80

Usage Guidelines

This command is configured in global configuration mode.

Example

The following example shows how to set the HTTP port to 1234.

```
Switch_config#ip http port 1234
```

1.3 ip http secure-port

Syntax

To set the HTTPS port, run this command. To return to the default setting, use the no form of this command.

```
ip http secure-port {portNumber}
no ip http secure-port
```

Parameters

Parameters	Notes:
<i>portNumber</i>	Means the HTTPS port's valid range is from 1 to 65535.

Default Value

443

Usage Guidelines

This command is configured in global configuration mode.

Example

The following example shows how to set the HTTPS port to 1234.

```
Switch_config# ip http secure-port 1234
```

1.4 ip http server

Syntax

To set the HTTP service, run this command.

[no] ip http server

Usage Guidelines

This command is configured in global configuration mode.

Example

The following example shows how to set the HTTP service.

```
Switch_config# ip http server
```

1.5 ip http http-access enable

Syntax

[no] ip http http-access enable

To set the HTTP access mode, run this command.

Usage Guidelines

This command is set in global configuration mode and used to access the website, which starts with http://.

Example

The following example shows how to set the HTTP access mode.

```
Switch_config# ip http http-access enable
```

1.6 ip http ssl-access enable

Syntax

[no] ip http ssl-access enable

To set the HTTPS access mode, run this command.

Usage Guidelines

This command is set in global configuration mode and used to access the website, which starts with https://.

Example

The following example shows how to set the HTTPS access mode.

```
Switch_config# ip http ssl-access enable
```

1.7 ip http web max-vlan

Syntax

```
ip http web max-vlan { max-vlan }
```

To set the maximum number of VLAN entries displayed in a web page, run this command.

```
no ip http web max-vlan
```

To resume the default maximum number of VLAN entries to 100, run this command.

Parameters

Parameters	Notes:
<i>max-vlan</i>	Means the maximum number of vlan entries in the web page, which ranges from 1 to 4094.

Default Value

100

Usage Guidelines

This command is configured in global configuration mode.

Example

The following example shows how to set the maximum number of VLAN entries displayed in a web page to 123.

```
Switch_config# ip http web max-vlan 123
```

1.8 ip http web igmp-groups

Syntax

```
ip http web igmp-groups { igmp-groups }
```

To set the maximum number of multicast entries displayed in a web page, run this command.

```
no ip http web igmp-groups
```

To resume the default maximum number of multicast entries to 15, run this command.

Parameters

Parameters	Notes:
<i>igmp-groups</i>	Means the maximum number of multicast entries in the web page, which ranges from 1 to 100.

Default Value

15

Usage Guidelines

This command is configured in global configuration mode.

Example

The following example shows how to set the maximum number of multicast entries displayed in a web page to 12.

```
Switch_config#ip http web igmp-groups 12
```

1.9 show ip http

Syntax

```
show ip http
```

Usage Guidelines

The command is used to browse whether the HTTP server is enabled.

Example

```
Switch_config#show ip http  
Http server is running
```