HIKVISION

DS-K5604A-3XF Series **Face Recognition Terminal**

Quick Start Guide

UD19290B-F

© 2021 Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.

This Manual is the property of Hangzhou Hikvision Digital Technology Co., Ltd. or its affiliates (hereinafter referred to as 'Hikvision'), and it cannot be reproduced, changed, translated, or distributed, partially or herein, Hikvision does not make any warranties, guarantees or representations, express or implied, about this Manual.

About this Manual The Manual includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of this Manual at the Hikvision website (https://www.hikvision.com/). Please use this Manual with the guidance and assistance of professionals trained in supporting the Product. Trademarks Acknowledgement

of this Manual ait the Hikvision website (https://www.hikvision.com/).
Please use this Manual with the guidance and assistance of professionals trained in supporting the Product.
The provided of the properties of Hikvision in various uniform the properties of Hikvision in various uniform.

Other trademarks and logos mentioned are the properties of their respective owners.

Other trademarks and logos mentioned are the properties of their respective owners.

Uniformatic Company of the properties of their respective owners.

Other trademarks and logos mentioned are the properties of their respective owners.

Uniformatic Company of the properties of their respective owners.

Other trademarks and logos mentioned are the properties of their respective owners.

Other trademarks and logos mentioned are the properties of their respective owners.

Other trademarks and logos mentioned are the properties of their respective owners.

Other trademarks and logos mentioned are the properties of their respective owners.

Other trademarks and logos mentioned are the properties of their respective owners.

Other trademarks and logos mentioned are the properties of their respective owners.

Other trademarks and logos mentioned are the properties of the p


IN THE EVENT OF ANY CONFLICTS BETWEEN THIS MANUAL AND THE APPLICABLE LAW, THE LATER PREVAILS. Data Protection
During the use of device, personal data will be collected, stored and processed. To protect data, the development of Hikvision devices incorporates privacy by design principles. For example, for device with facial recognition features, biometrics data is stored in your device with encryption method; for fingerprint and a stored in your device with encryption method; for fingerprint as data controller, you are advised to collect, store, process and transfer data in accordance with the applicable data protection laws and regulations, including without limitation, conducting security controls to safeguard personal data, such as, implementing reasonable administrative and physical security controls, conduct periodic reviews and assessments of the effectiveness of your security controls. Scan the QR code to get the user manual for detailed information.

Note that mobile data charges may apply if Wi-Fi is unavailable.



Use only power supplies listed in the user instructions:

Model	Manufacturer	Standa
C2000IC12.0-24P-DE	MOSO Power Supply Technology Co., Ltd.	CEE
C2000IC12.0-24P-GB	MOSO Power Supply Technology Co., Ltd.	BS
ADS-24S-12 1224GPG	Shenzhen Honor Electronic Co., Ltd.	CEE



2 Installation

Installation Environment:

Avoid backlight, direct sunlight, and indirect sunlight.

For better recognition, there should be light source in or near

Backlight Direct Sunlight 1 Close to Light

> Indirect Sunlight Direct Sunlight through Window

through Window

Temperature Measurement Environment:


- Sunlight, wind, hot/cool air from air conditioner and other external factors, which may affect surface temperature, will create the deviation of the temperature measurement. In order to get an accurate result, make sure the device is applied indoors and windlessly (where is relatively isolated from the outdoors). The working temperature should keep between 10 °C and 35 °C. If there are no suitable environments for temperature measurement (the area faces the indoor and connects the outdoor, the area at the door of the indoor environment, etc.), building a temporary temperature measurement environment is suggested.
- Influence Factors of Temperature Measurement:
- Wind: The wind will take the heat away, which may affect the measurement

Sweat: The sweat will take the heat away, which may affect the measurement result.

Air Conditioner (Cool Air): If the indoor temperature is low, the surface temperature may also lower than the actual temperature, which may affect

Air Conditioner (Heat) or Heating: If the indoor temperature is high, the surface temperature may also higher than the actual temperature, which may affect the measurement result.

• In order to make the device work properly, you should wait for 90 min after the device is powered on.



Before you start: Make sure the ground surface has drilled holes for device installation.


1. Remove the two bottom screws (2-SC-KM3×5B-JMF) on both sides of the bottom cover. And remove the bottom

- 2. Align the device with the drilled holes on the ground and insert 3 supplied expension bolts (M6×65). Make sure the expension bolts are higher than the ground.
- 3. Secure the expension bolts with nuts.
- 4. Install the bottom cover back on the device with 2 bottom
- 5. After installation, for the proper use of the device (outdoor) use), stick the protection film (parts of models supplied) on


- The device should be installed on the concrete surface or other
- non-flammable surfaces.

 The device supports plug & play. You can put the device on the ground and start operation after powering on.

3.1 Device Wiring (Normal)




• The wiring diagram of RS-485 and Door Lock on the left is shown below:



Bottom Cover Bottom Screw

- When connecting door contact and exit button, the device and the RS-485 card reader should use the common ground
- The suggested external power supply for door lock is 12 V, 1A.

3.2 Device Wiring (With Secure Door Control Unit)





- The secure door control unit should connect to an external power supply separately. The suggested external power supply is 12 V, 0.5
- For scenarios with high safety requirement, use the secure door control unit wiring first. You can ask the technical support to purchase for the secure door control unit separately.
- The picture here are parts of the wiring. For details, see the secure door control unit's user manual.

4 Activation

Activation via Device

After powering on, you will enter the activation page.

- 1. Create a password and confirm the password.

6 Add Face Picture

tions.

i Characters containing admin and nimda are not supported to be set as activation password.



STRONG PASSWORD RECOMMENDED-

We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly. especially in the high security system, resetting the password monthly or weekly can better protect your product.

Steps Afterwards

After activating, you can select language, set password change type, set reserved questions, set application mode, set network parameters, access to Hik-Connect, set privacy, and set administrator.

5 Temperature Measurement Settings

- 1 Hold the screen surface for 3 s and slide to right/left and verify the identity to enter the main page.
- 2. Tap "Temperature" to enter the Temperature Settings page. Configure the parameters.

Enable Temperature Detection:

When enabling the function, the device will authenticate the permissions and at the same time take the tempearture. When disabling the device, the device will authenticate the permissions only.

Over-Temperature Alarm Threshold:

Edit the threshold according to actual situation. If the detected temperature is higher than the configured one, an alarm will be triggered. By default, the value is 37.3°.

Temperature Compensation:

If the measured temperature is higher/lower than the actual object's temperature, you can set the compensation temperature here. Available range: -99 °C to 99 °C.

Door Not Open When Detecting Abnormal Termperature:

When Enabling the function, the door will not open when the detected temperature is higher than the configured temperature threshold. By default, the temperature is enabled.

Positions When Collecting/

Comparing Face Picture

(Recommended Distance: 0.5m)

Too High

Too Low

Temperature Measurement Only:

When enabling the function, the device will not authenticate the permissions, but only take the temperature. When disabling the function, the device will authenticate the permsissions and at the same time take the temperature.

Unit: Select a temperature unit according to your preference.

2. Tap **Activate** to activate the device.

1. Hold the screen surface for 3 s and slide to right/left and verify

2. Enter the User Management page, tap + to enter the Add User

4. Tap Face add the face information according to the instruc-

Make sure the face picture is in good quality and size

For details about the tips and positions when collecting or

For other authentication methods, see the device user manual.

Use other authentication methods if the device is affected

Biometric recognition products are not completely applicable to anti-spoofing environments. If you require a higher security

·----

3. Set the user parameters according to actual needs.

You can view the captured picture on the screen.

Go back to the initial page to start authentication.

face picture, see the contents on the right.

5. If the picture is in good condition, tap

Or tap o to take another face picture.

6. Tap the save icon to save the settings.

by the light or other items.

level, use multiple authentication modes.

the identity to enter the main page.


Tips When Collecting/ **Comparing Face Picture**

Expression

- Keep your expression naturally when collecting or comparing face pictures, just like the expression in the picture on the right.
- Do not wear hat, sunglasses, or other accessories that can affect the facial recognition function.
- Do not make your hair cover your eyes, ears, etc. and heavy makeup is not allowed

Posture

In order to get a good quality and accurate face picture, position your face looking at the camera when collecting or comparing face pictures.




Make sure your face is in the middle of the collecting window.

Too Far 🗙







Regulatory Information

compliance could void the user's authority to operate the equipment.

FCC compliance: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection again device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the senaration between the equipment and receiver.

consult the dealer or an experienced radio/TV technician for help

s device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

eU Conformity Statement





2006/66/FC (battery directive): This product contains a battery that cannot be disposed of 2000/00/EC (Dattery directive): "Inis product contains a battery that cannot be disposed as unsorted municipal waste in the European Union. See the product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point. For more information see:

unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: www.recyclethis.info s device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the

following two conditions:
(1) this device may not cause interference, and
(2) this device must accept any interference, including interference that may cause undesired operation of the Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radioexempts de

ence. L'exploitation est autorisée aux deux conditions suivantes [1] l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

(2) I 'utilisateur de l'appareil doit accepter tout brouillage radioelectrique sub, meme si le brouillage est susceptible d'en compromettre le fonctionnement.
COMPLIANCE NOTICE: The thermal series products might be subject to export controls in various countries or regions, including without limitation, the United States, European Union, United Kingdom and/or other member countries of the Wassenaar Arrangement. Please consult your professional legal or compliance expert or local government authorities for any necessary export license requirements if you intend to transfer, export, re-export the thermal series products between different countries.

Safety Instruction
These instructions are intended to ensure that user can use the product correctly to avoid danger or property

ioss. The precaution measure is divided into Warnings and Cautions: Warnings: Neglecting any of the warnings may cause serious injury or death. Cautions: Neglecting any of the cautions may cause injury or equipment dan

Warnings

In the use of the product, you must be in strict compliance with the electrical safety regulations of the nation and region.

Do not connect several devices to one power adapter as adapter overload may cause over-heat or fire hazard.

Do not connect several devices to one power adapter as adapter overload may cause over-heat or fire hazard.

Please make sure that the power has been disconnected before you wire, install or dismantle the device. Whe
 the product is installed on wall or ceiling, the device shall be firmly fixed.
 If smoke, odors or noise rise from the device, turn off the power at once and unplug the power cable, and

hen please contact the service center

then please contact the service center.

If the product does not work properly, please contact your dealer or the nearest service center. Never attempt to disassemble the device yourself. (We shall not assume any responsibility for problems caused by unauthorized repair or maintenance.)

The socket-outlet shall be installed near the equipment and shall be easily accessible. An all—pole mains switch shall be incorporated in the electrical installation of the building.

The equipment is not suitable for use in locations where children are likely to be present.

CAUTION: Risk or explosion if the battery is replaced by an incorrect type.

3. Improper replacement of the battery with an incorrect type may defeat a safeguard (for example, in the case of some lithium battery types).

4. Do not dispose of the battery into fire or a hot oven, or mechanically crush or cut the battery, which may

result in an explosion.

5. Do not leave the battery in an extremely high temperature surrounding environment, which may result in an explosion or the leakage of flammable liquid or gas.

6. Do not subject the battery to extremely low air pressure, which may result in an explosion or the leakage of flammable liquid or gas.

7. Dispose of used batteries according to the instructions.

identifies the positive terminal(s) of equipment which is used with, or generates direct current.

the negative terminal(s) of equipment which is used with, or generates direct current.

AUTION: This bracket is intended for use only with face recognition terminal. Use with other equipment may

result in instability causing injury.

CAUTION: This equipment is for use only with the corresponded bracket. Use with other (carts, stands, or carriers) may result in instability causing injury.

To prevent possible hearing damage, do not listen at high volume levels for long periods. A readily accessible disconnect device shall be incorporated external to the equipment.

Cautions

Provide a surge suppressor at the inlet opening of the equipment under special conditions such as the

mountain top, iron tower, and forest.

No naked flame sources, such as lighted candles, should be placed on the equipment.

The serial port of the equipment is used for debugging only.

Burned fingers when handling the back panel. Wait one-half hour after switching off before handling the parts.

Install the equipment according to the instructions in this manual.

To prevent injury, this equipment must be securely attached to the floor/wall in accordance with the installation instruction.

Inistallation instructions.
 This equipment is for use only with xx (manufacturer's name), xx (model number or series), bracket. Use with other (carts, stands, or carriers) may result in instability causing injury.
 Do not drop the device or subject it to physical shock, and do not expose it to high electromagnetism radiation. Avoid the equipment installation on vibrations surface or places subject to shock (ignorance can

cause equipment damage).
 Install the equipment according to the instructions in this manual. To prevent injury, this equipment must be securely attached to the floor/wall in accordance with the installation instructions.
 Do not place the device in extremely hot (refer to the specification of the device for the detailed operating

Do not place the device in extremely hot (refer to the specification of the device for the detailed operating temperature), cold, dusty or damp locations, and do not expose it to high electromagnetic radiation. The device cover for indoor use shall be kept from rain and moisture.
 Exposing the equipment to direct sun light, low ventilation or heat source such as heater or radiator is forbidden (ignorance can cause fire danger).
 Do not aim the device at the sun or extra bright places. A blooming or smear may occur otherwise (which is not a malfunction however), and affecting the endurance of sensor at the same time.
 Please use the provided glove when open up the device cover, avoid direct contact with the device cover, because the acidic sweat of the fingers may erode the surface coating of the device cover.
 Use only opwer supplies listed in the user manual or user instruction.
 Please use a soft and dry cloth when clean inside and outside surfaces of the device cover, do not use alkaline detergents.

detergents.

Please keep all wrappers after unpack them for future use. In case of any failure occurred, you need to return

Please keep all wrappers after unpack them for ruture use. In case of any failure occurred, you need to return
the device to the factory with the original wrapper. Transportation without the original wrapper may result in
damage on the device and lead to additional costs.
 The USB port of the equipment is used for connecting to a mouse, a keyboard, or a USB flash drive only.
 Improper use or replacement of the battery may result in hazard of explosion. Replace with the same or
equivalent type only. Dispose of used batteries according to the instructions provided by the battery
manufacturer.

Biometric recognition products are not completely applicable to anti-spoofing environments. If you require a higher security level, use multiple authentication modes. **~.** .—. .—. .—. .—. .—. .—. .—. .—.

Recorded the receiving afficients. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

1. This device may not cause harmful interference.

2. This device must accept any interference received, including interference that may cause undesired

